### 297-8281-550

## DMS-100 Family Remote Switching Center

Remote Switching Center-SONET Model B Maintenance Manual

XPM11 and up Standard 10.05 November 2000



## DMS-100 Family Remote Switching Center

Remote Switching Center-SONET Model B Maintenance Manual

Publication number: 297-8281-550 Product release: XPM11 and up Document release: Standard 10.05 Date: November 2000

Copyright © 1998-2000 Nortel Networks, All Rights Reserved

Printed in the United States of America

**NORTEL NETWORKS CONFIDENTIAL:** The information contained herein is the property of Nortel Networks and is strictly confidential. Except as expressly authorized in writing by Nortel Networks, the holder shall keep all information contained herein confidential, shall disclose the information only to its employees with a need to know, and shall protect the information, in whole or in part, from disclosure and dissemination to third parties with the same degree of care it uses to protect its own confidential information, but with no less than reasonable care. Except as expressly authorized in writing by Nortel Networks, the holder is granted no rights to use the information contained herein.

Information is subject to change without notice. Nortel Networks reserves the right to make changes in design or components as progress in engineering and manufacturing may warrant. Changes or modification to the DMS-100 without the express consent of Nortel Networks may void its warranty and void the users authority to operate the equipment.

Nortel Networks, the Nortel Networks logo, the Globemark, How the World Shares Ideas, Unified Networks, DMS, DMS-100, Helmsman, MAP, Meridian, Nortel, Northern Telecom, NT, SuperNode, and TOPS are trademarks of Nortel Networks.

## Contents

# Remote Switching Center-SONET Model B Maintenance Manual About this document About this document vii How to check the version and issue of this document vii References in this document vii What precautionary messages mean viii How commands, parameters, and responses are represented ix Input prompt (>) ix Commands and fixed parameters ix Variables ix Responses ix

#### 1 Maintenance overview

Functional description 1-2 Remote Switching Center-SONET 1-2 In-service firmware downloading 1-2 Primary components of RCC2 1-5 Modular supervisory panel 1-5 Remote cluster controller 2 1-23 Dual remote cluster controller 2 1-50 1-Meg Modem Service 1-55 RSC ESA firewall 1-61 Emergency stand-alone impacts 1-72 Remote cluster controller 2 with integrated services digital network 1-73 Fault conditions 1-76 Automatic maintenance 1-82 Escalation to manual maintenance 1-132

#### 2 RSC-S hardware

Hardware components 2-1 The RSC-S packaging 2-2 Model B 2-2 Single-cabinet configuration 2-3 Multicabinet configuration 2-14 Additional components 2-20 Remote cluster controller-2 with ISDN 2-20 Enhanced line concentrating module 2-21 Customer premises equipment 2-22 1-1

iii

2-1

Planned products 2-22 3 **RSC-S** signaling 3-1 Signaling for RSC-S 3-1 Signaling and communications protocols 3-1 C-side links 3-2 P-side links 3-6 Message links 3-7 Message channels 3-8 DMS-X and HDLC protocol applications 3-9 ISDN basic rate interface signaling 3-13 Meridian business set signaling 3-14 Global and Universal tone receiver (GTR/UTR) features 3-15 A- and B-bit signaling 3-17 1-Meg Modem Service supported protocols 3-18 DBIC 3-18 XLC and loop 3-19 1-Meg Modem 3-20 4 **RSC-S** recovery procedures 4-1 PM RCC2 critical 4-2 5 5-1 **RSC-S** alarm clearing procedures Ext MSP CLCE cabinet major 5-2 Ext MSP CLMI cabinet major 5-20 Ext MSP CPDC cabinet major 5-35 Ext MSP CRME cabinet major 5-43 Ext MSP CRSC and CEXT cabinets major 5-53 PM LCME critical 5-70 PM LCME major 5-83 PM LCME(RG) major 5-93 PM LCME minor 5-102 PM LCME(RG) minor 5-112 PM RCC2 critical 5-120 PM RCC2 major 5-132 PM RCC2 minor 5-143 PM RMM major 5-154 PM RMM minor 5-163 6 **RSC-S** card replacement procedures 6-1 6-2 NT0X10 in an RSC-S (DS-1) Model B RMM NT2X06 in an RSC-S (DS-1) Model B RMM 6-8 NT2X09 in an RSC-S (DS-1) Model B RMM 6-17 NT2X10 in an RSC-S (DS-1) Model B RMM 6-26 NT2X11 in an RSC-S (DS-1) Model B RMM 6-33 NT2X57 in an RSC-S (DS-1) Model B RMM 6-42 NT2X59 in an RSC-S (DS-1) Model B RMM 6-49 NT2X90 in an RSC-S (DS-1) Model B RMM 6-56 NT3X09 in an RSC-S (DS-1) Model B RMM 6-63 NT6X17 in an RSC-S (DS-1) Model B LCME 6-73

7-1

8-1

	NT6X18 in an RSC-S (DS-1) Model B LCME 6-81
	NT6X19 in an RSC-S (DS-1) Model B LCME 6-89
	NT6X20 in an RSC-S (DS-1) Model B LCME 6-97
	NT6X20 in an RSC-S (DS-1) Model B LCME 6-105
	NT6X30 in an RSC-S (DS-1) Model B LCME 6-114
	NT6X50 in an RSC-S (DS-1) Model B LCME 6-128
	NT6X52 in an RSC-S (DS-1) Model B LCME 6-135
	NT6X52 in an RSC-S (DS-1) Model B LCM(E) 6-144
	NT6X54 in an RSC-S (DS-1) Model B LCM(E) 6-153
	NT6X69 in an RSC-S (DS-1) Model B RCC2 6-160
	NT6X71 in an RSC-S (DS-1) Model B LCME 6-168
	NT6X74 in an RSC-S (DS-1) Model B RMM 6-176
	NT6X74 III all RSC-S (DS-1) Model B LCME 6-185
	NT6X78 in an RSC-S (DS-1) Model B RCC2 6-193
	NT6X92 in an RSC-S (DS-1) Model B RCC2 6-208
	NT6X99 in an RSC-S (DS-1) Model B LCME 6-216
	NT7X05 in an RSC-S (DS-1) Model B RCC2 6-224
	NTAX74 in an RSC-S (DS-1) Model B RCC2 6-233
	NTBX01 in an RSC-S (DS-1) Model B RCC2 6-244
	NTBX02 in an RSC-S (DS-1) Model B RCC2 6-253
	NTBX26 in an RSC-S (DS-1) Model B LCME 6-266
	NTBX27 in an RSC-S (DS-1) Model B LCME 6-274
	NTBX34 in an RSC-S (DS-1) Model B LCME 6-282
	NTBX35 in an RSC-S (DS-1) Model B LCME 6-292
	NTBX36 in an RSC-S (DS-1) Model B LCME 6-302
	NTBX72 in an RSC-S (DS-1) Model B LCME 6-312
	NTEX17 in an RSC-S (DS-1) Model B LCM 6-321
	NTEX54 in an RSC-S (DS-1) Model B LCM 6-331
	NTMX72 in an RSC-S (DS-1) Model B RCC2 6-348
	NTMX73 in an RSC-S (DS-1) Model B RCC2 6-357
	NTMX74 in an RSC-S (DS-1) Model B RCC2 6-367
	NTMX75 in an RSC-S (DS-1) Model B RCC2 6-376
	NTMX76 in an RSC-S (DS-1) Model B RCC2 6-384
	NTMX77 in an RSC-S (DS-1) Model B RCC2 6-391
	NTMX79 in an RSC-S (DS-1) Model B EXT 6-404
	NTMX81 in an RSC-S (DS-1) Model B RCC2 6-415
	NTMX87 in an RSC-S (DS-1) Model B RCC2 6-429
	NTRX41 in an RSC-S (DS-1) Model B MSP 6-452
	NTRX42 in an RSC-S (DS-1) Model B MSP 6-457
	NTRX43 in an RSC-S (DS-1) Model B MSP 6-477
	NTRX44 in an RSC-S (DS-1) Model B MSP 6-485
	NTRX54 in an RSC-S (DS-1) Model B MSP 6-495
7	Locating and clearing RSC problems
8	Trouble isolation and correction
	Description of troubleshooting 8-1
	Locating and clearing faults 8-1
	Trouble condition indicators 8-1

Trouble conditions 8-4
Fault isolation tests 8-12
Remote cluster controller 2 8-12
Remote cluster controller 2 with ISDN 8-15
Diagnostic tests 8-15
NTMX76 pack diagnostics 8-15
Enhanced line testing 1 8-17
Digital test access 8-21
Layer 1 performance monitoring 8-28
Extended peripheral modules diagnostics history 8-38
Remote cluster controller 2 8-45
Lines 8-45
Dual remote cluster controller 2 8-45
Remote cluster controller 2 with ISDN 8-45
ISDN lines 8-45
Ring pretrip on LCM lines 8-45
Product-specific test tools 8-48
Real-time performance monitoring for NTMX73AA and
NTMX76AA 8-48
Troubleshooting chart

9	Troubleshooting chart	9-1
10	Advanced troubleshooting procedures	10-1
	Advanced trouble locating procedures 10-1 Bigfoot utility 10-1	
	Diagnostics results graph output 10-1	
	Powering up the RSC-S 10-2	
	Power-up procedure 10-2	
	Powering down the RSC-S 10-3	
	Power-down procedure 10-3	
11	RSC-S routine maintenance procedures	11-1
	Inspecting cooling unit filters 11-2	
	Testing wrist strap grounding cords 11-6	
	Fuse replacement in the LCME 11-10	
	Replacing cooling unit filters 11-15	
	Testing power converter voltages 11-19	
	Returning a card for repair or replacement 11-24	
	Inspecting spare fuse holders 11-28	
	Checking torque on grounding bolts 11-30	
	Inspecting and changing bulbs 11-32	
	Cooling unit replacement 11-35	

vii

## About this document

#### How to check the version and issue of this document

The version and issue of the document are indicated by numbers, for example, 01.01.

The first two digits indicate the version. The version number increases each time the document is updated to support a new software release. For example, the first release of a document is 01.01. In the next software release cycle, the first release of the same document is 02.01.

The second two digits indicate the issue. The issue number increases each time the document is revised but rereleased in the same software release cycle. For example, the second release of a document in the same software release cycle is 01.02.

To determine which version of this document applies to the software in your office and how documentation for your product is organized, check the release information in *Product Documentation Directory*, 297-8991-001.

#### **References in this document**

The following documents are referred to in this document:

- 1-Meg Modem Service Network Implementation Guide, 297-8063-200
- Bellcore Technical Reference, ISDN D-Channel Exchange Access Signaling and Switching Requirements (Layer 2)
- North American DMS-100 Log Report Reference Manual
- Operational Measurements Reference Manual
- Product Documentation Directory, 297-8991-001
- PMDEBUG User Guide, TAM-1001-004
- Translations Guide
- XPM Log Report Reference Manual
- XPM Translations Reference Manual

#### What precautionary messages mean

The types of precautionary messages used in Nortel Networks documents include attention boxes and danger, warning, and caution messages.

An attention box identifies information that is necessary for the proper performance of a procedure or task or the correct interpretation of information or data. Danger, warning, and caution messages indicate possible risks.

Examples of the precautionary messages follow.

ATTENTION - Information needed to perform a task

#### ATTENTION

If the unused DS-3 ports are not deprovisioned before a DS-1/VT Mapper is installed, the DS-1 traffic will not be carried through the DS-1/VT Mapper, even though the DS-1/VT Mapper is properly provisioned.

DANGER - Possibility of personal injury



#### DANGER Risk of electrocution

Do not open the front panel of the inverter unless fuses F1, F2, and F3 have been removed. The inverter contains high-voltage lines. Until the fuses are removed, the high-voltage lines are active, and you risk being electrocuted.

WARNING - Possibility of equipment damage



#### WARNING

#### Damage to the backplane connector pins

Align the card before seating it, to avoid bending the backplane connector pins. Use light thumb pressure to align the card with the connectors. Next, use the levers on the card to seat the card into the connectors. CAUTION - Possibility of service interruption or degradation



#### CAUTION Possible loss of service

Before continuing, confirm that you are removing the card from the inactive unit of the peripheral module. Subscriber service will be lost if you remove a card from the active unit.

#### How commands, parameters, and responses are represented

Commands, parameters, and responses in this document conform to the following conventions.

#### Input prompt (>)

An input prompt (>) indicates that the information that follows is a command:

>BSY

#### **Commands and fixed parameters**

Commands and fixed parameters that are entered at a MAP terminal are shown in uppercase letters:

>BSY CTRL

#### Variables

Variables are shown in lowercase letters:

>BSY CTRL ctrl\_no

The letters or numbers that the variable represents must be entered. Each variable is explained in a list that follows the command string.

#### Responses

Responses correspond to the MAP display and are shown in a different type:

FP 3 Busy CTRL 0: Command request has been submitted.

FP 3 Busy CTRL 0: Command passed.

## **1** Maintenance overview

This chapter contains the following sections:

• functional description

The functional description provides a summary of the components that comprise the Remote Switching Center-SONET (RSC-S) configurations. This section provides a summary of the components of the modular supervisory panel (MSP) and remote cluster controller 2 (RCC2). This section also explains how software processes affect RCC2 components, and highlights voice and message flows.

• fault conditions

Fault conditions are problems that can occur in the following:

- components, like a card or power supply
- links that connect the components
- software that controls the voice and message flow
- automatic maintenance

The following components are designed with system actions that locate and correct faults when fault conditions occur:

- the RSC-S
- the Remote Switching Center (RSC)
- the Digital Multiplex System (DMS)
- the Data Packet Network (DPN)

If the faults that these components correct do not require manual intervention, the appropriate trouble indicators are explained.

• escalation to manual maintenance

With the RSC-S, automatic maintenance includes the output of the appropriate trouble indicators. Refer to the Automatic maintenance section for this information.

#### **Functional description**

This section describes components of the RSC-S, MSP, RCC2 along with feature descriptions.

#### **Remote Switching Center-SONET**

The RSC-S uses common peripheral module (CPM) architecture rather than XMS-based peripheral module (XPM) architecture. When the RSC-s uses a CPM instead of an XPM, the system implements the following differences:

- change in channel supervision message (CSM) connections in the CPM
- direct channel connection to the D-channel handler (DCH) (NTBX02), DS30A interface (NTMX74), and dual DS-1 interface (NTMX81) cards
- improvement of the matrix
- creation of the pulse code modulation (PCM) card to concentrate all signaling functions in one card
- how digital signal 1 (DS-1) signaling bits (A, B, C, D) are hendled
- addition of downloadable firmware to the Unified Processor (UP) (NTMX77), Cellular Access Processor (CAP) card (NTAX74) and PCM Signaling Processor (NTMX73) cards. The NTMX77 has two FLASH EEPROMs, or banks, that are two 256-kbyte programmable chips. These chips provide the ability to load the firmware independent of the RAM load on an RCC2 or manually busied (ManB) RCC2 unit. To load the firmware, type

```
>LOADFW PM
Or
>LOADFW UNIT unit_no
Or
```

>LOADFW INACTIVE

#### In-service firmware downloading

In-service firmware downloading permits XPM firmware loading in an XPM unit while the unit is in service (InSv). This feature reduces the amount of time one unit of the XPM is out-of-service (OOS). In-service firmware downloading supports NTMX77 and NTAX74 processors.

*Note:* In-service firmware downloading refers to the loading of the firmware while the unit is InSv. The upgrade of the firmware occurs with the XPM unit out of service (OOS).

This feature introduces the LOADFW command. The LOADFW command distinguishes the firmware load application from the firmware upgrade application. The command syntax for the LOADFW command is:

```
LOADFW: Load Firmware onto a PM or unit.

All parameter will execute LOADFW on

all PMs in the post set of the same

PM type displayed on the MAP.

LOADFW UPGRADE must be used to

activate the new firmware.

Parms: <DEVICE> {UNIT <UNIT_NO> {0 TO 1},

PM,

INACTIVE,

ACTIVE}

[<FILENAME> STRING]

[UPGRADE]

[NOWAIT]

[ALL]
```

To download firmware to the XPM, execute one of the following commands. The following are examples of the LOADFW command.

>LOADFW PM

or

>LOADFW UNIT unit\_no

or

>LOADFW INACTIVE

*Note 1:* If the firmware\_file is not specified with the LOADFW command, the command applies the firmware\_file datafilled in the appropriate inventory table.

*Note 2:* By using the LOADFW command without the UPGRADE option, the firmware downloads to the DMS system.

XPM Firmware Loader Robustness CM Component disables the firmware option of the LOADPM command. A message is output to the user if the firmware option of the LOADPM command is used. This message states this option is not supported and to use the LOADFW command.

#### Loadfile verification

Integrity checks are performed on the firmware for loadfile accuracy. A loadfile record length check ensures the file is a firmware file before submission to the XPM. If the record length is not 54, a message is output to the user and the LOADFW command fails.

Another accuracy check is a 32-bit cyclic redundancy check (CRC) along with a 16-bit checksum. The CM sends a validation message to the XPM to verify the accuracy of the firmware load. The XPM extracts the CRC and checksum that is in the firmware load. The XPM computes the CRC value and the checksum. The XPM compares the computed and extracted values to see if the values are the same. The XPM sends the result of the comparison to the CM.

To verify the firmware load enter the following command at the MAP display terminal:

#### >QUERYPM CNTRS

#### Firmware upgrade

After loadfile verification, the XPM can be upgraded to the new firmware. To upgrade the firmware use one of the following command string sets:

>BSY PM
>LOADFW PM UPGRADE
>RTS PM
or
>BSY UNIT unit\_no
>LOADFW UNIT unit\_no UPGRADE
>RTS UNIT unit\_no
or
>BSY INACTIVE
>LOADFW INACTIVE UPGRADE
>RTS INACTIVE

*Note:* By using the LOADFW command with the UPGRADE option, the firmware is upgraded to the new firmware load.

When this procedure is performed on a by-unit basis, perform a switch of activity (SwAct) followed by the RTS command. Execute the LOADFW command with the UPGRADE option on the now inactive unit.

The next table lists parameters used with the LOADFW command.

Parameter	Value	Definition
UNIT	n/a	Peripheral module unit
PM	n/a	Peripheral module
INACTIVE	n/a	State of peripheral module
ACTIVE	n/a	State of peripheral module
unit_no	0 or 1	PM unit number
filename	n/a	Name of firmware file. If the firmware file is not specified, the firmware load found in the appropriate inventory table is used.
UPGRADE	n/a	Upgrades the PM to the new firmware load. UPGRADE is an optional parameter.
ALL	n/a	Permits the use of the LOADFW command on a posted set of PMs. ALL is an optional parameter.
NOWAIT	n/a	Returns the prompt before the command is finished, on-screen status is not visible. NOWAIT is an optional parameter.

Table 1-1 LOADFW parameters

*Note:* In this table N/A is an abbreviation for not applicable.

#### Primary components of RCC2

In this architecture, the primary components of the RSC-S that can be assembled are the RCC2 or dual RCC2 (DRCC2). Installation can occur for an RCC2 with or without the integrated services digital network (ISDN) or emergency stand-alone (ESA). The following sections describe these components according to functional areas.

Each functional area provides the following features:

- highlight of the specified the functions
- description of the other RSC-S components

#### Modular supervisory panel

The following sections describe MSP components.

#### Talk battery module (NTRX44AA)

The NTRX44AA talk battery module provides filtered power feed of a maximum 20A for cabinets in a central office (CO) environment. This card

also provides inrush current protection (soft-start) to protect against power distribution center (PDC) breaker trips. This module is provisioned with the MSP and accepts -48V or -60V battery input.

The NTRX44AA provides the following functions:


- termination point for PDC feeds
- filtered battery feed through connector interfaces
- soft-start a current-limiting startup circuit provides to protect against PDC breaker trip
- two fail alarms

The NTRX44AA has the following functional blocks:

- inductor
- capacitors
- startup circuit
- alarm circuit

The relationship between the functional blocks appears in the following figure.





The NTRX44AA uses a 20A QHP77C bracket-mounted power inductor and six 80-V capacitors that provide 6800µF of capacitance.

**Current-limiting startup circuit** This circuit limits the inrush current on startup. This action eliminates the risk of a tripped PDC feed breaker. A thermistor initially charges the capacitors. When the capacitors are charged, a relay is powered on and the contacts connect the capacitors to the output. This soft-start occurs approximately 5 s from the time of application of input power.

**Alarm circuit** This block reports filter failure in an NTRX44AA to the alarm module (NTRX41AA) through connector P3. The alarm module generates a FRAMEFAIL alarm. this system reports a total power loss to the maintenance trunk monitor (MTM) through connector P4.

**Pin-outs** Pin-outs for NTRX44AA appear in the following four tables.

Pin-outs for the PCD power input connector P1 appear in the following table.

 Table 1-2
 PCD power input connector P1

Pin	Signal
A	-48V or -60V
В	-48V or -60V
С	BAT RTN
D	BAT RTN

Pin-outs for the talk battery output connector P2 appear in the following table.

 Table 1-3
 Talk battery output connector P2

Pin	Signal
A	TALKBAT
В	TALKBAT
С	BAT RTN
D	BAT RTN

Pin-outs for the FAIL alarm connector P3 appear in the following table.

#### Table 1-4 FAIL alarm connector P3

Pin	Signal
1	TALKALM
2	TALKALM
<i>Note:</i> Only pin 1 must connect to alarm module NTRX41AA.	

Pin-outs for the FAIL alarm connector P4 appear in the following table.

Table 1-5 FAIL alarm connector P4

Pin	Signal
1	LOSS1
2	LOSS2

**Power requirements** The nominal input voltage is -48V, but a range of -42V to -75V is acceptable. The maximum steady-state input current is 20A. The maximum inrush current is 50A.

**Output** Output specifications for NTRX44AA appear in the following table.

Table 1-6 NTRX44AA output specifications

Parameter	Value	
Voltage	-48V or -60V	
High voltage shutdown	-75V	
Low voltage shutdown	-42V	
Maximum current	20A	
Attenuation	40dB @1kHz	
Output impedance	50Ω @300 to 3500Hz	

#### Alarm module (NTRX41AA)

The NTRX41AA alarm card provides monitoring and alarm reporting for cabinets in a CO environment. This card requires an input battery voltage of -48V or -60V. This module has the MSP. The NTRX41AA monitors and detects the following types of faults:

- converter faults
- thermal breaker failures
- fan failure on one or two cooling units
- failures in the talk battery modules
- inverter failure in the cabinet

If any of these faults occur, NTRX41AA raises alarms and sends signals to the office alarm unit. The NTRX41AA also provides maintenance facilities in the form of telephone, data, and alarm battery supply (ABS) jacks.

The NTRX41AA has the following functional blocks:

- alarm circuit
- maintenance block

**Alarm circuit** The alarm circuit consists of transistor logic. The following four alarm inputs activate the transistor logic:


- battery-input voltage, which triggers a FRAMEFAIL signal for an inverter alarm, talk battery module alarm or fuse module alarm
- battery-return voltage, which triggers a FRAMEFAIL signal for a converter fail alarm and line concentrating equipment (LCE) alarm
- 90 Vrms, which triggers a FRAMEFAIL signal for a ringing generator (RG) on an LCE cabinet
- battery-input voltage, which generates a FANFAIL signal and triggers an alarm for the cooling units

The alarm circuit provides two light-emitting diodes (LED) as visual indicators of the FRAMEFAIL and FANFAIL signals. In addition to these LEDs, the alarm circuit can use a connector interface to drive two additional external LEDs.

**Maintenance block** The NTRX41AA provides several maintenance features. Examples of these features are jacks for telephone, data, and ABS. These features provide for interoffice communication and data transmission.

The relationship between the functional blocks appears in the following figure.





**Pin-outs** Pin-outs for the NTRX41AA appear in the following table.

Table 1-7 Connector J1 NTRX41AA (Sheet 1 of 2)

Pin	D	С	В	Α
1	RINGALM2			RINGALM1
2				
3				
4	BAT2	K2	BAT1	K1
5	BAT4	K4	BAT3	К3
6	BAT6	K6	BAT5	K5

Pin	D	С	В	Α
7	BAT8	K8	BAT7	K7
8	BAT10	K10	BAT9	K9
9	BAT12	K12	BAT11	K11
10	BAT14	K14	BAT13	K13
11	BAT16	K16	BAT15	K15
12	BAT18	K18	BAT17	K17
13	BAT20	K20	BAT19	K19
14		FRAMEFAIL		FRMFLTST
15	INVALM	FUSEALM	FAN48	FAN48
16	D1B	D1A	ТТВ	TTA
17	-48V2	-48V2	-48V1	-48V1
18	-48V4	-48V4	-48V3	-48V3
19	FAIL4	FAIL3	FAIL2	FAIL1
20	FAIL8	FAIL7	FAIL6	FAIL5
21	FAIL12	FAIL11	FAIL10	FAIL9
22	FAIL16	FAIL15	FAIL14	FAIL13
23	FAIL20	FAIL19	FAIL18	FAIL17
24		FANALM2		FANALM1
25				
26	FANLMPTST	ACO	AISALM2	AISALM1
27	D2B	D2A	TRB	TRA
28	BR	BR	BR	BR
29		TEMPSW2		TEMPSW1
30	+15FG	+15FG	+5FG	+5FG

Table 1-7 Connector J1 NTRX41AA (Sheet 2 of 2)

**Power requirements** The nominal input voltage is -48V or -60V. A range from -42V to -75V is acceptable. The maximum input current is 0.75A.

#### Fuse module (NTRX43AA)

The NTRX43AA fuse module provides a maximum of eight current-limited feed outputs and one alarm output for cabinets in a CO. This card is provisioned with the MSP and requires an input battery voltage of -48V or -60V.

*Note:* The QFF fuses do not have this module, but are provisioned at the cabinet level.

The NTRX43AA provides the following functions:

- acts as termination point for PDC feeds
- supplies eight current-limited outputs for miscellaneous circuits
- reports fuse and breaker failures to the NTRX41AA alarm module

Connector P1 provides the power feed for fuses F01 to F04. Connector P2 provides the power feed for fuses F05 to F08. These fuses are on the faceplate of the NTRX43AA.

Connector J1 provides the fused outputs with currents that range from 0.18A to 5.0A.

Connector P3 provides alarm outputs that report fuse failures to the NTRX41AA alarm module.

**Pin-outs** The following section describes pin-outs for the NTRX43AA.

Pin-outs for power input connectors P1 and P2 appear in the following table.

 Table 1-8 Power input connectors P1 and P2

Connector/pin	Signal
P1 1—9	-48V or -60V
P1 10—18	BAT RTN
P2 1—9	-48V or -60V
P2 10—18	BAT RTN

Pin-outs for output connector J1 appear in the following table.

Pin	Signal	Pin	Signal
1	-48VOUT 1	10	-48VOUT 5
2	-48VOUT 2	11	BAT RTN5
3	-48VOUT 4	12	BAT RTN6
4	-48VOUT 6	13	BAT RTN3
5	-48VOUT 7	14	BAT RTN4
6	-48VOUT 8	15	NC
7	BAT RTN1	16	NC
8	BAT RTN2	17	BAT RTN7
9	-48VOUT 3	18	BAT RTN8

Table 1-9 NTRX43AA output connector J1

Pin-outs for the FAIL alarm connector P3 appear in the following table.

 Table 1-10
 Fail alarm connector P3

Pin	Signal
1	FUSEALM
2	FUSEALM

**Power requirements** The nominal input voltage is -48V or -60V. A range from -42V to -75V is acceptable. The maximum input current is 30A.

**Output** Output specifications for the NTRX43AA appear in the following table.

Parameter	Value
Maximum voltage	-72V
Maximum current	5.0 A

Parameter	Value
Minimum voltage	-42V
Minimum current	0.18 A

#### Table 1-11 Output specifications NTRX43AA (Sheet 2 of 2)

#### Breaker module (NTRX42AA)

The NTRX42AA is a breaker module provisioned with the MSP. This module contains two circuit breakers of -48V or -60V that provide two 10-A power feeds.

The NTRX42AA receives two input feeds from the PDC and allows the two front-mounted breakers to limit the input current. The breakers are also equipped with automatic recovery from low battery and the standard DMS switch converter interface. These features allow the breakers to monitor converters.

The primary functions of NTRX42AA are as follows:


- monitor and detect converter failures
- trip breakers when overcurrent conditions occur
- trip breakers on converter failure
- provide termination points for PDC feeds
- provide battery feed samples for the alarm module
- respond to automatic recovery from low battery (ARLB) conditions

The NTRX42AA has the following functional blocks:

- ARLB
- trip circuitry and enable
- breakers

The relationship between the functional blocks appear in the following figure.

Figure 1-3 NTRX42AA functional blocks



**Automatic recovery from low battery** The breaker module sends the NT6L62AA ARLB hybrid a sample of each of the two input battery feeds. The ARLB provides two outputs to NTRX42AA. One output controls the two relays on each breaker module. When the tested voltage falls below  $-41.5V \pm 0.5V$ , the relays depower to prevent breaker trip. The relays also remove the DRIVE or ENABLE signal that causes the converters to shut down. The battery voltage must rise above  $-44.5V \pm 0.5V$  before the restart of the RESET relay.

**Trip and enable circuitry** A transistor circuit trips the associated circuit breaker in response to alarm relay release in the associated power converter or RG. This circuitry also provides the DRIVE or ENABLE signal for converters that require the signal.

**Breakers** Two 10-A magnetic breakers are stacked one on top of the other in this breaker module. The breakers operate over the complete -48V to -60V range.

Pin	Signal	Pin	Signal	
1	-48VSW1	13	CONVFAIL2	
2	not used	14	ILOKIN	
3	ON/OFF1	15	DRIVE2	
4	OEM-ALM1	16	not used	
5	OEM-ALM2	17	BAT RTN1	
6	ON/OFF2	18	BR1	
7	not used	19	RESET1	
8	-48VSW2	20	CONVFAIL1	
9	not used	21	CONVFAIL2	
10	DRIVE1	22	RESET2	
11	ILOKOUT	23	BR2	
12	CONVFAIL1	24	BAT RTN2	

**Pin-outs** Pin-outs for the NTRX42AA appear in the following table.

• •••	Signal		Signal
1	-48VSW1	13	CONVFAIL2
2	not used	14	ILOKIN
3	ON/OFF1	15	DRIVE2
4	OEM-ALM1	16	not used
5	OEM-ALM2	17	BAT RTN1
6	ON/OFF2	18	BR1
7	not used	19	RESET1
8	-48VSW2	20	CONVFAIL1
9	not used	21	CONVFAIL2
10	DRIVE1	22	RESET2
11		23	BR2

Table 1-12 Connector J1 NTRX42AA

The nominal input voltage is -48V or -60V. A Power requirements range from -42V to -72V is acceptable. The maximum input current is 20A.

Output Output specifications for the NTRX42AA appear in the following table.

Table 1-13 Output specifications NTRX42AA

Parameter	Value	
Voltage	-48V or -60V	
High voltage shutdown	-72V	
Low voltage shutdown	-42V	
Maximum current	2 x 10A	
Minimum current	0A	

#### Breaker module (NTRX42CA)

The NTRX42CA is a breaker module provisioned with an MSP. The NTRX42CA contains two circuit breakers of -48V or -60V that provide two 20A power feeds.

The NTRX42CA receives two input feeds from the PDC and allows the two front-mounted breakers to limit input current. The breakers are also equipped with automatic recovery from low battery and standard DMS switch converter interface. These features allow the breakers to monitor converters.

The primary functions of the NTRX42CA are as follows:


- monitor and detect converter failures
- trip breakers when overcurrent conditions occur
- trip breakers when the converter fails
- provide termination points for PDC feeds
- provide battery feed samples for the alarm module
- respond to ARLB conditions

The NTRX42CA has the following functional blocks:

- ARLB
- trip circuitry and enable
- breakers

The relationship between the functional blocks appears in the following figure.





**Automatic recovery from low battery** The breaker module sends the T6L62AA ARLB hybrid a sample of each of the two input battery feeds. The ARLB provides two outputs to NTRX42CA. One output controls the two relays on each breaker module. When the tested voltage falls below  $-41.5V \pm 0.5V$ , the relays depower to prevent breaker trip. The relays also remove the DRIVE or ENABLE signal and cause the converters to shut down. The battery voltage must rise above  $-44.5V \pm 0.5V$  before the restart of the RESET relay occurs.

**Trip and enable circuits** A transistor circuit trips the associated circuit breaker when an alarm relay release in the associated power converter or RG occurs. These circuits also provide the DRIVE or ENABLE signal for the converters that require the signal.

**Breakers** Two 20A magnetic breakers are stacked one on top of the other in this breaker module. The breakers operate over the complete -48V to -60V range.

**Pin-outs** Pin-outs for NTRX42CA appear in the following table.

Pin	Signal	Pin	Signal
1	-48VSW1	13	CONVFAIL2
2	Not used	14	ILOKIN
3	ON/OFF1	15	DRIVE2
4	OEM-ALM1	16	Not used
5	OEM-ALM2	17	BAT RTN1
6	ON/OFF2	18	BR1
7	Not used	19	RESET1
8	-48VSW2	20	CONVFAIL1
9	Not used	21	CONVFAIL2
10	DRIVE1	22	RESET2
11	ILOKOUT	23	BR2
12	CONVFAIL1	24	BAT RTN2

Table 1-14 Connector J1 NTRX42CA

**Power requirements** The nominal input voltage is -48V or -60V. A range from -42V to -72V is acceptable. The maximum input current is 40A.

**Output** Output specifications for the NTRX42CA appear in the following table.

Table 1-15 Output specifications NTRX42CA

Parameter	Value	
Voltage	-48V or -60V	
High voltage shutdown	-72V	
Low voltage shutdown	-42V	
Maximum current	2 x 20A	
Minimum current	0A	

#### Fan power control module (NTRX54BA)


The fan power control receives A-feed and B-feed inputs from the cabinetized power distribution center (CPDC). The fan control provides a combined C-feed for the 48 Vdc fans and an alarm output. The card can operate at -48 Vdc and -60 Vdc input in a CO environment.

The card includes two faceplate-mounted fuse holders that have 5-A fuses and an LED. A captive screw, attached to the faceplate, provides positive retention and conductive coupling to the shelf.

**Location** The fan power control circuit card occupies the last two card positions in an MSP. The fan power control circuit card is fully connectorized. The card uses two 6.35 mm (0.25 in) quick-connect plugs (A0381899) to provide A- and B-feed input. The card also uses an 18-pin Positronics power-lok connector (A0380977) to provide power/alarm output.

The fan power control circuit card provides a nominal regulated 48V for fan operation. Features include a fuse failure alarm and a redundant feed.

The functionality of the fan power control circuit card appears in the following figure.



#### Figure 1-5 NTRX54BA functional blocks

**Feed combining** To provide redundancy, combine feeds A and B. If one of the feeds is not present, the other feed supplies power.

**Fuse fail alarm** The system generates an alarm indication for a possible fuse failure.

**Signaling** Three connectors are on the rear of the NTRX54BA. These connectors are the P1 input, P2 input, and the J1 output.

The following table describes pin-outs of the P1 input (battery A) connector.

Table 1-16 Power input (P1) connector

Connector number	Signal	Function	Description
P1 / A, B	L - (A)	Input	-48 Vdc
P1 / C, D	L + (A)	Input	BAT RTN

The following table describes pin-outs of the P2 input (battery B) connector.

Table 1-17 Power input (P2) connector

Connector number	Signal	Function	Description
P2 / A, B	L - (B)	Input	-48 Vdc
P2 / C, D	L + (B)	Input	BAT RTN

The following table describes pin-outs of the J1 output (18-pin) connector.

 Table 1-18
 18 pin output (J1) connector

Pin number	Signal	Function	Description
1—9	L - (FAN1)	Output	-48 Vdc
18	FAIL	Output	O/C -> BR through 3.0k and LED on output failure causes Frame Fail to alarm module
10—17	L + (FAN)	Output	BAT RTN from fans

**Power requirements** The following table lists input power requirements for the fan power control circuit card.

Table 1-19	Power input	requirement	limits (A	and B)

	Limits		
Signal	Norm	Alarm minimum	Alarm maximum
Voltage	-48 Vdc	-39 Vdc	-56 Vdc
Current	1.5 A		2.5 A

The following table lists output power requirements for the fan power control circuit card.

	Limits		
Signal	Norm	Alarm minimum	Alarm maximum
Voltage	-48 Vdc		-56 Vdc
Current	1.5 A	0.0 A	3.0 A

**Environmental conditions** The fan power control circuit card performs under the limited environmental limits described in the following table.

Table 1-21 Ambient conditions

Condition	Operating range	Short-term range
Temperature	0°C to 50°C	N/A
	(32°F to 122°F)	N/A
Humidity	5.0% to 95.0%	N/A

**Equipment dimensions** The fan power control circuit card dimensions are 101.6 mm (4 in.) in height, 60.9 mm (2.4 in.) in width, and 254 mm (10 in.) in depth. The approximate weight is 0.68 kg (1.5 lb).

#### **Remote cluster controller 2**

The RCC2 is the primary operations device for the RSC-S. Functional areas of the RCC2 include the following:

- cards
- speech and message paths in the RCC2
- routine exercise (REX) test
- switch of activity (SWACT)
- update of static data (non-ESA)
- return to service of the RCC2 to service

*Note:* Figure Functional block diagram of RCC2 associates with the functional description of the RCC2 that follows.

#### Cards

The RCC2 uses the following cards:

- host communication
- processor
- speech bus
- peripheral communication

Refer to *RSC-S hardware* in this document for a description of RCC2 circuit card layouts.

#### Host communication cards

Host communication cards translate up to 20 C-side DS-1 ports to the parallel speech bus.

In NA010 or lower, up to 16 C-side ports are available. This configuration requires the following hardware:

- NTMX87AA/AB Quad Frame Carrier card in slots 9 and 19
- NTMX81AA Dual DS-1 Packlets (1-4 packlets for each Quad Frame Carrier) *or*
- NTMX83AA Filler Packlet (0-3)
- NTMX75AA Enhanced Matrix card

*Note:* NA011 and higher supports these packs when an office needs only up to 16 C-side DS-1 links.

In NA011 or higher, up to 20 C-side DS-1 ports are available. This configuration requires the following hardware:

- NTMX87BA Penta DS-1 Packlet Carrier cards in slots 9 and 19
- NTMX81BA Compact Dual DS-1 Packlets (1-5 packlets for each Penta DS-1 Packlet Carrier) *or*
- NTMX83BA Compact Filler Packlet (0-4 for each Quad Frame Carrier)
- NTMX75DA Enhanced Matrix card

*Note:* This hardware is backward compatible from NA008 to NA010 for use in the 16 C-side DS-1 link configuration.

A Penta DS-1 Packlet Carrier holds a maximum of five packlets. These packlets can be Compact Dual DS-1 packlets (NTMX81BA) or filler plate packlets (NTMX83BA). Compact Dual DS-1 packlets support all the features and maintenance functions the NTX6X50AB provides. The compact dual DS-1 packlets provide and support all performance counters that the NTX6X50AB supports.

The Quad Frame Carrier holds up to four packlets. These packlets are either Dual DS-1 packlets (NTMX81AA) or filler packlets (NTMX83AA). The Dual DS-1 packlets provide all the features and performance counters of the NT6X50AB.

The enhanced matrix NTMX75 card combines the functions of the formatter card (NT6X41/NT6X72) and the time switch (NT6X44) used on the remote cluster controller (RCC). The RCC uses the formatter card and time switch for RSC applications. This card is nonblocking and performs all switching functions that the RCC2 shelf and the extension shelf require. The card is a single stage time switch with 2528 channels (input and output). Any channel can be switched to any free channel. Input and output are divided into two groups: central side (C-side), which has 640 channels, of which 128 channels are for service cards, and peripheral side (P-side), which has 1888 channels.



#### WARNING

#### **Possible link failure**

An NTMX87BA with 1-5 NTMX81BA cards in slots 9 or 19 of the RCC2 requires the NTMX75DA. You cannot mix NTMX75AAs with NTMX87BAs or NTMX75DAs with NTMX87AA/ABs except during the upgrade to 20 C-side DS-1 links.

## **Processor cards**

The RCC2 can be provisioned with one of the following cards:

- The Unified Processor (UP) card (NTMX77 with 68020 CPU).
- The optional Cellular Access Processor card (NTAX74 with 16 Mb memory).

**NTMX77 Unified Processor** The UP card, with 68020 central processing unit (CPU), controls the RCC2 activities. Memory associated with the UP is consolidated on the card and provides 8 Mb of memory with a possible expansion to 16 Mb. The UP provides electrically erasable programmable read-only memory (EEPROM), and has two FLASH EEPROMs. Both of the FLASH EEPROMs are 256 Kbyte programmable chips.

The NTMX77 UP increases real time and replaces several cards in each unit of the RCC2. This condition causes a reduction of power use.

*Note:* The NTMX77 must support NT7X05 functionality.

**NTAX74 Cellular Access Processor (CAP)** The optional CAP card is in slots 3 and 25 of the RCC2 shelf. The CAP consists of the NTAX74 motherboard and an NTNX4814 microcontroller subsystem (MCS) daughterboard. The MCS daughterboard has a 68040 processor and 16 Mbytes of memory to support downloadable firmware capability. The CAP has direct read/write access to the matrix card, SIGP, EISP, CMR, UTR, and MSG and CSM card. The NTAX74 provides the following call processing functions:

- digit collection (pulse)
- channel assignment
- message processing

Real-time call processing functions are as follows:

- send and receive messages
- control the enhanced time switch
- supervise channels
- switch activity and reset control

### Speech bus cards

The speech bus consists of two speech buses, send and receive. Speech bus cards include NTMX76 or NT6X69, NT6X92, NTMX75, NTMX73, NT6X78, and NT7X05. A description of these cards follows.

**NTMX76 or NT6X69** The NTMX76 messaging is optional. If the speech bus card uses NTMX76 messaging , the NTMX76 circuit card replaces the NT6X69 messaging card. The NTMX76 card is the interface between the UP and and a maximum of 32 data links.

The new NTMX76 circuit card provides an interface and processes signaling and control messages between the RCC2 and the central control (CC). The NTMX76 uses the Consultative Committee for International Telegraphy and Telephony (CCITT) level 2 Signaling System No 7 (Q.703) over the data channels.

The NTMX76AB version of the message and CSM card contains upgraded firmware. This frirmware is required to support Analog Display Services Interface (ADSI) and deluxe spontaneous call waiting identification (DSCWID). A description of ADSI and DSCWID appears below.

The Q.703 protocol allows a maximum enhanced distance capacity of 804.5 km (500 mi) between the RSC-S and the host. The CLASS feature Deluxe Call Waiting with Disposition (DSCWID) and EDC are fully compatible and supported. The Q.703 protocol also provides for the following features:

- full duplexing
- windowing
- equal treatment and equal performance in both messaging directions

The message and CSM card processes signaling and control messages between the RCC2 and the CM. The NTMX76AB card can perform the following operations:

- channel supervision messaging (CSM) for call processing and diagnostics. The CSM messages are conveyed between two peripherals when the pulse code modulation (PCM) occurs. The CSM messages are also used to setup, maintain, and terminate calls and to check the parity and PCM path integrity.
- ROM and RAM tone generation
- receive and send DS30 control messages to the CM

# NT6X92

# ATTENTION

To maintain peak performance, do not install the UTR and GTR on the same RCC2. At this time, you cannot determine which receiver interprets tone samples. Some call processing tones can be degraded if designed for use with a GTR.

*Universal tone receiver (UTR)* The UTR (NT6X92BB, BC, CA) identifies and processes DTMF, MF, MF-socotel, CMF-forward and backward tones in 32 channels on the parallel speech bus.

*Global tone receiver (GTR)* The GTR (NT6X92EA) identifies and processes DTMF, MF, MF-socotel, CMF-forward and backward tones in 64 channels on the parallel speech bus.

The GTR complies to LATA switching systems general requirements (LSSGR) and International telegraph and telephone consultative committee (CCITT) standards. The GTR is available as a replacement for all national and international versions of the UTR.

**NTMX75** The formatter circuit card (NT6X41/NT6X72) and the time switch (NT6X44) from the RCC are combined in one card on the RCC2. The enhanced matrix NTMX75 is the RCC2.

**NTMX73** The NTMX73 supports all low-level signaling tasks and provides the system clock. This card replaces XPM circuit cards NT6X86, NT6X80, and NT6X28. Software for maintaining synchronization with the network also resides on this card.

**NT6X78** The NT6X78 custom local area signaling service (CLASS) modem resource (CMR) card supports Calling Number Delivery (CND) and other CLASS services. The CMR card provides the Analog Display Services Interface (ADSI) protocol to transmit CLASS data between the CC and ADSI-compliant customer premises equipment (CPE).

The NT6X78AB, NTMX76AB, and NT6X92BB cards are required for compliance with ADSI protocol. The ADSI protocol supports CLASS features that provide display-based information to subscribers with ADSI-compatible customer premises equipment (CPE). An example of a CLASS feature is DSCWID.

**DSCWID** The revised proprietary DSCWID feature complies to Bellcore TR-416 standards. Bellcore TR-416 describes the requirements for DSCWID and specifies how this feature interfaces with the following sets:

ADSI set

A screen-based ADSI CPE that can display options.

• SCWID set

A non-ADSI CPE that can deliver caller identification (CID) data.


• 2500 set

A non-ADSI CPE that can signal dual-tone multifrequency (DTMF). The 2500 set cannot deliver CID data while off-hook.

Tones the CC sends alert the DSCWID subscriber of a pending call, and the CPE of pending caller data. A line with the DSCWID option can have a call established when a second call attempts to terminate to the line. When this condition occurs, the CC provides one of two types of alerting signals. These signals are subscriber alerting signal (SAS), or an SAS that a CPE alerting signal (CAS) follows. The SAS is the tone that the subscriber recognizes as the call waiting tone (CWT). The CAS alerts the CPE of incoming data if the subscriber line has the Caller Identification (CID) feature.

In response to alert tones, the DSCWID CPE generates an acknowledgement (ACK) tone that indicates the DSCWID CPE is ready to receive DSCWID data. The ACK tone is collected on the GTR card in the RCC2. If the CPE is ADSI compatible, a DTMF A ACK signal is sent in response to the CAS. If the CPE is a SCWID CPE, the CPE sends a DTMF D ACK signal in response to the CAS. When this alert sends tones, the subscriber can control the condition of the incoming call. The subscriber can use the CPE softkeys to respond if the CPE is ADSI. The subscriber can use hard-coded keys to respond if the CPE is a SCWID or a 2500 set to respond. If the CPE does not send an acknowledgment tone, the CPE is treated as a 2500 set. The following figures provide examples of responses from the three set types.

Figure 1-6 Example of a DSCWID call on an ADSI set







Figure 1-7 Example of a DSCWID call on a SCWID set

# Figure 1-8 Example of a DSCWID call on a 2500 set



Alerting signals are sent to the CPE when a GTR channel is not available. If GTR channels are not available, data is not sent to the CPE. In the proprietary

DSCWID, when the RCC2 cannot attach a GTR, a flash was ignored. For Bellcore compliance, the switch must provide options if the switch detects a flash and cannot attach a GTR. To comply with this requirement, the RCC2 sends a flash to the CC if the RCC2 cannot attach a GTR in 400 ms. If the first notification of a pending call is not acknowledged in 10 s, the RCC2 sends a second alert signal. If display data was not sent to the CPE, not enough GTR channels are available. When this condition occurs, the data is held and sent again if re-alerting occurs.

After the RCC2 receives a flash signal from the ADSI compatible CPE of the customer, the RCC2 starts a T-tone timer. The T-tone timer times the maximum time allowed between a sent flash and the DTMF digit on an ADSI set. The timeout is 600 ms, during which the speech path is muted. The T-tone timer starts for the initial option selection during a DSCWID call. The type of the CPE does not affect the start of the T-tone timer. Any ADSI DSCWID option selections that follow also start the T-tone timer.

Any DSCWID option selections that follow on a SCWID or 2500 set use a new timer (T-flash). The T-flash timer occurs after a call is answered with SCWID and 2500 sets. The timer provides the customer with enough time to select an option after a flash. This new timer allows a subscriber enough time to flash and dial a DTMF digit in 600 ms.

The operating company can set the T-flash timer from 1 to 8 s. The default time is 1.5 s. The RCC2 starts the T-flash timer when the following condition occurs:

- the NONADSI field in table DSCWDTYP is set to Y
- the RCC2 receives a flash signal from a SCWID or 2500 set of a customer during the held or conference call state


The RCC2 must keep track of the DSCWID call state and the type of CPE. The timer used depends on on this information. If the RCC2 cannot attach a GTR before 400 ms, application of the RETURN option occurs.

The CC attempts to stay synchronized with the CPE at all times. This supervision prevents some conditions where the CPE thinks the CPE performed a function, but the switch does not process the call. The DSCWID call waiting disposition options are:

- answer the new call and put the current call on hold
- disconnect the current call and answer the new call
- forward the new call
- connect the new call to a busy announcement

- put the new call on hold after you connect to a hold announcement
- conference the new call with the current call.

DSCWID with ADSI set options appear in the figure on the following page.





sent for that digit.

Note 2: A non-ADSI set can be configured for hard-coded keys to perform DSCWID dispositions or the subscriber can provide a DTMF-digit in less than 600 ms. When this condition occurs, dispositions can be available if NONADSI = Y in table DSCWDTYP for the given DSCWID type.

**NT7X05** The NT7X05 provides local storage of XPM loads and images in a nonvolatile, nonmechanical based memory card.

The peripheral/remote loader-16 (PRL) allows XPM software loads to be transferred to the XPM and stored locally in an in-service XPM unit. This action reduces XPM simplex time and allows the replacement of the current load file with a newer load file. During load file replacement, the last image is available for recovery actions. The local storage mechanism is the NT7X05 card. To transfer the software, the enhanced LOADPM command instructs a manually busy (ManB) XPM unit to load from the NT7X05 card with the enhanced LOADPM command. The enhanced LOADPM command uses the following parameters:



# DANGER

Potential service interruption The LOCAL LOADFILE option of the LOADPM command has a parameter of [<file> string}]. When you use this parameter, the system does not patch the loadfile named in the parameter. Do not use this parameter unless

the NOPATCH option of the loadfile is required.

>LOADPM [PM] LOCAL LOADFILE

# [ACTIVE]

# [INACTIVE]

# [UNIT]

The PRL uses imaging technology to accomplish peripheral loading improvements. The monitoring of changes that ocur to restart survivable objects in the XPM provides control at a high level in the computing module (CM). Restart survivable objects are static data and code in the form of patches. The PRL dumps an image of the RAM of the MX77 in an in-service, active or inactive, XPM unit. The PRL copies the RAM to the NT7X05. To dump an image the PRL makes a copy. If the XPM must be reloaded, the image is restored from the NT7X05 to the UP RAM.

*Note:* You cannot dump an image of an embedded processor. The LOADPM command with a source of CC and a parameter of CMR must load the CMR processor from the CM.

You can dump an image of the Unified Processor RAM to the NT7X05 card when the XPM is InSv. Use the IMAGE command with the following parameters:

IMAGE

[<DEVICE {PM,

ACTIVE,

#### INACTIVE ]

 $[ <ALL > \{ALL \} ]$ 

When the installation of the NT7X05 card occurs, the load file is invalid. The card must be loaded with parameter XPMSTOR. To view the status of NT7X05 files, type

#### >QUERYPM FILES

Example of a MAP response:

```
Unit 0:

NT7X05 load File: ** Mismatch **

NT7X05 Image File:

CMR Load: CMR03A

Unit 1:

NT7X05 load File: ** Mismatch **

NT7X05 Image File:

CMR Load: CMR03A
```

*Note:* The example MAP response reflects RSC-S with ISDN. The NT7X05 image file name appears for non-ISDN configurations only.

When loading is a requirement, the CM verifies the NT7X05 datafill is present. If NT7X05 is present the following are transferred from the CM to the UP:

- the recovery software loader (RSL) software load
- the name of the desired load file
- an indication if the image or load file must is a requirement

The RSL checks the NT7X05 load file name. If the load name test passes, the RSL restores the image or load to the UP. To avoid delays in loading, part of the restore/loading process verifies the image/load file integrity. To view the status of the NT7X05 files, enter the following command again;

#### >QUERYPM FILES

Example of a MAP response:

```
Unit 0:
NT7X05 load File: CRI07AW
NT7X05 Image File:
CMR Load: CMR03A
Unit 1:
NT7X05 load File: CRI07AW
NT7X05 Image File:
CMR Load: CMR03A
```

*Note:* The example MAP response reflects RSC-S with ISDN. The NT7X05 image file name appears for non-ISDN configurations only.

## **Peripheral communication cards**

The following cards translate between the 54 P-side ports and the parallel speech bus:

*NTMX75* Application of the NTMX75 circuit card occurs as described in the host communication section.

*NTMX87AA/AB* The Quad Frame Carrier (NTMX87) provides an interface between RSC-S peripherals and collocated transmission equipment like channel banks. The octal DS-1 circuit card contains up to four NTMX81AA dual DS-1 packlets. The dual DS-1 packlets provide and support all features and maintenance functions that the NT6X50AB provides. The dual DS-1 packlets also provide and support all performance counters the NT6X50AB supports.

NTMX87BA The Penta DS-1 Packlet Carrier does not support P-side links.

*NTMX74* The DS30A (NTMX74) circuit card provides 32 DS30A links for the following components located at the RCS-S:

- terminating line concentrating modules (LCM)
- remote maintenance modules (RMM)
- Subscriber Carrier Module-100S Remotes (SMS-R)

Each interface (I/F) chip on the NTMX74 card serves 4 DS30A links. The following chart provides the link-to-chip relationship. A minimum of 4 must

separate message (MS) links table LCMINV. This condition prevents a single chip failure that causes a T1 outage.

Chip number	DS30A link numbers
1	22, 23, 24, 25
2	26, 27, 28, 29
3	30, 31, 32, 33
4	34, 35, 36, 37
5	38, 39, 40, 41
6	42, 43, 44, 45
7	46, 47, 48, 49
8	50, 51, 52, 53

Table 1-22 DS30A link relationship

### Speech and message paths in the remote cluster controller 2

The parallel speech bus consists of a transmit bus and a receive bus. Voice and message paths link the two RCC2 units in a DRCC2 from the RCC2 to the host.

For an RCC2 to function correctly, adequate communication between the RCC2 units must occur. For example, the inactive unit can take over call processing. The RCC2 units communicate over the intermodule communication (IMC) links.

An RCC2 communicates with the host over links 0 and 2. If both message links fail, the RCC2 cannot communicate with the host, and ESA is enabled.

A functional block diagram of the RCC2 appears in the following figure.




Figure 1-10 Functional block diagram of the RCC2

# Routine exercise test

The REX tests the RCC2 on a routine basis. The REX test makes sure that both units can perform call processing if one unit fails.

Parameter NODEREXCONTROL in table OFCVAR controls the REX schedule. When the table has datafill, operating company personnel can change access the PM level of the MAP display and post the associated PM This action activates the REX test schedule for a peripheral module (PM). The following are examples of this action:

#### >TST REX ON

XPM n is included in the REX test schedule
>TST REX OFF
XPM n is removed from the REX test schedule
>TST REX NOW
REX test in progress
(REX test messages)

The REX test for the RCC2 combines many of the diagnostic and functional routines available with the RCC. These routines improve fault coverage and reliability. The system generates logs for the duration of the test. The system suppresses operational measurement (OM) pegs and alarms if the pegs and alarms are active because of the REX test.

## Switch of activity

A SWACT process allows two units of an RCC2 to switch activity. The active unit becomes the inactive unit and the inactive unit becomes the active unit. The new active unit takes over call processing.

A peripheral that supports a subscriber line with an active DSCWID session can undergo a warm SWACT. This warm SWACT can occur between the alert tones plus the timer default seconds, after re-alert and before the incoming call is acknowledged. When this condition occurs, the system drops all parties to the call.

For an RCC2 with DS-1 links that operates in HDLC mode, all HDLC links can lose synchronization to the active unit. When this condition occurs, the unit attempts a SWACT. If the SWACT fails, the RCC2 enters ESA. If synchronization fails in the inactive unit, the unit operates in the DMS-X mode.

# Computing module datasync

The XPMs must follow several requirements to maintain system sanity. One requirement is that node and port tables in both units must remain synchronized. the same internal indexes must reference common tuples to both units and the tuples must contain the same data. Identical indexes in both units allow processes to communicate between units. Active processes continue to function after a warm SWACT. The addition of new XPM functionalities caused the preservation of synchronization of the mate unit node and port tables to be more difficult.

Data is set in the active unit of an XPM through the node and link RTS and external triggers cause the state changes. Data transfer to the inactive XPM unit can occur through the bulk and individual messages of the current XPM datasync mechanism. Data transfer occurs through the use of the following equipment:

- an IMC filter that blocks all individual XPM datasync messages
- an RTS NODATASYNC that blocks all bulk XPM datasync messages and compresses the node table in the XPM
- the CM supplied static and dynamic data for the RCC2 and subtending P-side nodes in the RCC2 that undergo the SWACT

For basic loads, the link states data and P-side node and port states data must be included to make sure that the correct initialization occurs for RCC2 data.

The inactive unit is forced to order the node table the same as the active unit. This action coordinates management of node table synchronization in the XPM. To perform this action, the active unit must send a map of the node table during a bulk download of configuration data. The inactive unit uses the map to enter data in the node table as data is received from the CM.


The inactive unit does not use the node map to write dynamic updates. The inactive unit expets to receive the data in the same order as the active unit. When the inactive unit runs, the node and port tables must remain in synchronization with the active unit. Units can lose synchronization if one unit lost an earlier dynamic update. The active unit can contain a temporary interprocessor message link (IPML) in the node table when a dynamic update occurred. The IPML is used for broadcasting. This condition causes the tables to be out of synchronization because addition of temporary IPMLs occurs only in the node table of the active unit.

# Node table synchronization enhancements

The XPM Node Table Sync Redesign feature AF5678 created table PMNODES. This table contains a list of all nodes in each XPM and transfers XPM node information to the new CM load during a software upgrade. This transfer makes sure the new CM software contains the correct node order for each XPM that becomes active. The CM controls the sequence and datafill of node and port tables in both XPM units. Synchronization continues between the CM and the tables in both active and inactive XPM units. The XPMs converted to this table management system do not synchronize with mapping information sent from the active unit to the inactive unit.

Table PMNODES is a read-only table. The system adds and deletes tuples as related inventory tables, like RCCINV and LCMINV, are entered. The system rejects attempts to directly update this table. The system checks XPM resources when addition of a tuple for a subtending node occurs or changes

occur in an inventory table. Warnings appear when an XPM does not have the table space, port, or terminal resources to support the new requirements. For a complete description of the datafill for table PMNODES, refer to the *XPM Translations Reference Manual*.



#### Figure 1-11 Enhanced XPM node table synchronization

Feature AF5678 adds configuration data table (CDT) management. The CDT bind interface allows XPM applications to bind an aspect with the set of procedures to a CDT during initial program load (IPL). An XPM with a software load that is bound with the new CDT management system notifies the CM during an XPM node data audit. The CM starts a CDT audit every 5 min. This initiates the node data audit in the XPMs.

The CDT / XPM node audits convert XPMs that have compatible software loads to the new node table management control. The CDT/XPM node audits also verify the sanity of XPMs for which the conversion occurs. To maintain backward compatibility, XPMs with software loads without CDT management capability continue to maintain mate unit synchronization.

The CM has control of both units of an XPM node when the following events.

- The CDT / XPM node data audits successfully updated the tuple(s) of that node in table PMNODES. When this update occurs, these tuples match the data and indices sequence of the tuples in the XPM node and port tables.
- The CM had control in a previous software load.
- A new XPM is added when a one night process (ONP) conversion does not occur. Nodes added during ONP are not new and are now in service.

*Note:* An office can receive an initial software load with the new node table management system. When this condition occurs the CM gains control of compatible XPM node and terminal tables during the next scheduled CDT / XPM node data audits. An XPM can be taken out of service (OOS). When this condition occurs, the CDT / XPM audit must successfully convert an XPM to the CDT management system and align the CM tables with the node tables. When this condition occurs, the CM assumes control.

The CM initiates the audit request to an XPM with a VERTUPLE message. The message has a parameter that identifies if the XPM responds with a message with actual tuples of data or a checksum of the table. The CM requests the tuples data to supply the CM with the required information to convert an XPM to CDT management control. differences between the active and inactive unit tables can be present. If this condition occurs, the CM aligns to the table of the active unit and sets the XPM ISTb. After an XPM converts to CDT, a checksum of the table is always requested when the CDT audit runs.

Checksums of the node and port table data verify the synchronization of XPM nodes in the CDT management system. Regenerate each tuple in the XPM table. Calculate the checksums. After a tuple is formatted, the calculation for that tuple occurs and is added to the table checksum for that XPM. The XPM checksums are verified against corresponding checksums that the system generates in the CM. An out-of-synchronization condition causes the unit to be set ISTb. The method that confirms XPM synchronization, mate unit synchronization or CM control, does not affect the state change of the unit. During the next audit cycle, if the unit checksum coincides with the CM checksum the ISTb condition is cleared.

Feature AF6436 provides EDDS and warm SWACT capabilities for ISDN basic rate interface (BRI) calls on the RCC2.

The XPM node table and the port table are only compressed when:

- both units of an XPM are taken out-of-service
- new configuration data is downloaded

This condition allows the CM to manage the node and port tables more effectively.

As the CM takes a more active role in the maintenance of the node tables in XPMs, the XPMs become less active. The XPM must accept the CM data as the data is sent without corrections or adjustments.

To implement the enhanced synchronization capability that feature AF5678 provides, the following functions are created or changed.

- The XPM does not derive node table data from a subset of data sent from the CM any longer. The CM specifies all data the node and port tables contain and the XPM stores the XPM data receives.
- The CM notifies operating company personnel if resources are not available on an XPM when inventory tables are changed. The state of the XPM (ManB or OOS) at the time the inventory tables are changed does not affect notification.
- The XPM does not compare node tables between units any longer. The CM makes sure that the node tables in each unit match because the CM controls the content of each table. An RTS that occurs on an inactive unit with the NODATSYNC option does not cause a configuration download from the CM. Configuration download occurs when both units are taken out-of-service and RTSed at the same time.
- Creation of node and port table aspect and access routines allows applications to access the data. Read-only access is provided to applications. Tuples in XPM tables continue to be dynamically updated from the CM when the XPM is InSv.
- Creation of new external node number to internal node number look-up table occurs in the XPM to provide fast conversion from external to internal node numbers. This action eliminates the possibility of collisions.
- An enhanced messaging interface includes status information between the CM and XPM. The new interface contains:
  - the ability to add a sequence number from 1 to 255 in the header to detect lost messages.
  - a byte of data transfer status information that informs the XPM if more messages follow.
  - a count of tuples the message affected.
  - table format identification to identify the version of XPM table software. Leave the current node table management software in the XPM until XPM06 to maintain backward compatibility.

# Enhanced Dynamic Data Sync (EDDS)

Dynamic data describes the link and node states in the XPM necessary to support call processing. These states are normally set in the active unit of an XPM through:

- the node and link RTS
- state changes that have external causes

These states transfer to the inactive XPM unit through the bulk and individual messages of the XPM data synchronization mechanism.

The EDDS is a necessary component of warm SWACT. A Warm SWACT preserves processing of ISDN and POTS calls. Warm SWACTs occur when the active unit of an XPM drops activity because of an XPM trap, REX test or other causes. The warm SWACT preserves call and unit states so that calls continue without interruption. For a warm SWACT to succeed the inactive unit must be in service (InSV).

If the inactive unit was previously out of service (OOS) because the unit was manually busy (ManB), system busy (SysB), or C-side busy (CBsy), the following events occur during an RTS:

- The initialization of the inactive unit.
- The OOS tests run on the inactive unit.
- the CM sends new static data and marks the inactive unit in-service trouble (ISTb) if the inactive unit static data is not correct.
- The active unit sends dynamic data to the inactive unit (bulk sync).
- The CM marks the inactive unit InSv.

# Reset non-remote carriers and trunk call cleanup

In addition to the CM dynamic data, all non-remote carriers that are present are cycled. Cycling is a busy and return-to-service sequence on a terminal. This activity makes sure all trunk data are initialized in the RCC2. This activity releases all trunk calls and attempts to RTS any system busy trunk carriers.

# Line call cleanup

On line concentrating XPMs, the system idles calls on all subtending P-side. This action takes into account intraswitched and interswitched calls on subtending RCC2s. The cleanup causes the calls in local P-side nodes to be first idled, and the calls in subtending RCC2s are idled. During the line call cleanup, the RCC2 is subject to messaging overload. When messaging overload occurs, the system inhibits call terminations and originations.

## **Special cases**

An LTC with subtending RCC2s can have subtending SMSRs. In this occurence not all of the RCC2s can have loads compatible with this feature.

If an error occurs during the SWACT, errors on the RCC2 that undergo the SWACT are handled differently based on when the error occurred. The failure can occur:

• before the activity switch. When this condition occurs, the SWACT aborts and the node is in the ISTb state. The inactive unit is made SysB, and

maintenance personnel can recover the unit. If the unit is left untended, the system recovers the SysB unit.

- after the activity switch and before the full post-SWACT cleanup completes. When this condition occurs, the complete node is made SysB. Maintenance personnel must determine the cause of the failure and bring the node in service. If the unit is left untended, the system recovers the SysB unit.
- after the activity switch and after the full post-SWACT cleanup. When this condition occurs, the newly inactive unit remains out of service for maintenance personnel to handle. If the unit is left untended, the system recovers the SysB unit.

A datasync failure can occur for any of the P-side nodes. When this condition occurs, the system in returns to service. A P-side node datasync failure of a single P-side node does not impact:

- the node that undergoes the SWACT
- any other P-side nodes

When a P-side node encounters a problem with the CM dynamic data synchronization, the problem is limited to that P-side node. The problem does not affect the host XPM or other P-side nodes.

**Controlled and uncontrolled switch of activity** The two types of SWACTs are controlled and uncontrolled. The following actions result in controlled SWACTS:

- manual action when you use the SWACT command)
- planned system requests from the REX test schedule
- when the active unit is busied while the inactive unit is in service (InSv)

Controlled SWACTs can occur when both units are InSv. Controlled SWACTs can also occur when the RCC2 is in the in-service trouble (ISTb) state because of a previous REX test failure.

*Note:* Feature AF2987 makes sure a system audit does not return the unit to service.

The system implements uncontrolled SWACTs when a hardware fault or a trap in the active unit occurs. Examples of failures that initiate uncontrolled SWACTs follows:

- power
- clock

- extension shelf
- power converter

# Updating static data (non-emergency stand alone)

To execute call processing and maintenance on the RCC2 and the subtending nodes, the RCC2 must know which of the following are present:

- cards
- ports
- execs
- terminals

This information is in tables and is called static data. The RCC2 does change dynamic data that is established when set up occurs.

The node data that resides in the RCC2 and subtending XPMs determine data entered through the inventory tables in the CM. These inventory tables include LTCINV, LCMINV, IPMLINV. These tables identify which nodes must communicate with other nodes. When a node, like a line concentrating module (LCM), is entered on an RCC2, an entry for the LCM must be placed in the RCC2 Node table. This action allows the RCC2 to route messages to and from the LCM.

As the data entry occurs through the inventory tables, the CM verifies that the head or messaging XPM has the resources available for the new node. If the XPM does not have the required resource, the data modification order (DMO) is rejected. If the DMO is not rejected, the CM writes the data in the copy of the XPM node table and determines the internal index for the new node.

When the data transfers to the XPM, the CM reads the data from the version of the XPM node table. The data transfer includes the internal index for each tuple to use in the XPM node table. The XPM uses the index the CM sends to determine the location of the tuple in the node table.

The transfer of the index to both units from the CM makes sure the XPM receives the same tuple indexes for both units. This transfer maintains the synchronization in the node table required for the XPM to support warm SWACTs and inter-unit messaging.

Previously, the CM transferred the port table information for a node in the same message as the node data. The node and port tables are separate tables in the XPM and do not affect this action. To manage these tables, the CM now transfers the node and port data in separate messages. The CM uses unique configuration table identifiers for each table to perform this transfer.

The status of the peripheral modules determines when and how the static data update occurs:

- If the host XPM is ManB, the static data load occurs during RTS.
- If the host XPM is InSv, the static data is dynamically updated.
- If the RCC2 is ManB, the static data load occurs during RTS.
- If the RCC2 is InSv, the static data is dynamically updated.

# **RSC\_XPMESAEXIT** parameter

This parameter (Remote Cluster Controller Xms-based Peripheral Module Emergency Stand Alone Exit) is required and appears only in a switching unit with the remote cluster controller (RCC) and the emergency stand alone (ESA) feature.

The RSC\_XPMESAEXIT parameter determines if the system initiates ESA exit or if manual intervention is required to exit ESA. It also determines how long the system waits to initiate the ESA exit.

# **Provisioning rules**

Set the value of this parameter to the desired delay between links being restored (or communication with C-side peripheral recovered) and the remote service center coming out of ESA mode.

The time is defined in 10-s intervals (for example, a value of 2 indicates a delay of 20 s). The default setting of 6 (see "Range information") indicates that after a 60-s delay, the system will initiate an ESA exit. A value of N indicates that a manual RETURN TO SERVICE (RTS) is required to exit ESA.

The range of values type is RSC\_ESA\_EXIT\_TYPE with the following multiple values:

#### Table 1-23

SYSTEM_ESA_EXIT	{N, Y}
EXIT_DELAY	{0 to 100}

The SYSTEM\_ESA\_EXIT field is a boolean that determines if the system initiates an ESA exit (Y) or if a manual ESA exit is required (N). The EXIT\_DELAY field determines how long the system waits to initiate the ESA exit. The value is non-zero if the system initiates the ESA exit. The delay increases in multiples of 10-s increments. The range has a minimum of 0, a maximum of 100, and a default of 6. The activation is immediate.

## Verification

Verification of the SYSTEM\_ESA\_EXIT field is "Y"; verification of the XPM\_EXIT\_DELAY field is "6".

To verify:

1. Set the parameter to its default value in table OFCENG as follows:

#### Table 1-24

RSC_XPMESAEXIT	Y	6		

- 2. From the MAP (Maintenance Administration Position) display, post an InSv RCC.
- 3. Break RCC C-side msg links at DSX.
- 4. From the MAP display, observe RCC go from InSv to CBsy, then to SysB.
- 5. From the MAP display, observe the ESA countdown start at 60.
- 6. From the MAP display, observe the system warm exit RCC.

## **Memory requirements**

This parameter value requires 1 word of memory.

### **Dump and restore rules**

Copy the existing value of this parameter when doing a dump and restore.

If the current software release has the parameter RSC\_XMPESAEXIT delay set to "0", then the new parameter will be set as follows:

## Table 1-25

RSC_XPMESAEXIT	Ν	0
----------------	---	---

If the previous software release had the parameter RSC\_XMPESAEXIT delay set to a non-zero setting, then the new parameter will be set as follows:

#### Table 1-26

IT Y <dt></dt>
----------------

where <dt> is the ESA exit delay time of the previous software release.

## Testing the RCC

Operating company personnel usually test the RCC by issuing the TST command. The type of test used depends on two factors, the state of the RCC and the parameters included in the TST command.

User input: To busy the inactive unit of the RCC, enter:

> TST UNIT 0

and press the Enter key

where

**0** = the inactive unit

System response: The following message sequence appears:

ROM/RAM query /Reset /Status Non Destr ROMtst /RunInitializing Testing TESTALL ABDIAG UTRDIAG PSLOOP MSGDIAG SPCHDIAG TS DIAG TONESDG CMRDIAG Initializing Tst Passed

Following is the message sequence for command testing the inactive unit. This is a subset of the TST command that performs full diagnostics.

User input: To test the inactive unit, enter:

> TST UNIT 0 ROM

*System response:* 

/Status ROM/RAM query Non Destr ROMtst Tst Passed

# **Testing other cards**

Following are cards with special test sequences:

• NT6X69

*Messaging* When the TST command is given and the RCC is both busy and inactive, the following tests are run:

- *destructive* replaces the contents of RAM by resetting the card, checking the message buffer, testing the interface to the speech bus, and testing ROM
- *nondestructive* runs when the destructive test cannot run. It tests the P-side by running a looparound test on a dedicated channel of the time switch card, checking the interface to the speech bus, and testing its ROM.
- NT6X50AA and NT6X50AB

*DS-1 interface* When the TST command is given for an out-of-service (OOS) unit, loopback tests are performed through the DS-1 card.

# Returning the remote cluster controller 2 to service

An RCC2 returns to service if manual maintenance occurred or if a system audit detects a defective component.

When manual maintenance occurs, a fault can occur in the RCC2 unit or PM becoming system busy (SysB). When this condition occurs, the unit is normally busied and tested. When the defective component is found and repaired or replaced, performance of an RTS occurs on the unit or PM.

If a system audit detects a defective component, an audit attempts to return the component to service.

**Performing a return to service without running diagnostics** Use of FORCE parameter with the RTS command causes the read-only memory (ROM) diagnostics to not perform.



# CAUTION

## Use the FORCE parameter only when directed.

Do not use the FORCE parameter unless directed, because diagnostics that are normally part of the RTS command can encounter additional faults.

The following message sequence appears when you use the RTS command with the FORCE parameter.

#### >TST UNIT 0 FORCE

ROM/RAM query /Clear data Initializing /Static Data Loading:Execs Initializing ESA Data Load

After the message sequence a dynamic data synchronization with a fault flag raised occurs. This action occurs because warm SWACT is disabled. When synchronization completes, the system returns the unit to service.

### Dual remote cluster controller 2

An RCC2 that is part of a dual configuration is functionally the same as a single RCC2. The main difference is that P-side DS-1 links connect the two peripherals. The following sections explain DRCC2 in terms of the functional areas in the following sections:

- speech and message paths
- ESA and dual ESA (DESA)
- maintenance messaging

#### Speech and message paths

The DRCC2 allows calls that originate on one RCC2 and terminate on the interconnected RCC2 to route directly over interlinks during call setup. The minimum DRCC2 configuration requires four messaging links. For this type of call to occur, the two peripherals must be able to communicate with the host and with each peripheral.

**C-side connections to the host** The NTMX81 and NTMX75 cards comprise the host communication cards. In the DRCC2, these cards also handle communication between the two peripherals. C-side ports 0 and 2 handle messaging links to the network.

#### Sending messages between the remote cluster controller 2s

When a message is received over a messaging link from the interconnected RCC2, the system routes the message to the NTMX76 of the active unit. The message card examines the message and determines if the message is for the active or inactive unit. The P-side ports 0 and 8 handle the messaging links between the two peripherals.

**Inter-RCC2 link dynamic static data update** Before feature AF6046 (Dynamic Download Of Static Data (SD) for Table IRLNKINV), interlinks information in table IRLNKINV was not dynamically downloaded to both

RCC2s of a DRCC2. A download of interlinks information required a manual busy and return-to-service of the two RCC2s. This download caused an E1 outage. Table IRLNKINV information was downloaded to both the master RCC2 and the spouse RCC2 as part of the SD bulk download.

Feature AF6046 provides a process which dynamically reconfigures interlinks between two in-service (InSv) RCC2 nodes in a dual configuration. This feature provides this process and preserves stable interswitched calls. This feature provides the following improvements:

- adds command INTERSW to the IRLINK MAP level. This command activates and disables interswitched calls for the posted RCC2.
- improves the BSY interlink MAP command. The improved command displays the number of interswitched calls that use available C-side channels to revert to the network.
- improves the QUERYIR interlink MAP command. The improved command displays the state of IRLINKS and the state of interswitching capability of the posted RCC2 of a DRCC2.
- allows the dynamic download of IRLINKS static data to both RCC2s that interconnect in a dual configuration.
- provides the dynamic download of ForceESA SD.

Enter the following command from the IRLINK MAP level to disable interswitching capability. Enter this command before you reconfigure (adding, removing, or moving) interlinks of a posted RCC2 of a DRCC2.>INTERSW DISABLE

To confirm interswitching is disabled, enter the QUERYIR command. The QUERYIR command displays the status of interswitching ability for the posted RCC2. >QUERYIR

## Example of a MAP response

rswitc	hing is	DISAB	LED						
FROM		TO		С	ALRM	SLIP	FRME	BER	STATE
RCC2	0, 0	RCC2	1, 0			0	0		OK
RCC2	0,8	RCC2	1, 8			0	0		OK
RCC2	0, 4	RCC2	1, 7			0	0		OK
RCC2	0, 9	RCC2	1, 12			0	0		OK
	FROM RCC2 RCC2 RCC2	FROM RCC2 0, 0 RCC2 0, 8 RCC2 0, 4	FROM         TO           RCC2         0, 0         RCC2           RCC2         0, 8         RCC2           RCC2         0, 4         RCC2	rswitching is     DISABLED       FROM     TO       RCC2     0, 0     RCC2     1, 0       RCC2     0, 8     RCC2     1, 8       RCC2     0, 4     RCC2     1, 7       RCC2     0, 9     RCC2     1, 12	FROM         TO         C           RCC2         0, 0         RCC2         1, 0         .           RCC2         0, 8         RCC2         1, 8         .           RCC2         0, 4         RCC2         1, 7         .	FROM         TO         C         ALRM           RCC2         0,0         RCC2         1,0         .           RCC2         0,8         RCC2         1,8         .           RCC2         0,4         RCC2         1,7         .	FROM         TO         C         ALRM SLIP           RCC2         0, 0         RCC2         1, 0         .         0           RCC2         0, 8         RCC2         1, 8         .         0           RCC2         0, 4         RCC2         1, 7         .         0	FROM         TO         C         ALRM         SLIP         FRME           RCC2         0,0         RCC2         1,0         .         0         0           RCC2         0,8         RCC2         1,8         .         0         0           RCC2         0,4         RCC2         1,7         .         0         0	FROM         TO         C         ALRM         SLIP         FRME         BER           RCC2         0, 0         RCC2         1, 0         .         0         0           RCC2         0, 8         RCC2         1, 8         .         0         0           RCC2         0, 4         RCC2         1, 7         .         0         0

When the interswitching ability is disabled, enter the BSY command with the IRLINK number(s) you want reconfigured. This action begins modification of the IRLINKS. The improved BSY command displays the number of interswitched calls that use C-side channels to revert to the network. The following is an example of this command:>**BSY 3** 

Example of a MAP response

67 interswitched calls will be reverted to the network. Potential loss of calls on the interlink if there are no available C-side channels.

The C-side channels of the RCC2 are a limited resource. Reconfigure IRLINKS during periods of low traffic. Loss of interswitched calls can occur if not enough C-side channels are available.

Enter the INTERSW command before an attempt occurs to BSY a specified IRLINK. If you do not enter this command before the BSY attempt, the MAP terminal displays the following response:>**BSY 3** 

Example of a MAP response

interswitched calls should be disabled before an interlink is busied.

When the IRLINKS are ManB, enter table IRLNKINV and make link changes for the desired IRLINK configuration. Static data immediately downloads to both units of both RCC2s of the DRCC2, if the units are InSv.

After DRCC2 IRLINKS are reconfigured, enter the improved RTS command to return the IRLINKS to service the IRLINKS. The MAP terminal displays the following response to indicate interswitching is disabled.>**RTS 3** 

Example of a MAP response

Be aware that Interswitching is Disabled.

To activate interswitching, enter the following command from the IRLINK MAP level:>INTERSW ENABLE

To confirm interswitching is activated for the posted RCC2, enter the QUERYIR command from the IRLINK MAP level. The MAP displays for the RCC2 appear in the following examples:>**QUERYIR** 

### Example of a MAP response

Inte	rswitc	hing i	s ENABL	ED								
IR	FROM		TO			C	7	ALRM	SLIP	FRME	BER	STATE
0	RCC2	0, 0	RCC2	1,	0				0	0		OK
1	RCC2	0,8	RCC2	1,	8				0	0		OK
2	RCC2	0,4	RCC2	1,	7				0	0		OK
3	RCC2	О, б	RCC2	1,	6				0	0		OK

The IRLINKS and ForceESA static data are dynamically downloaded to both RCC2s of the DRCC2. The following components must also download:

- ESA lines
- trunks and ESA table control data
- components of the ESA static data for both RCC2s

For this reason, the units of both RCC2s are set to in-service trouble (ISTb) with the message ESA STATIC DATA MISMATCH.

You can download the ESA static data manually at the PM MAP with the RCC2s posted. To download the ESA static data, enter the LOADPM command with the source CC and file ESADATA. You can update ESA static data at the automatic nightly static data updates as defined in table OFCENG tuples RSC\_XPMESASDUPD\_BOOL and RSC\_XPMESASDUPD\_HOUR.

## Emergency stand-alone and dual emergency stand-alone

The following sections describe how the system makes sure that the RCC2 can communicate with the host. The sections also describe how to enter and exit ESA and DESA are entered and exited.

**Synchronization in dual emergency stand-alone mode** When the DRCC2 enters DESA the following cards perform functions that allow both peripherals to synchronize and send messages to each other:

- NTMX81
- NTMX75
- NTMX76

For calls to be interswitched, both peripherals must be synchronized to the same source. In normal operation, each RCC2 in the DRCC2 follows the timing of the host line group controller (LGC) or line trunk controller (LTC). Both peripherals synchronize to the same source because the timing element is sent out to all nodes in the network.

The RCC2 uses the NTMX75 to generate the frame pulse. An internal XPM clock controls this pulse. The clock for the active unit dynamically adjusts to the network clock pulse so the RCC2 is synchronized with the host.

When loss of communication to the host occurs, the internal XPM clock for the active unit does not have a frame pulse to follow. The XPM clock goes into free-run mode. With the NTX380AA package, the RCC2 can synchronize to the interconnected RCC2. The DRCC2 software determines which RCC2 is the source of the frame pulse. This RCC2 sends frame pulses over links 0 and 8 to the other RCC2.

**Forced emergency stand-alone** When RCC2 A and RCC2 B are in ESA, DESA is implemented and interswitched calls are allowed.

*Note:* Because RCC2 B is not truly in ESA, it can exit ESA under certain conditions. For example, if the RCC2s can no longer exchange messages over the interlinks, the RCC2 B starts a timer. This timer is used to prevent bouncing links.

When this timer begins, the following conditions are possible:

- If the interlinks cannot resume messaging before the timer expires, RCC2 B stops the simulating faults and exits ESA.
- If the interlinks resume messaging before the timer expires, the timer is canceled and DESA is reestablished.
- If the timer expires and RCC2 B exits ESA and the interlinks resume messaging, the system forces RCC2 B into ESA.

# Maintenance messaging

For the messaging channels, RCC2 software can perform the following tasks:

- send and receive messages across the interlinks with DMS-X protocol
- handle intermessaging link faults the messaging system detects
- provide support when maintenance is performed on the messaging links

One RCC2 can send a message to the other RCC2. When this condition occurs, messaging software sends the message to the firmware of the NTMX76 card to be transmitted. If the software cannot send, the message to the messaging software. For example, the link can be closed, or a timeout exists in the DMS-X protocol. These messages rebounded.

When a message rebounds, the message link is closed and software tries to send the message over the other messaging link. The XPM maintenance in the RCC2 is informed of the rebound. This software tries to RTS the defective link. A PM181 log informs operating company personnel of these procedures.

## **Emergency stand-alone warm exit**

RCC2 warm exit is based on the RCC warm exit. The RCC warm exit software performs any adjustments required to operate warm exit for the RCC2.

Warm exit for the RCC2 addresses the following deficiencies when an RCC2 exits ESA:

- service outage of a maximum of 20 min
- drop of all stable calls
- messaging between the RCC2 and the CC that informs the CC of any active calls

The system supports the ESA warm exit for the DRCC2. The system does not support the ESA warm exit for ISDN.

# 1-Meg Modem Service

The RSC-S supports the 1-Meg Modem Service from frame-based LCMs and RLCMs that connect to RSC-S. The 1-Meg Modem Service provides high-speed, data-over-voice communications over standard telephone lines to the home or small-office subscriber. The service provides the following functionality:

- high bandwidth with line transport rates up to 1280 kilobits per second (kbit/s) downstream and 320 kbit/s upstream
- simultaneous data and voice connection
- continuous data connection
- data traffic routed to data networks, which reduces congestion on the voice switch

The 1-Meg Modem Service uses a digital subscriber line (DSL) technology to provide the increased bandwidth with current office equipment and the subscriber loop. In this document, the term xDSL refers to all the different DSL technologies.

# Components

The 1-Meg Modem Service includes the following components:


- The 1-Meg Modem is customer premises equipment (CPE) that connects the telephone line, extension telephone, and computer. To the subscriber, the modem installs like a regular voice band modem, except the modem uses a 10BaseT Ethernet connection to the computer. Voice and data circuits are kept separate on the loop. This separation allows simultaneous voice and data traffic with no impact to other telephony features.
- The xDSL line card (xLC) replaces the subscriber's line card in an existing line concentrating module (LCM) drawer. The card provides full voice service in parallel with high speed data communication with the 1-Meg Modem.
- The data-enhanced bus interface card (DBIC) replaces the existing bus interface card (BIC) in the existing LCM drawer. The card is a concentrator for the voice and data connections within a single LCM drawer. The card also separates the voice and data traffic for routing to the correct networks.
- The xDSL Element Management System (xEMS) provides operations, administration, maintenance, and provisioning (OAM&P) functions from a Hewlett-Packard (HP) or Sun workstation. Based on HP OpenView, the xEMS is a graphical user interface (GUI) that uses icons and pull-down

menus. Refer to *1-Meg Modem Service Network Implementation Manual*, 297-8063-200, for more information on xEMS.

• The transport network provides the connection to the service providers. Refer to *1-Meg Modem Service Network Implementation Manual*, 297-8063-200, for more information on transport networks.

The following figure illustrates a network with the 1-Meg Modem Service.

Figure 1-12 Telephone network with 1-Meg Modem Service



The LCM line drawer contains the DBIC and xLCs. One LCM can hold up to 10 line drawers. In a frame-based LCM, the line cards in each drawer can be a mix of xLCs and plain old telephone service (POTS) line cards. In a frame-based RLCM, the line cards in each drawer can be either xLCs or POTS line cards. Each 1-Meg Modem Service subscriber has an xLC. Each line drawer with xLCs must have a DBIC to provide data service. Each DBIC provides an Ethernet connection to the transport network for all subscribers in the LCM line drawer.

An LCM can have a maximum of ten Ethernet connections for all its 1-Meg Modem Service subscribers. The configuration of the transport network can require these Ethernet interfaces to connect to a mix of network components. The flexibility of the 1-Meg Modem Service allows you to change the interface to public and private wide area networks (WAN) to meet your requirements. Examples of WANs are Internet access providers (IAP), Internet service providers (ISP), and corporate networks.

# **Potential applications**

Potential applications of the 1-Meg Modem Service include the following:

• work-at-home

The subscriber uses the 1-Meg Modem Service, including the transport network, to connect to their corporate network.

• Internet access

The subscriber uses the 1-Meg Modem Service, including the transport network, to connect to their ISP.

• small office communications

The subscriber uses the 1-Meg Modem Service, including the transport network, to connect to their corporate network. Two small offices can communicate through the 1-Meg Modem Service and depend on on the transport network for interconnection.

# Compatibility

This section describes compatibility between the 1-Meg Modem Service and other services.

Voice services The 1-Meg Modem Service shares many components with the existing voice service. Some of these components are the following:

- LCE hardware, including power supplies and distribution
- the subscriber's copper loop

Other data services The 1-Meg Modem Service can function with the following data services in the same binder group:

- integrated services digital network (ISDN) basic rate interface (BRI)
- asymmetric digital subscriber line (ADSL)
- high bit rate digital subscriber line (HDSL) services

The 1-Meg Modem Service can function with T1 services in adjacent binder groups.

*Ethernet* The Ethernet interfaces at the 1-Meg Modem and the DBIC meet standard *ANSI/IEEE Standard* 802.3 with one exception. The 1-Meg Modem

does not support the truncated binary exponential backoff algorithm described in section 4.2.3.2.5 of the IEEE802.3 specification. This exception allows the best use of the bandwidth on the link. This exception also confirms a standard allocation between multiple users.

# **1-Meg Modem Service components**

The following section describes some of the components in the 1-Meg Modem Service.


*xDSL line card* The xDSL line card (xLC) provides full voice service and high speed data communication with a subscriber's 1-Meg Modem.

The xLC has the following features:

- located in a standard LCM line drawer with 1-Meg Modem Service capability
- provides standard voice service using the world line card (WLC)
- provides xDSL modem function over loops up to 18,000 feet on 26 American wire gauge (AWG) and 24,000 feet on 24 AWG
- rate-adaptable in both downstream (DS) and upstream (US) directions
- QAM modulation in both DS and US directions
- supports both narrowband and wideband DS spectra low and high transmission levels
- raw transport downstream data rates of 1280 kbit/s to 80 kbit/s
- raw transport upstream transport data rates of 320 kbit/s to 40 kbit/s
- provides an XLBUS interface to backplane
- -48 V power to data part of card
- self-identifying to DBIC on installation
- out-of-service data loopback capability for OAM
- low power design
- occupies a two-slot form factor

The xLC terminates the subscriber's line and transmits the call to the DBIC for multiplexing. The following figure illustrates the xLC in the 1-Meg Modem Service.

### Figure 1-13 xLC in 1-Meg Modem Service



The 1-Meg Modem Service supports three types of xLCs. Each xLC supports different transmission rates and LCM drawer fill requirements. The following table lists the xLCs supported by the 1-Meg Modem Service.

Table 1-27 Types of xLCs in 1-Meg Modem Service

PEC	Maximum US/DS rates (kbit/s)	Maximum LCM drawer fill	PMs
NTEX17AA	960/120	16	All
NTEX17BA	1280/320	16	All
NTEX17CA	1280/320	31	All
NTEX17DA	12809/320	31	RLCM
			Star Remote Hub

An LCM line drawer can contain a mix of POTS line cards and different types of xLCs. An RLCM line drawer can contain either xLCs or POTS line cards. However, thermal constraints and power distribution determine the location and maximum number of each type of card. Refer to *1-Meg Modem Service Network Implementation Guide*, 297-8063-200, for more information.


*Data-enhanced bus interface card* The DBIC replaces the existing BIC in each LCM drawer with an xLC. The DBIC separates the voice and data traffic. The card multiplexes the voice traffic to standard DS-30A interfaces to the existing circuit switched voice network. The card multiplexes the data traffic to one 10BaseT Ethernet connection to the transport network.


The DBIC has the following features:

- half duplex, standard compliant 10BaseT interface
- auto-sensing feature allows DBIC to connect at 10BaseT or 100BaseT
- maximum of 31 xLCs in a drawer
- connected to all line card slots through XLBUS

- backwards compatible with all POTS line cards compatible with the NT6X54AA
- different media access control (MAC) addresses for each xLC and DBIC
- demultiplex 64 voice channels from receive data (RD) links to XLBUS links
- multiplex 64 voice channels from XLBUS links to transmit data (TD) links
- +12.7v CODEC reference to all 64 line positions
- controls ring bus and automatic number ID (ANI)/COIN voltages using relays

Any LCM line drawer that contains xLCs must have a DBIC. The following figure illustrates the DBIC in the 1-Meg Modem Service.





The 1-Meg Modem Service supports three types of DBICs. Each DBIC supports different transmission rates and Ethernet interfaces. The following table lists the DBICs supported by the 1-Meg Modem Service.

Table 1-28 Types of DBICs in 1-Meg Modem Service (Sheet 1 of 2)

PEC	Maximum US/DS rates (kbit/s)	Ethernet interface	PMs
NTEX54AA	960/120	10BaseT	All
NTEX54AB	1280/320	10BaseT	All

PEC	Maximum US/DS rates (kbit/s)	Ethernet interface	PMs
NTEX54BA	1280/320	10Base T or 100BaseT	All
NTEX54CA	1280/320	10BaseT or 100BaseT	RLCM
			Star Remote

Table 1-28 Types of DBICs in 1-Meg Modem Service (Sheet 2 of 2)

# **RSC ESA firewall**

An RCC enters ESA when communication to the C-side node is lost. When this happens, the RCC node is marked CBsy. CBsy indicates that either the C-side node or C-side links are OOS. DMS system actions are not permitted on a CBsy node. This effectively provides a firewall and protects the RCC from any detrimental system actions. When communication with the C-side node is restored, the RCC is marked SysB, so that the system can restore the node fully to an InSv state, (usually through an ESA warm exit).

When a DS-1 link on the C-side of an RCC is broken, the link goes SysB and the unit goes CBsy. If no other message supporting links are available, the node also goes CBsy. This status remains until one or more message supporting links are restored. At that time, the link goes InSv and the RCC node or unit goes SysB with a SysB reason of "CSLink RTS". The node or unit is then RTSed or exits ESA by the DMS system.

Feature AF6240 prevents a CBsy node from going SysB when the C-side links are SysB and futher to prevent a SysB link from going to a state of "OK" without first verifying C-side communications. This feature alters the way in which system maintenance recovers a CBsy RCC. Instead of the CM forcing a CBsy node to SysB, the system waits for carrier maintenance to recover the DS-1 link(s) and then recovers the RCC node or unit.

Feature AF6142 enhances ESA service by the following actions:

- enhancements to the commands at the RCC level of the MAP display to prevent detrimental human machine interface (HMI) request to an RCC in ESA
- The ESA condition is displayed at the MAP terminal when an RCC is found in ESA
- new and modified log reports.

The following enhanced MAP display commands perform an ESA query prior to executing a command to an RCC that may be in ESA.

- BSY
- TST
- RTS
- LOADPM
- QUERYPM
- PMRESET
- XPMRESET
- RECOVER

The DMS system response to the above commands provide the operating company personnel better information of the RCC ESA status, thus improving RCC maintenance and preventing accidential outages through unnecessary maintenance actions.

#### BSY command

An RCC in ESA may still be busied however, the operating company personnel must respond to a new warning such as:

#### Example of a MAP response:

>BSY PM WARNING - The RCC is in ESA. A manual ESA exit is required if the RCC is busied. Please confirm ("YES", "Y", or "NO", "N"): >Y A manual ESA exit is now required.

To attempt ESA exit, type RTS WARMEXIT

## **Command syntax**

# **TST** command

If an RCC is in an ESA mode, enhancements to the TST command prevents the actions, such as below, from being implemented:

Example of a MAP response:

>TST PM		
RCC 0 Unit 1	Request Invalid RCC is in ESA	
RCC 0 Unit 1	Request Invalid RCC is in ESA	
or		
>TST UNIT 1		
RCC 0 Unit 1	Request Invalid RCC is in ESA	
or		
>TST UNIT 0		

RCC 0 Unit 0 Request Invalid RCC is in ESA

The CM rejects the test request because this HMI command is detrimental to the service of the RCC operating in the ESA mode.

# **Command syntax**

#### **RTS command**

The enhancements replace the system driven ESA exit with a manual ESA exit driver. It halts processing when an error condition is encountered and better informs the operating company personnel regarding failures and alternative actions. The command syntax and responses are:

Example of a MAP response:

>RTS PM COLDEXIT
WARNING
COLDEXIT causes all stable calls to be lost
WARMEXIT allows stable calls to survive ESA exit

#### $\mathbf{or}$

>RTS PM EXITBYPASS
WARNING
EXITBYPASS bypasses ESA exit
All stable calls and ESA OM data will be lost
WARMEXIT allows stable calls to survive ESA exit.

## **Command syntax**

```
Parms: <DEVICE> {UNIT <UNIT_NO> (0 TO 1)
                    [ <NODATASYNC> (NODATASYNC)]
                    [ <CMR> (CMR)],
                PM [ <CMR> {CMR}],
                LINK <PSIDE_LINK> (0 TO 63),
                    ACTIVE
                    INACTIVE [ <NODATASYNC> {NODATASYNC}],
                       SYSB)
        [<FORCE>
                   {FORCE}]
        [<EXIT>
                   {WARMEXIT,
                    COLDEXIT,
                    EXITBYPASS ]
        [<NOWAIT> {NOWAIT}]
        [ < ALL > {ALL } ]
```

Three new parameters are added to the RTS command they are:

- WARMEXIT
- COLDEXIT
- EXITBYPASS

Examples of responses to the WARMEXIT parameter include:

Example response to WARMEXIT parameter:

>RTS PM WARMEXIT ESA warm exit passed or Request Invalid PM not in ESA or Request Invalid

PM does not support warm exit COLDEXIT option must be used

#### $\mathbf{or}$

ESA warm exit failed No response from PM. Check MSG LINKS at TRKS;CARRIER level. Attempt WARMEXIT after links are verified.

#### $\mathbf{or}$

ESA warm exit failed Execs are invalid COLDEXIT option must be used.

#### $\mathbf{or}$

ESA warm exit failed. Static data was changed. COLDEXIT option must be used.

Examples of responses to the COLDEXIT parameter include:

Example response to COLDEXIT parameter:

```
>RTS PM COLDEXIT
WARNING
COLDEXIT causes all stable calls to be lost
WARMEXIT allows stable calls to survive ESA exit.
Please confirm ("YES", "Y", "NO", or "N"):
>Y
ESA COLD exit passed
             \mathbf{or}
Request Invalid
PM not in ESA
             \mathbf{or}
ESA COLD exit failed
No response from PM
Check MSG links at TRKS; CARRIER level
Attempt EXIT after links are verified
Examples of responses to the EXITBYPASS parameter include:
Example response to EXITBYPASS parameter:
>RTS PM EXITBYPASS
WARNING
EXITBYPASS bypasses ESA exit
All stable calls and ESA OM data will be lost
WARMEXIT allows stable calls to survive ESA exit.
Please confirm ("YES", "Y", "NO", or "N"):
>Y
RTS passed
             or
Request Invalid
PM not in ESA
```

or

RTS failed No response from PM Check MSG links at TRKS;CARRIER level Attempt EXIT after links are verified

# LOADPM command

The enhancements prevent a LOADPM command execution on an RCC that is known to be in ESA. It also prevents ESA static data from being loaded into an RCC operating in simplex mode with valid ESA static sata in the active unit. The command syntax and responses are:

Example of a MAP response:

>LOADPM PM		
RCC 0 Unit	1	Request Invalid
		RCC is in ESA
RCC 0 Unit	0	Request Invalid
		RCC is in ESA

Try LOADPM INACTIVE to load inactive unit or Try RTS WARMEXIT tp force PM out of ESA then LOADPM

#### $\mathbf{or}$

>LOADPM UNIT 0 CC ESADATA RCC Unit 0 Request Invalid Node is ISTb

ESA Data download aborted due to lack of node redundancy. Existing ESA static data is valid

# **Command syntax**

Parms: <DEVICE> {UNIT <UNIT\_NO> {0 TO 1}, PM, INACTIVE, ACTIVE } [<SOURCE> {CC [<MODE> {FULL, DATA, EXEC, ESADATA, CMR, FIRMWARE, XPMSTOR ] [<FILE> STRING], LOCAL [<MODE> {IMAGE, LOADFILE } ] [<FILE> STRING]}] [<FORCE> {FORCE}] [<NOWAIT> {NOWAIT}] [<ALL> {ALL [<RFILE> STRING]}]

## **QUERYPM** command

The enhancement adds a new parameter to the QUERYPM command of ESA. The enhancement also denies QUERYPM CNTRS request when the RCC is in ESA. This prevents the reset sent down to query the counters if the RCC is SysB. The enhancement also display the current ESA status information and office parameters configuration from the office engineering table, OFCENG.

Example of a MAP response:

>QUERYPM CNTRS	
RCC 0 Unit 1	Request Invalid
	RCC is in ESA
RCC 0 Unit 0	Request Invalid
	RCC is in ESA

 $\mathbf{or}$ 

>QUERYPM ESA RCC ESA Subsystem Status

ESA static data is valid Expected ESA exit is Warm Dual ESA entry force down is Enabled RCC 0 is in ESA

OFCENG RSC\_ESA Office Parm Configuration

Nightly ESA static data downloading is Enabled Nightly ESA static data download at 1 am ESA exit requires manual intervention ESA exit will be performed by the system ESA exit timer set at 60 seconds ESA dial tone notification is Enabled

# **Command syntax**

Parms: [<OPTION> {ESA, FLT, CNTRS, FILES, DIAGHIST [<OPTHIST> {DIAG, CARD,

CARD, RESET ] ] ]

## **PMRESET** command

The enhancement allows the PMRESET command to bypass the ESA firewall on the RCC that is known to be in ESA. Resetting an RCC in ESA drops all stable calls for the ESA exit procedure. Example of a MAP response:

>PMRESET PM RCC 0 Unit 1 Request Invalid RCC is in ESA RCC 0 Unit 0 Request Invalid RCC is in ESA Use EXITBYPASS option to force reset PM in ESA. or >PMRESET PM EXITBYPASS WARNING EXITBYPASS allows the RCC in ESA to be reset. The PMRESET will drop the RCC out of ESA. All stable calls and ESA OM data will be lost. Please confirm ("YES", "Y", "NO", or "N"): >Y

# **Command syntax**

#### **XPMRESET** command

The enhancement allows the XPMRESET command to bypass the ESA firewall on the RCC that is known to be in ESA. Resetting an RCC in ESA drops all stable calls and discards all ESA operational measurements data for the ESA exit procedure.

Example of a MAP response:

>XPMRESET PM RCC 0 Unit 1 Request Invalid RCC is in ESA RCC 0 Unit 0 Request Invalid RCC is in ESA Use EXITBYPASS option to force reset PM in ESA. or >XPMRESET PM EXITBYPASS WARNING EXITBYPASS allows the RCC in ESA to be reset. The XPMRESET will drop the RCC out of ESA. All stable calls and ESA OM data will be lost. Please confirm ("YES", "Y", "NO", or "N"): >Y

# **Command syntax**

Parms: <DEVICE> {UNIT <unit\_no> {0 TO 1}, PM} [<OPTION> {NORUN, NODATA, EXITBYPASS}]

## **RECOVER** command

The enhancement allows the RECOVER command to bypass the ESA firewall on the RCC that is known to be in ESA. Recovering an RCC in ESA drops all stable calls and discards all ESA OM data for the recover procedure. If the RCC has NT6X45BA hardware or later this command can determine if the RCC has been loaded since power up. If the RCC has not been loaded since power up, it will be loaded and returned to service. If the RCC is in ESA and the EXITBYPASS option is not specified, an ESA exit is attempted. Otherwise an RTS is executed.

Example of a MAP response:

# **Command syntax**

```
Parms: [<NOWAIT> {NOWAIT}]
    [<ALL> {ALL}]
    [<EXITBYPASS> {EXITBYPASS}]
```

# **Enhanced PM log reports**

Some enhancements are made to the logs generated by the ESA exit process, refer to the DMS-100 Logs Reference Manual and the Extended Peripheral Module Logs Reference Manual (DS-1) for detailed information on these log enhancements.

# RSC ESA Exit simplification and recovery of the inactive unit

Feature AF6244 improves the reliability and reduses down time of single and dual RCCs by:

- Restructuring and simplifying the RSC ESA exit procedures.
- Providing a new interface to the ESA exit procedures for the RSC ESA HMI.
- Giving the single RSC ESA exit drivers the ability to recover an inactive unit prior to an ESA exit.

The ESA exit procedure and the ESA exit drivers are restructured such that the manual ESA exit driver, the system ESA exit driver and the dual ESA exit driver use the same ESA exit procedures.

A manual ESA exit driver, which uses the restructured common RSC ESA exit procedures, is provided to support the improvements to the RSC ESA exit HMI. This manual driver also returns additional error information so the RSC ESA HMI can determine what has occurred when the ESA exit fails so the operating company personnel can be advised as to what should be done next.

The ability to recover an at task inactive unit of the RCC prior to an ESA exit, permits a system warm ESA exit to proceed. When communication has not been restored to the active unit, an ESA warm SwAct is not possible. After the inactive unit is recovered an ESA warm SwAct to warm exit is possible. The RCC can be returned to service without an outage and without waiting for the message link to the active unit to be restored.

This feature also RTSes the inactive unit of the RCC when, the only unit of the RCC that the CM can communicate with, is at ROM level. After being RTSed, the ESA state of the RCC should be determinate. If the RCC is found in ESA it performs a warm exit from ESA and return the RCC to service without an outage. Previously the RCC would remain in ESA until manual actions recovered the RCC.

When the single or dual RCC is in ESA, it is queried every ten seconds as long as it remains in ESA. After it has been queried for the amount of time specified in the Office Parm RSC\_XPMESAEXIT, the exit is initiated. For cold ESA exit, this is simply requesting that the ESA exit message be sent and the ESA OMs collected. The single RCC is then turned over to Base XPM Maintenance to be RTSed.

For a warm ESA exit, the instant RTS of the single or dual RCC and its subtending nodes is initiated. Once the single or dual RCC and subtending nodes are in service, the procedure to setup the ESA calls is run. The ESA OMs are then requested and the RCC is turned over to Base XPM Maintenance to be RTSed if required.

# **Emergency stand-alone impacts**

Emergency Stand-Alone Impacts (XPM) is a feature that improves the NI-2 compliancy of ESA call processing on the RCC2. It allows several NI-2 XPM09 activities to function properly or without detrimental results.

The following list presents the specific NA009 ISDN enhancements.

- support for more than two B-channel logical terminals on a BRI loop (any combination of initializing and noninitializing NI-2 logical terminals up to a maximum of eight)
- parameter download (PD) trigger following ESA EXIT
- associated groups on a terminal service profile (TSP) basis
- BRI on a residential line

# Support for more than two B-channel logical terminals on a BRI loop

This feature is supported in ESA mode by increasing the capacity to hold up to 14,436 directory numbers (DN). Dual configuration is also supported.

# Parameter download notification

During ESA, a fully initializing terminal (FIT) can reinitialize layer 2, then reinitialize layer 3 with a different service profile identifier (SPID), associating itself with a different LTID. The LTID is datafilled and attached to the loop. The newly initialized LTID can both originate and terminate calls within ESA. Because the RCC2 cannot communicate with the CM, service profile management (SPM) similar to PM is blocked. A failed PD request leaves the ISDN set with the same values it had prior to the request. USER must manually program into the set any new data associated with the new LTID. Sets that initialized layer 3 with a new SPID during ESA associate themselves with a different LTID. Following ESA EXIT, these sets are left with old data that may not be relevant to the new LTID.

PD notification is invoked from the ESA EXIT code to notify only those logical terminals (LT) that need a PD. This happens in WARM ESA EXIT, when communication is restored to the CM and call takeback has finished.

If ESA ENTRY reoccurs before this activity completes, the PD notification process aborts. This is because there is no communication with the CM. The check for ESA ENTRY is part of the Emergency Stand-Alone Impacts (XPM) feature.

# Associated groups (AG) on a TSP basis

AGs on a TSP basis provide the user with the ability to restrict B-channel usage. The user can have a particular interface for a specific application. This limits the call types employed on the B channels or restricts B-channel access for particular directory number/call type (DN/CT) combinations.

# **BRI on a residential line**

BRI on a residential line allows the operating company to provide ISDN lines to residential and small business customers without elaborate circumvention of centralized private branch exchange (CENTREX). By eliminating the need for separate customer groups for single line ISDN sets, the operating company reduces its cost of ownership.

# Remote cluster controller 2 with integrated services digital network

The RCC2 can be configured with ISDN services for RSC-S. The functional areas of the RCC2 with ISDN include the following:

- cards
- speech and message paths

- host ISDN peripherals
- enhanced LCM (LCME)

*Note:* Figure Functional block diagram of the RCC2 with ISDN relates to the functional description of the RCC2 with ISDN that follows.

## Cards

The RCC2 with ISDN is based on RCC2 with the addition of the enhanced ISDN signaling preprocessor (EISP) card and the DCH card. Use of the NTMX81 card occurs when clear DS-1 channels are needed.

The DCH card is an ISDN line group controller (LGCI) or ISDN line trunk controller (LTCI). The DCH card provides the primary interface to all D-channels and performs Q.921 link access procedure on D-channel (LAPD) layer 2 processing. The DCH is permanently connected to an ISDN loop and receives or sends messages on the signaling and packet data channel.

The EISP card provides a communication channel between the UP and the DCH cards.

The DS-1 cards (specifically NTMX81) provide the 64-kb/s clear channels necessary to process D-channels.

#### Speech and message paths

The speech and message paths of the RCC2 with ISDN are like the RCC2 without ISDN. The addition of DCH, EISP, and DS-1 (NTMX81) cards allows the RCC2 to process calls from ISDN terminals.

The DCH cards provide the Q.921 function and the processing for the D-channels from the ISDN loops that terminate on ISDN line cards. The DCH interprets the service access point identifier (SAPI). Data with SAPI 16 (packet data) is sent over Bd links to the PH. The system routes the SAPI 0 (call control messages) data to the EISP for further processing. SAPI 17 messages are returned back on the same loop.

A DCH resides in a P-side port and terminates a single port, which consists of 32 64-kb/s time slots. Time slot 0 is reserved for messaging to the EISP. The other slots support basic rate interface (BRI) D-channels to ISDN terminals, or Bd channels to the PH.

## Host integrated services digital network peripherals

The RCC2 can connect to an LGCI or an LTCI.

One of the main functions of the host XPM is to terminate the DS-1 links from the RCC2 and pass the circuit-switched traffic to the network. As with the RCC2 without ISDN, this traffic is nailed-up through the RCC2 and is

nonconcentrating. The other capabilities of the host XPM depend on how the RSC-S with ISDN is configured.

How data-switched traffic is to be handled also affects the other capabilities of the host XPM. The following is a list of host XPM capabilities:

- provides P-side DS-1 links to the PH if the PH is at the host
- terminates LCMs directly

*Note:* If the host XPM does not have to support an ISDN line concentrating module (LCME) directly. An LGC or LTC can support an ISDN LCME.

- terminates LCMEs directly if the host XPM is an LGCI or LTCI
- allows the RCC2 to support trunks if the host XPM is an LTC or LTCI

#### Enhanced line concentrating module

The LCME uses the two binary one quaternary (2B1Q) U-loop interface to provide the subscriber with BRI. Northern Telecom (Nortel) uses 2B + D channels, and six maintenance channels located throughout the 2B1Q superframe. these channels provide the North American Standard 2B1Q U-loop interface.

#### Line concentrating module


The RSC-S can be provisioned with an LCM. The RSC-S provisioned with an LCM does not support ISDN. The RSC-S with LCM offers coin and automatic number identification (ANI) support and increased line density (640 versus 480).

The LCM has six internal DS30A ports that consist of two message ports and four speech links. Thirty external ports are available for connection to LCMs or LCMEs.

The following figure is a functional block diagram of an RCC2 with ISDN.

## **1-76** Maintenance overview

## Figure 1-15 RCC2 with ISDN



# **Fault conditions**

The RSC-S includes internal monitoring systems that detect fault conditions. The following section describes fault conditions that automatic maintenance monitors, and automatic maintenance features. The configurations describe the RSC-S fault conditions.

# Remote cluster controller 2

The RCC2 fault conditions include errors specified to processor cards and errors that are not specified to processor cards.

## Errors specific to processor cards

The following errors can occur in RCC2 processor cards:

traps

errors that hardware or software causes. Traps occur when the CC receives a gain message that the new active unit does not request.

• software errors (SWERR)

errors caused by software.

- intermittent, soft parity, or hard parity, and exception faults
  - intermittent

The system detects a fault but does not detect an error during the reread of the location.

— soft

The system detects a parity error and detects an error when the RCC2 attempts to read the location again. The system does not detect an error when the RCC2 attempts to write to the location. The error can occur in the program store (PS) or memory store.

— hard

The RCC2 detects a fault and cannot reread or write to the memory location. The hardware is defective. You must replace the associated memory card to correct the fault.

exception

A special condition at the ROM or task level interrupts normal processing. Exception handling includes exception detection, data capture, and recovery. Exception services include exception administration, reporting, and data access and display. Internal and external conditions can cause exceptions.

The following *Internal* conditions can cause an exception:

- illegal instructions
- address errors
- tracing

- breakpoints
- coprocessor protocol violations

The following *External* conditions can cause an exception:

- interrupts from external devices
- bus errors
- coprocessor-detected errors
- resets

Exceptions that are fault conditions appear in the following table. These fault conditions require maintenance.

Туре	Fatal	Description
1	No	Value range error
2	No	Segment not present
3	No	Exit from uncalled procedure
4	No	Stack overflow
5	No	Floating point
6	No	Division by zero
7	No	Nil pointer reference
8	No	Not used
9	No	Not used
10	No	I/O error, result of system procedure IOCHECK
11	No	String
12	No	String indexing
13	No	Set error
14	No	Bad CSP, system does not implement standard procedure
15	Yes	Bad P-code instruction
16	No	Task error
17	Yes	Request for reset—Trap 7

 Table 1-29 XPM error type and description (Sheet 1 of 2)

Туре	Fatal	Description
18	No	Not used
19	Yes	Parity error
20	No	Addressing error
21	No	Illegal instruction
22	Yes	Spurious interrupt
23	No	Bus error
24	No	MMU error
25	No	Not used
26	No	Privilege violation
27	Yes	Sanity timeout

 Table 1-29 XPM error type and description (Sheet 2 of 2)

# Errors not limited to processor cards

The following list contains errors that are not limited to RCC2 processor cards:

• static data mismatch faults

Static data defines the RSC-S configuration and does not change when the system connects and disconnects calls. When static data in the host and the RCC2 do not match, data corruption can occur. The host can recognize a line when the RCC2 does not recognize the line. A loss of calls can occur.

• unit node table mismatch faults

Each XPM unit has tables that contain information about nodes the XPM connects to and terminals the XPM uses. The following two systems determine unit table mismatches:

- Mate unit matching compares the inactive unit tables with the active unit and sets the XPM ISTb if mismatch occurs. The active unit sends table mapping information to the inactive unit during updates.
- Node table audits determine if the information relates to data in the computing module (CM) table PMNODES. To prevent differences in datafill for the XPM units, the CM maintains all node information. For a complete description of the datafill for table PMNODES, refer to the *XPM Translations Reference Manual*. Feature AF5678 introduced table NODES.

Feature AF5678, Node Table Sync Redesign, introduces the following error handling changes.

- Table Control applications that change inventory tables reject tuples that a peripheral cannot support. The system cannot support tuples when a peripheral does not provide the required resources.
- The node table audit raises an ISTb condition on an XPM that has a node table mismatch with the CM. You must BSY and RTS the whole XPM to clear the ISTb condition.
- A negative acknowledgment from the XPM can occur when the configuration data table (CDT) node or port information downloads during a bulk download. The system can abort the loading or RTS process.
- A negative acknowledgment from the XPM can occur when the node CDT or port CDT data downloads during a dynamic configuration update. The system raises an ISTb condition on the XPM.
- Feature AF5678 creates two new PMDEBUG commands. Operating company personnel determine which tables are bound to the CDT data distribution. These commands allow operating company personnel to

display tuples in the tables. The syntax of the commands appears in the following list.

- To display a minimum of one tuple in a table bound to CDT management when in the CHNL:PROT level of PMDEBUG, enter
  - To obtain a list of the XPM data tables bound to CDT management, when in the CHNL:Prot level of PMDEBUG, type

#### >SHOWTBLS

#### without parameters

 To display a minimum of one tuple in a table bound to CDT management when in the CHNL:PROT level of PMDEBUG, type

#### >DISPTBL table\_id [<tuple\_no> | R <begtuple> <endtuple> | all ]

where

#### table\_id

is the name of the table that appears

#### tuple\_no

is the number of a specified tuple that appears

# R

is a range of tuples that appear

# begtuple

is the beginning tuple of the range

#### endtuple

is the end tuple of the range

#### all

is display all tuples in the table

If the table identification appears, all tuples appear in a list. Press the RETURN key to abort the list.

*Note:* Feature AF5678 XPM Node Table Sync Redesign changes the start of the command RTS with the NODATASYNC option. Refer to the *Trouble isolation and correction procedures* in this document.

Additional specified faults not related to cards:

intermodule communication faults

When two RCC2 units cannot communicate with each other, a warm SWACT cannot occur. Intermodule communication faults cause this

condition. A warm SWACT cannot occur because one unit does not know the type of information the other unit processes.

• messaging overload on speech bus cards

Messaging overload conditions can prevent the transmission of data from the CMR and UTR cards. The RCC2 can receive messages that support ADSI protocol for display-based features. The RCC2 forwards these messages to the CMR card. The CMR card forwards the data to the CPE. The CMR can receive the request to transmit data. If modem resources are not available, the CPE does not receive display data. An overload in the CMR causes this condition.

The CPM must receive an acknowledgment (ACK) tone from the UTR card to transmit data. The CMP transmits display data to the CPE. If the UTR card does not contain available channels to transmit the ACK tone, the CPM does not send the display data.

# **Dual remote cluster controller 2**

Interlink corruption can occur in a DRCC2. When interlink corruption occurs over messaging interlinks 0 and 8, the peripherals cannot communicate. Interswitched calls cannot occur.

# Remote cluster controller 2 with integrated services digital network

An RCC2 with ISDN can have the same faults as an RCC2 that does not have ISDN. Problems can occur when the RCC2 with ISDN attempts to send and receive data packets and call control messages. These problems normally involve the DCH card.

# Automatic maintenance

This section describes how audits and system actions identify fault conditions. The system can adjust the fault or produce a log that identifies the problem.

## Exception processing system

Feature AF5680, Exception Processing System Enhancements, provides improvements in exception handling and exception services. These improvements increase the strength of the RCC2. The exception processing system improvements support the following functions:

- removal of trap data loss when multiple traps occur in a period of 10 s
- accurate capture of trap-specified data
- guaranteed survival of trap data over restarts and reloads
- capture of both supervisor and user stacks at exception time
- circular buffer management at exception time
- enhanced trap administration

- expanded trap-specified error information to accommodate parity fault requirements. The exception processing system reports parity faults to the parity audit. This system does not report the CC.
- storage of the trap system version for each trap
- traceback support on patched procedures

**ROM-level exception processing** On initialization, the firmware maps all vectors to local exception handlers. The ROM-level exception processing performs the following functions:

- minimizes error records and reports
- establishes a bootstrap environment
- provides debug utilities
- allows for abstraction of memory management hardware

**Task-level exception processing** Task-level exception processing reports important information on hardware and software states. Task level exception processing reports this information when a hardware or software fault prevents normal operation of the CPM unit. The process attempts to restore the task to a known start point and allows the task to perform recovery actions. If the task cannot recover, the task-level exception processing initiates local maintenance to restart or reset the CPM unit.

**Exception processing system trap recovery** The exception processing system interacts with the CC, PMDEBUG, and local maintenance in the CPM to recover from error exceptions. The exception processing system reports and displays information about error exceptions.

Exception recovery consists of three different operations:

- determine how important a trap is. The trap can be fatal or recoverable.
- process fatal trap
- recover task, not-fatal trap

When the exception processing system detects a fatal error, the system initiates local maintenance action to drop activity in the active unit. The system initiates local maintenance action to reset or restart the CPM unit. When the CPM is INSV, the CPM sends exception errors to CC in the form of messages that are not requested. The CPM generates a report for each exception not reported in the trap buffer. The CC receives the report, acknowledges the message, and logs in PMDEBUG to access the exception information. The CC generates a PM185 log report for each trap.

The PMDEBUG can view and delete exception data from the trap buffer at the task level. Changes occur in the display routines that correctly reflect data

capture differences for required improvements. An example of the PMDEBUG debug TRAPINFO level display appears in the following figure. At the ROM level, exception data appears as a hex dump.

#### Figure 1-16 Example exception display with improvements

```
Run Load name = NLT02WY
MP ron name = XPMRKA03, SP rom name = XPMRKA03
trap in MP : Div by 0
Trap was Recoverable. Unit was Active/Busy
Task: BASEMON 0009 0009 Trap Sequence #: 1 Current load
PP Time : 00:00:22:04.70
Occurred at : 001951DF DEBUG 21 DOZERRODI 115 Offset: #21
Called from : 000D8A80 BASEMON 18 TDRIVBOD 30 Offset: #228
 000D8B8C BASEMON 18 TERMDRIV 11 Offset: #18
PC:000010AA SR=2100 US=0001FEB2 SS=001ABFF6 TCB=0001F00C
DO =0000FFFF D1 =00090000 D2 =FFFF0101 D3 =0000FF00
D4 =000100FF D5 =FFFF0009 D6 =00000B0D D7 =001A0000
A0 =0001F924 A1 =0001F92C A2 =0001FEB2 A3 =001951DF
A4 =000A6F6E A5 =0001FEC2 A6 =000F9BC2 A7 =001ABFF6
System Stack:
0017ABFF6: 0004 0000 0006 0001 F00C 000A 000A 0998
0017AC006: 0004 0000 0006 0001 F00C 000A 000A 0998
User Stack:
0001FEB2: 0004 0000 0006 0001 FOOC 000A 000A 0998
0001FEC2: 0004 0000 0006 0001 F00C 000A 000A 0998
0001FED2: 0004 0000 0006 0001 F00C 000A 000A 0998
```

When recovery is complete, the exception reporting system learns that trap data is available and exception handling is complete. The recovery process:

- sets up the trapped task for recovery and allows the task to continue or
- initiates a maintenance action to restart or reset the unit.

If the trap is not fatal, the system restores the selected task to a start point that allows the task to return to a known state. For recovery to occur, the task must exit many levels to return to the task mainline.

The task recovery model specifies that a task must provide a mainline. A mainline is a continuous loop that repeats calls to the main body of the steady state code. A call to a recovery procedure can follow. When the task follows a recoverable trap again, the task must return to the instruction that follows the call to the main body of code. This instruction is a call to a recovery procedure or a branch back to the loop start.

**Memory management unit error recovery** The enhanced exception processing system feature provides an improvement to exception recovery.

This improvement works with the direct memory access memory management unit (DMA MMU). When a DMA MMU error occurred before the improvement, the exception processing system convicted the interrupted task. The system convicted the task even though the software on the NTMX77 did not cause the error. The convicted task determined if the error was fatal. An MMU error is not fatal. The processor that caused the fault did not recognize the problem.

With the improved feature, the external processor receives invalid data if the access is for a read from NTMX77 memory. If the access is to write to NTMX77 memory, data is not written. The processor identifies a fatal trap and initiates maintenance action to restart or reset the unit.

# EDC protection for babbling links

Feature AF4915, EDC Protection for Babbling Links, provides software support of outgoing message channels on the NTMX76AA circuit card. Outgoing message channel management reduces the number of lost messages.

The NTMX76AA circuit card uses CCITT level 2 signaling (Q.703) over data channels. The NTMX76AA circuit card provides message interface to the UP. A maximum of 32 high-level data link control (HDLC) message channels are available for interface to the UP. To allow HDLC messaging, the host and remote offices must have the NTMX76AA circuit card.

The HDLC messages transfer through message buffers allocated in the common RAM. The NTMX76AA circuit card performs checks to verify the HDLC messages. This card copies the message to the R8071 Rockwell memory buffer. To receive a message in the R8071 data link, the NTMX76AA circuit card copies the message from the R8071 memory to the message buffer. The system queues the outgoing buffer in the R8071 transmit queue if the number of queued buffers is less than the maximum allowed. If the queue is full, the message returns.

The following section describes two messaging concerns. These concerns are channel management and overload.

**Channel management** When the RCC2 or LGC plus is ready to send a message on an HDLC link, the message is copied to a buffer. The message is copied to a buffer in the NTMX76AA circuit card. The NTMX76AA circuit card sends the message on the correct destination link. The message to send determines the correct link. The NTMX76AA circuit card contains a limited number of buffers used for messaging and R8071 transmit queues for a specified link. This feature controls the rate of outgoing messages. This action allows buffers for message transmission to remain available.

**Overload** An overload condition occurs when a messaging link receives too many messages in a specified time. An overload condition can occur if the

link increases the output to a destination. If a link becomes overloaded, the channel management system does not allow a transfer of messages to the NTMX76AA circuit card. The channel management system stores the messages in a holding queue until the system clears the link.

A description of the REx test and SWACT process, and the audits and system actions appear in the following section. The audits and system actions identify fault conditions related to RSC-S components.

## Loop recognition for HDLC links

Feature AN1523, Loop Recognition for HDLC (EDC) links, supports loop recognition in the HDLC protocol on the NTMX76AA. This feature detects loop conditions that are not required on the messaging channels in the LTC+ and the RCC2. When Feature AN1523 detects a loop that is not required, related protocol operational measurements (POM) increase. The EDC shelves alert the CC of protocol problems, like negative acknowledgements (NACKS), through the operational fault (OPF) system. The CC receives the alert and starts correct maintenance. The CC sets the RCC2 SysB, starts a SWACT, or causes the RCC2 to enter ESA.

*Note:* For Feature AN1523, loop refers to the recovery of the current transmitted data on the receiving side of the same link. The loop does not refer to the connection of links between the P-side output and another P-side link input.

#### Switch of activity

A SWACT occurs when two units of an XPM exchange activity state. The active unit that handles call processing becomes the inactive unit and the inactive unit becomes the active unit. The inactive unit controls call processing.

The SWACTs can be controlled or uncontrolled. The following events cause controlled SWACTs to occur:

- manual action, link the entry of a SWACT command
- planned system requests, like the REx test schedule
- system action to busy the active unit when the inactive unit is INSV.

If both units are INSV, a controlled SWACT can occur. If the RCC2 is ISTb because a previous REx test failed, a controlled SWACT can occur.

The system implements uncontrolled SWACTs when a hardware fault or a trap occurs in the active unit. The PM181 log messages indicate to operating company personnel the reason the active unit dropped activity.

In a controlled SWACT, the following message exchange occurs:

- The CC messages the active unit of the RCC2 to start an audit of the inactive unit.
- The active unit messages the inactive unit to start a pre-SWACT audit.
- The inactive unit messages back to the active unit the pre-SWACT audit results. The audit results determine if the system can start a warm SWACT.
- The original active unit remains INSV and clears data that is not stable.
- The new active unit sends five gain messages to the CC.
- The CC sends five gain-acknowledge messages to the RCC2.
- The RCC2 sends three gain-acknowledge received messages to the CC.
- The CC signals the original active unit to drop activity.
- The original active unit sends the CC a drop message, and the CC expects to receive this message.

If a controlled warm SWACT fails, the following message interchange occurs:

- The CC messages the active unit of the RCC2 to start an audit of the inactive unit.
- The user implements the pre-SWACT audit.
- The audit results determine if the system initiates a warm SWACT.
- The original active unit stays INSV and clears data that is not stable.
- The new active unit does not send messages to the CC.
- The wait time of the original active unit expires and a SWACT-back occurs.
- The original active unit sends a SWACT-failed message to the CC.
- The CC SysB and RTS the inactive RCC2 unit.
- If the CC does not receive any messages, the CC sets both units of the RCC2 to SysB. The CC returns to service both units of the RCC2.

In an uncontrolled SWACT, the RCC2 initiates the pre-SWACT audit. The sequence of messages is as follows:

- The active RCC2 unit messages the inactive unit to start a pre-SWACT audit.
- The user implements the pre-SWACT audit.
- The system initiates a warm SWACT based on the audit results.
- The new active unit messages the CC that a gain that is not solicited occurred.

- The original active unit stays INSV and clears data that is not stable.
- The new active unit sends five gain messages to the CC.
- The CC sends five gain-acknowledged messages to the RCC2.
- The RCC2 sends three acknowledge-received messages to the CC.
- The CC tells the original active unit to drop activity.
- If the CC does not receive any messages, the CC sets both units of the RCC2 to SysB. The CC returns both RCC2 units to service.


Controlled and uncontrolled SWACTs consider the SWACT complete when the CC receives the gain message from the new active unit. Controlled and uncontrolled SWACTs consider the SWACT complete when the CC acknowledges the gain to the original active unit. When a SWACT occurs, the CC and the RCC2 exchange a series of drop and gain messages to clarify the condition. Common phrases that occur in these messages appear in the following table.

Table 1-30 Message phrases that describe CC to RCC2 SWA	СТ
communication	

Message phrase	Explanation
Original active unit	Active unit before the SWACT (unit 0)
Original inactive unit	Inactive unit before the SWACT (unit 1)
Newly active unit	Active unit after the SWACT (unit 1)
Newly inactive unit	Inactive unit after the SWACT (unit 0)
Gain message	The message the new active unit (unit 1) sends to the CC tells the CC that unit 1 gains activity.
Gain acknowledge message	The message the CC sends to original active unit to confirm the new active unit sends messages.
Gain acknowledge received	Message original active unit sends to CC to confirm the new active unit passes the post-SWACT audit.
Drop message	Message the original active unit (unit 0) sends to the CC to tell the CC that unit 0 dropped activity.

The order for a controlled and uncontrolled SWACT and the SWACT-back operation of feature AN0538 appears in the following figure. The following sections discuss this feature.





**Pre- and post-SWACT audits** To improve the warm SWACT operation, feature AN0538, RCC2 Pre-SWACT/Post-SWACT Audit denies the SWACT if the inactive unit cannot maintain activity or communication with the CC.

Feature AN0538 can SWACT-back to the original active unit. The software that drives this feature is the SWACT controller and an autonomous capability added to the RCC2 software. The SWACT controller is in the CC.

**SWACT controller** The system routes manual requests and selected system requests for warm SWACTs to the SWACT controller in the CC. The SWACT controller polls PM diagnostic history data located in the CC and RCC2 state data. The controller does not poll static data. Polled data determines if the SWACT controller denies the request for a warm SWACT or allows a warm SWACT to proceed. During the SWACT, the new inactive unit remains in service. The new inactive unit cleans data structures left in states that do not have stability.

**Pre-SWACT audit** Before a SWACT occurs, the active RCC2 unit queries the mate RCC2 unit over the intermodule communication (IMC) links. The active RCC2 unit messages the SWACT controller in the CC. Feature AN0538 improves the pre-SWACT audit of the inactive unit to include the state of the unit during diagnostics. Feature AN0538 assigns a weighted value to the results of the diagnostics. The result of the pre-SWACT audit query is a boolean pass or fail.

If the SWACT controller denies a manual request for a warm SWACT, the MAP terminal alerts you of this information. The MAP terminal provides you with a detailed reason for the denial. You can enter the SWACT FORCE command to supersede the SWACT controller. If you override the SWACT controller, the system does not consult diagnostic history or state data to attempt a warm SWACT.

**Post-SWACT audit** The system busies and returns to service the inactive unit after a SWACT if:

- two-way communication with the CC is available
- the new active unit can maintain activity

The previously active unit remains in service until the new active unit can verify two-way communication with the CC. The new active unit must also verify the capability to maintain activity. If communication fails, or if the new active unit cannot maintain activity, the RCC2 performs a SWACT-back. The SWACT-back is to the originally active unit.

**SWACT-back** If an RCC2 does not receive a gain-acknowledged message from the CC, the originally active RCC2 unit initiates a SWACT-back. During a SWACT-back, the originally active RCC2 unit attempts to regain activity. If successful, the inactive unit is set SysB and returned to service, and the active unit remains in service. The system preserves calls with stability from the original active unit over the SWACT-back. The system drops calls made after the SWACT and before the SWACT-back. If a SWACT-back is not successful,

a cold SWACT occurs. The system sets both RCC2 units to SysB and returns the units to service.

*Note 1:* The system does not initialize operational measurements (OM) and peg counts after a SWACT-back.

*Note 2:* The system does not support this feature during RCC2 or CC overload.

The SWACT-back functions for the following manual SWACT commands are:

- SWACT
- SWACT TST
- SWACT NOW
- SWACT ALL
- SWACT FORCE
- TST REX NOW
- BSY UNIT unit\_no

where

unit\_no is the number of the active unit

• BSY ACTIVE

*Note:* The system provides a SWACT-back for a REX test initiated that the REX scheduler initiated. For additional information how this feature interacts with REX tests, refer to Routine exercise test.

**Manual switch of activity** To perform manual SWACT, enter the SWACT command at the MAP terminal. The following message appears at the MAP display.

## Example of a MAP response:

A warm SWACT will be performed after data sync of active terminals are attempted. The inactive unit may not be capable of gaining activity (please check logs). Do you wish to continue regardless? Please confirm (YES or NO)

The default must not proceed. The newly inactive unit can control call processing again.

**Uncontrolled switch of activity** An uncontrolled SWACT can occur when both units are INSV, the active unit is INSV, and the inactive unit is ISTb.

An uncontrolled SWACT can occur when the active unit is INSV and the inactive unit is SysB. Each of these states results in a different SWACT condition. The state of the units and the reason for the activity drop determine the sequence of events during an uncontrolled SWACT.

If a hardware fault occurs, the system generates a PM181 log. The log can contain messages that indicate the following:

- activity timeout
- no CC links

The message links to the CC or host XPM are broken. Messaging cannot occur.

• duplicate fault

A critical hardware fault occurred.

• jammed

the unit cannot change the active or inactive state because the unit is jammed.

• DRCC2 sync

The original active unit of a DRCC2 cannot continue to process calls. The unit must SWACT to allow the RCC2 to synchronize with the spouse RCC2.

• ready for ESA

This message deals with the RCC2. In this condition, the loss of all CC messaging can occur. If the original inactive unit does not send a drop message in a specified time period, the RCC2 enters ESA.

- static data corruption
- originally active unit sends a drop message to the CC.
- new active unit must send a gain message.

The XPM continues to send the gain message at a maximum of 15 s.

An uncontrolled SWACT can occur if the originally active unit is INSV and the original inactive unit is ISTb. This condition depends on the reason the inactive unit is ISTb. The inactive unit can be ISTB because of data synchronization. The condition is the same as when the active and inactive units are INSV. If the inactive unit is ISTb because of data synchronization, the originally active unit drops synchronization. The XPM starts again.

If the originally active unit is INSV for less than 3 min, the unit returns to service without the OOS diagnostic. The unit returns to service without the OOS diagnostic because a previous SWACT occurred. If the SWACT

occurred in less than 3 min previous to the current attempt, the active unit had OOS diagnostics run at that time. If the original unit is active more than 3 min, the active unit returns to service with OOS diagnostics.

Regardless of the type of RTS, the active unit attempts return to service. If the active unit cannot return to service, the system sets both units in the XPM to SysB.

# **Routine exercise test**

A REx test includes a series of tests performed on an XPM unit. The system scheduler or manual action by operating company personnel starts the REx tests each day. The REx test combines the diagnostic and functional routines available on XPMs. The REx test results can be grouped in four classes:

- not performed
- passed
- failed
- aborted by manual action. Maintenance action with FORCE parameter or with ABTK command from another MAP terminal with XPM posted causes the test to abort.

All four classes generate a log or display a message at the MAP terminal. The maintenance record contains only passed and failed REx. The user can access failure reasons only for failed REx tests.

The sequence of events the REx test state machine or controller performs, appear in the following numbered list:

- 1. Test the inactive unit. Test includes INSV tests only.
- 2. SysB the inactive unit.
- 3. RTS the inactive unit. This action includes out-of-service (OOS) tests only.
- 4. Wait for superframe and data synchronization to occur.
- 5. Perform a pre-SWACT audit.
- 6. Perform a warm SWACT.
- 7. Maintain call processing capability on previous active unit.
- 8. Perform a post-SWACT audit.
- 9. SWACT back to previously active unit, if necessary.
- 10. SysB the newly inactive unit.
- 11. RTS the inactive unit.
- 12. Wait for superframe and data synchronization to occur.

13. Run INSV diagnostics (TST) on the newly active unit.

14. Run INSV diagnostics (TST) on the inactive unit.

The REX test state machine controller actions appear in the following figure diagram.




Figure 1-18 REx test state machine actions

If a REx test fails, the system generates a PM600 log. The PM600 log initiates a major alarm for the XPM that failed the REx test. The major alarm appears at the MAP terminal under the PM banner at the top of the display.

If an INSV or OOS diagnostic test fails, the REx test failure reason includes the following:

- the mnemonic, an easy-to-remember abbreviation, of the diagnostic that failed
- the unit that failed (0 or 1)

The PM600 log details the start time of each step the REx test initiated, the unit the REx test step affects, and the failure reason. The REx test steps included in the log after the failed step are recovery actions. The REx test initiates these recovery actions because of the REx test failure. The unit number appears in this log only if the REx test action is unit-specified, like BSY unit, RTS unit, TST unit, or synchronization. The unit number does not appear if the REx test action does not affect the node, like SWACT, BSY both units. Additional data of the log consists of a card list and a mnemonic of the failed diagnostic.

The following commands contain information about the last REX test:

- QUERYPM
- QUERYPM FLT
- TST REx QUERY
- TST REXCOV QUERY

Manually and system-initiated REX tests store and display a new date, time, and state. The state can be passed or failed. The REX test maintenance record contains this information. *Passed* means that the REX test completed with no errors. *Failed* means that the REX test did not complete because an error was present. The user enters the QUERY PM and TST REx QUERY commands to access this information. If the REX test fails, operating company personnel perform a manual RTS, a manual REx test, or an automated REx test. Operating company personnel initiate one of these tests to return the XPM to service from ISTb.

A REX test maintenance record stored for each XPM contains the

- REX test scheduler, if the XPM is in the system
- date, time, and result of the last REx test. The result is passed or failed.
- failure reason, diagnostics failures, and a list of defective cards, if the last REX test failed
- date and time of previous REX test that failed
- date and time of first passed REX test that follows the previous failure

Limits that apply to REX tests appear in the following list:

- The system REX test controller runs a REx test on one XPM at a time if the office uses the NT-40 processor. SuperNode supports REx tests that run at the same time. These REx tests run for a maximum of ten XPMs with the same REx test class.
- A maximum of four LCM\_REx\_TESTs can run at the same time if a REx test for the HOST XPM of these limits is not currently in progress.
- The SREx scheduler schedules LCM\_RExCOV tests for converter and ringing voltages in LCM separately.
- For a REx test to run, the node must be one of the following states:
  - INSV, ISTb because of a REx test failure
  - ISTb because P-side DS-1 links are OOS.
- If a warm SWACT does not occur, a REx test terminates.
- After a REx test completes, the XPM has a newly active unit because of the SWACT.
- If a restart occurs when a REx test is in progress, the system does not generate the PM600 log. The system does not generate the PM600 log because the restart deallocates the temporary DS that generates the PM600 log.
- A manual REx test cannot access a SWACT controller override.

## **REX test state machine interface to the pre-SWACT and post-SWACT audits** The REx test state machine or controller

- calls the pre-SWACT audit, messages the other unit, and the warm SWACT occurs if the audit passes
- accounts for SWACT denial and failure reasons
- terminates a REx test if the controller denies SWACT
- terminates a REx test if a SWACT back occurs. This action occurs when the active unit of the XPM does not change from the time the REx test started. A REx test performs the recovery. The recovery consists of a busy (BSY) and an RTS of the inactive unit.
- displays the failure reason for a SWACT denial or failure performed during a manual REx test at the MAP terminal. The controller displays REx failed as the result. The user can enter the TST REx QUERY command string for the posted XPM to access the reason for the failure. The system generates a PM600 log report that details the REx test failure reason.

## System REX controller: XPM maintenance

Feature AF3771, System REx Controller: XPM Maintenance, provides the SuperNode switch with an S/DMS system REx test (SREx) controller. The

SREx coordinates all system REx tests under a common REx test scheduler. The REx test scheduler can schedule LCM REx tests when other REx tests are in progress. The SREx test controller performs a REx test on the whole switch in less time. The test runs on all peripherals, like the RSC-S, in less time. The REx tests indicate faults that can affect service. The tests allow operating company personnel to take corrective measures. The NT 40 systems use IORExP for LGC node types.

Feature AF3771 allows the controller to locate and resolve REx test failures sooner. This feature helps reduce outages in the field. The SREx test controller allows operating company personnel to

- change the order in which the system tests peripherals
- coordinate between manual- and system-initiated REx tests
- receive alarms for the RSC-S that are not REx tested in a time limit set. The time limit appears in table RExSCHED

The SREx test scheduler allows the user to enter the CI level RExTEST command and the following parameters:

- The SUSPEND suspends REx tests for one maintenance window. A maintenance window is the time between the REx START and STOP time entered in table OFCVAR under the NODERExCONTROL parameter.
- The RESUME resumes REx tests after the system suspends REx tests.
- The QUERY returns the state of the REx test. The state can be active or suspended.
- The HELP returns a short description of the REx test.

The REx test order for feature AF3771 is as follows:

- critical nodes, like communications module [CM] and MS
- the number of days since the last system or manual REx test second
- the order of internal PM (RSC-S) number last

Table RExSCHED must be entered to establish the REX test schedule for the RSC-S. This table contains the information that the REx test coordinator requires. The coordinator must schedule tests according to operating company specifications. Datafill in table RExSCHED can disable this test. For additional information on table RExSCHED, refer to the data design section of the *Translations Guide*.

The system generates IOAU112 log report for LCMs if:


- the LCM is not REx tested for a minimum of seven days
- The REx test takes longer than specified
- The REx test does not start after a defined number of attempts

**Extended line concentrating module REx test results** Table RExSCHED controls scheduling of SREx for LCMs. The LCM\_REx\_TEST task SREx runs at the same time in groups of four and with REx tests of XPMs. The LGC, LTC, and the RCC XPMs can act as hosts to LCMs. Problems occur when an XPM scheduled for REx tests hosts an LCM scheduled for REx tests.

To avoid problems, the SREx controller schedules REx tests of XPMs and LCMs that occur at the same time. The LCM SREx subsystem registers the LCM\_REx\_TEST class and identifies conditions with other REx\_TEST types during initial program load (IPL). When LCM nodes join the SREx database, the controller automatically enters entries with defaults in table RExSCHED.

A functional diagram of SREx system requirements appears in the following figure.






The converter voltage and ring test sections of LCM\_REx\_TEST require wait states and different test resources. Wait states and different test resources cause delays in SREx main task initiation. The LCMCOV\_REx\_TEST runs at a lower priority and implements these tests separately from the LCM\_REx\_TEST. The LCMCOV\_REx\_TEST requires logical test unit (LTU) connections in the maintenance line card. An LCM unit can only access one LTU when the other unit is out of service. This resource limit makes sure LCMCOV\_REx\_TEST initiation does not occur at the same time. The entry of the PARALLEL execution field for LCMCOV\_REx\_TEST, in table RExSCHED, allows a maximum of one entry.

A functional diagram of SREx scheduling appears in the following figure.

Figure 1-20 SREx scheduling



When the LCM\_REx\_TEST and the LCMCOV\_REx\_TEST are separate, faster completion of site REx\_TEST coverage occurs. The LCM\_REx\_TESTs that do not have limits of the converter voltage and ring tests run at the same time. The coordinator schedules these tests separately for maximum start periods.

*Note:* The LCMCOV\_REx\_TEST runs only on LCMs, XLCMs, OPMs, and RLCMs.

The following REx test improvements for LCM peripherals and variants, like LCME, appear in feature AF3234:

- ESA REx test
- LCM and ESA-independent REx test
- MAP command for manual REx test
- fault indicators

- REx test maintenance record
- MAP commands to access REx test failures

**Emergency stand-alone REx test** The ESA REx tests the ability of RLCM units to enter and exit ESA and to message the ESA processor in ESA. The ESA REx test starts after the LCM REx test completes.

**MAP commands for manual REx tests** The addition of a REx or RExCOV parameter to the TST command at the PM level of the MAP display can start a manual LCM REx test. Examples of this command appear as follows:

#### >MAPCI;MTC;PM;POST LCM <site><frame><unit>

*Note:* Posts the LCM

#### >QUERYPM

*Note:* Displays information about the LCM node. Feature AF5898 adds information about the LCMCOV REx test.

To set manual control of scheduled LCM or LCMCOV REx tests, when the LCM appears, type

```
>TST REx [ON] [OFF]
```

*Note:* You can enable or disable the REx test of the posted LCM.

or

>TST COVREx [ON] [OFF]

Note: You can enable or disable the COVREx test of the posted LCM.

To start LCM REx tests immediately, type

>TST REX NOW

*Note:* Performs LCM\_REx\_TEST on the posted LCM.

or

>TST COVREX NOW

*Note:* Performs LCMCOV\_REx\_TEST on the posted LCM.

The following message appears when you enter the TST COVREx NOW command.

Example of a MAP response:

LCM HOST 00 0 will be put into takeover mode during the COV REX Do you want to continue with the COV REX test Please confirm ("YES", "Y", "NO", or "N")

**Line concentrating module and ESA-independent REx test** The scheduler initiates REx tests on an LCM. The scheduler initiates the ESA REx test when the ESA REx test completes. A manually implemented LCM REx test does not start an ESA REx test. The LCM sets ISTb if INSV diagnostics fail or SysB if OOS diagnostics fail if a REx test is not complete. After a REx test fails, the system sets the LCM to ISTb if INSV diagnostics fail. The system set the LCM to SysB if OOS diagnostics fail.

**Fault indicators** A REx test that is not complete sets the LCM unit to ISTb or SysB. The REx test audit provides a REx failed reason. Audits on LCMs occur at intervals of 10 min and run INSV tests. The ISTb flag remains with a REx failed reason. If the audit fails and detects additional failure conditions, the audit contributes to the ISTb list. If the LCM is SysB and a successful system RTS occurs, the unit returns to ISTb with the REx failed reason. The unit does not return to INSV. To remove the ISTb, the LCM must complete a manual RTS or a manual or scheduled REx test.

The system generates the node evaluation graph log (NAG400) each hour. The system generates the NAG400 in response to the NAG command, to list all nodes not in service (INSV). The results of the current REx test appear in field REx\_INFO in log NAG400. For LCMs, the LCM\_REx\_TEST result appears first. A colon separates this result from the LCMCOV\_REx\_TEST result. For additional information about NAG400 logs, refer to the *RSC-S Related Logs section of this document*.

**NAG command** The CI level NAG command displays all out-of-service nodes. The MAP response to the NAG command and the response in the NAG400 log report are the same. The command and log report are part of the node evaluation graph (NAG) feature. The NAG feature provides an image of nodes in the system that are out-of-service or have a REx issue. To include offline nodes in the output, enter the command NAG ALL. The log report runs each hour. The user can enter the command string NAG ON or NAG OFF to turn the log report on and off.

The output or log report includes nodes in the following states.

- system busy (SysB)
- C-side busy (CBsy)
- in-service trouble (ISTb)

- manual busy (ManB)
- failed
- aborted
- does not complete the last REx test

If a node does not have REx problems, the string ATP appears in the REx column. The string indicates all tests passed.

An abbreviated report in response to the NAG command appears in the following example.

	nt End Load				~ ~ ~ ~ ~ ~ ~	0	
Lev		-	Status	REX INFO	COUNT	UNIT 0	UNIT 1
	CPU	1	ACT				
СМ			NORMAL				
ЧS			NORMAL				
MS			NORMAL				
IOD			NORMAL				
NET			NORMAL				
PM	LTC	3	ISTB	FAILED	1	ISTB	ISTB
	DTC	0	ISTB	NO_REX_RUN	4	ISTB	ISTB
	SMS	0	ISTB	NO_REX_RUN	4	•	•
	TMS	1	ISTB	FAILED	1	ISTB	ISTB
	LTC	0	ISTB	OFF	9	•	•
	LTC	2	ISTB	ATP	1		
	TMS	0	ISTB	NO_REX_RUN	4	ISTB	ISTB
	SMA	0	ISTB	NO_REX_RUN	4	ISTB	MANB
	SMA	1	ISTB	ATP	2	ISTB	ISTB
	TMS	2	ISTB	NO_REX_RUN	4	ISTB	ISTB
	MSB7	0	ISTB	ATP	1	ISTB	ISTB
	LCM HOST	00 0	ISTB	FAIL: PASS	2	ISTB	ISTB
	LCM HOST	00 1	ISTB	FAIL:PASS	2	ISTB	ISTB
	LCME HOST	01 0	ISTB	Pass:N/A	4	ISTB	ISTB
	IDT	0	MANB		2		
	LIM	0		NO_REX_RUN	2		
	LIM	1		NO_REX_RUN	2		

**REX maintenance records** The system generates a maintenance record from a REx test. This test indicates the results of current REx tests for each LCM entered. You can access this information at the PM level of the MAP display for a posted LCM.

*Note:* The system erases the maintenance record for each LCM after a reload restart occurs.

## Diagnostics

The following section describes fault conditions for the RCC2, the RCC2 with ISDN, and the DRCC2. The current diagnostics and REx test results for the extended line concentrating module (XLCM) appear in the following example.

**Extended line concentrating module diagnostics** The XLCM diagnostics implements the CC and the XLCM software. This software is necessary to test the tip/ring reversal relay on each LCM bus interface card (BIC), NT6X54. The system or operating company personnel runs this test on separate logical drawers from the MAP display level. The XLCM diagnostics apply to the LCM. The XLCM diagnostic does not run on the LCME.

The XLCM diagnostics implement the following:

- BIC test schedules
- test activation and deactivation
  - BICRELAY command
- test operation
  - system test, run according to user-defined schedule
  - manual test, initiated from the LCM MAP display level over a single drawer of an LCM
- test results
  - new LCM node ISTb reason
  - PM132 log report
  - PM181 log report

The BIC acts as an interface between the 64 line cards in a drawer and the digroup control card (DCC), NT6X52, in the LCM. Each BIC consists of two identical parts that connect to a maximum of 32 line cards, 0-31. The identical parts form a drawer pair. Each drawer of the pair can be a logical drawer or digroups 0 or 1. Each LCM has ten BICs in ten physical drawers. Each LCM contains 20 logical drawers.

Two relays perform ring distribution on each half of the BIC. The first relay selects between ringing voltages and the ANI and coin voltages. Ringing voltages consist of ac ringing voltages to a telephone. The ANI and coin voltages consist of dc voltages that perform coin-activated functions. The second relay is the tip and ring reversal relay. This relay switches ringing voltages from tip to ring and ring to tip for multiparty ringing.

This feature tests the reversal relay only. The XLCM diagnostics allow the system to schedule the system BIC relay test (BRT). The system schedules this test over a specified set of LCMs and the associated drawers. The drawers

are scheduled BRT drawers. The XLCM can run the manual BRT on separate logical drawers.

To schedule the BRT, use information from table OFCVAR office parameters BICRELAY\_XLCM\_TEST\_SCHEDULE and BICRELAY\_MUM\_SIMUL\_TESTS. The parameters allow flexibility to schedule the BRT from one to seven days a week. You can define the window size, and define how many tests (LCM-level) can run at the same time.

The XLCM diagnostics implement tests at the office level, LCM, and drawer levels. The office-level test loops over each LCM in the schedule. A single BRT runs on each drawer of the LCM. Test results appear in a report that combines the results of each drawer test.

The scheduled BRT runs the LCM-level test. The test selects an LCM with drawers not tested during the BRT window that office parameters define. The test runs a BRT on each drawer of this LCM. This test is a single LCM drawer test. The system runs this test from the LCM-level test. Operating company personnel run this test from the LCM MAP display level.

The office-level test loops over the LCMs in an office and performs the LCM-level test. The LCM-level test loops over each drawer of a specified LCM and performs the drawer-level test which constitutes a BRT.

A new command interpreter can enable, disable, reset, or query the BRT for the whole office. The BICRELAY command has one parameter that can be ON, OFF, RESET or QUERY:

• ON

allows the test to start at the scheduled window

• OFF

disables current scheduled drawer-level tests. This setting does not allow the office-level test to start again

• RESET

allows you to restart office-level tests if the test did not run on LCMs

QUERY

displays the current on or off state of the office-level test, the number of LCM-level tests in progress, and the next LCM tested in the scheduled BRT.

An example of the BICRELAY command follows:

#### >BICRELAY ON

The system BRT displays the results of each LCM-level test in the form of a new log report, PM132. This report displays a combined report of each drawer-level test in a specified LCM.

The following limits apply:

- The system test sets the logical drawer to ManB before the system runs the relay test. For this test cycle, the drawer skips over lines in a call-processing busy state.
- Before maintenance personnel run the manual BRT on a single drawer, maintenance personnel must set the drawer to ManB.
- If a minimum of one NT6X17 line card is not entered in each logical drawer, the system does not test the drawer.
- This test does not run on an LCM at the same time with the following:
  - automatic line test (ALT)
  - REX test
- The BRTST\_START\_TIME and BRTST\_STOP\_TIME fields of the BICRELAY\_XLCM\_TEST\_SCHEDULE office parameter cannot have the same value. A time span of 10 min between these fields must occur.

The XLCM diagnostics use the test access bus, the metal test equipment, and a single NT6X17 card in each drawer. The XLCM diagnostics use these features to complete tests. When the ALT and the BRT run at the same time, a delay of both tests can occur. If a REx test starts on an LCM, the BRT does not run on that LCM. The LCM remains in the current state. The system generates a PM181 log. This log indicates the BRT does not run because a REx test is in progress.

## Line card diagnostics for NT6X18AA and NT6X18AB A

description of line card types A and B appear as follows:

- standard line card type A (NT6X17AA, AB, AC, AD) or plain old telephone service (POTS) card
- line card type B (NT6X18AA, AB, BA) or COIN card

Provides all features of type A and multiparty lines. This card supports the following features:

- coded ringing
- private branch exchange (PBX)
- ground start
- hotel/motel
- analog pay telephone sets that require coin control

For NT6X18AA and NT6X18AB, use the service order (SERVORD) option negate partial ground start diagnostics (NPGD). The SERVORD option NPGD allows the system to test a line against a smaller subset of ground start diagnostics. When table LENLINES contains option NPGD, the table omits loop detector, reversal relay, and ground start relay tests. If the system identifies the NT6X18AA or NT6X18AB card as ground start (GND=Y) in table LNINV, run diagnostics again. Run diagnostics again if initial diagnostics fail.

*Note:* For additional information about SERVORD, refer to the *XPM Translation Guide*.

**Extended line concentrating module REX test results** The REx tests indicate faults that can affect service. The REx tests allow operating company personnel to take corrective measures. The system initiates REx tests for LCMs that an office parameter controls. This office parameter determines the time interval to perform a REx test on the LCM. The system tests the LCMs one LCM at a time in the order in which you datafill the LCMs. A REx test involves OOS and INSV tests run on both LCM units.

*Note:* Before the addition of this feature, only the system scheduler initiated REx tests on an LCM. A manual REx test was not available.

This feature generates changes to the system REx test that do not affect the functionality of the current diagnostic subtests.

Feature AF3234 contains the following REx test improvements for LCM peripherals and the variants, like LCME:

- ESA REx test
- LCM and ESA-independent REx test
- MAP command for manual REx test
- fault indicators
- REx test maintenance record
- MAP commands to access REx test failures

## Too many levels of nesting!! Not a good idea.Emergency stand-alone REX test

The ESA REx test occurs on ESAs subtended for RLCMs. The ESA REx test tests the ability of RLCM units to enter and exit ESA and to message to the ESA processor when in ESA. Before the addition of this feature, a system or manual request did not initiate the ESA REx test. This functionality stays the same. The XLCM diagnostics changed the sequence order of the system REX test. Operating company personnel run the ESA REx test after the system LCM REx test completes. Operating company personnel do not run this test as a subtest.

# Too many levels of nesting!! Not a good idea.Line concentrating module and ESA-independent REX test

Before the addition of this feature, the system scheduler initiated an ESA REx test as part of the LCM REx subtests. The scheduler now initiates REx tests on an LCM. The scheduler initiates the ESA REx test when the REx test completes. An LCM REx test that operating company personnel run does not implement an ESA REx test. If a REx test does not complete, the LCM is put in an ISTb state if INSV diagnostics fail. The system places the LCM in a SysB state if OOS diagnostics fail.

#### Too many levels of nesting!! Not a good idea.MAP command for manual REx test

The XLCM diagnostics can implement a manual LCM REx test. The user must add a parameter named REx test to the TST command at the PM level of the MAP display. The user performs this action to complete a manual REx test. An example of this command follows:

#### >TST REx QUERY

*Note:* All subcommands occur on one posted LCM.

#### Too many levels of nesting!! Not a good idea.Fault indicators

A REx test that is not complete sets the LCM unit ISTb or SysB with the reason REX failed. The LCM audits occur at intervals of 10 min and run INSV tests. Before the addition of this feature, a successful audit cleared the ISTb flag. This feature affects only a successful audit. The ISTb flag remains with the reason REX failed. If the audit does not complete and the audit detects additional failure conditions, the audit contributes to the ISTb list. If the LCM is SysB and a successful system RTS occurs, the system resets the unit to ISTb with the reason REX failed. The system does not reset the unit to INSV. You can recognize a failed REx test. To clear the ISTb, the LCM must complete a successful manual RTS or a successful REx test. The REx test can be manual or scheduled.

#### Too many levels of nesting!! Not a good idea.REx test maintenance record

The system generates a maintenance record from a REx test and stores the record in an internal database. This record indicates the results of current REx tests for each LCM entered. When REx test activity occurs, the system updates the maintenance record. This information is available at the PM level of the MAP display for a posted LCM.

*Note:* The system deletes the maintenance record for each LCM after a reload restart.

## Too many levels of nesting!! Not a good idea.MAP commands to access REx test failures

The QUERYPM FLT command indicates that an LCM unit is ISTb or SysB because a REx test failure has the reason REX failed. Use the TST REx

QUERY command to provide the test ID of the subtest and the card list that caused the REx test to fail for each unit.

**Remote cluster controller 2** The most common method to test the RCC2 is to enter the TST command. The types of test depends on the RCC2 state and the TST command parameters. The following conditions determine the fault conditions for the RCC2:

- overload indicators (PM128, QUERYPM)
- REx tests
- audits of the intermodule communication links
- parity errors in the RCC2

## **Overload resources**

When call processing on an LCM exceeds the amount that LCM processor cards can handle, the RLCM accepts calls at a slower rate. The RLCM accepts calls at a slower rate until the overload clears. Normally, the LCM queues call requests and assigns the call request priorities in the data store. As the data store fills near capacity, RLCM overload controls slow the rate of load acceptance. The RLCM overload controls can stop the call process until data store becomes available.

The LCM overload control occurs for the following areas of operation:

• C-side communication

The LCM processor cards can slow or stop C-side communication. The cards decrease the rate at which the LCM processor cards scan for messages on the C-side. When the cards slow the incoming workload, the demand for data store decreases. This action slows MAP display queries of the LCM state, and C-side responses to LCM-supported terminals.

• line scanning

During overload, LCM processor cards do not scan the BIC until enough data store becomes available. When the LCM cards do not scan the BIC, the cards prevent incoming work from the P-side. The LCM cards queue incoming work from the P-side in the BIC output buffers. When the buffers are full, the buffers do not accept additional work. Partial dials or ignored keys on business sets can occur.

**Display of overload state** When the LCM becomes overloaded, the LCM state display changes to in-service trouble (ISTb) when both units show INSV. When the user enters the QUERYPM FLT command at the LCM level, the MAP response includes the message: LCM Overloaded.

# Too many levels of nesting!! Not a good idea.Overload indicators (PM128, QUERYPM)

The system generates a PM128 log (RCC2 is ISTb) when the RCC2 enters overload. The message PM Overloaded displays. If you post the RCC2 at the PM level of the MAP display and enter the QUERYPM FLT command, the MAP also displays PM Overloaded.

When this condition occurs, the user must collect all important OMs that track the amount and types of traffic. The reason that the RCC2 entered overload relates to a maintenance area, like network faults. Lack of engineering of the RCC2 configuration can cause the RCC2 to enter overload. Maintenance and engineering personnel must receive the OM reports for analysis.

Log reports PM128 and PM181 indicate the LCM overload condition. When call processing continues, the system generates log PM128 with the message: LCM out of Overload.

#### Too many levels of nesting!! Not a good idea.Overload control

Overload control maintains system sanity and component sanity during overload conditions. Flow control provides overload control. Flow control provides a use trigger that regulates the basic flow task to the CPU. Flow control regulation starts when the CP level tasks use a specified percentage threshold of the real time available to the CP level. When CP level tasks use less real time, flow tasks send another message that indicates the overload condition passed.

# Too many levels of nesting!! Not a good idea.Extended line card module overload controls

The XLCM has a defined number of small, medium, and large memory blocks of a specified size. Domestic LCMs and XLCMs use only small and large memory blocks to receive and send external messages. Small memory blocks (SMB) are used for utility purposes, like timer control blocks. Call data blocks, which hold data associated with active lines, use medium blocks (MMB).

The system reports overload when the XLCM cannot receive an external message, (DMS-X or inter-unit communication [IUC]). The XLCM cannot receive an external message because not enough small or large memory blocks are available. Service degradation can occur before the XLCM enters overload.

An XLCM has four levels of throttling to prevent overload. Three of these levels depend on the number of available SMBs. These levels can conserve


SMBs. The four levels are weighted. Terminating calls have priority over originating calls. The four throttling levels appear as follows:

- 1. An XPM throttles messages to a minimum of two XLCMs at intervals of 50 ms to control small peaks of very heavy traffic. At this rate, sustained messaging can drive the XLCM to overload.
- 2. An XLCM appends the number of SMBs available for external messages to each POTS origination message. An XLCM appends the number of SMBs available to all messages that originate from P-phones. This number = total available SMBs the number of SMB reserve. When this number is less than 20, the XPM delays processing of the origination until this number equals or exceeds 20.
- 3. The total number of SMBs available for external messages is less than 15. (The total available SMBs the number of SMB reserve < 15.) An XLCM does not send call processing updates to the mate.
- 4. The total number of SMBs available for external messages is less than 10. The total available SMBs the number of SMB reserve < 10. An XLCM does not scan the bus interface cards (BIC) for line scan changes.

An XLCM holds a reserve of small memory blocks. The blocks do not receive external messages. Even if the XLCM enters extremely heavy overload, internal processes have enough small memory blocks to complete the tasks. When the total number of SMBs available is less or equal to the size of the SMB reserve, the following occurs. The system rejects external messages that require SMBs, except for maintenance or monitor messages. At this point, the XLCM sends an overload report to the computing module (CM).

The overload protection system is static because throttle levels remain constant and not reactive. The overload protection system is distributed because a specified area is not present where the system monitors overload. No specified area is present where the system initiates and controls protective measures. The XLCM overload protection system appears in the following figure.

#### Figure 1-21 The XLCM overload protection system



Previous POTS models of the small memory LCM (64k) can be memory block limited. The LCM uses the small memory blocks before the LCM runs out of real-time use. The design of the LCM depends on this loss of memory blocks before a loss of real-time use. Memory block limited is an LCM functionality that also applies to XLCMs.

The XLCM overload system functions with POTS traffic. The current selection for the number of SMBs, (100) and the size of the SMB reserve (25), allow the processor to be memory block limited. The processor will sustain a loss of SMBs before a loss of real-time use. Processor occupancy or real-time use compared to memory block use appears in the following figure.




Figure 1-22 Processor occupancy or real-time use compared to memory blocks

The XLCMs contain more memory blocks than small-memory LCMs. The XLCMs must contain messaging requirements, like P-phones. The P-phones have features like displays and MADN. The XLCM can sustain a loss of real-time before a loss of memory blocks. The following figures show real-time overload.







Figure 1-24 Processor occupancy—memory block reduced after real-time overload detection



The XLCM is memory block limited. The XLCM cannot handle real-time overload. Outages can occur because of the following conditions:

- 1. The XLCMs do not send an overload report because XLCMs do not currently detect real-time overload. The CM does not suspend functions that require a response from the XLCM. If the XLCM does not respond in time, the CM sets the XLCM to SysB.
- 2. The XLCM cannot handle starvation. This condition occurs when low priority tasks do not run. This condition can cause traps or important software errors. These errors cause the CM to set the XLCM to SysB.

# Too many levels of nesting!! Not a good idea.Enhancements to the overload protection system

In addition to the current functions, the improved XLCM overload protection system performs the following functions:

- detects when an XLCM is in real-time overload
- reports overload to the CM
- takes protective measures to make sure of XLCM sanity

The protective measures are active for a short time to retain the XLCM call processing capabilty.

This improvement adds the following components to the current overload protection system. The system changes to accommodate the components.

1. Processor occupancy data collection component

Distributes over key areas of XLCM code to collect raw data used to detect real-time overload. A depository contains the raw data for the data analysis component. The data analysis component matches the priority of the segment of the system in which this data resides.

2. Real-time data analysis component

Analyzes data in the depository. This component indicates the processor occupancy state. This state consists of a distress rating, not a percentage. The control component does not use percentages because percentages are difficult and do not supply all the information required. The control component uses and reports the distress rating to the CM when an XLCM reports overload. The data analysis component indicates activity, and if the control component functions normally. This component runs at a high priority.

3. Real-time overload control component

Scans the distress rating that the data analysis component generates. If the rating indicates real-time overload, the control component adjusts parameters in the overload protection system. The adjusted parameters recover real-time and keep memory block limits ahead of the real-time limits of the XLCM. This process appears in the following chart. If the data does not indicate trouble, the control component restores the overload protection system parameters to allow maximum call processing. This component runs at a very high priority.




Figure 1-25 Overload protection system variable thresholds

## Too many levels of nesting!! Not a good idea. Changes to the real-time subsystem


The real-time subsystem changes memory block system parameters to keep memory block limits ahead of real-time limits.

Improvements to the real-time subsystem appears in the following list:

- 1. Reduction of memory blocks. Preserves real-time and reduces the number of memory blocks available for external messages and all associated throttles. This process continues until reduction of memory blocks recovers some real-time use.
- 2. Real-time overload. A processor occupancy rate of a minimum of 75% for a minimum amount of time is real-time overload. The calculation of percentages is real-time intensive. This improvement is not a flexible method of calculation. Premature reaction if the XLCM is not in severe real-time trouble can occur.
- 3. The system monitors the amount of time required to process specified key maintenance requests at high levels of occupancy under 100%. The system monitors the amount of time to make sure the XLCM responds to these requests before the CM times out or enters overload. The average time to process these key requests is benchmarked. If processing time exceeds the benchmarked average, assume real-time overload.
- 4. The user monitors idle task activity. The user enters real-time overload if an idle task does not run for a defined period of time.
- 5. The timer task slip counter is at a high occupancy of under 100%. If the timer task slips at more than the normal high occupancy rate, real-time overload is entered.
- 6. The user monitors the size of the set message queue. If the height of the queue exceeds 40 messages, the XLCM almost reaches real-time overload.
- 7. The reduction of memory blocks component includes large memory blocks (LMB) to recover real-time.

# Too many levels of nesting!! Not a good idea.Extended line card module log report appendages

An XLCM adds a new field to current overload messages the CM receives to indicate the extent of real-time overload. If the CM is at CCM04 or later, this new information appears in the modified PM180 LCM Enters Overload log. This information appears in the modified PM180 Overloaded log. The new field contains a ratio of the maximum read-time distress reached before the system generated the overload report. This ratio contains the values 0-9. The new field contains a ratio of the maximum read-time distress to the maximum level of real-time distress. This ratio contains the values 5-9. A real-time overload symptoms summary byte in hexadecimal format appears in the following diagram.



#### Figure 1-26 Summary of real-time overload symptoms

The XLCM maintains overload data that provides a summary of the overload period. This summary appears with the current overload exit message to the CM. If the CM is at CCM04 or later, this information appears in a modified PM180 LCM Out Of Overload log.

#### 1-118 Maintenance overview

This feature is active in XLCMs and international XLCMs with extended memory and XPM04 loads. The new logs apply automatically when the user installs CCM04 in the CM.

This feature detects only real-time overload to report overload state to the CM. The XLCM must have enough real-time in order to function according to the operating model, with memory block limited.

The current memory block overload system contains the real-time overload detection and protection subsystem. When in real-time trouble, to reduce memory block, the system changes memory block overload system parameters. Memory block overload system parameters change to reduce the amount of memory blocks available for new work. This feature makes the new overload system dynamic. The system adjusts to allow very high processor occupancy in traffic configurations.

#### Line card module talk battery audit

Before the addition of the Talk Battery Alarm feature, the system reported a loss of talk battery to an LCM shelf only if the talk battery fuse blew. When this condition occurred, maintenance personnel did not know that LCM subscriber lines did not have dial tone.

The Talk Battery Alarm feature adds new computing module (CM) and LCM maintenance software. The software audits each LCM shelf to detect talk battery. If the audit fails to detect talk battery, the system generates a critical alarm log report (PM179).

To support this feature, each LCM shelf must be provisioned with a minimum of one world line card (WLC). A subscriber can use the WLC used for the talk battery audit for call processing. The system generates a minor alarm log report (PM179) when WLCs cannot perform the audit when the feature is on.

*Note:* This feature supports all WLC types. The WLC can reside in any position in the LCM shelf.

**Loss of talk battery** Talk battery distribution in a line concentrating equipment (LCE) frame with four shelves appears in the following diagram.




Figure 1-27 Talk battery distribution on an LCE frame

The A feed provides talk battery for the second and fourth shelves of the LCE frame. The B feed provides talk battery for the first and third shelves. The feeds are not repeated. A single fault that loses a feed can affect two shelves. Two shelves can hold a maximum of 640 subscriber lines.

*Note:* Talk battery returns have some redundancy. A possibility exists that a single fault does not cause an outage.

Before the addition of this alarm, the system indicated that a loss of talk battery occurred only if the talk battery fuse blew. If the talk battery blows, the LCM indicates InSv (in service) on the MAP display. The LCM performs a line card audit. This audit cannot check for loss of talk battery. Loss of talk battery affects one or two LCM shelves. The location of the fault determines the shelves affected.

Without talk battery, LCM line cards cannot signal an off-hook condition. The LCM recognizes any off-hook line as on-hook. The system forces any LCM calls to the on-hook state when talk battery feed is lost. The LCM lines cannot originate and terminate calls while talk battery is not available.

**Feature activation** To control activation of the Talk Battery Alarm feature, change the value of office parameter TALK\_BATTERY\_ALARM in table OFCENG. The default setting disables the Talk Battery Alarm feature. Each LCM shelf in the office must contain a WLC before this feature starts. A minor alarm occurs for each LCM shelf that does not contain a WLC.

When the Talk Battery Alarm feature starts, talk battery tests occur through diagnostics and background audits.

When you disable the Talk Battery Alarm feature, talk battery alarms and in-service trouble (ISTb) reasons that this feature introduces clear up.

**Background audit** Each LCM can audit the shelves for loss of talk battery. When the Talk Battery Alarm feature is disabled, audits do not perform checks. Audits do not check for loss of talk battery on any of the LCMs in the office.

When the Talk Battery Alarm feature activates, a search occurs for an available WLC on each LCM shelf. To be available, a WLC must be in one of the following states:

- hardware assigned, software unassigned (HASU)
- INSV and assigned to a subscriber

If the audit does not find an available WLC, the system generates a minor alarm log report (PM179). The PM179 indicates that the audit cannot test talk battery, and the LCM becomes ISTb. If the audit locates an available WLC, a special audit checks for loss of talk battery feed each minute. The audit tests all LCM shelves at intervals of 1 min. Audits do not perform talk battery tests on an out-of-service (OOS) LCM.

If the WLC used for audit tests is not available, the audit searches for another available WLC. This occurs, for example, if the WLC goes OOS. If the audit locates another available WLC, audit testing continues with the new WLC. If the audit does not locate an available WLC, the system generates a minor alarm log report (PM179). The PM179 indicates the audit cannot test the talk battery, and the LCM shelf is set ISTb.

To test for loss of talk battery feed, the WLC must verify the presence of talk battery feed to the WLC. The test passes if talk battery feed is present and fails if talk battery feed is not available. If an off-hook or call processing busy (CPB), or both, occupy an INSV WLC, the talk battery test does not occur. The system assumes that the talk battery test passed. Examples of occupied states include talking, ringing, and maintenance lockout. For ringing, the WLC is on-hook and in a CPB state.

When the audit detects a failure of the talk battery test, the system generates a critical alarm log report (PM179). The system places the LCM shelf in an ISTb state. The audit does not report the failure until diagnostics clears the alarm and ISTb state.

**Diagnostics** The audit incorporates the talk battery test into INSV and OOS diagnostics for an LCM unit. The diagnostics affected include the following commands:

- TST UNIT UNIT\_NO
- TST PM
- TST REX NOW
- RTS UNIT UNIT\_NO
- RTS PM

Diagnostics report all talk battery failures, even if the audit tests the same LCM again. If the talk battery test passes, diagnostics clear the alarm and ISTb reason. This process affects both manual and automatic versions of these commands. Diagnostics run talk battery tests only when the talk battery alarm feature is not active.

To support the Talk Battery Alarm feature, each LCM shelf must contain an WLC. The WLC can reside in any position in the shelf. If the maintenance line card in LSG 0 Card 0 for the LCM shelf is assigned as a WLC, the feature can use this card. This line card since this line card tests the ringing generators.

The MAP commands that busy the last available WLC on an LCM shelf issue a warning message if this condition occurs. These commands appear as follows:

• BSY

Enter the BSY command at the LTP MAP level when the user posts a WLC.

• DIAG

Enter the DIAG command at the LTP MAP level when the user posts a WLC. DIAG temporarily manually busies [ManB] the WLC.

• BSY DRWR

Enter the BSY DRWR command at the PM MAP level when the user posts an LCM.

If one of these commands busies the last available WLC on the LCM shelf, a warning message appears. An example follows:

Example of a MAP response:

Busying the last available WLC on LCM shelf. This prevents testing for talk battery failure on the LCM shelf. Minor alarm will be raised within one minute unless WLC becomes available.

The QUERYPM FLT command displays new ISTb reasons by shelf and line equipment number (LEN) for both alarm conditions. An example of the MAP response follows:

Example of a MAP response:

Node inservice trouble exist:

One or both units Inservice Trouble

LCM UNIT 0 Inservice Trouble Exist:

Talk Battery failure detected on shelf <shelf #> by <LEN>

LCM UNIT 1 No Faults Exist

or

Node inservice trouble exist:

One or both units Inservice Trouble:

LCM UNIT 0 Inservice Trouble Exist:

Cannot test Talk Battery on shelf <shelf #> by <LEN>

LCM UNIT 1 No Faults Exist

The MAP commands that RTS the first available WLC on an LCM shelf issue the following notification messages. These notification messages indicate that the minor alarm and ISTb reason for the LCM shelf is cleared. The alarm and reason clear when a WLC becomes available to test for talk battery failures. The following commands cause this condition:

• RTS

You can enter the RTS command at the LTP MAP level when you post and returns to service a WLC. This command generates the following MAP response:

Example of a MAP response:

RTSing the first available WLC on the LCM shelf. Loss of talk battery can now be detected on LCM shelf. The minor alarm and ISTb reason will be cleared for the LCM shelf within ten minutes (unless the last WLC becomes unavailable again).

RTS DRWR

You can enter the RTS DRWR command at the PM level when you post an LCM. This command generates the following MAP response:

Example of a MAP response:

RTSing DRWR of the first available WLC on the LCM shelf. Loss of talk battery can now be detected on LCM shelf. The minor alarm and ISTb reason will be cleared for the LCM shelf within ten minutes (unless the last WLC becomes unavailable again).

This audit does not affect emergency stand alone (ESA) for RCC2. The audit ignores talk battery alarm conditions. During the ESA exit procedure, the CM diagnoses the LCM to determine if talk battery failures are present.

**Limits** The following limits apply to the Talk Battery Alarm feature:

- Only the following LCM types support the Talk Battery Alarm feature:
  - extended LCM (XLCM) (256-kbyte capacity)
  - improved LCM with ISDN (LCME)
  - cabinetized XLCM (ELCM), called the Meridian cabinetized LCM
  - remote line concentrating module (RLCM)
  - outside plant module (OPM), cabinetized RLCM with 256-kbyte capacity
- The same WLC used for talk battery tests functions as a subscriber line. If the talk battery test is in progress on a WLC, the WLC goes on-hook to request a call origination. The subscriber goes off-hook. An additional delay of up to 90 ms can occur before the subscriber receives dial tone. The talk battery test can be in progress on a WLC when the WLC receives a call termination request to ring the line. These conditions can cause a

delay of 90 ms before ringing starts. For originations and terminations, only this delay affects call processing.

- The Talk Battery Alarm feature only detect the loss of talk battery *feed* to an LCM shelf. The audit cannot detect the loss of talk battery *return* because of WLC limits. Talk battery returns repeat. Return failures probably do not occur. Refer to figure, "Talk battery distribution on LCE frame".
- The CM does not perform talk battery tests when the LCM or one of the C-side nodes is in the overload condition.
- The Talk Battery Alarm feature only isolates shelf-level failures of talk battery feed. The only reported talk battery feed failures are the failures that affect talk battery for all lines on the LCM shelf. The audit can detect drawer-level failures. The detection of failures depends on the drawer in which the WLC resides and the drawer in which the failure occurs.
- Faults specified to the WLC or the drawer can prevent the correct detection of talk battery failures. These faults include errors that cause the WLC to fail line card diagnostics. If this condition occurs, the WLC can report talk battery failure by mistake. An important alarm can occur, even if talk battery is present for other lines on the shelf. These occurrences probably do not occur. The important alarm log report (PM179) provides the location of the WLC to help troubleshoot occurrences.
- The Talk Battery Alarm feature does not affect the following features:
  - emergency stand-alone (ESA) on remote cluster controllers (RCC)
  - remote line concentrating modules (RLCM)
  - outside plant modules (OPM)

The audit ignores talk battery alarm conditions or reports during ESA. The audit does not report talk battery features when an LCM is in ESA. During ESA exit, the CM diagnoses the LCM to determine if talk battery failures are present.

- If the SERVORD OUT command deletes the directory number (DN) assigned to the last WLC on an LCM shelf, a minor Cannot test Talk Battery alarm occurs. The alarm message indicates the WLC for which the SERVORD OUT command deleted the last assigned DN. In this condition, the WLC is HASU. The WLC is in a maintenance state that is not normal. The LCM cannot use the WLC to detect talk battery failures because of this maintenance state that is not normal. Use one of the following procedures to solve this condition:
  - BSY and RTS the LCM. Nortel does not recommend this procedure. The procedure causes service outage. When the WLC is in the correct

HASU maintenance state, the LCM can use the WLC for talk battery tests.

- Assign a second WLC on the same LCM shelf. This WLC can remain as HASU. The WLC does not require a DN assigned. This option requires additional hardware, like an additional WLC. This option provides redundancy for the Talk Battery Alarm feature.
- Assign a DN to the WLC. The LCM can use the WLC for talk battery tests. This option provides a simple solution.

## Too many levels of nesting!! Not a good idea.Routine exercise test

For the REx test sequence to occur, both units must be INSV. The REx test does not run if the following conditions are present:

- a REx test runs on a HOST XPM where the audit subtends this node
- the system does not activate a warm SWACT for the PM
- one unit is SysB, the PM is ISTb, or both units are SysB, the PM is SysB.
- the PM is in overload or is ISTb

*Note:* If the PM is ISTb because of a previous REx test, the REx test runs again.

When the system aborts the REx test because of a TST REX NOW command, a message appears. The message describes the reason that the REx test terminated. In any other condition, the system generates a PM181 log with the same type of message.

# Too many levels of nesting!! Not a good idea.Audits of the intermodule communication links

An audit runs sanity tests on the intermodule communication links to make sure data passed on those links is not lost or corrupted. The audit runs on the inactive and active units. If the audit detects a fault, only the active INSV unit reports the fault to the CC. When the audit detects a fault on the intermodule communication link or links, the following steps occur:

- The system closes the link.
- The RCC2 state changes to ISTb.
- The RCC2 units does not communicate over the links. A warm SWACT cannot occur.
- The system generates a PM128 log.
- At the RCC2 level, the QUERYPM FLT command contains the message NON-CRITICAL HARDWARE FAULT.

# Too many levels of nesting!! Not a good idea.Parity errors in the remote cluster controller 2

On the RCC2, a parity system checks the integrity of the main memory systems. The parity system adds one bit of data to each byte stored. The hardware that maintains this additional bit can detect any single-bit memory fault. When a parity fault occurs, the fault indicates a memory integrity fault. The system implements the parity hardware on the NTMX77 processor where the memory resides.

Feature AN0741, Parity Improvements, improves the ability of the CPM to collect and report additional information on parity faults. This feature

- unifies the parity audit and parity trap handlers
- improves the data that the current handler captured and saved
  - use the information stored in the card state register
  - localize the parity fault to a specified byte address
  - perform hard/soft/intermittent fault groups
  - query to determine if the fault is in code
- updates interfaces to log reports PM189 and PM185 to include the current information

Before the addition of feature AN0741, the CPM dropped activity and went out-of-service if code execution detected a fault. The parity audit can initiate an interrupt instead of a bus error. This action allows the parity audit to identify memory faults before code initiation hits the memory faults. This process can prevent a potential loss of service.

#### Too many levels of nesting!! Not a good idea.Task-level parity handler

A level 6 interrupt reports parity faults to the local CPU. The level 6 interrupt autovector in a CPM connects to an assembly interrupt handler. This handler has one handler entry point for each interrupt level. This handler receives interrupts that the standard code execution or parity audit detected. The handle decides which handler functions to perform.

The parity interrupt handler determines if the parity audit caused the interrupt. The parity handler takes a snapshot of the state of the processor when the interrupt occurred. The handler stores the following data:

- processor register set
- interrupt return address and CPU state register
- memory card state registers

The parity handler categorizes the parity faults as hard, soft, or intermittent. The parity handler saves the fault word address, and returns control to the parity audit. The parity handler completes these tasks and passes standard trap information, like registers or task, to the generic trap handler. The generic trap handler can initialize or set the unit again.

#### Too many levels of nesting!! Not a good idea.Parity error log reports

. A PM181 log indicates parity fault type. Logs, like PM128 and PM106, indicate any action the CC performs. These logs indicate if the CC cleared the fault. Enter the QUERYPM FLT command to display information about this type of parity fault.

The system generates PM185 log reports. These logs indicate that a parity trap occurred. This log report can display the system or supervisor stack and the user stack. These stacks display the exact location of the trap. Log PM189 indicates if the parity error is in or out of code.

A PM185 log report that contains all available data appears in the following example.

```
Figure 1-28 Example of a PM185 log report
```

```
PM185 FEB16 12:41:58 8900 TBL PM TRAP
LTC 9 Unit 0 : Inact
Trap Sequence #: 1 Current load
# Reloads since trap: 0  # Restarts since trap: 0
Trap in UP : Division by 0
Trap was Recoverable
Load name = ECL03AN
Executable EEPROM version: XPMRMA25
Loadable EEPROM version: XPMRMA25
RTSS Version = AI15 Trap Version = 01
                                                        Trap flags: 2080
Unit was Inactive/Ready Mate was Active/Running
Kstats: 3F00 Load Status: A1A1A1A1
Task: BASEMON 000B 000B
CC Time : 16:12:34:34.00 PP Time : 00:02:32:59.79
Occurred at: 008D4881 TRAPMSG 44 DOZERODI 54
                                                                     Offset: #2B
                                           19 TDRIVBOD 30
Called from: 3E0023A4 BASEMON
                                                                     Offset: #22C
                3E0024B3 BASEMON 19 TERMDRIV 11
                                                                     Offset: #19
PC:00001350 SR=2004
                             US=000A69AE SS=002B0FF6 TCB=00024D9A
D0 =0000010C D1 =00000059 D2 =00020000 D3 =00000003
D4 =000A5DA6 D5 =FFFF0040 D6 =0000FFF4 D7 =00000000
A0 =00001A96 A1 =008E9BCE A2 =00025C5E A3 =008D4881
A4 =02000000 A5 =00025C6C A6 =00009724
Supervisor Stack:
  002B0FF6 FAB9 FFFB FAB9 FFFB 2367 0000 0001 0000

        002B1006
        FB20
        0000
        0001
        0102
        0001
        0000
        0000

        002B1016
        0000
        6B09
        0000
        0000
        0000
        0000
        0000
        0000

User Stack:

        00025C5E
        0000
        0000
        0000
        008D
        488E
        0218
        0000
        0002

        00025C6E
        5E40
        002C
        0036
        0000
        25E4
        015A
        5000
        0000

Possible Locals:
  00025C44 3E00 0001 008E 9BCE 0218 0000 0002 5C6C
  00025C54 0006 008F CD5C 000F 000F 0000 0000 0000
Stack Frame:
              008D 488E 0218 0000 0002 5E40 002C 0036
  00025C64
  00025C74 0000 25E4
Possible Parameters:
  00025C78015a 5000 0000 002E 0000 24C8 008F 536800025C880002 5CAA 0218 0000 002E 9E46 0002 5CAC
END OF TRAP
```

#### Too many levels of nesting!! Not a good idea. Feature requirements

The Parity Improvement feature depends on features AF5680, XPM Exception Processing System Enhancements, and AF5682, XPM Code Protection. The parity audit audits areas of memory that are protected and not protected. Feature AF5682 allows parity audit to write to a write-protected memory area to pattern test a parity fault location byte. The following allows the audit to write in this memory area to query if a specified address is in loaded code. The parity interrupt handler must determine if the parity fault occurred in execution space to perform the best recovery process.

Feature AF5391 allows the system to allocate protected memory for protected patches if there are no protected patches available. If the allocation fails, the system can use memory that is not protected to store the patch. Local patches must be stored in not direct memory access (DMA) memory, if possible.

*Note:* In the enhanced processor (UP) and unified processor (UP), the system allocates additional non-DMA. In the facilities processor (FP), non-DMA can only use released code space.

**Handling a parity error fault** If the audit detects a parity fault, the audit can normally correct the fault without loss of service. This section provides information on different parity faults. The section provides an overview of the actions the CM takes to handle parity faults. The actions that operating company personnel must take appear in this section.

Errors specified to processor cards. The three types of parity faults described in Error specified to processor cards are:

- an intermittent fault occurs when the audit detects a fault and does not find an error. The audit does not find an error during the reread of the location.
- a soft fault occurs when the audit detects a parity error. The audit detects error when the XPM reads the location again. The audit does not detect an error when the XPM tries to write to the location. The error can occur in the program store or memory store.
- a hard fault occurs when an XPM detects a fault and cannot reread or write to the memory location

When a parity fault occurs, the CM determines the action to perform on the RCC2 unit. The state of the unit that reports the active or inactive fault determines the action of the CC on the RCC2. The CM handles all three types of faults by the same method.

When the CM detects a parity fault in the active unit of the RCC2, the CM sets the unit ISTb with a reason of parity. The CM recovers the unit during a maintenance window. The XPM REx test window is as maintenance window that can recover a parity fault on the active unit. If the time for the XPM REx test window is the same as the current time of the switch, an audit checks if the active unit of the XPM has an ISTb of parity. If an ISTb is present, the CM SWACTs and reloads the RCC2 if no dependencies are present. This action clears the ISTb parity fault and the short term failure (STF) parity fault peg. This action clears the parity fault in the RCC2. When the active unit reports the parity fault, the system generates a PM181 log. Recovery actions by the CM include a SWACT of the XPM and the loading of the newly inactive unit. The CM loads the unit with the XPM software load defined in the related inventory table. The CM considers loading as an autoload. A manual CM or mate reload of the XPM software to the affected unit clears the ISTb.

The CM does not allow a REx test to occur on

- a P-side or C-side node of the XPM that recovers from a parity fault
- the XPM if a P-side or C-side node that recovers from a parity fault

The CM does not allow a parity reload by two XPMs in the same configuration. A P-side node cannot perform a parity reload at the same time as the C-side node. A C-side parity reload cannot occur at the same time as the P-side node. This limit makes sure that only one XPM in a configuration is in simplex at a time.

The PM181 logs report parity faults. Operating company personnel can check for associated logs, like the PM128, to understand actions the CM takes. Examples of the messages associated with the PM181 and PM128 logs appear in this section.

The RCC2 unit can be set ISTb with many reasons at the same time. All the ISTb reasons perform a QUERYPM FLT at the MAP level. When this process occurs, the ISTb reasons that occurred on the unit that are not cleared appear.

#### Too many levels of nesting!! Not a good idea.Hard parity fault

When the active unit of the RCC2 reports a hard parity fault to the CM, the system generates a PM181 information log. This log alerts operating company personnel that

- a parity fault occurred on the active unit, and the unit is set ISTb
- the CM loads the unit again during the XPM REx test window

A manual SWACT and reload can occur to clear the ISTb and the parity fault.

An example of a PM181 log report follows:

Example of a MAP response:

PM181 JUL23 23:29:16 7700 INFO RCC2 0 Unit 0
Node: Istb, Unit0 Inact: ISTb, Unit1 Act: ISTb
Parity audit has detected a hard parity fault.
The system will autoload the unit during the next
XPM REX test window.
Monitor the system for maintenance and recovery.
Site Flr RPos Bay\_id Shf Description Slot EqPEC
RAL1 00 C05 CMVI 00 18 RCC2 : 000 3 AX74

When a unit changes state to ISTb of UP RAM parity fault, the system generates a PM128 log report. This log informs operating company personnel that the unit has changed state.

An example of a PM128 log follows:

Example of a MAP response:

\*PM128 MAY09 09:49:56 9000 TBL ISTB RCC2 1 Node: ISTb (Unit ISTb) Unit0 Inact: InSv Unit1 Act: ISTb (UP RAM Parity)

The command string QUERYPM FLT displays the faults on a posted RCC2. A hard parity fault is present in unit 1 of the posted RCC2 and appears in the following example MAP response:

Example of a MAP response:

```
>querypm flt
Node is ISTb
One or both Units inservice trouble
Unit 0
no fault exists
Unit 1
The following inservice troubles exists:
Parity audit has detected a hard parity fault.
A reload is required to clear this fault.
The system will autoload this unit during the next
XPM REX test window.
```

Action by the CM:

The CM SWACTs and loads the RCC2 again during the next XPM REx window. After the reload, the system clears the ISTb fault.

*User action:* There is no action required. The system can initiate a manual SWACT and reload to clear the parity fault.

**Dual remote cluster controller 2** The maintenance functions provided for the DS-1 interlinks and the DS-1 links connected to the host PM are the same. These functions must

- detect if the card is present
- monitor the DS-1 circuits

Conditions reported include slips, frame loss, bipolar violation (BpV), remote carrier group alarms (RCGA), and local carrier group alarms (LCG).

• report the state of the link

**Remote cluster controller 2 with ISDN** The system can configure the RCC2 with a spare DCH. If a DCH card goes OOS, the spare DCH gains control of the current D-channel processing. A loss of D-channel service does not occur. Enter the SWITCH command to implement this function.

The RCC2 does not affect data communication when the RCC2 performs a warm SWACT. During a cold SWACT, the system interrupts the data connection during the SWACT. The system establishes the data connection again when the SWACT completes.

#### **Escalation to manual maintenance**

Automatic maintenance for the RSC-S includes the output of the correct trouble indicators. The information normally in this section is in the Automatic maintenance section.

# 2 RSC-S hardware

# Hardware components

The development phases of the Remote Switching Center-SONET (Synchronous Optical Network) (RSC-S) produce different hardware and software components. The table that follows lists hardware component products.

Hardware	Product engineering code (PEC)						
Cellular Access Processor with 16Mb Memory	NTAX74AA						
MSP for CRSC and CEXT	NTRX40AA						
Power converter	NTMX72AA						
PCM signaling	NTMX73AB						
32-port DS30A	NTMX74AA						
Enhanced matrix	NTMX75AA NTMX75DA						
Processor with 8-MB Dynamic Random Access Memory (see note)	NTMX77AA						
DS60 extender and power supply	NTMX79AA						
Dual DS-1 packlet	NTMX81AA						
Compact Dual DS-1 packlet	NTMX81BA						
Filler packlet	NTMX83AA						
Compact Filler packlet	NTMX83BA						
<i>Note:</i> The NTMX77AA supports the functionality of the NT7X05 Peripheral/Remote Loader-16.							

Table 2-1 Hardware component products (Sheet 1 of 2)

duct ineering code C)
1X8501
1X8602
IX87AA/AB
1X87BA
1X89FC
1X89FB
1X89FA
1X76AB
X05AA

 Table 2-1
 Hardware component products (Sheet 2 of 2)

The hardware developed during the first phase includes nine circuit cards. The first phase hardware also includes the main shelf housed in the cabinetized Remote Switching Center (CRSC) and the cabinetized extension module (CEXT) cabinets. The hardware also introduces the modular supervisory panel (MSP) for CRSC and CEXT.

# The RSC-S packaging

The RSC-S hardware component packaging differs from normal Remote Switching Center (RSC) packaging. The RSC-S is in cabinets and not equipment frames. These cabinets contain different hardware units. The configuration of these cabinets and cabinet components determines the services the RSC-S can offer. Northern Telecom offers RSC-S in both single-cabinet and multicabinet configurations.

### Model B

The Model B RSC project introduces the enhanced cabinet and the MSP to the RSC-S for domestic applications. Improvements in the cooling unit (CU) and system cabling eliminate many assignment limits that remote maintenance module (RMM) shelves required. These limits applied to RSC-S applications. The improvements help integrate remote cabinets with current frame equipment.

Model B addresses cabinet, cooling, MSP, and cabling issues. Circuit card provisioning rules do not change. The equipment of remote cluster controller 2 (RCC2) and extension shelves (EXT) is the same as the original RSC-S. Numbers and types of interfaces supported do not change. The Model B uses vertical power for all applications except the extension of a current Model A alignment. A top-mounted remote power filter unit powers the remote Model B. The extension of a current Model A arrangement uses horizontal (internal) power. A horizontal power kit is available for this application. Cabinet colors are brown and FiberWorld gray.

# Single-cabinet configuration



**RCC2 supports a maximum of ten P-side peripherals** Peripheral nodes include LCM(E)s, RLCMs, SMSRs, RMMs. The number of peripheral nodes and remote modules configured on an RCC2 cannot exceed ten. The system rejects attempts to datafill more than ten P-side nodes in inventory tables.

The single cabinet RSC-S configuration requires only the CRSC cabinet. The CRSC cabinet provides facilities for the following components:

- a master controller (the RCC2) that controls associated line concentrating modules (LCM), RMMs, remotes, and digital trunks as the host directs
- the 480 lines for one enhanced line concentrating module (LCME) that can support combined services

The LCMEs can provide services like the following:

• integrated services digital network (ISDN)

WARNING

- two binary one quarternary (2B1Q)
- plain old telephone service (POTS)
- Meridian Digital Centrex (MDC)

LCMs support services like POTS and MDC.

- maintenance and service circuits that the RMM provides
- 640 lines for one LCM
- MSP
- ringing generators (RG)

*Note:* The single-cabinet configuration requires an external power source.

The provisioning options for a single-cabinet configuration are as follows:

- peripheral-side (P-side) digital signal 1 (DS-1) links for trunking
- central-side (C-side) links for communication with the host

The phase 1 enhancements phase introduces another provisioning option. This option is the Subscriber Carrier Module-100S Remote (SMS-R) for digital integration of digital loop carriers compatible with the TR-008.

Model B does not change P-side and C-side port requirements for the CRSC and CEXT.

### Cabinetized remote switching center


The CRSC is a single-cabinet RSC-S that supports service and maintenance circuits and DS-1 links to the host. A single configuration RSC-S can have one CRSC cabinet with the following:

- one RCC2 shelf (always provisioned)
- one RMM served by dedicated DS30A links
- one LCME or LCM
- one MSP
- two RGs

The single CRSC C-side interfaces are DS-1 links to a line trunk controller (LTC) or line group controller (LGC) host peripheral.

The diagrams that follow show CRSC components. A description of each CRSC component follows the diagrams. The first diagram shows a CRSC cabinet with an LCME.

Figure 2-1 CRSC cabinet with LCME



The following figure shows a CRSC cabinet with an LCM.




Figure 2-2 CRSC cabinet with LCM

**Enhanced remote cluster controller-2** The RSC-S is based on the RCC2, which is the master controller for all RSC-S peripherals.

The RCC2 controls the following as the host directs:

- associated LCMs
- RMMs
- remotes
- digital trunks

During normal operations (without SONET interfaces), the host line group controller (LGC) or LTC controls the RCC2. The RCC2 P-side ports can be configured to support the following:

- lines
- trunks
- Outside Plant Modules (OPM)
- remote line concentrating modules (RLCM)
- the SMS-Rs off the RSC-S

The RCC2 is the remote office unit of the common peripheral module (CPM). The RCC2 is a single-shelf, a 68020 module that has units 0 and 1. The RCC2 units 0 and 1 run in an active and standby mode for reliability.

The RCC2 shelf contains the components that follow:

- duplicated RCC2 processor cards that have a processor based on 68020 or 68040 (NTMX77 or NTAX74, in the order given). The NTAX74 CAP with a 68040 base is an optional upgrade replacement for the NTMX77 UP with the 68020 base. The CAP increases XPM capacity, real-time availability, and memory. An RCC2 with the CAP requires the components that follow to support NTAX74 functionality:
  - the NTBX01BA or NTBX01AC ISDN Signaling Preprocessor
  - the NTBX02BA Enhanced D-Channel Handler

*Note:* An RCC2 with NTAX74 requires the NTBX01BA or NTBX01AC ISDN Signaling Preprocessor and the NTBX02BA Enhanced D-Channel Handler.

- duplicated expanded time switch, a high capacity switch matrix
- duplicated messaging interface circuit cards that have the interface to both C-side and P-side message channels
- duplicated power converters to power circuit cards

- a pulse code modulation (PCM) signaling card that supports all low-level PCM signaling tasks
- the DS-1 interface cards (ten DS-1 links for each card) for host-directed DS-1 links for P-side link requirements
- a DS30A interface card, that provides 32 DS30A links for interfacing to LCMs, RMMs, and SMS-Rs located at the RSC-S
- a selection of the following service circuit cards:
  - global tone receiver (GTR) or universal tone receiver (UTR)
  - custom local area signaling service (CLASS)
  - modem resource (CMR)
  - D-channel handler (DCH)
  - enhanced ISDN signaling preprocessor (EISP)

The RCC2 contains RSC-S processor and memory cards for the following:

- normal and emergency stand-alone (ESA) modes
- time switches
- tone generators
- power converters

The RCC2 also supports GTR/UTR for lines and trunks in normal and ESA modes, and provides local switching for the following:

- host-directed calls that connect LCM, DS-1 trunking, RLCM, OPM, and data line card (DLC) channels to host-directed DS-1 channels
- line and trunk calls internal to the RSC-S and associated remotes of the RSC-S that the intraswitching feature supports
- intraswitched calls during ESA supported when the ESA feature is in use

This process uses up to 20 C-side ports and 54 P-side ports. The ports support all features of the current RSC and RSC with ISDN with increased capacity. The RCC2 peripheral allows the following connections:

- C-side to P-side
- P-side to C-side
- P-side to P-side
- C-side to C-side

The C-side ports support host-to-remote capabilities

The RCC2 performs the termination functions that follow:

- the C-side links from the host LGC or LTC (for DS-1 electrical links), with a maximum of 20 DS-1 links. The links provide a maximum of 480 channels
- the DS-1 links from the mate RCC2 in a dual configuration
- the P-side DS-30A links from LCMs, RMMs, and SMS-Rs
- the P-side DS-1 links for digital connectivity to RLCMs and OPMs in the remote-off-remote configuration
- the P-side DS-1 links for digital trunking to community dial offices (CDO) and private branch exchanges (PBX)

The following diagram shows the circuit card layout for an RCC2 shelf.

*Note:* Space limits mean that the following diagram that does not show slot 27. This slot contains an NTMX72 power converter.




Figure 2-3 RCC2 circuit card layout

In NA010 and lower, up to 16 C-side ports are available. This configuration requires the NTMX87AA/AB in slots 9 and 19. NA011 and higher supports these packs when an office needs only up to 16 C-side links.

In NA011 and higher, up to 20 C-side ports are available. This configuration requires the NTMX87BA in slots 9 and 19. This hardware is backward compatible from NA008 to NA010 for use in the 16 C-side link configuration.

The following table describes circuit cards for RCC2 unit 0 (slots 01 through 13).

Table 2-2 RCC2 unit 0 circuit cards (Sheet 1 of 2)

Slot	Description	PEC
01-02	Power Converter	NTMX72
03	Unified Processor or Cellular Access Processor	NTMX77 <i>or</i> NTAX74
04	ISDN Signaling Preprocessor	NTBX01
05	CLASS Modem Resource or Peripheral Recovery Loader-16	NT6X78 <i>or</i> NT7X05
06	Global/Universal Tone Receiver	NT6X92
07	Global/Universal Tone Receiver orPeripheral Recovery Loader-16	NT6X92 <i>or</i> NT7X05
08	Enhanced Message and Tone Card <i>or</i> HDLC Message and Tone Card (for EDC)	NT6X69 <i>or</i> NTMX76
09	The following configurations are possible: (see notes below)	
	Penta DS-1 Packlet Carrier <i>with</i> Compact Dual DS-1 Packlet (1-5) <i>or</i> Filler Face Plate (0-4)	NTMX87BA <i>with</i> NTMX81BA <i>or</i> NTMX83BA
	Quad Frame Carrier <i>with</i> Dual DS-1 Packlet (1-4) <i>or</i> Filler Face Plate (0-3)	NTMX87AA/AB <i>with</i> NTMX81AA <i>or</i> NTMX83AA
10	Enhanced Matrix NTMX75AA <i>with</i> NTMX87AA/AB in slots 9 and 19 <i>or</i> Enhanced Matrix NTMX75DA <i>with</i> NTMX87BA in slots 9 and 19.	NTMX75AA <i>or</i> NTMX75DA
11	Pulse Code Modulation Signaling Processor	NTMX73

*Note 2:* The functionality of the NT7X05 Peripheral/Remote Loader-16 requires the NTMX77AA for support .

*Note 3:* For NA011, a 20 C-side link configuration is available. This configuration requires the Penta DS-1 Packlet Carrier. For a 16 C-side link configuration, the Quad Frame Carrier is acceptable. The Penta DS-1 Packlet Carrier is hardware backward compatible to NA008, but only in a 16 C-side link configuration.

Table 2-2	RCC2 unit 0 circuit cards	(Sheet 2 of 2)

Slot	Description	PEC
12	(Enhanced) D-Channel Handler <i>or</i> Quad Frame Carrier <i>with</i> Dual DS-1 Packlet (1-4) <i>or</i> Filler Face Plate (0-3)	NTBX02 or NTMX87AA/AB with NTMX81 AA or NTMX83AA
13	DS-30A Interface Card	NTMX74

*Note 1:* Refer to "Maintenance overview" in this document for detailed descriptions of circuit cards for an RCC2 shelf.

*Note 2:* The functionality of the NT7X05 Peripheral/Remote Loader-16 requires the NTMX77AA for support .

*Note 3:* For NA011, a 20 C-side link configuration is available. This configuration requires the Penta DS-1 Packlet Carrier. For a 16 C-side link configuration, the Quad Frame Carrier is acceptable. The Penta DS-1 Packlet Carrier is hardware backward compatible to NA008, but only in a 16 C-side link configuration.

The following table describes circuit cards for RCC2 unit 1 (slots 14 through 27).

Table 2-3 RCC2 unit 1 circuit cards (Sheet 1 of 2)

Slot	Description	PEC
14	(Enhanced) D-Channel Handler <i>or</i> Quad Frame Carrier <i>with</i> Dual DS-1 Packlet (1-4) <i>or</i> Filler Face Plate (0-3)	NTBX02 or NTMX87AA/AB withNTMX81AA or NTMX83AA
15	DS-30A Interface	NTMX74
16	(Enhanced) D-Channel Handler <i>or</i> Quad Frame Carrier <i>with</i> Dual DS-1 Packlet (1-4) <i>or</i> Filler Face Plate (0-3)	NTBX02 or NTMX87AA/AB with NTMX81AA or NTMX83AA
17	Pulse Code Modulation Signaling Processor	NTMX73

*Note 1:* Refer to "Maintenance overview" in this document for detailed descriptions of circuit cards for an RCC2 shelf.

*Note 2:* The functionality for the NT7X05 Peripheral/Remote Loader-16 requires the NTMX77AA for support.

*Note 3:* For NA011, a 20 C-side link configuration is available. This configuration requires the Penta DS-1 Packlet Carrier. For a 16 C-side link configuration, the Quad Frame Carrier is acceptable. The Penta DS-1 Packlet Carrier is hardware backward compatible to NA008, but only in a 16 C-side link configuration.

#### 2-12 RSC-S hardware

Slot	Description	PEC
18	Enhanced Matrix NTMX75AA <i>with</i> NTMX87AA/AB in slots 9 and 19 <i>or</i> Enhanced Matrix NTMX75DA <i>with</i> NTMX87BA in slots 9 and 19.	NTMX75AA <i>or</i> NTMX75DA
19	The following configurations are possible: (see notes below)	
	Penta DS-1 Packlet Carrier <i>with</i> Compact Dual DS-1 Packlet (1-5) <i>or</i> Filler Face Plate (0-4)	NTMX87BA <i>with</i> NTMX81BA <i>or</i> NTMX83BA
	Quad Frame Carrier <i>with</i> Dual DS-1 Packlet (1-4) <i>or</i> Filler Face Plate (0-3)	NTMX87AA/AB <i>with</i> NTMX81AA <i>or</i> NTMX83AA
20	Enhanced Message and Tone Card <i>or</i> HDLC Message and Tone Card (for EDC)	NT6X69 <i>or</i> NTMX76
21	Global/Universal Tone Receiver or Peripheral Recovery Loader-16	NT6X92 <i>or</i> NT7X05
22	Global/Universal Tone Receiver	NT6X92
23	CLASS Modem Resource or Peripheral Recovery Loader-16	NT6X78 <i>or</i> NT7X05
24	ISDN Signaling Preprocessor	NTBX01
25	Unified Processor	NTMX77
26-27	Power Converter	NTMX72

#### Table 2-3 RCC2 unit 1 circuit cards (Sheet 2 of 2)

*Note 1:* Refer to "Maintenance overview" in this document for detailed descriptions of circuit cards for an RCC2 shelf.

*Note 2:* The functionality for the NT7X05 Peripheral/Remote Loader-16 requires the NTMX77AA for support.

*Note 3:* For NA011, a 20 C-side link configuration is available. This configuration requires the Penta DS-1 Packlet Carrier. For a 16 C-side link configuration, the Quad Frame Carrier is acceptable. The Penta DS-1 Packlet Carrier is hardware backward compatible to NA008, but only in a 16 C-side link configuration.

**Remote maintenance module** The RMM is based on the DMS-100 switch maintenance trunk module (MTM). Each RSC-S site requires one or more RMM to perform diagnostic and line tests, and monitor alarm conditions. Each RCC2 can have a maximum of two RMMs. Each RMM has one dedicated DS30A P-side port.

An RMM can contain the components that follow:

- one RMM control card
- one group coder-decoder (CODEC) card
- two power converters
- a maximum of 14 service circuit cards that include the following:
  - scan
  - signal distribution (SD)
  - metallic test access (MTA)
  - test trunk
  - line test unit

**Enhanced line concentrating module** The LCME is part of the CRSC and an additional LCME can connect to the RSC-S. The LCME shelf extends the capabilities of the CRSC. The LCME is the subscriber interface of the RSC-S for a maximum of 480 lines. The LCME has two ISDN line concentrating array (LCAI) shelves. Each LCAI shelf contains the following equipment:

- four line drawers that contain line cards
- one power converter
- two digroup control cards
- one processor card

Additional LCMEs connect to the P-side of the RCC2 through 2 to 18 DS30A links. The traffic requirements of the operating company determine the number of DS30A links for each LCME. The P-side links of the RCC2 define a maximum of two LCMEs.


**Line concentrating module** The LCM can be part of the CRSC. The LCM is the subscriber line interface of the RSC-S for a maximum of 640 lines. The LCM connects to the P-side of the RCC2 through two to six DS30A links. The LCM consists of two line concentrating array (LCA) shelves. Each LCM shelf contains the following equipment:


- a maximum of five line drawers that contain 64 line cards for each drawer
- one digroup controller
- one LCM processor card
- one power converter

**Modular supervisory panel** The NTRX40AA MSP provides alarm monitoring and control functions for C28 cabinets. Modules are provisioned

with specified functions. A maximum of ten breaker modules, each with two breakers, can provide -48V dc distribution. A maximum of eight fuse modules, each with eight breakers, can protect subcircuits. The MSP can provision a total of 13 fuse and breaker modules.

The following diagram shows an MSP for a CRSC and CEXT.





**Ringing generators** The provisionable NT6X30HA RGs module provides analog ringing voltage. The RG unit operates with the NTRX40AA MSP.

**Cooling unit** The new NTRX91AA CU is a 10-in. deep forced air unit that uses three Rotron type (6-in diameter) tube axial fans. These fans provide 200 cfm at 3 in of back pressure, that evenly spread 1600 watts. The NTRX91AA uses the A0346832 air filter, an 80% dust arrestance synthetic fiber material filter.

### **Multicabinet configuration**

The multicabinet configuration requires one of the following, in addition to the CRSC:

- a cabinetized power distribution center (CPDC)
- cabinetized remote miscellaneous equipment (CRME) cabinet

The configuration can include a CEXT cabinet.

The CEXT can contain a maximum of five cabinetized line concentrating equipment (CLCE) cabinets and an LCME. The number of CLCE cabinets


and an LCME increases the maximum size for a line. An NTMX8601 EXT provides additional RCC2 capacity on the CEXT.

This setup can include an NTRX34BA cabinetized miscellaneous equipment cabinet (CMIS) to store equipment that the customer specifies. An NTRX49AA cabinetized miscellaneous spares storage (CMSS) cabinet can provide spare card storage. An NTRX30DA cabinetized line module ISDN (CLMI) allows the system to contain a maximum of two ISDN 2B1Q line modules.

*Note:* The five line cabinets cannot contain ISDN lines until phase 2/3.

The following diagram shows a multicabinet configuration.

Figure 2-5 Summary of multicabinet RSC-S configuration



The provisioning options that follow are also available for the multicabinet configuration:

- the P-side DS-1 links for trunking
- the C-side links for communication with the host

#### 2-16 RSC-S hardware

The phase 1 enhancements phase introduce an additional provisioning option. This option is the SMS-R for digitally integration of digital loop carriers compatible with the TR-008.

The sections that follow describe the cabinets and cabinet components.

### Cabinetized line concentrating equipment

A single configuration RSC-S can have a maximum of five CLCE cabinets. Each cabinet supports a maximum of two completely duplicated LCMs. Each LCM provides 640 line card capacity.

The POTS applications use the CLCE. The CLCE connects to the RCC2 through two to six DS30A links. A maximum of ten LCMs can connect to the RCC2 in a single RCC2 configuration.

Each CLCE cabinet contains the following equipment:

- a maximum of two duplicated LCMs to terminate subscriber lines
- one MSP for power, control, two RGs and alarm circuits

*Note:* Phase 1 limits ISDN lines to the CRSC and CEXT cabinets only. The five additional line cabinets cannot have ISDN lines until a later release.

### The CRSC extension cabinet


The hardware required to support 54 ports exceeds the physical capacity of the RCC2. The EXT shelf extends the capacity of the hardware. The CEXT contains the following:

- EXT
- MSP
- RMM shelf
- LCME, which provides
  - power
  - service
  - maintenance circuits
  - an additional 480 lines

This cabinet contains more ISDN DCHs or DS-1 interfaces. The EXT shelf has one ISDN LCM also.

The following diagram shows the CEXT components. A description of each CEXT component follows the diagram.

Figure 2-6 CEXT cabinet



The CEXT provides room for more DS-1 interfaces and DCH cards. The CEXT units 0 and 1 require the DS60 card that provides DS60 links to the CRSC. The extension card contains 12 DS60 links that connect the card to the RCC2 shelf. The EXT shelf uses two extension cards.

**Extension shelf** The EXT shelf contains two extension half shelves. Each half of the EXT shelf supports one RCC2 shelf. One CEXT can support two CRSC cabinets.

The EXT shelf provides additional DS-1 links or supports additional DCHs to accommodate ISDN line requirements. This shelf works with the RCC2 shelf and connects to the RCC2 shelf through a DS60 plus power card.

The EXT shelf on the CEXT contains the following cards:

- 0 to 3 octal DS-1 interface cards (up to 24 DS-1 links) in an NTMX87 Quad Frame Carrier
- 0 to 10 DCH cards
- DS60 extension cards

The following diagram figure shows the circuit card layout for an RCC2 EXT shelf.

*Note:* The figure that follows cannot show slot 27 as a result of space limits. This slot also can contain an NT0X50 filler face plate.

Figure 2-7 RCC2 EXT shelf circuit card layout

	EXT																								
	First CPM														— Ur	nit 1	<u> </u>	Seco	nd (	CPN		Unit	0 —		
N	Ν	N	N	N	N	N	N					N	N					Ν	N	N	N	N	N	Ν	Ν
Т	Т	Т	Т	Т	Т	Т	Т					Т	Т					Т	Т	Т	Т	Т	Т	Т	Т
0	M	B	M	B	M	B	M	1	NTB	X02	2	M	M		NTE	SX02	2	M	B	M	B	M	B	M	0
X	X 7	X 0	X 8	X 0	X 8	X 0	X 8					7						X 8	X 0	X 8	X 0	X 8	X 0	X 7	X 5
0	9	2	7	2	7	2	7					9	9					7	2	7	2	7	2	9	0
01	02	03	04	05	06	07	08	09	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26

The following table describes the circuit cards for an RCC2 EXT shelf.

Table 2-4	RCC2 EXT	shelf circu	it cards	(Sheet 1 of 2)
-----------	----------	-------------	----------	----------------

Slot	Description	PEC				
01	Filler Face Plate	NT0X50				
02	DS60 Extender	NTMX79				
	<i>Note 1:</i> Refer to "Maintenance overview" in this document for detailed descriptions of circuit cards for an RCC2 EXT shelf.					
Note 2:	Do not use the NTMX87BA Penta DS-1 Packlet Carrier in the RCC2	extension shelf.				

Slot	Description	PEC		
03	(Enhanced) D-Channel Handler	NTBX02		
04	Quad Frame Carrier <i>with</i> Dual DS-1 Packlet (1-4) <i>or</i> Filler Face Plate (0-3)	NTMX87AA/AB <i>with</i> NTMX81AA <i>or</i> NTMX83AA		
05	(Enhanced) D-Channel Handler	NTBX02		
06	Quad Frame Carrier <i>with</i> Dual DS-1 Packlet (1-4) <i>or</i> Filler Face Plate (0-3)	NTMX87AA/AB <i>with</i> NTMX81AA <i>or</i> NTMX83AA		
07	(Enhanced) D-Channel Handler	NTBX02		
08	Quad Frame Carrier <i>with</i> Dual DS-1 Packlet (1-4) <i>or</i> Filler Face Plate (0-3)	NTMX87AA/AB <i>with</i> NTMX81AA <i>or</i> NTMX83AA		
09-12	(Enhanced) D-Channel Handler	NTBX02		
13-14	DS60 Extender	NTMX79		
15-18	(Enhanced) D-Channel Handler	NTBX02		
19	Quad Frame Carrier <i>with</i> Dual DS-1 Packlet (1-4) <i>or</i> Filler Face Plate (0-3)	NTMX87AA/AB <i>with</i> NTMX81AA <i>or</i> NTMX83AA		
20	(Enhanced) D-Channel Handler	NTBX02		
21	Quad Frame Carrier <i>with</i> Dual DS-1 Packlet (1-4) <i>or</i> Filler Face Plate (0-3)	NTMX87AA/AB <i>with</i> NTMX81AA <i>or</i> NTMX83AA		
22	(Enhanced) D-Channel Handler	NTBX02		
23	Quad Frame Carrier <i>with</i> Dual DS-1 Packlet (1-4) <i>or</i> Filler Face Plate (0-3)	NTMX87AA/AB with NTMX81AA or NTMX83AA		
24	(Enhanced) D-Channel Handler	NTBX02		
25	DS60 Extender	NTMX79		
26-27	Filler Face Plate	NT0X50		
<i>Note 1:</i> for an RC	Refer to "Maintenance overview" in this document for detailed descrip	tions of circuit cards		
Note 2:	Do not use the NTMX87BA Penta DS-1 Packlet Carrier in the RCC2 e	extension shelf.		

Table 2-4 RCC2 EXT shelf circuit cards (Sheet 2 of 2)

**Other CEXT components** The MSP, RMM, and LCM for the CEXT perform the same functions described for the CRSC. Unit redundancy of the CEXT increases RSC-S abilities.

### **Cabinetized line module ISDN cabinet**

One CLMI cabinet on a single-configuration RSC-S can contain a maximum of two ISDN 2B1Q line modules.

### Cabinetized miscellaneous equipment cabinet

One CMIS cabinet on a single-configuration RSC-S can contain equipment that the customer specifies.

### Cabinetized miscellaneous spares storage

One CMSS cabinet on a single-configuration RSC-S can provide spare card storage.

# Additional components

The RSC-S with ISDN configuration is like the RSC-S without ISDN configuration. The ISDN basic rate interface (BRI) services require additional components as follows:

- the RCC2 or DRCC2 with ISDN
  - DCH card
  - EISP card
- the LCME
  - host
  - operation, administration, and maintenance (OAM) processor
- customer premises equipment (CPE)

### **Remote cluster controller-2 with ISDN**

Perform the following steps to activate ISDN services on an RSC-S:

- Use P-side DS-1 slots to allow DCH circuit cards.
- Change the MSP to support DCH cards.
- Add the software loads.

### The D-channel handler

The DCH card functions like the DCH for a host ISDN office, as follows:

- service access point identifier (SAPI) discrimination function at layer 2 (Q.921 link access procedure on the D-channel [LAPD])
- termination of SAPI (signaling) frames and routes the frames to the ISDN signaling preprocessor (ISP) card

- statistical multiplexing of SAPI 16 (packet) frames and transmission of the frames to the packet handler (PH). The DCH card functions with a statistical multiplex ratio of up to 64:1
- reflection of SAPI 17 (user-to-user looparound) frames back toward the user

### **Enhanced ISDN signaling preprocessor**

The EISP card provides ISDN layer 3, Q.931 processing. Slot 4 in unit 0 and slot 24 in unit 1 contains this card. Each RCC2 has one ISP card and EISP card card activity links to and is part of the RCC2 unit activity. The active ISP communicates with the DCHs.

The EISP card functions like the ISP does for a host ISDN office, as follows:

- provision of a communication channel between the signaling processor (SP), master processor (MP) and the DCH cards
- processing of SAPI 0 call control messages received from the DCH card

An RCC2 with ISDN has ISP and ISP16. The ISP card has data entries in translations.

### Enhanced line concentrating module

The LCME uses the 2B1Q U-loop interface to provide the subscriber with BRI. Nortel uses the following to provide the North American Standard 2B1Q U-loop interface:

- 2B + D channels
- six maintenance channels (M) located in the 2B1Q superframe

### Packet handler

Based on the DPN-100 Family of packet switches, the PH consists of the main components that follow:

• digital interworking unit (DIU)

The DIU takes the B- and D-channel packets received in DS-1 format from the DMS-100 controller peripheral. The controller peripheral can be the RCC2, LTCI, or other peripheral compatible with ISDN. The DIU converts the packets into the V.35 format for the AM. For data in the opposite direction, the DIU changes data in the V.35 format to DS-1 format.

• access module (AM)

The AM provides access to the RMs of the DPN from local subscriber packet lines and from the DIU.

- resource module (RM). The RM performs the following functions:
  - The RM sends packet-switching operations on data packets from the AM, or from digital trunks in the packet-switched network
  - The RM sends the switched packets to the AM for format conversion and distribution or out to terminals in the packet-switched network through a digital trunk

### The OAM processor

The ISDN OAM processor helps to achieve centralized OAM. The OAM processor allows the transfer of information to and from the PH from the MAP terminal at the exchange termination (ET).

### **Customer premises equipment**

For BRI, the CPE consists of the components that follow:

• the S/T-bus

the part of the ISDN BRI interface connected to ISDN terminals

the ISDN terminals

include the T2317, M5209T/TD, and M5317T/TD telephone sets that provide voice and data features

• the ISDN Universal Terminal Adapter (UTA)

connection of the S/T-bus to a personal computer.

• network termination 1 (NT1)

conversion of the proprietary loop protocol on the network side to the CCITT standardized protocols on the user side. The NT1 is necessary for BRI when an ISDN U-line card terminates a line. An S/T-line card that terminates on ISDN lines requires Network termination 2 (NT2). The ISDN switch acts as an NT2.

the U-loop

the part of the BRI interface that converts the NT1 to an ISDN U-line card in the ET ISDN switch.

### **Planned products**

Future RSC-S development will add STS-1 capability to allow the RSC-S to provide an interface to a SONET multiplexer. A paddleboard that will contain a junction circuit card will connect two STS-1 interface cards. The two cards

will connect into one STS-1 transmission link interface. The two functions of the paddleboard are as follows:

- in the transmit path, the paddleboard selects the transmission STS-1 interface card. The card generates the data stream according to the fiber activity signal
- in the receive path, the paddleboard splits the input data stream to both STS-1 interface cards

# 3 RSC-S signaling

# **Signaling for RSC-S**

This section describes the signal design and protocols of Remote Switching Center SONET (RSC-S) and the features RSC-S support.

# Signaling and communications protocols

The RCS-S uses the following protocols for communications and subscriber services:

• DMS-X

The use of a full duplex message channel implements DMS-X. The DMS-X is a half-duplex, byte-oriented protocol. The DS-1 or DS-30A links are full duplex message channels. The RSC-S processor handles the DMS-X message protocol on the message channels of the DMS-X to the host, remote or collocated equipment.

• HDLC

The HDLC is a full duplex message protocol based on the CCITT level 2 Signaling System 7 (Q.703). The LTC+ and RCC2 peripherals support this protocol.

• Q.921 CCITT link access procedure on the D-channel (LAPD)

Use Q.921 LAPD protocol to establish data link communications between a service access point identifier (SAPI) and a terminal end point identifier (TEI). This action transmits information from a higher layer protocol or receives information for delivery to a higher layer protocol. The Q.921 protocol transmits common signal channel (CSC) messages and embedded operations channel (EOC) messages.

• Q.931 CCITT digital network access

Use Q.931 protocol to communicate call setup, call monitoring and call tear-down information between the RSC-S and the host. The RSC-S must translate Q.931 generic-based signaling messages into a DMS-X message format the host can understand. Use Q.931 protocol for common signal channel messages.

• X.200

The X.200 protocol is the Open Systems Interconnect (OSI) defined 7-layer stack communications protocol.

• Bellcore compliant ADSI tones and Compatible Voiceband Data

Bellcore Customer Premises Equipment Compatibility for Voiceband data transmission, CLASS features and ADSI tones.

### **C-side links**

The RSC-S and the host central controller (CC) use an extended super frame format. The RSC-S and the host CC use this format to exchange information over 2 to 20 DS-1 control side (C-side) links. The DS-1 links operate at a rate of 1.544 Mb/s, with a sampling frequency of 8000 frames each second.

The DS-1 link has 24 information channels. Each channel contains eight bits of pulse code modulation (PCM) data. A framing bit is present at the end of the sequence. The framing bit makes sure the RSC-S and the host recognize the start of each 24-channel sequence. Framing bits are also called stuffing or S-bits. The sequence can send 192 bits of information and a framing bit during each 24-channel sequence.

The DS-1 channel frames carry speech, signaling or operations information. The following figure is the format of a DS-1 frame and a super frame that has 12 DS-1 frames.




Figure 3-1 DS-1 frame format

### **Extended frame format**

The DS-1 extended super frame format (ESF) has 24 frames. The 24 sync-bits are used as follows:

• six bits for framing pattern sequence (FPS)

Every fourth framing bit carries a FPS bit. When the FPS works with the cyclic redundancy check (CRC), the FPS defines an in-frame condition.

• 12 bits for facility data link (FDL)

The 4-kb/s facility data link (FDL) bit begins with the first framing bit. An FDL-messaged bit carries over every other frame.

• six bits for cyclic redundancy check (CRC)

The cyclic redundancy check (CRC) bit begins with the second bit and carries over every fourth bit. In an extended super frame, the system checks a block check field six times. The CRC-6 check detects bits that emulate an FSP bit and determines if an out-of-frame condition is present.

The superframe alignment pattern appears in the following table.

Frame number	Framing bit type	Framing bit value
1	FDL	m
2	CRC	CB1
3	FDL	m
4	FPS	0
5	FDL	m
6	CRC	CB2
7	FDL	m
8	FPS	0
9	FDL	m
10	CRC	CB3
11	FDL	m
12	FPS	1
13	FDL	m
14	CRC	CB4

Table 3-1 Superframe alignment pattern (Sheet 1 of 2)

Frame number	Framing bit type	Framing bit value
15	FDL	m
16	FPS	0
17	FDL	m
18	CRC	CB5
19	FDL	m
20	FPS	1
21	FDL	m
22	CRC	CB6
23	FDL	m
24	FPS	1
CB = check bitsm = message byte		

 Table 3-1
 Superframe alignment pattern (Sheet 2 of 2)


### **Signaling additions**

Use of the Bellcore TR-303 protocol adds an information facility data link as a part of the North America signaling.

### **DDL signaling to SLC-96**

A derived data link (DDL) frame has 6 super frames or 72 channel frames. Use the derived data link (DDL) to virtually connect the CC to the SLC-96. The DDL message uses the first 24 of 36 frame-signaling (Fs) bits of 72 frames. The format of the synchronization bits of 72 consecutive frames appears in the following figure.

Figure 3-2 DDL signaling format



The 24-bit pattern conveys three types of information:

- frame pattern sequence
- facility data link performance
- cyclic redundancy check

# Incoming DDL

The DS-1 interface (IF) card places a string of six consecutive DDL bits from the DS-1s on the DS30 lines. The DS30 signaling protocol is like DS30A protocol.

# **Outgoing DDL**

In transmission, the CPM places a 6-bit byte in every 12th frame that comes out of the matrix card. This action occurs four times in 72 frames for a total of 24 DDL bits.

# DDL processing

The matrix card switches all frame output into one DS60 digroup connected to the SIGP card. The DS60 digroup is 2 DS-30s. The signaling processor (SP) takes control from this point.

DDL bits	Field name	Explanation
1 —11	Concentrator field (C-field)	Shelf groups AB and CD only use the C-field when the groups operate in Mode II. This field carries information for shelves A, B, C and D. This field also carries information for control of subscriber assignment and de-assignment to DS-1 channels. The field also carries information for hook changes and activation of the PCM looping test.
		<i>Note:</i> When C-field is not available to send on the DDL link, the microprocessor sends an idle pattern on the link. The RSC-S sends an idle pattern when a new C-field is not present.
12—14	Spoiler bits (fixed pattern of 010)	The system inserts spoiler bits at specified positions in the DDL. This action makes sure the DDL does not duplicate the signaling pattern.
15—17	Maintenance field (M-field)	The M-field on the A-link carries information for all shelves and controls card and customer loop testing. Refer to note.
patterns. Th		between messages, the microprocessor sends previous field formation to the SP only when a DDL field changes. The

 Table 3-2
 DDL message bits and field names (Sheet 1 of 2)

DDL bits	Field name	Explanation
18—19	Alarm data link field (A-field)	The A-field on the A-link carries alarm and system control information for all shelves (refer to note).
20—23	Protection line switch field (S-field)	The S-field on the A-link controls the switching of the DS-1 protection link (refer to note).
24	Spoiler bit field (fixed pattern of 1)	The system inserts spoiler bit at the specified position in the DD. This action makes sure the DDL does not duplicate the signaling pattern.

Table 3-2	DDL message	bits and field	names (	Sheet 2 of 2)
	DDE moodage		1 11411100 (	011001 2 01 2)

*Note:* If fields M, A or S do not change between messages, the microprocessor sends previous field patterns. The microprocessor sends information to the SP only when a DDL field changes. The system does not transmit idle patterns.

# **Planned products**

Future development of the RSC-S adds synchronous transport signal level 1 (STS-1) capability for the RSC-S. This development provides an interface to a SONET multiplexer.

### **SONET** format

The SONET uses the basic building block of STS-1 with a bit rate of 51.84 Mb/s. Higher level signals are integer multiples of the base rate.

A quantity of 8-bit bytes organized into a frame  $125 \ \mu s$  in length make a synchronous signal. In the frame, framing or marker bytes identify each byte.

In an STS-1 frame, the synchronous payload has two areas. The areas are path overhead and payload area. The payload area contains customer data. The path overhead contains alarm and performance monitoring information. Transport support and maintenance of the synchronous payload envelop between end locations requires this information.


*Note:* One STS-1 level signal can transport 28 DS-1 links.

### **P-side links**

The RSC-S supports a maximum of 54 P-side links that can configure to various combinations of DS-1 links and DS-30A links. The P-side DS-1 links can attach to remote line concentrating modules (RLCM), outside plant modules (OPM) and PBX or CDO trunking. The P-side DS-1 links have the same format as C-side DS-1 links. The P-side DS-30A links can connect to collocated equipment like improved line concentrating modules (LCME) or remote maintenance modules (RMM). Both DS-1 links and DS30A links use the DMS-X protocol.

The DS30A channel frames carry speech or message information. The format of a DS30A frame appears in the following figure. The DS30A links operate at a rate of 2.56 Mb/s with a sampling frequency of 8000 frames every second. The DS30A link frame contains 32 channels. Each channel contains 10 bits of pulse code modulation (PCM) data.

Figure 3-3 DS-30A frame format




A frame synchronization bit is at channel 0 bit 0. This bit makes sure the RCC2 and the LCME or RMM recognize the start of each frame sequence.

### Message links

The RSC-S and host exchange system control information with dedicated message links. The host uses system control messages to transfer call processing, initialization and maintenance information to the RSC-S. The RSC-S uses system control messages to inform the host of the activities of the RSC-S. System control messages contain information like time slot assignments to off-hook subscriber lines, test requests and alarm statuses.

One message channel time slot is the primary message link. The other message channel is the secondary message link. The primary message link is active and the secondary message link is not active. The host monitors both links for messages and only responds to messages on the primary link. When DS-1 links 0 and 2 are installed, the selected primary message channel is the first DS-1 link 0.

Figure 3-4 RCC2 message links



### Message channels

Communication links between the RCC2 and the host peripherals on the C-side use the DMS-X protocol. Communication links between the RCC2 and peripherals on the P-side also use the DMS-X protocol.

Messages from the CC to the RCC2 are first sent to the host XPM, like a line trunk controller (LTC+). The host LTC recognizes the message for the P-side node and sends the message with the XPM messaging software system. The message uses a message channel. The message channel sends the message between the two nodes to the destination.

The XPM messaging software system contains the following operating layers:

- The link layer (level 1) provides the mechanism required to transfer the data bits from one node to another node. In this condition, the required mechanism is the DS-1 link. This link connects between the host XPM P-side interface card and the RCC2 C-side interface card.
- The data link layer (level 2) provides the mechanism required to transfer messages from one node to another node. The second node is directly connected to the node. The data link layer uses the route the network layer selects. This layer performs error detection and notification and maintains

sequential order of messages. This layer allows the activation and deactivation of message support links.

• The network layer (level 3) provides the application software with the mechanism required to send a message in the network. Messages go from one node to another node. The network layer selects a route to send the message toward the desired destination node. The layer starts the required service from the message link layer.

### Data link layer

The RCC2 converts two standard DS-1 frames into one internal DS60 frame. Timeslot 1 of links 0 and 2 is extracted from the DS-1 interface. Timeslot 1 is wired directly to the first network message interface (NMIF) channel. The timeslot is wired in the correct RCC2 message card. The speech bus interface (SBIF) directs messages along the speech bus until the messages reach the messaging card. Each timeslot on the speech bus also functions as a messaging channel, toward the C-side or P-side of the shelf. The DMS-X protocol uses channel 1 on each link .

# **DMS-X and HDLC protocol applications**

Two data link protocols are used between LTC (DMS-X) or an LTC+ (DMS-X and HDLC) and an RCC2. The data link protocols are DMS-X and high data link control (HDLC). To apply a data link protocol on a specified timeslot, the specified channel is declared a data link. Data link protocols apply to the C-side of an RCC2 or P-side of an LTC or an LTC+. The system assigns this data link to a specified node entity. Additional data links occur in the LTC+ and RCC2.

### **DMS-X protocol**

The DMS-X is a half-duplex, byte-oriented protocol implemented with a full duplex message channel, like the DS-1 links. The DMS-X is a state-driven code. The DMS-X requires handshake messaging between the RSC-S and host at each stage of data transfer. This requirement allows communicating terminals to delay the message transfer if one of the terminals is not ready. The DMS-X handshaking protocol appears in the following figure.




Figure 3-5 DMS-X handshaking protocol

Message time-out and message checksum or CRC calculation perform message error detection. Protocol, checksum or CRC failure can occur on an outgoing message. When this event occurs, the node that attempted the send sequence attempts the send sequence again. On an incoming message failure, the node that sends routes the message again over an alternate (C-side) link. Hardware redundancies provide a minimum of one alternative path to and from a node.

### **DMS-X** message format

The DMS-X message applies to both DS-1 and DS30A. The DMS-X message header in the first six bytes is as follows:

- The first byte is the start of message.
- The second byte is the destination task identification (ID) of the message. An outgoing message uses this ID to identify the process to receive the message.
- The third byte is the source task ID. An incoming message uses this ID to identify the process that sent the message.
- The last three bytes are the task ID numbers.

The number of bytes in the message or data can change. The CRC, that occupies two bytes, detects transmission errors. The end of message occupies one byte. The DS-1 message format appears in the following figure.




Figure 3-6 DMS-X message format

### HDLC protocol

High data link controller (HDLC) protocol is a new LTC+ to RCC2 message protocol for the extended distance capability (EDC) application. The NTMX76AA messaging card implements this protocol. The NTMX76AA messaging card is in the host and the remote peripherals. The NTMX76AA card replaces the NT6X69 card. The LTC+ and the RCC2 use the same links as message links. The LTC+ and the RCC2 use timeslot 6 through the speech bus interface (SBIF).

You cannot apply HDLC protocol with the NMIF. The system requires two additional timeslots on the speech bus. The system cannot use the timeslots for speech.

When all HDLC links lose synchronization to the active RCC2 unit, the RCC2 attempts to SWACT. When the SWACT fails, the RCC2 enters ESA. When all HDLC message links of a RCC2 unit are not in synchronization, the RCC2 unit works in the DMS-X mode. The message links must be in synchronization after the dynamic upgrade.

# Protocol change from DMS-X to HDLC

Feature AN1548, with feature AN0979, In-service Upgrade DMS-X to HDLC, supports the upgrade of DS-1 links between the LTC+ and the RCC2. When the messaging protocol changes, the remote can be in service. Static data downloaded from the CC is updated dynamically in both the host and the remote peripherals.

When HDLC protocol is applied dynamically, the system scans for current calls on channels for HDLC messaging. When established calls are present on these channels, the system displays a warning that the system can drop active calls. The system prompts the user to reject or confirm dropping these calls. Free channels are channels calls do not occupy. These channels are reserved for HDLC. The system reserves these channels until the protocol changes or the user refuses the change in protocol.

The following is an example MAP display of this process:

Enter Y to confirm, N to reject or  ${\tt E}$  to edit

>Y

3 existing calls will be dropped Please confirm ("Yes", "Y", "NO", or "N")

# >Y

In the example, the user establishes three calls. The user allows the three calls to drop and continues the DMS-X to HDLC protocol change. Static data goes from the CC to the LTC+ and the RCC2. This action establishes RCC2 nailed-up connections for HDLC message channels. Data and network links are created and bound into the messaging system. The PM is set ISTb until all HDLC links synchronize.

The NTMX76 firmware (layer) handles HDLC synchronizations. The link synchronizes when the host link and remote sides communicate. The NTMX76 audit process verifies if the new HDLC links synchronize.

When a minimum of one HDLC link (for each unit) synchronizes, the audit activates the HDLC link for messaging. An unsolicited message goes to CC. The system generates a PM181 log for each synchronized HDLC link. The ISTb state the synchronization problem causes clears when all HDLC message links of an RCC2 unit synchronize again.

When a link fails to synchronize or loses synchronization, an unsolicited message from each remote unit goes to the CC. The message goes out after the version registry check to prevent problems in one-night-process (ONP). The system generates a PM181 log to indicate the exact link is not in synchronization.

When all HDLC links lose synchronization to the active RCC2 unit, the RCC2 attempts to SWACT. When the SWACT fails, the RCC2 enters ESA. When all HDLC message links of a RCC2 unit are not in synchronization, the RCC2 unit works in the DMS-X mode. The message links must be in synchronization after the dynamic upgrade.

### Limits

The following limits apply for the in-service upgrade from DMS-X to HDLC protocol.

- When the HDLC protocol is declared on a new defined remote peripheral, DS-1 carriers must use the B8ZC attribute. The DS-1 carriers must also use this attribute during the upgrade from DMS-X to HDLC. Some DS-1 carriers are dedicated to messaging between the host and remote, as table LTCPSINV defines. These DS-1 carriers cannot use the ZCS attribute as defined in the corresponding tuple in table CARRMTC.
- During dynamic upgrade, the system can drop a maximum of six current calls.
- Do not perform a dynamic upgrade during heavy call traffic.

### ISDN basic rate interface signaling

The ISDN basic rate interface (BRI) has two 64-kbit B-channels for voice and data and a 16-kbit D-channel for signaling and packet data. The ISDN basic rate interface is referred to as 2B+D. The two types of ISDN BRI signaling are functional and stimulus.

Software assembled into the physical set of the functional BRI terminal supports functional BRI signaling. The Q.931 protocol and the signaling control protocol (SCP) sends call control messages. The protocol sends control messages between the functional BRI terminal and the network.

The system does not support stimulus BRI signaling for the RSC-S configuration.

### Q.931 digital network access protocol

Call control uses Q.931 signaling protocol. The following determines the protocol procedure:

- setup and takedown of calls and features between the network and terminals
- address displays and progress indicators at the terminal and the network
- B-channel control from the network

The Q.931 protocol supports basic error-handling procedures and re-initialization after the errors occur. The system can recover from these errors. The Q.931 protocol also determines the signaling methods used in host-switched calls.

### Meridian business set signaling

Meridian Business Set (MBS) signaling allows call processing software to communicate directly with the MBS terminal. An above-voice frequency, low-speed data channel transports the MBS messaging over the loop. This data channel sends signaling information over a separate D-channel between the RSC-S DCH card and the host.

Data channels communicate data by the presence or absence of an 8-kHzsignal. The system supports the following MBS features for the RSC-S:

- Automatic Answer Back
- Automatic Dial
- Automatic Line
- Executive Busy Override
- Call Back Queueing
- Call Forward All Calls
- Call Park
- Call Pickup
- Call Waiting
- End-to-End signaling
- Group Intercom
- Individual Business Line
- Intercom
- Listen on Hold
- Make Set Busy
- Malicious Call Hold

- Multiple Appearance DN
- On-Hook Dialing
- Privacy Release
- Ring Again
- Speed Calling
- 3-Way Call/Call Transfer
- 6-Port Conference
- Feature Display
- Display Called Number
- Display Calling Number
- Query Time
- Business Set Inspect Key
- Automatic Inspect Mode
- Business Set Call Forward Universal Per Key
- Call-Request Enhancement
- Direct Station/Busy Lamp Field for MBS
- Station Camp-On for MBS
- Group Intercom All Call
- MADN Cut-Off on Disconnect (COD)
- MADN Bridging—Three-Way Call
- Multiple Executive Message Waiting Keys per DN

### Global and Universal tone receiver (GTR/UTR) features

### ATTENTION

For peak performance, do not install the UTR and GTR on the same RCC2. You cannot identify the receiver that interprets tone samples. Some call processing tones can degrade if designed for use with a GTR.

Subscriber lines associated with an RSC-S can use the optional global and universal tone receiver (GTR/UTR) feature. The GTR/UTR feature allows the part of the processing load to be removed from the host computing module (CM) to be implemented in the PM.

If the GTR/UTR feature is on the RSC-S, the RSC-S performs all digit collection functions at the subscriber terminal. These functions can be to perform the following:

- allocate a free receiver
- establish a path to the receiver
- collect and process digits
- de-allocate the receiver

The RSC-S goes through the following steps if the GTR/UTR is on:

- 1. Request a GTR/UTR channel.
- 2. Instruct the GTR/UTR to monitor tones.
- 3. When monitoring starts, the system informs the RSC-S of collected digits and normally performs some translation functions on the digits.
- 4. When the system does not require the receiver, the RSC-S frees the allocated GTR/UTR channel.

Note: To start the sequence requires a receiver request.

The RSC-S creates alerting tones to support the Deluxe Spontaneous Call Waiting Identification (DSCWID) feature. A line with the DSCWID option can establish a call and a second call can attempt to terminate to that line. In this occurrence, the RSC-S provides one of two types of alerting signals. The two types of signal are a subscriber alerting signal (SAS) and an SAS followed by a customer premises equipment (CPE) alerting signal (CAS). The tones alert the DSCWID subscriber of the pending call and the DSCWID CPE of pending caller data.

The subscriber recognizes the SAS as the call waiting tone. The CAS alerts the CPE of incoming data. The CAS must follow the SAS to trigger an Analog Display Services Interface (ADSI) compatible CPE to display the DSCWID options. The CAS tone prepares the CPE to receive caller identification (CID) data.

The DSCWID CPE generates an acknowledge (ACK) tone to indicate the DSCWID CPE can receive DSCWID data. If the CPE is ADSI compatible, the CPE sends a DTMF A ACK signal in response to the CAS. If the CPE is a SCWID CPE, the CPE sends a DTMF D ACK signal in response to the CAS. When alerting tones are sent, the subscriber can use the CPE softkeys to control disposition to the incoming call. The CPE must be ADSI for the subscriber to change the ADSI. If the CPE is a SCWID or a 2500 set, the subscriber can use hard-coded keys.

T-tone timers set the maximum amount of time between sending a flash and the DTMF digit on an ADSI set. The RSC-S starts a T-tone timer. This event occurs after the RSC-S receives a flash signal from the ADSI compatible CPE of the customer. The value of T-tone is 600ms. The speech path is silent during the T-tone. The first option of a DSCWID call uses the T-tone timer. The CPE type does not affect this action. Additional DSCWID options on an ADSI set also use the T-tone timer.

Additional DSCWID options on a SCWID or 2500 use a new timer (T-flash). These options use T-flash after a call is answered, with SCWID and 2500 sets. The use of T-flash provides the customer with enough time to select an option after a flash. The T-flash was introduced because subscribers did not have enough time to flash and dial a DTMF digit in 600 ms. The T-flash is an operating company controlled timer that the operating company can set from 1 to 8 seconds. The default value is 1.5 seconds. The RSC-S starts the T-flash timer if the NON-ADSI field is set to Y. The RSC-S receives a flash signal from the SCWID or 2500 set of the customer. The RSC-S receives the signal during the held or conference call state. The RETURN option applies if the RSC-S cannot attach a GTR/UTR before 400 ms.

*Note:* The RSC-S must provide options for Bellcore TR-416 compliance. The RSC-S must provide options if the RSC-S detects a flash and cannot attach a GTR/UTR. The RSC-S sends a flash to the CC if the RSC-S cannot attach a GTR/UTR in 400 ms. The RSC-S sends a flash to comply with the Bellcore requirement.

### A- and B-bit signaling

The RSC-S basic call processing supports software for basic call processing, CLASS services, ISDN and ESA. The RSC-S and host must exchange system control messages over the DS-1 message channel to support these activities. Each channel signaling message uses A- and B-bits from selected speech channels. The A-bits transport on bit 8 of the 6th frame of every 12 frame sequence. The B-bits transport on bit 8 of the 12th frame in the sequence.

A- and B-bits are signaling bits that provide the following supervisory information:

- status of subscriber lines (on-hook or off-hook)
- ringing
- dial pulses

A- and B-bits have a value of 0 or 1 and are used together for signaling. The type of line card that receives or sends the bits determines how the bits are interpreted. For dial pulses, a series of makes and breaks are sent on the subscriber loop. The value A=1 represents a make and A=0 represents a break.

Coin lines use A- and B-bits in selected speech channels for each channel signaling. These lines use 8-bit patterns in correct speech channels for supervision. The coin lines use A- and B-bits and 8-bit coin signaling patterns together to perform supervision. The coin line card handles ground start or loop start supervisory signaling.


The following eight areas are essential to call processing:

- origination and channel allocation
- tone generation with dial tone speed recording
- digit collection
- ringing
- automatic number identification
- loss padding
- messaging loss to host
- busy/return to service of lines

### 1-Meg Modem Service supported protocols

The 1-Meg Modem Service uses several protocols to carry data from the subscriber to the service provider. The following figure illustrates the 1-Meg Modem Service architecture.

#### Figure 3-7 1-Meg Modem Service architecture



### DBIC

The following section describes the protocols used by the DBIC, xLC, subscriber loop, and 1-Meg Modem.

### Ethernet

The DBIC has a half-duplex Ethernet interface on the network side. The DBIC stores downstream frames and transmits the frames to the user. The DBIC only sends frames with MAC addresses that match the MAC addresses of the active

users. Similarly, the DBIC stores frames from the user side. The DBIC sends these frames to the network when it receives the whole frame.

The DBIC sends all user traffic out at the Ethernet port. The DBIC does not route traffic between users. This method has the following advantages.

- makes sure that all traffic goes to the correct service provider
- reduces the bandwidth overhead for broadcasts
- improves network security

The 1-Meg Modem Service does not process data above Layer 2. The 1-Meg Modem Service remains at the MAC layer and only uses the Ethernet address. Since the DBIC does not look at the payload carried in the Ethernet frames, except for ARP and BOOTP messages, the DBIC can carry Layer 3 data, such as internet protocol (IP), Internet Packet Exchange (IPX), and Appletalk. However, 1-Meg Modem Service only supports TCP/IP. The 1-Meg Modem Service can support other protocols, such as IPX, if MAC translation is turned off. When you turn MAC translation off, you reduce security and increase the configuration work for the transport network. However, this setup can be acceptable in a campus environment. The maximum transfer unit (MTU) size for the 1-Meg Modem Service is 1500 bytes, the same size that is defined in the ANSI 802.3 standard.

### XLBUS

The DBIC uses a point-to-point connection to each line card to exchange voice and data with the xLCs. The extended LBUS (XLBUS) is bidirectional with a total capacity of approximately 1.5 Mbit/s for data traffic. Upstream data, downstream data, and control data share this capacity. The XLBUS carries user data, synchronization and xLC control and status information. The control data carried over the XLBUS allows the DBIC processor to access registers in the xLC. User frames passed by the XLBUS have special Start Of Frame (SOF) and End Of Frame (EOF) control bytes.

### XLC and loop

The xLC and subscriber loop use the following protocols.

### XDLC

The user data in the xLC is encapsulated into the XDLC protocol, which is based on HDLC.

### XLINK

The XLINK frame has a fixed length for robust framing.

### XLOOP

The XLOOP includes the details that relate to the modulation used to carry data over the copper loop. In the downstream direction, 256/64/16/4-QAM can

be used over narrowband or wideband spectrums providing 1280, 960, 640, 320, 240, 160 or 80 kbit/s of raw data throughput. In the upstream direction, 256/64/16/4-QAM are also used providing 320, 240, 160, 120, 80 or 40 kbit/s of raw data throughput.

### 1-Meg Modem

The Ethernet interface at the 1-Meg Modem provides a half-duplex 10BaseT or 100BaseT connection. The interface does not filter local traffic and passes all traffic upstream. Only one Ethernet device can connect to the 1-Meg Modem.

# **4 RSC-S recovery procedures**

This chapter contains the recovery procedure for the DMS-100 Remote Switching Center-SONET (RSC-S). This procedure allows maintenance personnel to return an RSC-S to service from an out-of-service condition. These conditions include an emergency stand-alone (ESA) condition.

# PM RCC2 critical

# Alarm display

СМ	MS	IOD	Net	PM	CCS	Lns	Trks	Ext	Appl	
				nRCC2 *C*				•		


# Application

Use this procedure to restore call processing under central control (CC) on an RCC2.


# Action

This procedure contains a summary flowchart and a list of steps. Use the flowchart to review the procedure. Follow the steps to perform the procedure.

#### Summary of recovering an RCC2



### Summary of recovering an RCC2 (continued)



#### **Recovering a PM RCC2**

#### At the host office

- 1 Proceed if:
  - an Alarm Clearing Procedure procedure directed you to this procedure
  - your maintenance support group directed you to this procedure

#### At the MAP terminal

2 To silence an alarm that is audible, type

>MAPCI;MTC;SIL

and press the Enter key.

3 To access the peripheral module (PM) level of the MAP display and identify the defective RCC2, type

>PM;DISP STATE SYSB RCC2

and press the Enter key.

4 To post the RCC2 with the alarm condition, type

>POST RCC2 SYSB

and press the Enter key.

5 To determine the fault condition, type

>QUERYPM FLT

and press the Enter key.

*Example of a MAP response:* Unit 0 System busy reason: Link Audit Unit 1 System busy reason: Link Audit

**6** To determine if the RCC2 is equipped with emergency stand-alone (ESA), type

#### >QUERYPM

and press the Enter key.

Example of a MAP response: PM Type: RCC2 PM No.: 0 PM Int. No.: 1 Node\_No.: 203 PMs Equipped: 309 Loadname: CRI07AZ EEPRom Load: MX77NH08 ESA equipped: YES IntraSwitching is ON WARM SWACT is supported and available. RCC2 0 is included in the REX schedule. Last REX date was FRI. 1995/03/10 at 12:25:07; PASSED. Node Status: {OK, FALSE} Unit 0 Act, Status: {SysB, TRUE}

	Unit 1 Inact, Status: {SysB, TRUE} Site Flr RPos Bay_id Shf Descript RSC0 01 A00 RCE 00 18 RCC2	
	(CAP) ithe EEPROM load name re Unified Processor (UP) the EEPR the example, the EEPROM load n	al NTAX74AA Cellular Access Processor effects NTAX74AA. For the NTMX77AA OM load name reflects NTMX77AA, In ame is $MX77NH08$ . If the RCC2 were xample EEPROM load name would be
	If the RCC2	Do
	is equipped with ESA	step 7
	is not equipped with ESA	step 16
7	Determine if the ESA exit time is set access table OFCENG, type	for manual recovery from ESA. To
	>TABLE OFCENG	
	and press the Enter key.	
8	To check the remote switching cente type	r-synchronous (RSC-S) ESA exit time,
	>POS RSC_XPMESAEXIT	
	and press the Enter key.	
	Example of a MAP response: PARMNAME PARM	IVAL
	RSC_XPMESAEXIT 0	
	If the PARMVAL	Do
	is set to zero	step 9
	is more than zero	Allow the system to recover the RCC2. Go to step 37.
9	To quit table OFCENG and remain at	the POST level of the MAP display, type
	>QUIT	
	and press the Enter key.	
10	To examine PM181 log reports that t	his RCC2 generates, type
	>LOGUTIL;OPEN PM 181;BACK A	
	and pross the Enter key	

and press the Enter key.

Example of a PM181 log report:

PM181 MAR14 14:33:54 7534 INFO RSC0 RCC2 0 UNIT 0
Node:SysB, Unit 0 Act:SysB, Unit 1 Inact:SysB
PM in ESA, Communication restored, ready to be RTSed

*Note:* The system only generates this log when the value for XPMESAEXIT in table OFCENG is equal to 0.

11 To quit Logutil and remain at the POST level of the MAP display, type

>QUIT

and press the Enter key.

12 Before you manually restore the RCC2 from ESA, check if links to the RCC2 are stable. To find the link numbers for this RCC2, type

>trnsl c

and press the Enter key.

Example of a MAP response:

(Host XPM P-side link number)

0: LTC 1	0;Cap MS;Status:OK	P;MsgCond:CLS, Restrict
1: LTC 1	2;Cap MS;Status:OK	P;MsgCond:CLS, Unrestricted
2: LTC 1	4;Cap S;Status:OK	
3: LTC 1	5;Cap S;Status:OK	
	1: LTC 1 2: LTC 1	1: LTC 12;Cap MS;Status:OK2: LTC 14;Cap S;Status:OK

13 To access the CARRIER level of the MAP display, type

#### >trks;carrier

and press the Enter key.

14 To post the host XMS-based PM (XPM) peripheral-side (P-side) links that interface the RCC2 in ESA and to check link conditions for slips and framing errors, type

>post pm\_type pm\_no link\_no

and press the Enter key.

where

pm\_type

is a line group controller (LGC) or line trunk controller (LTC)

pm\_no

is the number of the LGC/LTC (0 to 255)

link\_no

is the number of the link associated with the host XPM identified in

step 12

*Note:* Repeat the POST command for each link that interfaces the RCC2 in ESA.

Example of a MAP response:

	(Host XPM)	P-side link number)	
	N CLASS SITE LTC CK D ALRM SLIP 0 REMOTE HOST 1 0 C 0	FRME BER ES SES	STATE INSV
	If the link conditions	Do	
	have a high number of SLIP and FRME errors	Leave the RCC2 ir step 36.	ESA. Go to
	have a low number of SLIP and FRME errors	step 15	
;	To access the PM level of the MAP ter >PM;POST RCC2 rcc2_no and press the Enter key.	minal and to post the	RCC2, type
	where		
	rcc2_no is the number of the RCC2 ider	ntified in step 4	
;	To manually busy (ManB) the PM, type	-	
	>BSY PM		
	and press the Enter key.		
	To test the RCC2, type		
	>TST PM		
	and press the Enter key.		
	If the system response		Do
	is test passed		step 18
	is TEST FAILED with reason available	n, C-side links not	step 24
	is TEST FAILED and the system list	m generates a card	step 34
	To return the PM to service, type		
	>RTS PM		
	and press the Enter key.		
	MAP response example of an RCC2:		

```
RCC2 rcc2_no UNIT unit_no IN ESA MODE.
THIS ACTION WILL CAUSE ESA EXIT with n ACTIVE CALLS
A WARM EXIT WILL BE ATTEMPTED.
SOME CALLS MAY BE ABORTED.
PLEASE CONFIRM ("YES" OR "NO")
```

If the system response	Do
is RTS PASSED	step 37
is RTS FAILED and the RCC2 is configured with an NTMX77AA processor	step 19

is RTS FAILED and the RCC2 is configured with an step 21 NTAX74AA processor

*Note:* The system generates a PM171 log during ESA EXIT. This action details the call processing operational measurements (OM) during ESA.

**19** The peripheral/remote loader-16 card (NT7X05) allows local loading of RCC2 data. This procedure reduces recovery time. To check if the NT7X05 card is provisioned, type

#### >QUERYPM FILES

and press the Enter key.

Example of a MAP display:

										$\sim$
/ (	СМ М	S IOD	Net			LNS	Trks	Ext	APPL	
	•		•	1RCC2 *C*	•	•	•	•	•	
				-						
R	CC2	SysB	Ma	nB	OffL	CBsy	IST	b	InSv	
0	Quit	PM 2		0	2	0		2	25	
2	Post	RCC2 1		0	0	0		0	1	
3	ListSet									
4		RCC2	0 ISTb	Links	s_00S:	CSide	0, PSi	de 0		
5	TRNSL_	Unit 0:	Inact	SysB						
6	TST_	Unit 1:	Inact	SysB						
7	BSY_									
8	RTS_	QUERYPM	files							
9	OffL	Unit 0:								
10	LoadPM_	NT7X0	5 load	File: (	CRI07AZ					
11	Disp_	NT7X0	5 Image	File:						
12	Next_	CMR L	oad: C	MR03A						
13	SwAct	Unit 1:								
14	QueryPM	NT7X0	5 load	File: (	CRI07AZ					
15		NT7X0	5 Image	File:						
16	IRLINK	CMR L	oad: C	MR03A						
17	Perform									
18										)
										/

*Note:* If the NT7X05 card is not provisioned, the MAP response is: NT7X05 not datafilled, QueryPm files invalid

If the NT7X05 card	Do	
is provisioned	step 20	
is not provisioned	step 21	

20

21

22



#### DANGER Possible service interruption

The LOCAL LOADFILE option of the LOADPM command has a parameter of [<file> string}]. The LOADPM command does not patch the loadfile when you use this parameter. Do not use this parameter unless you need to use the NOPATCH option of the loadfile.

#### To load the RCC2 from the local loadfile, type

#### >LOADPM PM LOCAL LOADFILE

and press the Enter key.

If the load	Do
passes	step 22
fails	step 36
To load the RCC2 from the CC, type	)
>LOADPM PM	
and press the Enter key.	
If the load	Do
passes	step 22
fails	step 36
To return the PM to service, type	
>RTS PM	
and press the Enter key.	
If the system response	Do

	If the system response	Do
	is RTS FAILED	step 36
23	Check for dial tone accord	ling to local operating company procedures.
	If the dial tone	Do
	is not restored	step 36
	is restored	step 37
24	To identify central-side (C- (LGC) or an line trunk co	-side) links to the host PM, a line group controller htroller (LTC), that are system busy (SysB). type
	>TRNSL C	
	and press the Enter key.	
	Example of a MAP respor	ise:
		CAP MS;SysB;MSGCOND:CLS,Restricted
		CAP S;STATUS:OK
		CAP MS;SysB;MSGCOND:CLS,Unrestricted CAP S;STATUS:OK
~ -		
25	To post the host PM identi	
	>POST host_pm host_	pm_no
	and press the Enter key.	
	where	
	host_pm is an LGC or an LT	С
	host_pm_no is the number of the	e LGC or LTC

Example of a MAP display:

DMS-100 Family Switching Center-SONET Model B Maintenance Manual

/												
	CM MS	5 IOD		Net	PM	CCS	LNS		Trks	Ext	APPL	
	•			•	1RCC2	•	•		•	•	•	
					*C*							
Ľ	rc		S	ysB	ManB	0	ffL	CB	sy	ISTb	InSv	
(	) Quit	PM		3	0		1		0	4	12	
2	2 Post_	LTC		0	0		2		0	2	9	
	8 ListSet	5										
4	1	LTC	1	ISTb	Links_0	OS:	CSide	Ο,	PSide	2		
ļ	5 Trnsl_	Unit0:		Inact	InSv							
	5 Tst_	Unit1:		Act	InSv							
	7 Bsy_											
	B RTS_											
	9 OffL											
	) LoadPM_	-										
	Disp_											
	2 Next											
	8 SwAct											
	l QueryPN	4										
1												
10												
	7 Perform	n										
18	3											

26

#### To identify the defective P-side links, type

#### >TRNSL P

and press the Enter key.

Example of a MAP response:

LINK 0:	RCC2 1	0;CAP MS;STATUS;	SysB;MSGCOND:CLS,Restricted
LINK 1:	RCC2 1	1;CAP S;STATUS:	OK
LINK 2:	RCC2 1	2;CAP MS;STATUS	SysB;MSGCOND:CLS,Unrestricted
LINK 4:	RCC2 1	3;CAP S;STATUS:	OK
LINK 5:	RCC2 1	4;CAP S;STATUS:	OK
LINK 6:	RCC2 1	5;CAP S;STATUS:	OK
LINK 7:	RCC2 1	6;CAP S;STATUS:	OK

27 To busy the defective link, type

>BSY LINK link\_no

and press the Enter key.

### where

link no

is the number of the defective P-side link identified in step 26

- **28** To test the defective link, type
  - >TST LINK link\_no

and press the Enter key.

where

#### link\_no

29

30

31

32

is the number of the link manually busied in step 27 *Note:* Perform this step for each ManB link.

If the system response	Do
is test passed	step 29
is test failed	step 36
To return the link(s) to service, type	
>RTS LINK link_no	
Note 1: and press the Enter key	
Note 2: where	
link_no is the number of the link test	ed in step 28
Note: Perform this step for each	ManB link.
If the system response	Do
is RTS FAILED	step 36
is RTS PASSED	step 30
To post the RCC2, type	
>POST RCC2 rcc2_no	
and press the Enter key.	
where	
rcc2_no is the number of the ManB R	CC2
To return the RCC2 to service, type	
>RTS PM	
and press the Enter key.	
If the system response	Do
is RTS PASSED on both units	step 37
is RTS FAILED on both units	step 36
is RTS FAILED on one unit	step 32
To test the ManB RCC2 unit, type	

33

# PM RCC2 critical (continued)

### where

#### unit\_no

is the number of the ManB RCC2 unit (0 or 1) that did not RTS

If the system response	Do	
is TST PASSED	step 33	
is TST FAILED	step 36	
To return the tested RCC2 unit	to service, type	
<pre>&gt;RTS UNIT unit_no</pre>		
and press the Enter key.		
where		
unit_no	C2 unit tested in step 32	

If the system response	Do
is RTS PASSED	step 37
is RTS FAILED	step 36

34 Check the card list in the MAP display, that results from step 17.

For RCC2s with the optional NTAX74AA Cellular Access Processor (CAP) the card list in the MAP response reflects AX74 in slot 03. For RCC2s with the NTMX77AA Unified Processor (UP), the card list in the MAP response reflects MX77. This condition appears in the following examples.

#### NTMX77

Example of a MAP response for an RCC2 configured with the NTMX77 Unified Processor:

SITE		FLR		RPOS	BAY_ID	SHF	DESCI	RIP	TION	SLOT	EQPEC
RSC0	01	P	700	CRSC	00	05	RCC2	:	000	:03	MX77
RSC0	01	P	700	CRSC	00	05	RCC2	:	000	:08	6X69
RSC0	01	P	700	CRSC	00	05	RCC2	:	000	:11	MX73
RSC0	01	P	700	CRSC	00	05	RCC2	:	000	:13	MX74
RSC0	01	P	700	CRSC	00	05	RCC2	:	000	:05	6X78

#### NTAX74

Example of a MAP response for RCC2s configured with the optional NTAX74AA Cellular Access Processor:

# PM RCC2 critical (end)

SITE		FLR		RPOS	BAY_I	D	SHF		DE	SCRIP	FION	SLOT	EQPEC
RSC0	01		A00	CRSC	00	05		RCC2	:	000	:03	AX74	
RSC0	01		A00	CRSC	00	05		RCC2	:	000	:08	6X69	
RSC0	01		A00	CRSC	00	05		RCC2	:	000	:11	MX73	;
RSC0	01		A00	CRSC	00	05		RCC2	:	000	:15	MX74	ł
RSC0	01		A00	CRSC	00	05		RCC2	:	000	:05	6X78	;
		the ca	rds	on th	e list		Do	-					
are	rep	laced					ste	ep 36					
are	not	replac	ed				ste	ep 37					

**35** If the system indicates other defective cards, go to the card replacement procedure in *Card Replacement Procedures* for the next card on the card list. Complete the card replacement procedure and go to step 17.

**36** For additional help to clear this alarm, contact the next level of support.

**37** This procedure is complete. If the system displays other alarms, refer to the appropriate alarm clearing procedures in the *Alarm Clearing Procedures*.

# **5 RSC-S alarm clearing procedures**

This chapter contains the alarm clearing procedures for the DMS-100 Remote Switching Center-SONET (RSC-S). Maintenance personnel use these procedures to clear alarms as the alarms appear at the MAP display.

Procedures in this chapter correspond to the alarms as the alarms appear at the MAP display. These procedures are in alphabetical order to allow maintenance personnel to locate the procedures easily.

# Ext MSP CLCE cabinet major

# Alarm display

СМ	MS	IOD	Net	PM	CCS	Lns	Trks		APPL
•	•	-	•	•	•	•	•	1FSP	•
								М	

# Indication

An FSP that follows a number under the Ext header of the alarm banner indicates an Ext modular supervisory panel (MSP) alarm. An M under the FSP indicates that the alarm class is major. The alarm display is at the MTC level of the MAP display.

*Note:* Current software does not reflect the change from FSP to MSP in the MAP display.

# Meaning

An MSP alarm occurs when one or more cabinets in the office have a power fault or a cooling unit fault. The number before the FSP is the number of cabinets with an MSP alarm. Refer to the previous note.

## Result

The effect of this alarm on subscriber service depends on the type of fault. The effect also depends on the type of frame the fault is in.

### **Common procedures**

This procedure refers to the common procedure "Replacing the cooling unit". Refer to this common procedure in the routine maintenance section of this manual.


## Action

This procedure applies to the following cabinets:

- Cabinetized Remote Switching Center with Line Concentrating Module (CRSC with LCM), NTMX89FA
- Cabinetized Line Concentrating Equipment (CLCE), NTRX30CA

The following flowchart is only a summary of the procedure to clear an alarm. A detailed step-action procedure follows the flowchart.

### Summary of clearing an Ext MSP CLCE cabinet major alarm



#### Clearing an Ext MSP CLCE cabinet major alarm

#### At the CLCE cabinet

1

#### ATTENTION

Illustrations of the CLCE cabinet, LCME fuse panel, and MSP are located at the end of this procedure.

#### Check the FAN FAIL LEDs.

2 Check the CONVERTER FAIL LED on each converter in the cabinet.

lf	Do
any CONVERTER FAIL LEDs are lit	step 51
no CONVERTER FAIL LEDs are lit	step 3
Check the RG FAIL LED on both RGs The FAIL LED is behind the front pane	
lf	Do
one RG has a lit FAIL LED	step 40
none of the RGs have a lit FAIL LED	step 4
Check the line drawer fuses located o each line concentrating array (LCA) (C	
lf	Do
there is a blown fuse (protrud- ing)	step 9

lf	Do			
there are no blown fuses	step 5			
Check the alarm battery supply (ABS) ocated on the MSP.	fuses F01, F02, F03, F04, and F08			
lf	Do			
there is a blown fuse (protrud- ing)	step 6			

- 6 Obtain a replacement fuse with the same voltage and amperage as the blown fuse.
- 7 Remove the blown fuse.
- 8

9

5



# DANGER

**Risk of fire** For continued protection against risk of fire, replace the fuse only with a fuse of the same type, rating (color code), and manufacturer.

Insert the replacement fuse.

If the fuse	Do	
blows (protrudes) again	step 87	
does not blow	step 83	

Determine which fuse is blown.

*Note:* Fuses 01 to 05 each supply +5 V, fuses 06 to 10 each supply +15 V, and fuses 11 to 15 each supply -48 V.

If the blown fuse	Do
is 01 to 05	step 14
is 06 to 15	step 10
is RA or RB	step 14

**10** Use the following table to determine which +15V fuse (06 through 10) is associated with which -48V fuse (11 through 15).

Do+15V fuse number	
06	
07	
08	
09	
10	
	06 07 08 09

11 Remove the blown fuse and the associated fuse. For example, if the blown fuse is 06, remove fuse 06 and 11.

- 12 Obtain a replacement fuse with the same voltage and amperage as the blown fuse.
- **13** Insert the -48V fuse, then the +15V fuse.

If the fuse	Do	
blows (protrudes) again	step 17	
does not blow	step 83	

- 14 Obtain a replacement fuse with the same voltage as the blown fuse.
- **15** Remove the blown fuse.
- 16



#### DANGER Risk of fire

For continued protection against risk of fire, replace the fuse only with a fuse of the same type, rating (color code), and manufacturer.

Insert the replacement fuse.

If the fuse	Do	
blows (protrudes) again	step 19	
does not blow	step 83	

17 Remove the blown fuse and the associated fuse. For example, if the blown fuse is 06, remove fuse 06 and 11.

- **18** Obtain a replacement fuse with the same voltage and amperage as the blown fuse.
- **19** Use the following table to identify the drawer associated with the blown fuse. The drawers are located in the shelf below the fuse panel. The RA and RB fuses supply ringing voltage to all five drawers in the shelf.

Fuse number	shelves 5 and 33	shelves 19 and 47
	drawer number	drawer number
01, 06, 11	0 (leftmost)	5 (leftmost)
02, 07, 12	1	6
03, 08, 13	2	7
04, 09, 14	3	8
05, 10, 15	4	9

20

Pull out the line drawer associated with the blown fuse. Begin with the leftmost drawer for a blown RA or RB fuse.

21



#### DANGER

**Personal injury** Do not touch the line feed resistors on the line cards. The line feed resistors generate enough heat to burn you.

#### CAUTION Loss of service

Perform this procedure during periods of low traffic.

Unseat all the line cards in the drawer. Do not remove them from the drawer.

If the fuse	Do
is any one of fuses 01 to 05	step 23
is any one of fuses 06 to 15	step 22

DMS-100 Family Switching Center-SONET Model B Maintenance Manual

22

If the fuse	Do	
is an RA or RB fuse	step 23	
nsert the -48V fuse, then the +15	5V fuse.	
If the fuse	Do	
blows (protrudes) again	step 26	
does not blow	step 28	

24 Remove the blown fuse.

25

23



#### DANGER Risk of fire

For continued protection against risk of fire, replace the fuse only with a fuse of the same type, rating (color code), and manufacturer.

Insert the replacement fuse.

If the fuse	Do	
blows (protrudes) again	step 26	
does not blow	step 28	

26

Check the drawer for loose or short-circuited wires.

lf	Do
there are loose or short-circuited wires	step 89
there are no loose or short-circuited wires, and the fuse is a ringing voltage fuse (RA or RB)	step 27
there are no loose or short-circuited wires, the fuse is a ringing voltage fuse (RA or RB), and you have done all five drawers in the shelf	step 89
there are no loose or short-circuited wires, and the fuse is one of the line drawer fuses (01 to 15)	step 89

- 27 Reseat all the line cards in the drawer and repeat steps 20 and 21 for the next drawer.
- **28** Reseat the line cards one at a time, and check the fuse.

lf	Do
after you reseat a line card, the	step 29

fuse blows (protrudes) again

after you reseat all the line cards, step 85 the fuse does not blow

### 29



### DANGER

**Personal injury** Do not touch the line feed resistors on the line cards. The line feed resistors generate enough heat to burn you.

Remove the line card from the drawer.

- **30** Obtain a replacement line card. Make sure that the replacement card has the same PEC, including suffix, as the old card.
- 31 Insert the replacement line card into the drawer.

If the fuse	Do
is any one of fuses 01 to 05	step 35
is any one of fuses 06 to 15	step 32
is an RA or RB fuse	step 35

- 32 Obtain a replacement fuse with the same voltage as the blown fuse.
- **33** Remove the blown fuse and the associated fuse. For example, if the blown fuse is 06, remove fuse 06 and 11.
- 34 Insert the -48V fuse, then the +15V fuse.

If the fuse	Do	
blows (protrudes) again	step 89	
does not blow	step 38	

**35** Obtain a replacement fuse with the same voltage and amperage as the blown fuse.

**36** Remove the blown fuse.

37



#### DANGER Personal injury

Do not touch the line feed resistors on the line cards. The line feed resistors generate enough heat to burn you.



#### DANGER Risk of fire

For continued protection against risk of fire, replace the fuse only with a fuse of the same type, rating (color code), and manufacturer.

Insert the replacement fuse.

If the fuse	Do	
blows (protrudes) again	step 89	
does not blow	step 38	

- **38** Reseat all the other line cards in the drawer.
- **39** Push the drawer back in and go to step 83.
- **40** Use the following table to identify the circuit breaker that is associated with the RG with a lit FAIL LED. This circuit breaker is on the MSP.

lfRG number	DoCircuit breaker numbe
RG0 (leftmost)	CB1
RG 1	CB3
heck the associated circuit bre	eaker.
heck the associated circuit bre	eaker. Do
f the circuit breaker	Do

41

42 Set the circuit breaker to ON.

### If the circuit breaker

goes OFF and the FAIL LED on<br/>the RG is litstep 43remains ON and the FAIL LED<br/>on the RG is not litstep 83remains ON and the FAIL LED<br/>step 48step 48

on the RG is lit

### At the CPDC

43 Locate the fuse that associates with the cabinet and shelf number.

If the fuse	Do
is blown (protrudes)	step 44
is not blown	step 49

Do

- 44 Remove the fuse holder with the blown fuse.
- 45



#### DANGER Risk of fire

For continued protection against risk of fire, replace the fuse only with a fuse of the same type, rating (color code), and manufacturer.

Replace the cartridge fuse inside the fuse holder.

46 Install the fuse holder back on the CPDC.

### At the CLCE cabinet

47 Set the circuit breaker to ON.

If the circuit breaker	Do
goes OFF and the RG FAIL LED is lit	step 49
remains ON and the RG FAIL LED is not lit	step 83

If the circuit brea	iker Do	
remains ON an LED is lit	d the RG FAIL step 48	
Set the circuit brea	ker to OFF.	
	procedure in <i>Card Replace</i> complete the procedure, re	ement Procedures to replace turn to this point.
Check the FAIL LE	D on the RG you replace.	
If the RG	Do	
FAIL LED is lit	step 82	2
FAIL LED is no	t lit step 83	1
Note the number o	f the shelf that contains the LED.	converter with the lit
Use the following ta the shelf that conta on the MSP.	able to identify the circuit bre in the lit CONVERTER FAIL	eaker that is associated with . LED. This circuit breaker is
If Shelf number	Do use circuit breaker	number
65		
05	CB1 (RG-0)	
05, 33	CB1 (RG-0) CB2 (LCM0/LCA0)	(LCM1/LCA0)
		(LCM1/LCA0)
05, 33	CB2 (LCM0/LCA0)	
05, 33 65	CB2 (LCM0/LCA0) CB3 (RG-1)	
05, 33 65 19, 47	CB2 (LCM0/LCA0) CB3 (RG-1) CB4 (LCM0/LCA1) (	
05, 33 65 19, 47 33	CB2 (LCM0/LCA0) CB3 (RG-1) CB4 (LCM0/LCA1) ( CB5 (converter)	
05, 33 65 19, 47 33 05	CB2 (LCM0/LCA0) CB3 (RG-1) CB4 (LCM0/LCA1) ( CB5 (converter) CB6 (converter)	
05, 33 65 19, 47 33 05 47 19	CB2 (LCM0/LCA0) CB3 (RG-1) CB4 (LCM0/LCA1) ( CB5 (converter) CB6 (converter) CB7 (converter) CB8 (converter)	
05, 33 65 19, 47 33 05 47 19	CB2 (LCM0/LCA0) CB3 (RG-1) CB4 (LCM0/LCA1) ( CB5 (converter) CB6 (converter) CB7 (converter) CB8 (converter) ed circuit breaker.	· · ·
05, 33 65 19, 47 33 05 47 19 Check the associa	CB2 (LCM0/LCA0) CB3 (RG-1) CB4 (LCM0/LCA1) ( CB5 (converter) CB6 (converter) CB7 (converter) CB8 (converter) ed circuit breaker.	LCM1/LCA1)

step 54

is OFF

# Ext MSP CLCE cabinet major (continued)

54 Set the circuit breaker to ON.

### If the circuit breaker

If the circuit breaker	Do
goes OFF and the CONVERTER FAIL LED is lit	step 55
remains ON and the CONVERTER FAIL LED is lit	step 62
remains ON and the CONVERTER FAIL LED is not lit	step 83

55 Note the numbers of the cabinet and shelf that contain the converter with the lit CONVERTER FAIL LED.

### At the CPDC

56 Locate the fuse that powers the shelf in the CLCE cabinet.

If the fuse	Do
is blown (protruding)	step 57
is not blown	step 62

- 57 Remove the fuse holder with the blown fuse.
- 58 Replace the cartridge fuse inside the fuse holder.
- 59



#### DANGER Risk of fire

For continued protection against risk of fire, replace the fuse only with a fuse of the same type, rating (color code), and manufacturer.

Replace the blown fuse.

- 60 Install the fuse holder back on the CPDC.
- 61 Set the circuit breaker to ON.

If the circuit breaker	Do
goes OFF and the CONVERTER FAIL LED is lit	step 63
remains ON and the CONVERTER FAIL LED is not lit	step 83
remains ON and the CONVERTER FAIL LED is lit	step 62

Set the circuit breaker to OFF.		
Refer to the correct procedure the converter. Complete the p	in <i>Card Replacement Proced</i> rocedure and return to this po	<i>lures</i> to replac
Check the current replaced con	nverter and the associated cir	cuit breaker.
If the circuit breaker		Do
goes OFF and the CONVE	RTER FAIL LED is lit	step 66
remains ON and the CONV lit	ERTER FAIL LED is not	step 83
remains ON and the CONV	/ERTER FAIL LED is lit	step 65
Set the circuit breaker to OFF.		
Remove the NT6X51 and NT6 CONVERTER FAIL LED.	X52 cards from the shelf with	the lit
Set the circuit breaker to ON.		
If the CONVERTER FAIL LE	D Do	
is lit	step 80	
is not lit	step 68	
Set the circuit breaker to OFF.		
Insert the NT6X51 card back in	nto the shelf.	
Set the circuit breaker to ON.		
If the circuit breaker		Do
goes OFF and the CONVE	RTER FAIL LED is lit	step 72
remains ON and the CONV lit	ERTER FAIL LED is not	step 74
remains ON and the CONV	/ERTER FAIL LED is lit	step 71
Set the circuit breaker to OFF.		
Go to the appropriate procedur the NT6X51 card. Complete the transmission of transmission of the transmission of the transmission of transmiss		
Set the circuit breaker to ON.		
If the circuit breaker		Do

If the circuit breaker	Do
remains ON and the CONVERTER FAIL LED is not lit	step 74
remains ON and the CONVERTER FAIL LED is lit	step 77
Set the circuit breaker to OFF.	
Insert the NT6X52 card back into the shelf.	
Set the circuit breaker to ON.	
If the circuit breaker	Do
goes OFF and the CONVERTER FAIL LED is lit	step 78
remains ON and the CONVERTER FAIL LED is not lit	step 83
remains ON and the CONVERTER FAIL LED is lit	step 7
Set the circuit breaker to OFF.	
Refer to the procedure in Card Replacement Procedures to	roplaca
NT6X52 card. Complete the procedure and return to this p	oint.
NT6X52 card. Complete the procedure and return to this possible the circuit breaker to ON.	oint.
NT6X52 card. Complete the procedure and return to this p	Do
NT6X52 card. Complete the procedure and return to this post of the circuit breaker to ON.	Do
NT6X52 card. Complete the procedure and return to this possible the circuit breaker to ON.	Do step 80
NT6X52 card. Complete the procedure and return to this possible the circuit breaker to ON.  If the circuit breaker goes OFF and the CONVERTER FAIL LED is lit remains ON and the CONVERTER FAIL LED is not	Do Step 80 Step 83
NT6X52 card. Complete the procedure and return to this possible the circuit breaker to ON.  If the circuit breaker goes OFF and the CONVERTER FAIL LED is lit remains ON and the CONVERTER FAIL LED is not lit	Do Step 80 Step 83 Step 82
NT6X52 card. Complete the procedure and return to this poset the circuit breaker to ON. If the circuit breaker goes OFF and the CONVERTER FAIL LED is lit remains ON and the CONVERTER FAIL LED is not lit remains ON and the CONVERTER FAIL LED is lit	Do step 80 step 83 step 82
NT6X52 card. Complete the procedure and return to this poset the circuit breaker to ON. If the circuit breaker goes OFF and the CONVERTER FAIL LED is lit remains ON and the CONVERTER FAIL LED is not lit remains ON and the CONVERTER FAIL LED is lit Check the backplane of the shelf for bent or short-circuited	Do Step 80 Step 83 Step 82
NT6X52 card. Complete the procedure and return to this procedure and return to this procedure in the circuit breaker         If the circuit breaker         goes OFF and the CONVERTER FAIL LED is lit         remains ON and the CONVERTER FAIL LED is not         lit         remains ON and the CONVERTER FAIL LED is lit         Check the backplane of the shelf for bent or short-circuited         If the pins       Do	Do Step 80 Step 83 Step 82
NT6X52 card. Complete the procedure and return to this procedure and return to this procedure in the circuit breaker         If the circuit breaker         goes OFF and the CONVERTER FAIL LED is lit         remains ON and the CONVERTER FAIL LED is not         lit         remains ON and the CONVERTER FAIL LED is lit         Check the backplane of the shelf for bent or short-circuited         If the pins       Do         are bent or short-circuited       step 89	Do Step 80 Step 83 Step 82

### At the CLCE cabinet

83 Check the frame FAIL lamp on the MSP.

	If the frame FAIL lamp	Do
	is lit and you did not complete steps 2, 3, 4, and 5 in this procedure	step 84
	is lit and you did not complete steps 2, 3, 4, and 5 in this procedure	step 89
	is not lit	step 85
	Refer to the step you have not completed, that is, step 2, 3, procedure.	4, or 5 in tł
41	MAD torminal	
tne	e MAP terminal	
tne	To access the Ext level of the MAP display to determine if an present, type	n MSP alar
	To access the Ext level of the MAP display to determine if an	n MSP alar
	To access the Ext level of the MAP display to determine if an present, type	n MSP alar
	To access the Ext level of the MAP display to determine if ar present, type >MAPCI;MTC;EXT	n MSP alar Do
	To access the Ext level of the MAP display to determine if ar present, type >MAPCI;MTC;EXT and press the Enter key.	
	To access the Ext level of the MAP display to determine if ar present, type >MAPCI;MTC;EXT and press the Enter key. If an MSP alarm is present, and you did not access all the cabinets	Do

### At the CLCE cabinet

87




### DANGER

Risk of injury from high energy levels Some of the terminals inside the MSP have an electrical potential of -48 Vdc. Do not touch any terminals inside the MSP.


Loosen the slotted nut on the left-hand side of the MSP.

- 88 Open the MSP panel.
- 89 For additional help, contact the next level of support.
- **90** Refer to the table of contents, routine maintenance section, to find the procedure Replacing the cooling unit. Perform the Replacing the cooling unit procedure. If the MSP alarm presence continues, return to this procedure at step 85.
- **91** The procedure is complete.


### **CLCE** cabinet



LCME fuse panel



# Ext MSP CLCE cabinet major (end)



CLCE modular supervisory panel (MSP)

# Ext MSP CLMI cabinet major

# Alarm display

СМ	MS	IOD	Net	PM	CCS	Lns	Trks	Ext	APPL
•	•	•	•	•		•	•	1FSP M	•

### Indication

An FSP that follows a number under the Ext header of the alarm banner indicates an Ext modular supervisory panel (MSP) alarm. An M under the FSP indicates that the alarm class is major. The alarm display is at the MTC level of the MAP display.

*Note:* Current software does not reflect the change from FSP to MSP in the MAP display.

### Meaning

An MSP alarm occurs when one or more cabinets in the office has a power fault or cooling unit fault. The number that precedes FSP is the number of cabinets with an MSP alarm. Refer to the previous note.

### Result

The effect on subscriber service depends on the type of fault. The effect on subscriber service also depends on the type of cabinet that contains the fault.

### **Common procedures**


This procedure refers to the common procedure "Replacing the cooling unit". Common procedures are located in the routine maintenance section of this manual.

### Action

This procedure applies to the Cabinetized Line Module ISDN (CLMI), NTRX30DA.

This procedure contains a summary flowchart and a list of steps. Use the flowchart to review the procedure. Follow the steps to perform the procedure.

### Summary of clearing an Ext MSP CLMI cabinet major alarm



### Clearing an Ext MSP CLMI cabinet major alarm

### At the CLMI cabinets

1

### ATTENTION

Illustrations of the CLCE cabinet, LCME fuse panel, and MSP appear at the end of this procedure.

#### Check the FAN FAIL LEDs.

lf	Do
any FAN FAIL LEDs are lit	step 63
FAN FAIL LEDs are not lit	step 2

2 Check the CONVERTER FAIL LED on each converter in the cabinet.

lf	Do
any CONVERTER FAIL LEDs are lit	step 43
CONVERTER FAIL LEDs are not lit	step 3
Check the RG FAIL LED on both RGs. The FAIL LED is behind the front par	
lf	Do
an RG's FAIL LED is lit	step 30
the RGs' FAIL LEDs are not lit	step 4
Oberely the line drawer frage (E04 to E	
47, slot number 18.	17). The fuses are on shelves 33 and
	17). The fuses are on shelves 33 and <b>Do</b>
47, slot number 18.	17). The fuses are on shelves 33 and Do step 9

lf	Do
a fuse is blown (protruding)	step 6
there are no blown fuses	step 62

- 6 Obtain a replacement fuse with the same voltage and amperage ratings as the blown fuse.
- 7 Remove the blown fuse.

8

5



### DANGER

**Risk of fire** For continued protection against risk of fire, replace the fuse with a fuse of the same type, rating (color code) and manufacturer.

Insert the replacement fuse.

lf	Do
the fuse blows (protrudes) again	step 10
the fuse does not blow	step 58

- 9 Identify the blown fuse.
- **10** Obtain a replacement fuse with the same voltage as the blown fuse.
- **11** Remove the blown fuse.
- 12



#### DANGER Risk of fire

For protection against risk of fire, replace the fuse with a fuse of the same type, rating (color code), and manufacturer.

Insert the replacement fuse.

lf	Do
the fuse blows (protrudes) again	step 13

lf	Do
the fuse does not blow	step 58

**13** Use the following information to identify the drawer associated with the blown fuse. The drawers are located next to the fuse panel.

### **Fuse location**

Fuse number	Drawer number
F1 -48 battery return	0 or 4
F2 -48 battery return	1 or 5
F3 -48 battery return	2 or 6
F4 -48 battery return	3 or 7
F5 -48V	0 or 4
F6 -48V	1 or 5
F7 -48V	2 or 6
F8 -48V	3 or 7
F9 +15V	0 or 4
F10 + 15V	1 or 5
F11 + 15V	2 or 6
F12 + 15V	3 or 7
F13 -48V	0 or 4
F14 -48V	1 or 5
F15 -48V	2 or 6
F16 -48V	3 or 7
F17 RG	0 -7

14

Pull out the identified line drawer. When working on a blown RG fuse, begin with the drawer on the far left.

15



### DANGER

**Personal injury** Do not touch the line feed resistors on the line cards. The line feed resistors generate enough heat to burn you.



#### CAUTION Loss of service

Carry out this procedure during periods of low traffic.

Unseat all the line cards in the drawer. Do not remove the line cards from the drawer.

- 16 Obtain a replacement fuse with the same voltage and amperage ratings as the blown fuse.
- 17 Remove the blown fuse.
- 18

19



### DANGER

Risk of fire

For continued protection against risk of fire, replace the fuse with a fuse of the same type, rating (color code) and manufacturer.

Insert the replacement fuse.

step 19	
step 21	
rcuited wires.	
	Do
present	step 62
	1

20

21

22

present, and the ng voltage fuse present, the fuse oltage fuse, and in the shelf present, and the i the line drawer	step 20 step 62 step 62
oltage fuse, and in the shelf present, and the the line drawer repeat steps 15 ar	step 62
the line drawer	•
	nd 16 for the
heck the fuse after	you resear e
ep 22	
ep 29	
) t	bo tep 22 tep 29

Do not touch the line feed resistors on the line cards. The line feed resistors generate enough heat to burn you.

Remove the line card from the drawer.

- **23** Obtain a replacement line card. Make sure the replacement card has the same PEC, including the suffix, as the removed card.
- 24 Insert the replacement line card into the drawer.
- 25 Obtain a replacement fuse with the same voltage and amperage ratings as the blown fuse.
- 26 Remove the blown fuse.

27

31



#### DANGER Personal injury

Do not touch the line feed resistors on the line cards. The line feed resistors generate enough heat to burn you.



#### DANGER Risk of fire

For continued protection against risk of fire, replace the fuse with a fuse of the same type, rating (color code) and manufacturer.

Insert the replacement fuse.

lf	Do
the fuse blows (protrudes) again	step 62
the fuse does not blow	step 28

- 28 Reseat all line cards in the drawer.
- **29** Push the drawer back in and proceed to step 59.
- **30** Use the following table to identify the circuit breaker associated with the RG that displays a lit FAIL LED. The circuit breaker is located on the MSP.

IfRG number	DoCircuit breaker number
RG0	13
RG1	15
Check the associated circuit br	eaker.
If the circuit breaker	Do
is ON	step 39

2	Set the circuit breaker to ON. If the circuit breaker	Do	
	goes OFF (the FAIL LED on the RG is lit)	step 33	-
	remains ON and the FAIL LED on the RG is not lit	step 58	
	remains ON and the FAIL LED on the RG is lit	step 39	

### At the CPDC cabinet

33 Locate the fuse associated with the cabinet and shelf number.

Do
step 34
step 4(

- **35** Replace the cartridge fuse inside the fuse holder.
- 36

34



#### DANGER Risk of fire

For continued protection against risk of fire, replace the fuse with a fuse of the same type, rating (color code) and manufacturer.

Replace the blown fuse.

**37** Install the fuse holder back on to the cabinetized power distribution center (CPDC).

### At the CRSC or CEXT cabinet

38 Set the circuit breaker to ON.

If the circuit breaker	Do
goes OFF (the RG FAIL LED is lit)	step 40
remains ON and the RG FAIL LED is not lit	step 58
remains ON and the RG FAIL LED is lit	step39

**39** Set the circuit breaker to OFF.

Go to Card Replacement Procedures to replace the RG. After you replace 40 the RG, return to this step.

#### Check the FAIL LED on the RG just replaced. 41

If the FAIL LED on the RG	Do
is lit	step 43
is not lit	step 58

42 Go to Alarm Clearing Procedures to clear the RG alarm. After clearing the RG alarm, return to this step.

44 Use the following information to identify which circuit breakers associated with the shelf that you noted in step 43. The circuit breakers are located on the MSP.

If Shelf number is	Do use circuit breaker number
05	6, 10
19	8, 12
33	5, 9
47	7, 11

#### 45

Check the associated circuit breaker.

If the circuit breaker	Do
is ON	step 54
is OFF	step 46

<sup>46</sup> Set the circuit breaker just identified to ON.

If the circuit breaker	Do
goes OFF and the CONVERTER FAIL LED is lit	step 47
remains ON and the CONVERTER FAIL LED is lit	step 54
remains ON and the CONVERTER FAIL LED is not lit	step 58

47 Note the numbers of the cabinet and shelf that contain the converter with the lit CONVERTER FAIL LED.

<sup>43</sup> Note the number of the shelf that contains the converter with the lit CONVERTER FAIL LED.

### At the CDPC

48 Locate the fuse that powers the shelf noted in step 47 in the CLMI cabinet.

If the fuse	Do
is blown (protruding)	step 49
is not blown	step 54

- 49 Remove the fuse holder with the blown fuse.
- 50 Replace the cartridge fuse inside the fuse holder.
- 51



### DANGER

**Risk of fire** For continued protection against risk of fire, replace the fuse with a fuse of the same type, rating (color code) and manufacturer.

Replace the blown fuse.

52 Install the fuse holder back on to the CPDC cabinet.


### At the CRSC or CEXT cabinet


53 Set the circuit breaker to ON.

If the circuit breaker	Do
goes OFF (the CONVERTER FAIL LED is not lit)	step 55
remains ON and the CONVERTER FAIL LED is not lit	step 58
remains ON and the CONVERTER FAIL LED is lit	step 54
Set the circuit breaker to OFF.	
Go to <i>Card Replacement Procedures</i> to replace the converter replacing the converter, return to this step.	er. After
Check the replaced converter and the associated circuit brea	aker.
If the circuit breaker	Do
goes OFF (the CONVERTER FAIL LED is lit)	step 62
remains ON and the CONVERTER FAIL LED is not lit	step 58

	If the circuit breaker	Do
	remains ON and the CONVERTER FAIL LED is lit	step 57
57	Set the circuit breaker to OFF.	
At th	e CLCE cabinet	
58	Check the frame FAIL lamp on the MSP.	
	If the frame FAIL lamp	Do
	is lit and you have not completed steps 2, 3, 4 and 5 in this procedure	step 59
	is lit and you have completed steps 2, 3, 4 and 5 in this procedure	step 62
	not lit	step 60
59	Go to the step you have not completed (step 2, 3, 4, or 5) in	this procedure
At th	e MAP terminal	
4 <i>t th</i> 60	e MAP terminal Access the Ext level of the MAP display. To determine if MS present, type	SP alarms are
	Access the Ext level of the MAP display. To determine if MS	SP alarms are
	Access the Ext level of the MAP display. To determine if MS present, type	SP alarms are
	Access the Ext level of the MAP display. To determine if MS present, type >MAPCI;MTC;EXT	SP alarms are
	Access the Ext level of the MAP display. To determine if MS present, type >MAPCI;MTC;EXT and press the Enter key.	
	Access the Ext level of the MAP display. To determine if MS present, type >MAPCI;MTC;EXT and press the Enter key.  If an MSP alarm is present and you have not accessed all the cabinets	Do
	Access the Ext level of the MAP display. To determine if MS present, type >MAPCI;MTC;EXT and press the Enter key. If an MSP alarm is present and you have not accessed all the cabinets with an MSP alarm is present and you accessed all the cabinets with an	Do step 61
50	Access the Ext level of the MAP display. To determine if MS present, type >MAPCI;MTC;EXT and press the Enter key. If an MSP alarm is present and you have not accessed all the cabinets with an MSP alarm is present and you accessed all the cabinets with an MSP alarm	Do step 61 step 62 step 64
	Access the Ext level of the MAP display. To determine if MS present, type >MAPCI;MTC;EXT and press the Enter key. If an MSP alarm is present and you have not accessed all the cabinets with an MSP alarm is present and you accessed all the cabinets with an MSP alarm is not present Go to the table of contents in this document to find the proceed	Do step 61 step 62 step 64 dure for cabine
60	Access the Ext level of the MAP display. To determine if MS present, type >MAPCI;MTC;EXT and press the Enter key. If an MSP alarm is present and you have not accessed all the cabinets with an MSP alarm is present and you accessed all the cabinets with an MSP alarm is not present Go to the table of contents in this document to find the proced with MSP alarms. Perform that procedure. For additional help, contact the personnel responsible for the	Do step 61 step 62 step 64 dure for cabine next higher lev on, to find the

### **CLMI** cabinet






### LCME fuse panel

# Ext MSP CLMI cabinet major (end)

### MSP for CLMI cabinet



# Ext MSP CPDC cabinet major

# Alarm display

СМ	MS	IOD	Net	PM	CCS	Lns	Trks	Ext	APPL
•	•	•	•	•	•	·	•	1FSP M	•

### Indication

An FSP that follows a number under the Ext header of the alarm banner indicates an Ext modular supervisory panel (MSP) alarm. An M under the FSP indicates that the alarm class is major. The alarm display is at the MTC level of the MAP display.

*Note:* Current software does not reflect the change from FSP to MSP in the MAP display.

### Meaning

An MSP alarm occurs when one or more cabinets in the office has a power or a cooling unit fault. The number that precedes FSP is the number of cabinets with an MSP alarm. Refer to the previous note.

### Result

The type of fault and the type of cabinet that contains the fault determines the effect on subscriber service.

### **Common procedures**


This procedure refers to the common procedure "Replacing the cooling unit". Common procedures are located in the routine maintenance section of this manual.

### Action

This procedure applies to the Cabinetized Power Distribution Center (CPDC), NTRX31AA.

This procedure contains a summary flowchart and a list of steps. Use the flowchart to review the procedure. Follow the steps to perform the procedure.

### Summary of clearing an Ext MSP CPDC cabinet major alarm



### Clearing an Ext MSP CPDC cabinet major alarm

### At the CPDC

1 Check the FAN FAIL LEDs.

lf	Do		
any FAN FAIL LEDs are lit	step 45		
FAN FAIL LEDs are not lit	step 2		
Check the alarm LED, which is on the	right side of the break	ker panel.	
lf	Do		
any alarm LEDs are lit	step 3		
alarm LEDs are not lit	step 4		
Check the circuit breakers on the brea	aker panel that has the	e lit alarm LEI	
lf	Do		
any circuit breaker is in cen- ter-trip position	step 5		
all circuit breakers are ON	step 4		
Check the ABS fuse on the MSP.			
lf	Do		
the ABS fuse is blown (protrud- ing)	step 22		
the ABS fuse is not blown	step 44		
Check the label under the circuit brea	ker in the center-trip p	osition.	
If the circuit breaker		Do	
supplies the talk battery to a line c ment (LCE) cabinet	oncentrating equip-	step 7	

If the circuit breaker	Do
If the circuit breaker	Do

supplies power to a filter capacitor on the CPDC step 25 breaker panel

- 6 Set the circuit breaker to ON, and go to step 21.
- **7** Record the numbers of the CLCE cabinet and shelf that associates with the circuit breaker.

### At the CLCE cabinet

8 Remove the ten talk battery fuses, five for each shelf. The fuses are located above the shelves.

*Note:* Talk battery A powers the first and third shelves from the bottom of the LCE. Talk battery B powers the second and fourth shelves from the bottom of the LCE.

**9** Obtain a capacitor-forming tool.

*Note:* A capacitor-forming tool consists of a 100 W 120 V light bulb inserted into a socket with pigtail leads. The pigtail leads must have spring-type alligator clips on each end.

### At the CPDC

10



### DANGER

**Risk of injury from high energy levels** The fuse holder contacts on the filter panel faceplate have high voltages. Do not touch the probes of the capacitor-forming tool to the faceplate of the filter panel. Do not let the probes of the capacitor-forming tool touch each other.

Connect the leads of the capacitor-forming tool across the circuit breaker to charge the capacitors.

If, after a few seconds pass, the bulb	Do
is lit	step 11
is not lit	step 17

### At the CLCE cabinet

- 11 On the positive terminal of the capacitor, label the leads as (+), indicating positive, and the negative terminal as (-), indicating negative.
- **12** Disconnect the leads from the short-circuited capacitor.

- **13** Remove the capacitor.
- 14 Install a replacement capacitor.
- 15 Connect the positive lead to the capacitor's positive terminal.
- 16 Connect the negative lead to the capacitor's negative terminal. Return to step 10 to recharge the capacitors.

### At the back of the CPDC

**17** Remove the capacitor-forming tool.

#### At the front of the CPDC

**18** Set the circuit breaker to ON.

#### At the CLCE cabinet

- **19** Insert the ten talk battery fuses that you removed in step 8. Insert the fuses one at a time, and pause between fuses.
- **20** Press the indicator on one of the talk battery fuses you replace to determine if the talk battery works.

lf	Do
the FRAME FAIL LED is lit	step 40
the FRAME FAIL LED is not lit	step 21

### At the CPDC

21 Check the circuit breaker.

If the circuit breaker	Do
is OFF	step 44
is ON	step 40

- 22 Obtain a replacement fuse that has the same voltage and amperage as the blown ABS fuse.
- 23 Remove the blown ABS fuse.
- 24

#### DANGER Risk of fire

For protection against risk of fire, replace the fuse with a fuse of the same type, rating (color code), and manufacturer.

25

Insert the replacement ABS fuse.

If the fuse	Do	
blows (protrudes) again	step 43	
does not blow again	step 40	
Make sure that the circuit breaker	for the capacitor is OFF.	
If voltage	Do	
is within 3V of -48V rail	step 38	

is greater than 3V from -48V rail step 26

### At the back of the CPDC

26 Obtain a capacitor-forming tool and a voltmeter.

*Note:* A capacitor-forming tool consists of a 100 W 120 V light bulb inserted into a socket with pigtail leads. The pigtail leads must have spring-type alligator clips on each end.

- 27 On the positive terminal of the capacitor, label the leads as (+), positive, and the negative terminal as (-), negative.
- 28 Connect one lead of the capacitor-forming tool to a ground stud on the battery return ground plate (L+) of the breaker panel.
- **29** Connect the other lead of the capacitor-forming tool to the bottom post of the circuit breaker that powers the short-circuited capacitor.
- **30** Use the voltmeter to make sure voltage does not occur across the terminals of the capacitor.
- **31** Use the voltmeter to make sure voltage does not occur between either terminal of the capacitor and the battery return.
- 32



### DANGER

#### Risk of injury from high energy levels

The terminals at the back of the CPDC have an electrical potential of -48 Vdc to -60 Vdc. Do not attempt to replace the capacitor when you detect voltage with the voltmeter.

With the capacitor-forming tool in place, disconnect the leads from the short circuited capacitor

- 33 Remove the capacitor.
- 34 Install a replacement capacitor.

- **35** Connect the positive terminal of the capacitor to the positive lead, and the negative terminal of the capacitor to the negative lead.
- **36** Remove the capacitor-forming tool.
- 37 Wait approximately 3 to 5 min to allow the capacitor to recharge.

### At the front of the CDPC

- **38** Set the circuit breaker for the capacitor to ON.
- **39** Check the circuit breaker.

If the circuit breaker	Do
is OFF	step 44
is ON	step 40

40 Check the FRAME FAIL LED on the MSP.

If the FRAME FAIL LED	Do
is lit and you did not complete step 4 in this proce- dure	step 5
is lit and you completed step 4 in this procedure	step 43
is not lit	step 41

### At the MAP terminal

42

41 To access the Ext level of the MAP display to determine an MSP alarm, type >MAPCI;MTC;EXT

and press the Enter key.

If an MSP alarm	Do
is present, and you have not accessed all the cabinets with an MSP alarm	step 42
is present, and you have accessed all the cabinets with an MSP alarm	step 44
is not present	step 44
Refer to the table of contents in this document to find the pr cabinet with an MSP alarm. Perform that procedure.	ocedure for the

# Ext MSP CPDC cabinet major (end)

At the back of the CPDC

43



**DANGER Risk of injury from high energy levels** The terminals at the back of the CPDC have an electrical potential of -48 Vdc to -60 Vdc. Do not touch any terminals inside the MSP.

Note any short-circuits of the ABS wiring inside the MSP. The personnel at the next level of support can request this information.

- 44 For additional help, contact the next level of support.
- 45 Go to the table of contents, in the routine maintenance section, to find the procedure "Replacing the cooling unit". Perform that procedure. If the MSP alarm is still present, return to this procedure at step 41.
- 46 The procedure is complete.

# Ext MSP CRME cabinet major

# Alarm display

	СМ	MS	IOD	Net	PM	CCS	Lns	Trks	Ext	APPL
-	•	•	•	•	•	•	•	·	1FSP M	•

### Indication

The alarm code FSP, preceded by a number, under the Ext header, indicates an EXT modular supervisory panel (MSP) major alarm. The FSP appears at the MTC level of the MAP display

*Note:* Software is not updated to reflect changes from FSP to MSP in the MAP display.

### Meaning

An MSP alarm occurs when one or more cabinets in the office have a power fault or a cooling unit fault. The number that precedes FSP is the number of cabinets with an MSP alarm. Refer to the previous note.

### Result

The type of fault and the type of cabinet that contains the fault determines the effect on subscriber service.

### **Common procedures**


This procedure refers to the common procedure "Replacing the cooling unit". Common procedures are located in the routine maintenance section of this manual.

### Action

This procedure applies to Cabinetized Remote Miscellaneous Equipment (CRME), NTRX31EA.

This procedure contains a summary flowchart and a list of steps. Use the flowchart to review the procedure. Follow the steps to preform the procedure.

### Summary of clearing an Ext MSP CRME cabinet major alarm



### Clearing an Ext MSP CRME cabinet major alarm

### At the CRME

1

2

3

4

<b>ATT</b> Illustrations of the CRME cabinet an procedure.	<b>ENTION</b> d MSP appear at the end of this
Check the FAN FAIL LEDs.	
lf	Do
any FAN FAIL LEDs are lit	step 49
FAN FAIL LEDs are not lit	step 2
Check the alarm LED on the right side	de of the breaker panel.
<i>Note 1:</i> The alarm extension par internal fuses.	nel does not hold shelf alarms and
Note 2: The alarm panel has a re	edundant power supply.
lf	Do
any alarm LEDs are lit	step 3
alarm LEDs are not lit	step 4
Check the circuit breakers on the bre	eaker panel that has the lit alarm LED
lf	Do
any circuit breaker is in cen- ter-trip position	- step 5
•	step 4
ter-trip position all circuit breakers are ON <i>Note:</i> eWhen the handle is in the	-
ter-trip position all circuit breakers are ON <i>Note:</i> eWhen the handle is in the overload condition. If the circuit b	step 4
ter-trip position all circuit breakers are ON <i>Note:</i> eWhen the handle is in the overload condition. If the circuit b position, alarms do not occur.	step 4
ter-trip position all circuit breakers are ON <b>Note:</b> eWhen the handle is in the overload condition. If the circuit b position, alarms do not occur. Check the ABS fuse on the MSP.	step 4 e center position, the system is in an oreaker is manually set to the OFF

DMS-100 Family Switching Center-SONET Model B Maintenance Manual

5 Check the label under the circuit breaker in center-trip position.

	If the circuit breaker	Do
	supplies the talk battery to a line concentrating equipment (LCE) cabinet	step 11
	does not supply the talk battery to an LCE cabinet	step 10
	supplies power to a filter capaci- tor on the CRME breaker panel	step 29
	supplies power to miscellaneous equipment at bottom of cabinet	step 6
	<i>Note:</i> Circuit breakers in the CRMI alarm occurs if an electrical overloa	E provide alarm contact closure. An ad trips a device.
6	Check any fuses that power the misce If any fuses are blown (protrude), check	Ilaneous shelves for alarm indication. ck the associated miscellaneous shelf.
7	Check the Cook Digital Announcer cor the fuse on the rear of the unit if require	nponent for alarm indication. Replace red.
	<b>Note:</b> The Cook Digital Announcer supply.	does not have a redundant power
8	Check the DS-6 modem for alarm indic power supply if required.	ation. Replace the internal fuse on the
	Note: The DS-6 modem does not	t have a redundant power supply.
9	Check the LaMarche inverter for alarm supplied to end aisle ac. Reset the cir required.	
10	Set the circuit breaker to ON, and go t	to step 25.
11	Record the numbers of the CLCE cabir breaker.	net and shelf associated with the circuit
At the	e CLCE cabinet	
12	Remove the ten talk battery fuses, five fuses are above the shelves.	e for each shelf. The ten talk battery
	<i>Note:</i> Talk battery A powers the first the LCE. Talk battery B powers the	st and third shelves from the bottom of e second and fourth shelves.
13	Obtain a capacitor-forming tool.	
		sists of a 100 W 120 V light bulb. This gtail leads The pigtail leads must have and.

### At the CRME

14



### DANGER

**Risk of injury from high energy levels** The fuse holder contacts on the filter panel faceplate have high voltages. Do not touch the probes of the capacitor-forming tool to the faceplate of the filter panel. Do not let the probes of the capacitor-forming tool touch each other.

To charge the capacitors connect the leads of the capacitor-forming tool across the circuit breaker

If seconds pass and the bulb	Do
is lit	step 15
is not lit	step 21

### At the CLCE cabinet

- **15** Label the positive terminal of the leads of the capacitor as (+) positive. Label the negative terminal capacitor leads as (-) negative.
- 16 Disconnect the leads from the short-circuited capacitor.
- **17** Remove the capacitor.
- **18** Install a replacement capacitor.
- **19** Connect the + lead to the positive terminal of the capacitor.
- 20 Connect the lead to the negative terminal of the capacitor. To charge the capacitors again return to step 10.

### At the back of the CRME

**21** Remove the capacitor-forming tool.

### At the front of the CRME

22 Set the circuit breaker to ON.

### At the CLCE cabinet

**23** Insert the ten talk battery fuses that you removed in step 12. Insert the fuses one at a time. Pause between each fuse.

24 To determine if the talk battery is present, press the indicator on one of the talk battery fuses you just replaced.

If the frame FAIL LED	Do
is lit	step 44
is not lit	step 25

### At the CRME

25 Check the circuit breaker.

If the circuit breaker	Do
is OFF	step 48
is ON	step 44

- 26 Obtain a replacement fuse with the same voltage and amperage as the blown ABS fuse.
- 27 Remove the blown ABS fuse.
- 28



#### DANGER Risk of fire

For continued protection against risk of fire, replace the fuse with a fuse of the same type. Replace the fuse with a fuse with the same rating (color code), and manufacturer.

Insert the replacement ABS fuse.

If the fuse	Do	
blows (protrudes) again	step 47	
does not blow again	step 44	
Make sure the circuit breaker for the capacitor remains OFF. Obtain a		

29

voltmeter. Check voltage across capacitor leads.

If voltage	Do
is in 3V of -48V rail	step 42
is more than 3V from -48V rail	step 30

### Ext MSP CRME cabinet major (continued)

#### At the back of the CRME

**30** Obtain a capacitor-forming tool and a voltmeter.

*Note:* A capacitor-forming tool consists of a 100 W 120 V light bulb. The light bulb connected to a socket with pigtail leads The pigtail leads must have spring-type alligator clips on each end.

- **31** Label the positive terminal leads of the capacitor as (+) positive. Label the negative terminal of the capacitor as, (-) negative.
- **32** Connect one lead of the capacitor-forming tool to a ground stud on the battery return ground plate (L+) of the breaker panel.
- **33** Connect the other lead of the capacitor-forming tool to the bottom post of the circuit breaker that powers the short-circuited capacitor.
- 34 Make sure voltage is not present across the terminals of the capacitor with the voltmeter.
- **35** Make sure voltage is not present between either terminal of the capacitor and the battery return with the voltmeter.

36



#### DANGER Risk of injury from high energy levels

The terminals at the rear of the CRME have an electrical potential of -48 Vdc to -60 Vdc. Do not attempt to replace the capacitor when you detect voltage with the voltmeter.

The capacitor-forming tool can remain in place. If this event occurs, disconnect the leads from the short-circuited capacitor.

- **37** Remove the capacitor.
- 38 Install a replacement capacitor.
- **39** Connect the positive lead to the positive terminal of the capacitor. Connect the negative lead to the negative terminal if the capacitor.
- **40** Remove the capacitor-forming tool.
- 41 To allow the capacitor to recharge, wait approximately 3 to 5 min.

#### At the front of the CRME

- 42 Set the circuit breaker for the capacitor to ON.
- 43 Check the circuit breaker.

If the circuit breaker is	Do
OFF	step 48
ON	step 44

### Ext MSP CRME cabinet major (continued)

44 Check the frame FAIL LED on the MSP.

If the frame FAIL LED	Do
is lit and you do not complete step 5 in this procedure	step 5
is lit and you complete step 5 in this procedure	step 47
is not lit	step 45

#### At the MAP terminal

**45** To access the Ext level of the MAP display, to determine if an MSP alarm is present, type

#### >MAPCI;MTC;EXT

and press the Enter key.

If an MSP alarm	Do
is present, and you have not ac- cessed all the cabinets with an MSP alarm	step 46
is present, and you accessed all the cabinets with an MSP alarm	step 48
is not present	step 48

**46** To find the procedure for the cabinet with the MSP alarm go to the table of contents in this document. Perform that procedure.

#### At the back of the CRME

#### 47



#### DANGER

**Risk of injury from high energy levels** The terminals at the rear of the CRME have an electrical potential of -48 Vdc to -60 Vdc. Do not touch any terminals inside the MSP.


Check if the ABS wiring in the MSP is short-circuited. Personnel at the next level of support can request this information.

48 For additional help, contact next level of support.

### Ext MSP CRME cabinet major (continued)


- **49** To find the common procedure "Replacing the cooling unit", go to the table of contents, in the routine maintenance section. Perform that procedure. If the MSP alarm remains present, return to this procedure at step 45.
- **50** The procedure is complete.

#### **CRME** cabinet



## Ext MSP CRME cabinet major (end)

#### MSP for CRME



### Ext MSP CRSC and CEXT cabinets major

### Alarm display

СМ	MS	IOD	Net	PM	CCS	Lns	Trks	Ext	APPL	
	•	•	•	•	•	•		1FSP M	•	

### Indication

An FSP that follows a number under the Ext header of the alarm banner indicates an Ext modular supervisory panel(MSP) major alarm. An M under the FSP indicates that the alarm class is major. The alarm display is at the MTC level of the MAP display.

*Note:* Current software does not reflect the change from FSP to MSP in the MAP display.

### Meaning

An MSP alarm occurs when one or more cabinets in the office has a power fault or a cooling unit fault. The number that precedes FSP is the number of cabinets with an MSP alarm. Refer to the previous note.

### Result

The type of fault and the type of cabinet that contains the fault determines the effect on subscriber service.

### **Common procedures**

This procedure refers to the common procedure "Replacing the cooling unit". Common procedures are located in the routine maintenance section of this manual.


### Action

This procedure applies to the following cabinets:

- Cabinetized Remote Switching Center with Integrated Services Digital Network (CRSC with ISDN), NTMX89FB
- Cabinetized Extension cabinet (CEXT), NTMX89FC

The procedure contains a summary flowchart and a list of steps. Use the flowchart to review the procedure. Follow the steps to perform the procedure.

Summary of clearing a Ext MSP CRSC and CEXT cabinets major alarm



#### Clearing a Ext MSP CRSC and CEXT cabinets major alarm

#### At the CRSC or CEXT cabinets

2

3

4

5

6

1 Check the FAN FAIL LEDs.

*Note:* Diagrams of the CRSC and CEXT cabinets, LCME fuse panel and MSP appear at the end of this procedure.

lf	Do
any FAN FAIL LEDs are lit	step 64
FAN FAIL LEDs are not lit	step 2
Check the CONVERTER FAIL LED or	each converter in the cabinet.
lf	Do
any CONVERTER FAIL LEDs are lit	step 44
CONVERTER FAIL LEDs are not lit	step 3
Check the RG FAIL LED on both RGs a is behind the front panel of the RG.	at the top of the cabinet. The FAIL LEE
lf	Do
an RG's FAIL LED is lit	step 31
both RGs' FAIL LEDs are not lit	step 4
Check the line drawer fuses (F01 to F1 47, slot number 18.	7). These fuses are on shelves 33 and
If a fuse	Do
is blown (protruding)	step 10
is not blown	step 5
Check the ABS fuses 01 to 04 on the	MSP.
lf	Do
a fuse is blown (protruding)	step 6
	step 7

DMS-100 Family Switching Center-SONET Model B Maintenance Manual

- 7 Check the D-channel handler (DCH) power fuses. These fuses are on the power converter circuit card (NTMX72AA) in shelf position 06 in the CRSC cabinet. Check the DCH power fuses on the DS60 extender circuit card (NTMX79AA) in position 06 in the CEXT cabinet.
- 8 Remove the blown fuse.
- 9



#### DANGER Risk of fire

For continued protection against risk of fire, replace the fuse with a fuse of the same type, rating (color code) and manufacturer.

Insert the replacement fuse.

If the fuse	Do
blows (protrudes) again	step 11
does not blow	step 59

- **10** Determine which fuse is blown.
- 11 Obtain a replacement fuse with the same voltage as the blown fuse.
- 12 Remove the blown fuse.
- 13



#### DANGER Risk of fire

For continued protection against risk of fire, replace the fuse with a fuse of the same type, rating (color code) and manufacturer.

Insert the replacement fuse.

If the fuse	Do
blows (protrudes) again	step 14
does not blow	step 59

14 Use the following information to identify the drawer of the blown fuse. The drawers are beside the fuse panel.

#### **Fuse location**

Fuse number	Drawer number
F1 -48 battery return	0 or 4
F2 -48 battery return	1 or 5
F3 -48 battery return	2 or 6
F4 -48 battery return	3 or 7
F5 -48V	0 or 4
F6 -48V	1 or 5
F7 -48V	2 or 6
F8 -48V	3 or 7
F9 + 15V	0 or 4
F10 + 15V	1 or 5
F11 + 15V	2 or 6
F12 + 15V	3 or 7
F13 -48V	0 or 4
F14 -48V	1 or 5
F15 -48V	2 or 6
F16 -48V	3 or 7
F17 RG	0 - 7

**15** Pull out the identified line drawer. When working with a blown RG fuse, begin with the the top left drawer.

16



DANGER Personal injury

Do not touch the line feed resistors on the line cards. The line feed resistors generate enough heat to burn you.

WARNING Loss of service

Perform this procedure during periods of low traffic.

Unseat all the line cards in the drawer. Do not remove the line cards from the drawer.

- 17 Obtain a replacement fuse with the same voltage and amperage ratings as the blown fuse.
- **18** Remove the blown fuse.
- 19



### DANGER

Risk of fire

For continued protection against risk of fire, replace the fuse with a fuse of the same type, rating (color code) and manufacturer.

Insert the replacement fuse.

If the fuse	Do	
blows (protrudes) again	step 20	
does not blow	step 22	

### 20

II 1003e OF SHOLE-CITCUILED WILES DO	If loose or	short-circuited wires	Do
--------------------------------------	-------------	-----------------------	----

are present

step 63

	Do
are not present, and the fuse you use is a ringing voltage fuse	step 21
are not present, and the fuse you use is a ringing voltage fuse. You have also done all four line drawers in the shelf.	step 63
are not present, and the fuse you use is one of the line drawer fus-	step 63
es (1-17) Reseat all the line cards in the drawer	and repeat steps 15 and 16 for the n
es (1-17)	
es (1-17) Reseat all the line cards in the drawer rawer. Reseat the line cards one at a time, ar	
es (1-17) Reseat all the line cards in the drawer rawer. Reseat the line cards one at a time, ar ne card.	nd check the fuse after you reseat ea



21

22

23

Personal injury Do not touch the line feed resistors on the line cards. The line feed resistors generate enough heat to burn you.

Remove the line card from the drawer.

- 24 Obtain a replacement line card. Make sure the replacement card has the same PEC and PEC suffix, as the card you removed.
- 25 Insert the replacement line card into the drawer.
- 26 Obtain a replacement fuse with the same voltage and amperage ratings as the blown fuse.
- 27 Remove the blown fuse.

28



### DANGER

**Personal injury** Do not touch the line feed resistors on the line cards. The line feed resistors generate enough heat to burn you.



#### DANGER Risk of fire

For continued protection against risk of fire, replace the fuse with a fuse of the same type, rating (color code) and manufacturer.

Insert the replacement fuse.

If the fuse	Do	
blows (protrudes) again	step 63	
does not blow	step 29	

- 29 Reseat all line cards in the drawer.
- **30** Push the drawer in and proceed to step 59.
- 31 Use the following information to identify the circuit breaker associated with the RG that has a lit FAIL LED. The circuit breaker is located on the MSP.

Do Circuit breaker number
3
5
aker.
Do
step 40

32

33 Set the circuit breaker to ON.

If the circuit breaker	Do
goes OFF (the FAIL LED on the RG is lit)	step 34
remains ON and the FAIL LED on the RG is not lit	step 59
remains ON and the FAIL LED on the RG is lit	step 40

#### At the CPDC cabinet

34 Locate the fuse for the cabinet and shelf number.

If the fuse	Do	
is blown (protruding)	step 35	
is not blown	step 41	

- **35** Remove the fuse holder with the blown fuse.
- **36** Replace the cartridge fuse inside the fuse holder.
- 37



#### DANGER Risk of fire

For continued protection against risk of fire, replace the fuse with a fuse of the same type, rating (color code) and manufacturer.

Replace the blown fuse.

**38** Install the fuse holder back on the CPDC.

#### At the CRSC or CEXT cabinet

39 Set the circuit breaker to ON.

If the circuit breaker	Do	
goes OFF (the RG FAIL LED is lit)	step 41	

If the circuit breaker	Do						
remains ON and the RG FAI LED is not lit	IL step 59						
remains ON and the RG FAI LED is lit	IL step 40						
Set the circuit breaker to OFF.							
o replace the RG,go to <i>Card Replacement Procedures</i> . After you replace the RG, return to this step.							
Check the FAIL LED on the RG that	at you replaced.						
If the FAIL LED on the RG	Do						
is lit	step 43						
is not lit	step 59						
To clear the RG alarm, go to <i>Alarm</i> RG alarm, return to this step.	Clearing Procedures. After you clea						
Note the number of the shelf that c	contains the converter with the lit						
Note the number of the shelf that c CONVERTER FAIL LED. Identify the circuit breaker associat Use the following information to ide							
Note the number of the shelf that c CONVERTER FAIL LED. Identify the circuit breaker associat Use the following information to ide	ed with the shelf that you noted in ster						
Note the number of the shelf that c CONVERTER FAIL LED. Identify the circuit breaker associat Use the following information to ide breaker is located on the MSP.	ed with the shelf that you noted in step entify this circuit breaker. The circuit						
Note the number of the shelf that c CONVERTER FAIL LED. Identify the circuit breaker associat Use the following information to ide breaker is located on the MSP.	ed with the shelf that you noted in step entify this circuit breaker. The circuit <b>Do Circuit breaker number</b>						
Note the number of the shelf that c CONVERTER FAIL LED. Identify the circuit breaker associat Use the following information to ide breaker is located on the MSP. If Shelf number is 06	ed with the shelf that you noted in step entify this circuit breaker. The circuit <b>Do Circuit breaker number</b> 7, 8, 9, 10						
Note the number of the shelf that c CONVERTER FAIL LED. Identify the circuit breaker associat Use the following information to ide breaker is located on the MSP. If Shelf number is 06 19	ed with the shelf that you noted in step entify this circuit breaker. The circuit <b>Do Circuit breaker number</b> 7, 8, 9, 10 1						
Note the number of the shelf that c CONVERTER FAIL LED. Identify the circuit breaker associat Use the following information to ide breaker is located on the MSP. If Shelf number is 06 19 33	ed with the shelf that you noted in step entify this circuit breaker. The circuit Do Circuit breaker number 7, 8, 9, 10 1 4, 11						
Note the number of the shelf that c CONVERTER FAIL LED. Identify the circuit breaker associat Use the following information to ide breaker is located on the MSP. If Shelf number is 06 19 33 47	ed with the shelf that you noted in step entify this circuit breaker. The circuit Do Circuit breaker number 7, 8, 9, 10 1 4, 11 6, 13						
Note the number of the shelf that c CONVERTER FAIL LED. Identify the circuit breaker associat Use the following information to ide breaker is located on the MSP. If Shelf number is 06 19 33 47 61 65	ed with the shelf that you noted in step entify this circuit breaker. The circuit <b>Do Circuit breaker number</b> 7, 8, 9, 10 1 4, 11 6, 13 12, 14 3, 5						
Note the number of the shelf that c CONVERTER FAIL LED. Identify the circuit breaker associat Use the following information to ide breaker is located on the MSP. If Shelf number is 06 19 33 47 61 65	ed with the shelf that you noted in step entify this circuit breaker. The circuit <b>Do Circuit breaker number</b> 7, 8, 9, 10 1 4, 11 6, 13 12, 14 3, 5						
Note the number of the shelf that c CONVERTER FAIL LED. Identify the circuit breaker associat Use the following information to ide breaker is located on the MSP. If Shelf number is 06 19 33 47 61 65 Check the associated circuit break	ed with the shelf that you noted in step entify this circuit breaker. The circuit Do Circuit breaker number 7, 8, 9, 10 1 4, 11 6, 13 12, 14 3, 5 er.						

47 Set the circuit breaker that you identified to ON.

	If the circuit breaker	Do
	goes OFF (the CONVERTER FALLED is lit)	AIL step 48
	remains ON and the CONVERT FAIL LED is lit	ER step 55
	remains ON and the CONVERT FAIL LED is not lit	ER step 59
8	Note the numbers of the cabinet and she lit CONVERTER FAIL LED.	If that contain the converter with the
At th	e CDPC	
19	Locate the fuse that powers the shelf that loctaed in the CRSC or CEXT cabinet.	at you noted in step 48. The fuse is
	If the fuse	00
	is blown (protruding)	top 50

is blown (protruding)	step 50	
is not blown	step 55	

- 50 Remove the fuse holder with the blown fuse.
- 51 Replace the cartridge fuse inside the fuse holder.
- 52



#### DANGER Risk of fire

For continued protection against risk of fire, replace the fuse with a fuse of the same type, rating (color code) and manufacturer.

Replace the blown fuse.

53 Install the fuse holder back on the CPDC cabinet.

#### At the CRSC or CEXT cabinet

54 Set the circuit breaker to ON.

<i>,</i> ,											
	If the circuit breaker	Do									
	goes OFF (the CONVERTER I LED is not lit)	FAIL step 56									
	remains ON and the CONVER FAIL LED is not lit	TER step 59									
	remains ON and the CONVER FAIL LED is lit	TER step 55									
55	Set the circuit breaker to OFF.										
56	Go to <i>Card Replacement Procedures</i> replacing the converter, return to this										
57	Check the replaced converter and the	associated circuit breaker.									
	If the circuit breaker	Do									
	goes OFF (the CONVERTER FAIL step 63 LED is lit)										
	remains ON and the CONVERTER step 59 FAIL LED is not lit										
	remains ON and the CONVERTER step 58 FAIL LED is lit										
58	Set the circuit breaker to OFF.										
At the	CLCE cabinet										
59	Check the frame FAIL lamp on the MS	SP.									
	If the frame FAIL lamp	Do									
	is lit and you did not complete steps 2, 3, 4, and 5 in this procedure	step 60									
	is lit and you completed steps 2, 3, 4, and 5 in this procedure	step 63									
	is not lit	step 61									
50	Go to the step that you did not comple	te (step 2, 3, 4, or 5) in this procedu									
	, ,,										

#### At the MAP terminal

**61** To access the Ext level of the MAP display and determine if an MSP alarm is present, type


### >MAPCI;MTC;EXT

and press the Enter key.


If an MSP alarm	Do
is present, and you did not access all the cabinets with an MSP alarm	step 62
is present, and you did access all the cabinets with an MSP alarm	step 63
is not present	step 65
Check the table of contents of this doc of cabinet that has an AMP alarm.	ument. Find the procedure for the type arform the porcedure.
For additional help, contact the next le	evel of support.
Go to the table of contents in the routi common procedure "Replacing the co the MSP alarm is present, return to th	oling unit". Perform that procedure. If
The presedure is complete	

**65** The procedure is complete.


### **CRSC** cabinet



#### **CEXT** cabinet




#### LCME fuse panel



*Note:* Drawers: 0–3, shelf position 33; 4–7, shelf position 47.

### MSP shelf for CRSC and CEXT cabinets



### PM LCME critical

### Alarm display

CALL MS OD Het PAL CCS This Est	СМ	MS	IOD	Net	РМ	CCS	Lns	Trks	Ext	APPL	
	•	•	•		1LCME *C*	•	·	•		•	

### Indication

An 1LCME \*C\* under the PM subsystem header at the MTC level of the MAP terminal indicates a critical condition in the LCME.

### Meaning

The indicated number of LCME units are in the system-busy (SysB) state.

### Result

Call processing ceases if all LCME units fail. There is no call processing support.


### **Common procedures**

There are no common procedures.

### Action

This procedure contains a summary flowchart and a list of steps. Use the flowchart to review the procedure. Follow the steps to perform the procedure.

#### Summary of clearing a PM LCME critical alarm



#### Clearing a PM LCME critical alarm

#### At the MAP terminal

1

#### ATTENTION

Enter this procedure from a PM system-level alarm clearing procedure step that identified an LCME-associated fault.

To silence the alarm, if required, type

#### >MAPCI;MTC;PM;SIL

and press the Enter key.

2 To identify the LCME that has faults, type

>DISP STATE SYSB LCME

and press the Enter key.

*Typical response on the MAP display*. SysB LCME : 2

3 To post the SysB LCME identified in step 2, type

>POST LCME lcme\_site\_name lcme\_frame\_no lcme\_no and press the Enter key.

where

Icme\_site\_name is the site name for the LCME that has faults

Icme\_frame\_no
 is the number of the associated LCME equipment frame
Icme\_no

is the number of the LCME that has faults

Normal response on the MAP display:

										)
( (	CM	MS	IOI	) Ne			Lns	Trks	Ext	APPL
	•	·	•	•	1LCM *C*	Е.	•	•	•	•
					^(·^					
L	CME			SysB	ManB	Of	fL	CBsy	ISTb	InSv
0	Quit		PM	1	0		2	0	2	12
2	Post_		LCME	0	0		2	0	2	9
-	ListSe									
					-	sB Lin	—	CSide	2 PSi	de 0
		-	Unit0:	-			/RG			
	_		Unit1:	Sys	В		/RG			
	Bsy_		<b>-</b> .	0.1 0.2						f 1 InSv
			Drwr:	01 23	45 67	89 0	1 23	45 67	89 Stb	y O InSv
	OffL LoadPM			•••••	• •• •	• ••	•••••	•• ••	••	
	Disp_	<u> </u>								
	Next									
13										
-	QueryF	м								
15	2									
16										
17										
18										
$\langle \rangle$										)

To check for fault indicators, type >QUERYPM FLT and press the Enter key. Normal response on the MAP display:

4

DMS-100 Family Switching Center-SONET Model B Maintenance Manual

CM MS	IOD	Net	PM 1LCME *C*	ccs	Lns	Trks	Ext	APPL
LCME		SysB	ManB	Of	£Ъ	CBsy	ISTb	InSv
0 Quit	PM	1	0		2	0	2	12
2 Post_ 3 ListSet	LCME	0	0		2	0	2	9
	LCME	RSC-S 14	l 1 SysB	Lin	ks_00S	: CSide	0 PSid	le 0
5 Trnsl_	Unit0:	SysB			/RG	: 1		
6 Tst_	Unit1:	SysB			/RG	: 1		
7 Bsy_				11	11	11 11 1	1 RG:Pre	ef 1 InS <sup>.</sup>
8 RTS_ D	rwr: 01	L 23 45	678	9 01	23	45 67 8	9 Stk	oy 0 InS <sup>.</sup>
9 OffL								
10 LoadPM_	QUERYPN	I FLT						
11 Disp_	Node ir	nservice	trouble	s exi	st:			
12 Next	One	e or both	n Units	inser	vice t	rouble		
13	LCME	UNIT O	Out of	Servi	ce Tro	ubles Exi	st:	
14 QueryPM 15	LCME	UNIT 1	Out of	Servi	ce Tro	ubles Exi	st:	
16	SITE F	FLR RPC	S BAY	_ID :	SHF 1	DESCRIPTI	ON SLOT	r eqpec
17	RSCS0	01 A0	0 LCM	E 00	32 3	LCME :	000 : 21	L BX34
18	RSCS0	01 A0	0 LCM	E 00	32 3	LCME :	000 : 19	9 BX35
<b>、</b>	RSCS0	01 AC	0 LCM	E 00	32	LCME :	000 : 20	) BX35

If the system	Do
indicates a card that has faults	step 15
does not indicate a card that has faults	step 5
To manually busy (ManB) the LCME posted in step 3, type	
>BSY PM	
and press the Enter key.	
To test the ManB LCME, type	
>TST PM	
and press the Enter key.	
Typical response on the MAP display.	
Test Passed	
or	
Test Failed	
If TST	Do
passed	step 14

5

6

failed and the system did not generate a card list st cannot test central-side busy (CBsy) st To identify C-side links that are SysB, type >TRNSL C and press the Enter key. Normal response on the MAP display: LINK 0 RCC2 2 ; CAP MS; STATUS: SYSB, ; MSGCOND: CLS	tep 15 tep 16 tep 7
cannot test central-side busy (CBsy)       st         To identify C-side links that are SysB, type       st         >TRNSL C       and press the Enter key.         Normal response on the MAP display:       LINK 0         RCC2 2 ; CAP MS; STATUS:       SYSB, ;MSGCOND: CLS	1
To identify C-side links that are SysB, type TRNSL C and press the Enter key. Normal response on the MAP display: LINK 0 RCC2 2 ;CAP MS;STATUS: SYSB,;MSGCOND:CLS	tep 7
>TRNSL C         and press the Enter key.         Normal response on the MAP display:         LINK 0       RCC2 2 ; CAP MS; STATUS:	
and press the Enter key. Normal response on the MAP display: LINK 0 RCC2 2 ; CAP MS; STATUS: SYSB, ; MSGCOND: CLS	
Normal response on the MAP display.	
Normal response on the MAP display: LINK 0 RCC2 2 ; CAP MS; STATUS: SYSB, ; MSGCOND: CLS	
LINK 0 RCC2 2 ; CAP MS; STATUS: SYSB, ; MSGCOND: CLS	
LINK 10 RCC2 2 CAP MS;STATUS: SYSB,;MSGCOND:CLS	
LINK 1 RCC2 2 CAP S; STATUS: OK	
LINK 11 RCC2 2 CAP S; STATUS: OK	
LINK 2 RCC2 2 ; CAP S; STATUS: OK	
If links Do	
are SysB step 8	
are open step 25	

Normal response on the MAP display.

7

8

1 -		MS	10I		Net	PM 1LCI *C	ME	CS		ł		Ext	APPL
RC	CC2			SΣ	∕sB	ManB	(	OffL		CB	зу	ISTb	InSv
0	Quit	PM			3	0		1			0	4	12
2	Post_	RCC	2		0	0		2			0	2	9
3	ListSet	t											
4		RCC	2	1	ISTb	Links	_00S:	CSi	de	Ο,	PSide	2	
5	Trnsl_	Uni	t0:		Act	InSv							
6	Tst_	Uni	t1:		Inact	InSv							
7	Bsy_												
8	RTS_												
9	OffL												
10	LoadPM_	_											
11	Disp_												
12	Next												
13	SwAct												
14	QueryPI	M											
15													
16													
17													
18													

**9** To identify the P-side links that have faults, and choose a link that has faults, type

#### >TRNSL P

and press the Enter key.

Normal response on the MAP display:

LINK 24:LCME	1	0;CAP	MS;STATUS:	SYSB;MSGCOND:CLS
LINK 25:LCME	1	1;CAP	S;STATUS:	OK
LINK 26:LCME	1	2;CAP	S;STATUS:	OK
LINK 27:LCME	1	3;CAP	S;STATUS:	OK
LINK 28:LCME	2	0;CAP	MS;STATUS:	SysB;MSGCOND:CLS
LINK 29:LCME	2	1;CAP	S;STATUS:	OK
LINK 30:LCME	2	2;CAP	S;STATUS:	OK

**10** To busy the link that has faults, type

```
>BSY LINK link_no
```

and press the Enter key.

where

#### link\_no

is the number of the P-side link chosen in step 9

- **11** To test the ManB link, type
  - >TST LINK link\_no

and press the Enter key.

where	
link_no is the number of the link manua	ally busied in step 10
If the system	Do
indicates a card that has faults	step 15
does not indicate a card that has faults	step 12
To return the ManB link to service, typ	e
>RTS LINK link_no	
and press the Enter key.	
where	
link_no is the number of the link tested	in step 11
If RTS	Do
passed	step 13
failed	step 25
<i>Note:</i> If the system identifies other procedures in steps 10 through 12 until the system busies, tests and re	for each link. Perform the procedure
To post the LCME identified in step 2,	type
>POST LCME lcme_site_name lc	me_frame_no lcme_no
and press the Enter key.	
where	
Icme_site_name is the site name for the LCME t	hat has faults
Icme_frame_no is the number of the associated	LCME
Icme_no is the number of the LCME that	t has faults
To test the LCME, type	
>TST PM	
and press the Enter key.	
If TST	Do
passed	step 26

If TST	Do
failed	step 18

15 If the system produced a list of cards that have possible defects, replace the cards. Begin with the first card in the list. A MAP example follows.

Normal response on the MAP display for an LCM in an LCE cabinet.

SITE	FLR	RPOS	BAY_I	D	SHF	DESCH	RIPTION	SLOT	EQPEC
REM1	01	A00	LCE	00	21	LCM	:00 0	: 04	6X51
REM1	01	A00	LCE	00	21	LCM	:00 0	: 05	6X52
REM1	01	A00	LCE	00	21	LCM	:00 0	: 01	6X53
REM1	01	A00	LCE	00	21	LCM	:00 0	:	6X54
REM1	01	A00	LCE	00	32	RCC	:00 0	: 07	6X48

Normal response on the MAP display for an LCME in a CLCE cabinet.

SITE	FLR	RPOS	BAY_ID		SHF	DESCR	IPTION	SLOT	EQPEC
REM1	01	A00	CLCE	00	04	LCME	:01 0	: 21	BX34
REM1	01	A00	CLCE	00	04	LCME	:01 0	: 20	BX35
REM1	01	A00	CLCE	00	04	LCME	:01 0	: 25	BX72
REM1	01	A00	CLCE	00	04	LCME	:01 0	: 22	6X53
REM1	01	A00	CLCE	00	05	RCC2	:01 0	: 13	MX74

lf you		Do	

replaced all the cards on the list step 16

did not replace all the cards on step 23 the list

- **16** The trouble can be the DS30A interface (I/F) card connected to the links that have defects shown in step 9. The DS30A I/F is in one of two locations:
  - on the NTMX74 card in the RCC2
  - on two NT6X48 cards in the RCC

lf you	Do
replaced the NTMX74 or 6X48 cards	step 18
did not replace the NTMX74 or 6X48 cards	step 17
<b>Note:</b> If the system indicates the N several links have faults Repeat the	ITMX74 card, check to see if one or e procedure to clear as necessary.

17 Determine the location of the card with link(s) that have faults. Each interface (I/F) chip on the NTMX74 card serves four DS30A links. The following chart illustrates the link-to-chip relationship.

To make sure that the message (MS) links are redundant, separate the links by a minimum of four links on an RCC2 when you datafill table LCMINV.

#### Chip-to-link relationship table for an RCC2

NTMX74 I/F Chip number	DS30	)A link	s	
1	22,	23,	24,	25
2	26,	27,	28,	29
3	30,	31,	32,	33
4	34,	35,	36,	37
5	38,	39,	40,	41
6	42,	43,	44,	45
7	46,	47,	48,	49
3	50,	51,	52,	53

Each I/F chip on the 6X48 cards serves two DS30A links. The following chart illustrates the card and chip-to-link relationship.

To make sure that the message (MS) links are redundant, separate the links by a minimum of two links on an RSC when you datafill table LCMINV.

#### Card and chip-to-link relationship table for an RSC

Chip number	Card Slots	DS30A links
1	7	0
1	7	1
1	6	2
1	6	3
2	7	4
2	7	5
2	6	6
2	6	7
3	7	8
3	7	9
3	6	10
3	6	11
4	7	12
4	7	13
4	6	14
4	6	15
5	7	16
5	7	17
5	6	18
5	6	19

18 A line drawer that has faults could cause the trouble. Remove the fuses from each line drawer that service the posted LCM(E) module in the following order. This action isolates the trouble to one line drawer.

- a -48V fuse(s)
- b +15V fuse
- c +5V fuse
- **19** After you remove the fuses from all line drawers connected to the defective LCME, try to return the LCME to service. Type

>RTS PM

and press the Enter key.

If RTS	Do	
passed	step 20	
failed	step 25	

- **20** Insert the drawer fuses, one drawer pair at a time, in the following order and apply power. This process isolates the failing line drawer.
  - a +5V fuse
  - b +15V fuse
  - c -48V fuse(s)
- 21 After you insert fuses in a drawer pair and apply power, attempt to restore the drawer to service. Type

>BSY DRWR drwr\_no

where

drwr\_no

is either drawer number of a pair

and press the Enter key.

Normal response on the MAP display:

/	/															
1	CI	4 N	IS	IOD	N	et	Pl	М	CC	CS	Lns	Т	rks	Ext	Appl	
	CM	Flt .		•			4 R	CS	5 F	RSC		17	CC	1Crit		
	N	4					*C	*	*(	2*		*	C*	*C*		
	LCN	4E			SysB		Man	В	Of	fL	CI	Bsy		ISTb	InSv	
	0	Quit		PM	6			2		1		0		23	39	
	2	Post_		LCME	0			0		0		0		1	0	
	3	ListSe	et													
	4	SwRg		LCME RS	CS 0	0 0	ISTb	Li	nks_	_00S:	CS	ide	0			
	5	Trnsl_	-	Unit0:	IS	tb				/RG:	0					
	б	Tst_		Unit1:	IS	tb				/RG:	0					
	7	Bsy_								11	11	11	RG:	Pref 0	InSv	
	8	RTS_		Drwr:	01	23	45	67	89	01	23	45		Stby 1	InSv	
	9	OffL									• •					
	10	LoadPM	1	bsy drw	r 13											
	11	Disp_		Warning		th	is ac	tion	ı wil	ll af	fect	bot	h dr	wrs 12 a	and 13	
	12	Next		LCNE RS	CS 0	0 0	Drwr	13	will	L be	takeı	n ou	t of	service	е	
	13			Please	conf	irm	("YE	s, "	Υ″,	"NO"	, or	″N″	):			
	14	QueryE	М													
	15															
	16															
	17															
	18															
	< l>															

*Note:* In a MAP display drawer numbers above 9 read vertically, from top to bottom.

22 To return the line drawer to service, type

>RTS DRWR drwr\_no

and press the Enter key.

where

drwr\_no

is the number of the drawer busied in step 21

Repeat steps 20, 21 and 22 until you insert fuses again in all drawers and return all drawers to service.

Normal response on the MAP display:

### PM LCME critical (end)

								~		
I MS	S IOD	Net	PM	CCS	Lns	Trks	Ext	Appl		
Flt .	•	•	4 RCS	5 RSC						
I			*C*	*C*		*C*	*C*			
-				0.5.5	~	_	T ( )			
		-				-				
~				1	-	-				
Post_	LCME	0	0	(	)	0	1	0		
ListSet	:									
SwRg	LCME RS	CS 00 0	ISTb :	Links_00	S: CS	ide O				
Trnsl_	Unit0:	IStb		/ F	RG: 0					
Tst_	Unit1:	IStb		/F	RG: 0					
Bsy_				1	.1 11	11 RG	: Pref 0	InSv		
RTS_	Drwr:	01 23	45 6	7890	1 23	45	Stby 1	InSv		
OffL										
LoadPM_	_ rts drw	r 13								
Disp_	Warning	thi	is acti	on will	affect	both di	rwrs 12 a	and 13		
Next	OSvce T	5								
	LCME RS	CS 00 0	Drwr 1	3 Tst Pa	ssed					
OuervPM	LCME RS	CS 00 0	Drwr 1	3 Rts Pa	ssed					
2										
	Flt . E Quit Post_ ListSet SwRg Trnsl_ Tst_ Bsy_ RTS_ OffL LoadPM_ Disp_ Next	Flt E Quit PM Post_ LCME ListSet SwRg LCME RS Trnsl_ Unit0: Tst_ Unit1: Bsy_ RTS_ Drwr: OffL LoadPM_ rts drw Disp_ Warning Next OSvce T LCME RS	Flt E SysB Quit PM 6 Post_ LCME 0 ListSet SwRg LCME RSCS 00 0 Trnsl_ Unit0: IStb Tst_ Unit1: IStb Bsy_ RTS_ Drwr: 01 23 OffL LoadPM_ rts drwr 13 Disp_ Warning this Next OSvce Tests Indi- LCME RSCS 00 0	Flt       .       .       4 RCS *C*         E       SysB       ManB         Quit       PM       6       2         Post_       LCME       0       0         ListSet       0       0       1         SwRg       LCME RSCS 00 0 ISTb       1       1         Trnsl_       Unit0:       IStb       1         Tst_       Unit1:       IStb       1         Bsy_       RTS_       Drwr:       01       23       45       6         OffL               LoadPM_       rts drwr 13       1	Flt 4 RCS 5 RSG *C*         E       SysB       ManB       OffI         Quit PM 6 2       1         Post_ LCME 0       0       0         ListSet       0       0       0         SwRg       LCME RSCS 00 0 ISTb       Links_00         Trnsl_ Unit0:       IStb       /F         Tst_ Unit1:       IStb       /F         Bsy_       1       123       45       67       89       0         OffL               LoadPM_ rts drwr 13       Disp_ Warning this action will       Next       OSvce Tests Initiated       LCME RSCS 00 0 Drwr 13 Tst Pa	Flt       .       .       4 RCS 5 RSC .       .         *C*       *C*       *C*         E       SysB       ManB       OffL       C         Quit       PM       6       2       1         Post_       LCME       0       0       0         ListSet       SwRg       LCME RSCS 00 0 ISTb       Links_OOS:       CS         Trnsl_       Unit0:       IStb       /RG:       0         Tst_       Unit1:       IStb       /RG:       0         Bsy_       11       11       11       11         RTS_       Drwr:       01       23       45       67       89       01       23         OffL                LoadPM_       rts       drwr 13       13       Japace       Japace </td <td>Flt       .       .       4 RCS 5 RSC .       .       17 CC *C* *C* *C* *C*         E       SysB       ManB       OffL       CBsy         Quit       PM       6       2       1       0         Post_       LCME       0       0       0       0         ListSet       SwRg       LCME RSCS 00 0 ISTb       Links_OOS:       CSide       0         Trnsl_       Unit0:       IStb       /RG:       0         Tst_       Unit1:       IStb       /RG:       0         Bsy_       11       11       11 RG         RTS_       Drwr:       01       23       45       67       89       01       23       45         OffL                 LoadPM_       rts drwr 13       Isation will affect both dr       Isation will affect both dr       Isation will affect both dr         Next       OSvce Tests       Initiated       LCME RSCS 00       Drwr 13       Tst Passed</td> <td>E         SysB         ManB         OffL         CBsy         ISTb           Quit         PM         6         2         1         0         23           Post_         LCME         0         0         0         0         1           ListSet         SwRg         LCME RSCS 00 0 ISTb         Links_OOS:         CSide         0           Trnsl_         Unit0:         IStb         /RG:         0           Tst_         Unit1:         IStb         /RG:         0           Bsy_         11         11         RG:         Pref         0           RTS_         Drwr:         01         23         45         67         89         01         23         45         Stby 1           OffL   .</td>	Flt       .       .       4 RCS 5 RSC .       .       17 CC *C* *C* *C* *C*         E       SysB       ManB       OffL       CBsy         Quit       PM       6       2       1       0         Post_       LCME       0       0       0       0         ListSet       SwRg       LCME RSCS 00 0 ISTb       Links_OOS:       CSide       0         Trnsl_       Unit0:       IStb       /RG:       0         Tst_       Unit1:       IStb       /RG:       0         Bsy_       11       11       11 RG         RTS_       Drwr:       01       23       45       67       89       01       23       45         OffL                 LoadPM_       rts drwr 13       Isation will affect both dr       Isation will affect both dr       Isation will affect both dr         Next       OSvce Tests       Initiated       LCME RSCS 00       Drwr 13       Tst Passed	E         SysB         ManB         OffL         CBsy         ISTb           Quit         PM         6         2         1         0         23           Post_         LCME         0         0         0         0         1           ListSet         SwRg         LCME RSCS 00 0 ISTb         Links_OOS:         CSide         0           Trnsl_         Unit0:         IStb         /RG:         0           Tst_         Unit1:         IStb         /RG:         0           Bsy_         11         11         RG:         Pref         0           RTS_         Drwr:         01         23         45         67         89         01         23         45         Stby 1           OffL   .		

If RTS	Do	
passed	step 26	
failed	step 24	

- **23** Go to the card replacement procedure in *Card Replacement Procedures* for the next card on the card list. When you finish with the card replacement procedures, go to step 6 of this procedure.
- 24 You have isolated the trouble to a line drawer pair. Diagnose the trouble to a card, shelf, frame, or cable. Make the necessary replacement. After you correct the trouble, return to step 20 of this procedure. Insert all fuses again, and busy and return to service all drawers.
- **25** For additional help, contact the next level of support.
- 26 This procedure is complete. If the system displays other alarms, reference the correct alarm clearing procedures for the indicated alarms.

### PM LCME major

### Alarm display

Call MS OD Hot Phi CCS The Edt	СМ	MS	IOD	Net	PM	CCS	Lns	Trks	Ext	APPL	
					1LCME M						

### Indication

A 1LCME alarm code under the PM subsystem header at the MTC level of the MAP display indicates an alarm involving an LCME. The letter M under the alarm code indicates that the alarm class is major.

### Meaning

The indicated number of LCME units are in the in-service (InSv) or system-busy (SysB) state.

### Result

The alarm affects subscriber service. Local LCME backup is not available if the other LCME units fail.

### **Common procedures**

There are no common procedures.


### Action

This procedure contains a flowchart and a list of steps. Use the flowchart to review the procedure. Follow the steps to perform the procedure.

## PM LCME

major (continued)

#### Summary of clearing a PM LCME major alarm



#### Clearing a PM LCME major alarm

### ATTENTION

You must enter this procedure from a step in a PM system-level alarm clearing procedure that identified an LCME-associated fault.

#### At the MAP terminal

1 To silence the alarm, type

>MAPCI;MTC;PM;SIL

and press the Enter key.

2 To identify the SysB LCME type

>DISP STATE ISTB LCME

and press the Enter key.

Example response on the MAP display: SysB LCME : 2

3 To post the SysB LCME that you identified in step 2, type

>POST LCME lcme\_site\_name lcme\_frame\_no lcme\_no

and press the Enter key.

where

Icme\_site\_name is the site name for the LCME that has faults

Icme\_frame\_no is the number of the associated LCME equipment frame

lcme\_no

is the number of the LCME that has faults

Example response on the MAP display:

## PM LCME

major (continued)

	СМ •	MS	IOD	N		1L					Tri		Ext		APPL	
L	CME			SysB		Mai	nB	0	ffL		CBsy		ISTb		InSv	7
0	Quit		PM	- 1			0		2		0		2		12	2
2	Post_		LCME	1			0		2		0		2		9	9
3	ListS	et														
4	SwRG		LCME	RSCS	14	1 I:	STb	Lin	ks_0	)0S:	CSid	e (	) PS:	ide	e 0	
5	Trnsl	_	Unit0:	In	Sv	Tak	eove	r		/RG:	1					
	_		Unit1:	Sy	sB					/RG:						
	Bsy_												G:Pref			
	_		Drwr:	01	23	45	67	89	01	23	45		Stby	0	InSv	
	OffL			••	••	••	••	••	••	••	••	••	••			
	LoadP	_														
	Disp_															
	Next															
13		<b>D</b> 14														
14	Query	РМ														
16																
17																
18																
																Ϊ

4

To check for fault indicators type

#### >QUERYPM FLT

and press the Enter key.

Example response on the MAP display:

CM ·	MS	IOD	Net	PM 1LCME M	CCS	Lns	Trks	Ext	APPL
LCME			SysB	ManB	01	EfL	CBsy	ISTb	InS
0 Quit		PM	1	0		2	0	2	1:
2 Post_		LCME	1	0		2	0	2	(
3 Lists	Set	T CIME	D000 14	1 TOMb	T d ml	000.			- 0
4 SwRG 5 Trnsl		LCME Unit0:	RSCS 14 InSv	Takeove		ks_00s. /RG		0 PSic	de O
6 Tst	-	Unit1:	SysB	Tancove	-	/RG			
7 Bsy_			-1			11 11		RG:Pref 1	l InSv
8 RTS_		Drwr:	01 23	45 67	89	01 23	45	Stby (	0 InSv
9 OffL			•••••	•••••	••			••	
.0 LoadF	_								
.1 Disp_ .2 Next			nservice e or botl				roublo		
.2 NEXU		LCME					les Exis	: <b>+ :</b>	
.4 Query	7PM		UNIT 1				ubles Ex		
.5									
.6	SI			BAY_ID			DESCRIPT		
.7		CSO 01 CSO 01	A00 A00	LCME LCME	00 00		LCME : LCME :	000 : 1	
16 84	A D -	lanlar							
		lisplay				Do			
			d that ha	s faults		<b>Do</b> step 16	õ		
indi	cate	s a care	l that ha ate a car				5		
indie does fault	cate s no ts	s a caro		d that h	as	step 16 step 5			
india does fault	cate s no ts	s a card t indica	the LCN	d that h	as	step 16 step 5			
india does fault To ma >BSY	cate s no ts inua unua	s a caro t indica lly busy IT uni	the LCN	d that h	as	step 16 step 5			
india does fault To ma >BSY	cate s no ts anua un: ress	s a card t indica	the LCN	d that h	as	step 16 step 5			
india does fault To ma >BSY and pu where	cate s no ts anua un: ress	s a caro t indica lly busy IT uni the Ent	the LCN	d that h	as	step 16 step 5			
india does fault To ma >BSY and pu where	cate s no ts nua un: ress e nit_i	s a caro t indica lly busy IT uni the Ent	the LCN	d that h IE poste	as d in s	step 16 step 5 step 3,ty			
india does fault To ma >BSY and pt where u	cate s no ts nua un: ress e nit_i is t	s a caro t indica lly busy IT uni the Ent	the LCN the LCN t_no ter key.	d that h IE poste	as d in s	step 16 step 5 step 3,ty			
india does fault To ma >BSY and pu where u To tes	cate s no ts nua unua ress ress nit_i is t	s a card t indica lly busy IT uni the Ent he num	the LCM the LCM t_no ter key. ber of the type	d that h IE poste	as d in s	step 16 step 5 step 3,ty			
india does fault To ma >BSY and pl where un To tes >TST	cate s no ts inua unua ress e nit_i is ti	s a caro t indica lly busy IT uni the Ent he num e LCME	the LCN the LCN t_no ter key. ber of the type t_no	d that h IE poste	as d in s	step 16 step 5 step 3,ty			
india does fault To ma >BSY and pl where un To tes >TST	cate s no ts unua unv: ress e nit_1 is ti ti the unv: ress	s a caro t indica lly busy IT uni the Ent he num he num e LCME IT uni	the LCN the LCN t_no ter key. ber of the type t_no	d that h IE poste	as d in s	step 16 step 5 step 3,ty			

5

6

**unit\_no** is the number of the LCME unit manually busied in step 5 *Example response on the MAP display:*  7

8

## PM LCME

major (continued)

If TST		Do	
passed		step 15	
failed		step 16	
cannot te	st CBsy links	step 7	
o identify (	C-side links that are in a S	sysB state type	
TRNSL C			
nd press t	he Enter key.		
iypical resp	oonse on the MAP display	:	
SINK 0	RCC2 2 ;CAP MS;STATUS:	SYSB,;MSGCOND:CLS	
LINK 1 LINK 2	RCC2 2 CAP S; STATUS: RCC2 2 CAP S; STATUS:	OK OK	
	RCC2 2 CAP S; STATUS:	OK	
LINK 4	RCC2 2 ;CAP MS;STATUS:	OK,;MSCOND:OPN,	
lf links		Do	
are SysB		step 8	
are open		step 20	
o post the	RCC2 unit associated wit	h the LCME, type	
POST RC	C2 rcc2_no		
nd press t	he Enter key.		
here			

	СМ	MS	IOI	)			ME	ccs		.S	Trks		t A	PPL
R	CC2			Sy	∕sB	ManB		Off	L	CB	sy	ISTb	I	nSv
	Quit			-					1		-	4		12
2	Post_	RCC	22		0	0			2		0	2		9
3	ListSe	et												
4		RCC	22	1	ISTb	Links	_005	s: C	Side	Ο,	PSide	1		
	Trnsl_	-												
	Tst_	Uni	t1:		Inact	InSv								
	Bsy_													
	RTS_													
	OffL													
	LoadPM	1												
	Disp_ Next													
	SwAct													
	QueryE	м												
15		1.1												
16														
17														
18														
$\langle$														

**9** To identify the P-side links that have faults, and to choose a link that has faults, type

>TRNSL P

and press the Enter key.

Example response on the MAP display:

LINK 23:LCME10;CAPMS;STATUS:SYSB;MSGCOND:CLSLINK 24:LCME11;CAPS;STATUS:OKLINK 25:LCME12;CAPS;STATUS:OKLINK 26:LCME13;CAPS;STATUS:OKLINK 27:LCME20;CAPMS;STATUS:OKLINK 28:LCME21;CAPS;STATUS:OKLINK 29:LCME22;CAPS;STATUS:OK

**10** To busy the link that has faults, type

```
>BSY LINK link_no
```

and press the Enter key.

where

#### link\_no

is the number of the P-side link chosen in step 9

**11** To test the ManB link, type

>TST LINK link\_no

and press the Enter key.

12

13

14

## PM LCME

major (continue	ea)	
-----------------	-----	--

where link_no is the number of the link manua	lly busied in step 10
If the MAP display	Do
indicates the card that has faults	step 16
does not indicate the card that has faults	step 12
To return the ManB link to service by ty	уре
>RTS LINK link_no	
and press the Enter key.	
where	
link_no is the number of the link tested	in step 11
<i>Note:</i> If the MAP display identifies of procedures in steps 10 through 12 fo until you busy, test, and return to se	r each link. Perform these procedure
If RTS	Do
passes	step 13
fails	step 20
fails To post the LCME that you identified in	•
	n step 2 type
To post the LCME that you identified in	n step 2 type
To post the LCME that you identified in >POST LCME lcme_site_name lcm	n step 2 type
To post the LCME that you identified in >POST LCME lcme_site_name lcm and press the Enter key.	n step 2 type me_frame_no 1cme_no
To post the LCME that you identified in >POST LCME lcme_site_name lcm and press the Enter key. where lcme_site_name	n step 2 type me_frame_no 1cme_no nat has faults
To post the LCME that you identified in >POST LCME lcme_site_name lcm and press the Enter key. where lcme_site_name is the site name for the LCME the lcme_frame_no	n step 2 type me_frame_no lcme_no hat has faults LCME
To post the LCME that you identified in >POST LCME lcme_site_name lcm and press the Enter key. where lcme_site_name is the site name for the LCME th lcme_frame_no is the number of the associated lcme_no	n step 2 type me_frame_no lcme_no hat has faults LCME
To post the LCME that you identified in >POST LCME lcme_site_name lcm and press the Enter key. where Icme_site_name is the site name for the LCME the Icme_frame_no is the number of the associated Icme_no is the number of the LCME that	n step 2 type me_frame_no lcme_no hat has faults LCME
To post the LCME that you identified in >POST LCME lcme_site_name lcm and press the Enter key. where lcme_site_name is the site name for the LCME the lcme_frame_no is the number of the associated lcme_no is the number of the LCME that To test the LCME unit type	n step 2 type me_frame_no lcme_no hat has faults LCME

	<b>unit_no</b> is the numb	er of the LCME unit	t posted in step 13
	If TST		Do
	passes		step 15
	fails		step 16
15	To return the LCMI	E to service, type	
	>RTS UNIT unit	_no	
	and press the Ente	er key.	
	where		
	unit_no is the numb	er of the LCME test	ted in step 14
	If RTS		Do
	passes		step 21
	fails		step 20
16	Check the card list	ing that appears in	the following MAP display.
	Example response	on the MAP displa	ıy:
	SITEFLRRPOSRSCS001A00RSCS001A00RSCS001A00	LCME 00 3 LCME 00 3	HF         DESCRIPTION         SLOT         EQPEC           32         LCME         :000         : 21         BX34           32         LCME         :000         : 19         BX35           32         LCME         :000         : 20         BX35
			rate a card list, check the logs. Go to maintenance support.
	lf you		Do
	replaced all card	ls on the list	step 17
	did not replace list	all cards on the	step 19
17			the RCC2 can cause the problem. that have faults that appear in step 9.
	lf you		Do
	replaced the NT	MX74 card	step 20
	did not replace card	e the NTMX74	step 18

## PM LCME major (end)

*Note:* If the MAP display indicates the NTMX74 card, determine if one link or several links have faults. Repeat clearing procedure as necessary.

18 Each interface (I/F) chip on the NTMX74 card serves four DS30A links. The following chart illustrates the link to chip relationship. The user must separate Message (MS) links by a minimum of four when the user enters data in table LCMINV.

Chip number	DS3	0A link	S		
1	22,	23,	24,	25	
2	26,	27,	28,	29	
3	30,	31,	32,	33	
4	34,	35,	36,	37	
5	38,	39,	40,	41	
6	42,	43,	44,	45	
7	46,	47,	48,	49	
8	50,	51,	52,	53	

Go to the card replacement procedure for the NTMX74 circuit card in *Card Replacement Procedures*. Complete the card replacement procedures and go to step 11 of this procedure.

- **19** Go to the card replacement procedure in *Card Replacement Procedures* for the next card on the card list. Complete the card replacement procedures and go to step 14 of this procedure.
- 20 For additional help contact the next level of support.
- 21 The procedure is complete. If other alarms appear, refer to the correct alarm clearing procedures for the indicated alarms.

## PM LCME(RG) major

## Alarm display

CM MS OD Not PM CCS The list	СМ	MS	IOD	Net	РМ	CCS	Lns	Trks	Ext	APPL
	•	·	•	•	1LCME M	·	•	•		•
					141					

## Indication

The alarm code 1LCME M under the PM subsystem header indicates a major alarm that involves an LCME ringing generator. The header appears at the MTC level of the MAP display.

## Meaning

One ringing generator unit is in the in-service trouble (ISTb) state. The other ringing generator is system-busy (SysB).

## Result

This alarm affects subscriber service. The system does not provide ringing to the subscribers.


### **Common procedures**

There are no common procedures.


## Action

This procedure contains a summary flowchart and a list of steps. Use the flowchart to review the procedure. Follow the steps to perform the procedure.


#### Summary of clearing a PM LCME (RG) major alarm (flowchart 1 of 3)



#### Summary of clearing a PM LCME (RG) major alarm (flowchart 2 of 3)



#### Summary of clearing a PM LCME (RG) major alarm (flowchart 3 of 3)



#### Clearing a PM LCME(RG) major alarm

#### At the MAP terminal

1

#### ATTENTION

Enter this procedure from a peripheral module (PM) system-level alarm clearing procedure step that identified an LCME-associated fault.

To silence the alarm, type:

#### >MAPCI;MTC;PM;SIL

and press the Enter key.

2 To identify the LCME that has faults, type:

>DISP STATE ISTB LCME

and press the Enter key.

Sample response on the MAP display: ISTb LCME : 2

**3** To post the ISTb LCME from step 2, type:

>POST LCME lcme\_site\_name lcme\_frame\_no lcme\_no

and press the Enter key.

where

## Icme\_site\_name

is the site name for the LCME that has faults

#### lcme\_frame\_no

is the number of the associated LCME equipment frame

Icme no

is the number of the LCME that has faults

Sample response on the MAP display:

/																	
		CM	MS	]	IOD	N	let				I		Tr	rks	Ext	APF	۰L
		•	•		•		·		CME	·		·		•	•	•	
								N	1								
	LCN	10				Svat	,	Mar	Ð	Of	ft		CBsy		ISTb	т	nSv
				DM		Syse 1		Mai	0	01	2		свъу 0		1	1	12
		Quit				-			-		_		-		-		
		Post_		LCME	5	1			0		2		0		1		9
		ListS															
	4	SwRG		LCME	C	RSCS	14	1 IS	STb	Link	s_00	)S:	CSic	le (	) PSid	e	0
	5	Trnsl	_	Unit	:0:	IS	Tb				,	/RG:	1				
	6	Tst_		Unit	:1:	Sy	зB				,	/RG:	1				
	7	Bsy_								11	11	11	11	11	RG:Pre	f 1	ISTb
	8	RTS_	Dru	wr:	01	23	45	67	89	01	23	45	67	89	Stb	y 0	ISTb
	9	OffL															
	10	LoadP	М														
		Disp_	_														
		Next															
	13	nene															
		Query	ъм														
	15	Query	E 1º1														
	15 16																
	17																
	18																)

4

To check for fault indicators, type:

>QUERYPM FLT

and press the Enter key.

Sample response on the MAP display:

	CM	MS	IOD	Net	PM 1LCME M	CCS			Ext	APPL
LCN	ſΕ			SysB	ManB	Of	fL	CBsy	ISTb	InSv
0	Quit		PM	1	0		2	0	1	12
2	Post_		LCME	1	0		2	0	1	9
3	ListSe	t								
4	SwRG		LCME	RSCS 14	1 ISTb	Link	s_00S:	CSide	0 PSid	e 0
5	Trnsl_		Unit0:	ISTb			/RG:	: 1		
6	Tst_		Unit1:	SysB			/RG:	: 1		
7	Bsy_					11	11 11	l 11 11	RG:Pre	f 1 ISTb
8	RTS_	Drv	vr: 01	23 45	67 89	01	23 45	5 67 89	) Stb	y O ISTb
9	OffL									
10	LoadPM	[	QUERYPI	M FLT						
11	Disp_		Node in	nservice	trouble	s exi	st:			
12	Next		On	e or both	n Units :	inser	vice tr	couble		
13			LCME	UNIT O	Inservi	ce Tr	oubles	Exist:		
14	QueryP	М	Ringing	g Generat	or Fail	ure :	Ring Ge	enerator	in Exces	s load
15			LCME	UNIT 1	Inservi	ce Tr	oubles	Exist:		
16			Ring G	enerator	in Exce	ss lo	ad			
17										
\18										)

If the system	Do
indicates a card that has faults	step 10
does not indicate a card that has faults	step 5

#### At the LCME

5 Perform a visual inspection of the ringing generator. Check if the LED is ON.

If the LED	Do	
is ON	step 6	
is OFF	step 7	

6

To power up the ringing generator, move the power switch to the ON position. (The LED goes OFF.) The switches are: RG 0 and RG 1.

lf	Do
turning ON the RG restores power	step 15
turning ON the RG does not restore power	step 7

## PM LCME(RG)

major (continued)

### At the MAP terminal

e	MAP te	rminal					
	To mar	nually bu	sy the	LCM	Eu	hit that is	ISTb, type:
	>BSY	UNIT u	nit_1	no			
	and pr	ess the E	Inter I	key.			
	where						
	un	i <b>t_no</b> is the nu	mber	of the	LC	ME unit	that appear in step 3
	To test	the Man	BLC	ME, ty	pe		
	>TST	UNIT u	nit_	no			
	and pr	ess the E	Enter I	key.			
	where						
		i <b>t_no</b> is the nu	mber	of the	LC	ME unit	manually busied in step 7
	Sampl	e respon	se on	the N	1AP	display:	
	LCME LCME	RSCS0 RSCS0	14 14	1 1 	or –	Unit 1 Unit 1	
	LCME LCME	RSCS0 RSCS0	14 14	1 1	,, –	Unit 1 Unit 1	OSVCE Test Initiated Tst passed
	If TS	т					Do
	passe	es					step 9
	fails						step 10
	To retu	irn the M	anB L	.CME	to s	ervice, t	ype:
	>RTS	UNIT u	nit_	no			
	and pr	ess the E	Inter I	key.			
	where						
		i <b>t_no</b> is the nu	mber	of the	LC	ME teste	ed in step 8
	If RT	S					Do
	passe	es					step 15
	fails						step 14
	Check	the card	list th	at app	bear	s. The d	card list results from step 8.

Sample response on the MAP display:

## PM LCME(RG) major (end)

	SITE	FLR 01	RPOS A00	BAY_ID	0.0	SHF 32		IPTION		LOT 20	EQPEC
	RSCS0 RSCS0	01	A00 A00	LCME LCME	00	32	LCME LCME	:000 :000	:		BX35 BX34
	If yo	vu					Do				
	repl	aced a	ll the	cards	on the	list	step 1	1			
	did the		place	e all the	e cards	on	step 1	3			
11	Deter	mine if	the N	IT6X30	circuit o	card w	as repla	aced.			
	If yo	ou					Do				
	repl care		the	NT6X.	30 cir	cuit	step 1	4			
		not re	place	the NT	[6X30	cir-	step 1	2			
12	Repla	acemer	nt Pro					e NT6X30 ci e the card re			
13	for the	e next (	card c	replace on the ca step 8.	ment pr ard list.	ocedu Whei	re in <i>Ca</i> n you co	ard Replacent complete the c	<i>nent</i> ard r	Proc epla	<i>edures</i> cement
14	For a	ddition	al help	o to clea	ar this a	larm,	contact	the next leve	l of n	naint	enance.
15	The p to the	rocedu appro	ure is o priate	complet alarm o	e. If otl clearing	her ala proce	arms ap edures.	pear at the M	1AP c	displa	ay, refer

## PM LCME minor

## Alarm display

ſ	CM MS OD Not PM CCS The lbd Liu7	СМ	MS	IOD	Net		CCS	Lns	Trks	Ext	APPL	
		•	•	•	·	1LCME	•	•	•	•	•	

## Indication

The alarm code 1LCME under the PM subsystem header indicates an LCME minor alarm. This header appears at the MTC level of the MAP display.

## Meaning

One of LCME units are in the in-service trouble (ISTb) state.

### Result

This condition does not affect subscriber service. Local backup is not available if the other LCME units fail.


## **Common procedures**

There are no common procedures.

## Action

This procedure contains a summary flowchart and a list of steps. Use the flowchart to review the procedure. Follow the steps to perform the procedure.

#### Summary of clearing a PM LCME minor alarm



#### **Clearing a PM LCME minor alarm**

#### At the MAP terminal

1

#### ATTENTION

Enter this procedure from a PM system-level alarm clearing procedure step that identifies an LCME-associated fault.

To silence the alarm, type

#### >MAPCI;MTC;PM;SIL

and press the Enter key.

2 To identify the LCME that has faults type >DISP STATE ISTB LCME and press the Enter key. Sample response on the MAP display:

ISTb LCME : 2

3 To post the ISTb LCME from step 2, type

>POST LCME lcme\_site\_name lcme\_frame\_no lcme\_no

and press the Enter key.

where

Icme\_site\_name is the site name for the LCME that has faults

lcme\_frame\_no
 is the number of the associated LCME equipment frame

lcme\_no

is the number of the LCME that has faults

Sample response on the MAP display:

( CI	M MS			PM			Trks	Ext APPL
•	•	•	•	1LCME	•		•	
L	CME		SysB	ManB	OffL	CBsy	ISTb	InSv
0	Quit	PM	1	0	2	0	2	12
	Post_ ListSet	LCME	0	0	2	0	2	9
					_	DOS: CSid	le 0 PS	ide O
	_		ISTb	Takeove:		/RG: 1 /RG: 1		
	ISL_ Bsy	011111.	1510			/RG· 1 11 11	RG:Dref	1 InSv
		Drwr:	01 23	45 67		23 45		
	OffL							
10	LoadPM_							
11	Disp_							
	Next							
13								
	QueryPM							
15								
16								
17								
( <sup>18</sup>								)

To check for fault indicators, type >QUERYPM FLT and press the Enter key. Sample response on the MAP display:

4

DMS-100 Family Switching Center-SONET Model B Maintenance Manual

(						)
CM MS	IOD Net	PM	CCS	Lns	Trks	Ext APPL
		1LCME				
LCME	SysB	ManB	OffL	CBsy	ISTb	InSv
0 Quit	PM 1	0	2	0	2	12
2 Post_	LCME 0	0	2	0	2	9
3 ListSet						
4 SwRG	LCME RSCS 14	1 ISTb	Links_00	DS: CSid	le 1 PS	ide O
5 Trnsl_	Unit0: InSv	Takeove	r,	/RG: 1		
6 Tst_	Unitl: ISTb		/	/RG: 1		
7 Bsy_			11	11 11	RG:Pref	1 InSv
8 RTS_	Drwr: 01 23	45 67	89 01	23 45	Stby	0 InSv
9 OffL			•••••	•• ••		
10 LoadPM_	QUERYPM FLT					
11 Disp_	Node inservice	trouble	s exist:			
12 Next	One or bot	h Units :	inservice	e trouble	2	
13	LCME UNIT 0					
14 QueryPM	LCME UNIT 1	Inservi	ce Troubl	les Exist	::	
15						
16						
17						
18						,

If the system	Do
indicates a card that has faults	step 17
does not indicate a card that has faults	step 5
To manually busy the LCME that appe	ars in step 3, type
>BSY UNIT unit_no	
and press the Enter key.	
where	
unit_no is the number of the ISTb LCM	E unit
To test the ManB LCME, type	
>TST UNIT unit_no	
and press the Enter key.	
where	
unit_no is the number of the LCME unit	manually busied in step 5
Sample response on the MAP display	:

5

6

If TST		Do	
passes		step 16	
fails		step 17	
cannot	test CBsy	step 7	
To identify	y C-side links in a SysB cor	ndition, type	
>TRNSL	С		
and press	s the Enter key.		
Sample r	esponse on the MAP displa	ay:	
LINK O	RCC2 2 ;CAP MS;STATUS:	OK,;MSGCOND:OPN	
LINK 1 LINK 2	RCC2 2 CAP S; STATUS: RCC2 2 CAP S; STATUS:	SysB OK	
LINK 2 LINK 3	RCC2 2 CAP S; STATUS: RCC2 2 CAP S; STATUS:	OK	
LINK 4	RCC2 2 ;CAP MS;STATUS:	OK, ; MSCOND: OPN	
lf links		Do	
are Sys	В	step 8	
are ope	n	step 21	
To post th	e RCC2 unit that associate	es with the LCME, type	
>POST R	CC2 rcc2_no		
and press	s the Enter key.		
where			

7

8

	CM	MS	IOI	D N	et PM	CCS	Lns	Trks	Ext	APPL
	•	•	•		. 1LCME	•	•	•	•	•
	RCC2	2		SysB	ManB	OffL	CBsy	ISTb		InSv
	0 Q1	uit	PM	0	0	0	0	4		12
	2 Pc	ost_	RCC2	0	0	0	0	2		9
	3 L:	istSet								
	4		RCC2	2 ISTb	Links_00S	: CSide	0, PSi	ide 1		
	5 Ti	rnsl_	Unit0:	Act	InSv					
	бΤя	st_	Unit1:	Inac	t InSv					
	7 Bs	sy_								
	8 R.	rs_								
	9 01	EfL								
	10 Lo	oadPM_								
	11 D:	isp_								
	12 Ne	ext								
	13 Sv	wAct								
	14 Qi	leryPM								
	15									
	16									
	17									
	18									
$\langle \rangle$										/

**9** To identify the P-side links that have faults and to choose a link that has faults, type

#### >TRNSL P

and press the Enter key.

Sample response on the MAP display:

LINK	23:LCME	1	0;CAP	MS;STATUS:	OK;MSGCOND:OPN
LINK	24:LCME	1	1;CAP	S;STATUS:	SysB
LINK	25:LCME	1	2;CAP	S;STATUS:	OK
LINK	26:LCME	1	3;CAP	S;STATUS:	OK
LINK	27:LCME	2	0;CAP	MS;STATUS:	OK;MSGCOND:OPN
LINK	28:LCME	2	1;CAP	S;STATUS:	OK
LINK	29:LCME	2	2;CAP	S;STATUS:	OK

**10** To busy the link that has faults, type

#### >BSY LINK link\_no

and press the Enter key.

#### where

#### link no

is the number of the P-side link manually busied in step 9

11 To test the ManB link, type

>TST LINK link\_no

and press the Enter key.

vhere		
link_no is the num	ber of the link manua	ally busied in step 10
If TST		Do
passes		step 16
fails		step 12
Read the followir	ng table to determine	your next action.
If the system		Do
indicates a car	d that has faults	step 17
does not indic faults	ate a card that has	step 13
o return the Ma	nB link to service, typ	0e
RTS LINK li	nk_no	
and press the En	ter key.	
vhere		
link_no is the num	ber of the link tested	in step 11
If RTS		Do
passes		step 22
fails		step 21
		step 21
		er links that have faults. Execute step are busied, tested, and returned to
10 to 13 for easervice.		er links that have faults. Execute step
10 to 13 for ea service. To post the LCM	ch link until the links E from step 2, type	er links that have faults. Execute step
10 to 13 for ea service. To post the LCM	ch link until the links E from step 2, type cme_site_name lo	er links that have faults. Execute step are busied, tested, and returned to
10 to 13 for ea service. To post the LCM	ch link until the links E from step 2, type cme_site_name lo	er links that have faults. Execute step are busied, tested, and returned to
10 to 13 for ea service. o post the LCM POST LCME 1 ond press the En where Icme_site_n	ach link until the links E from step 2, type cme_site_name lo ter key.	er links that have faults. Execute step are busied, tested, and returned to me_frame_no lcme_no
10 to 13 for ea service. To post the LCMI POST LCME 10 and press the En where Icme_site_n is the site Icme_frame	ach link until the links E from step 2, type cme_site_name lo ter key. ame name for the LCME t	er links that have faults. Execute step are busied, tested, and returned to me_frame_no lcme_no

15

16

17

18

## PM LCME

**minor** (continued)

t that appears in step 14
Do
step 16
step 17
ре
t tested in step 15
Do
step 22
step 21
the MAP display.
<i>":</i>
DESCRIPTION SLOT EQPEC
LCME :000 : 19 BX35 LCME :000 : 20 BX35
LCME :000 : 21 BX34
Do
step 18
step 20
0A interface card in the RCC2 that isted in step 9.
Do
step 21

# PM LCME minor (end)

lf you

Do

did not replace the NTMX74 step 19 card

*Note:* If the system indicates the NTMX74 card, check if one link or several links have faults. Repeat the alarm clearing procedure.

**19** Each interface (I/F) chip on the NTMX74 card serves 4 DS30A links. The following chart illustrates the Link to chip relationship. A minimum of 4 must separate message (MS) links when you enter data in table LCMINV.

Chip number	DS3	DS30A links								
1	22,	23,	24,	25						
2	26,	27,	28,	29						
3	30,	31,	32,	33						
4	34,	35,	36,	37						
5	38,	39,	40,	41						
6	42,	43,	44,	45						
7	46,	47,	48,	49						
8	50,	51,	52,	53						

Go to the card replacement procedure for the NTMX74 circuit card in *Card Replacement Procedures*. Complete the card replacement procedures. Go to step 11.

- **20** Go to the card replacement procedure in *Card Replacement Procedures* for the next card on the card list. Complete the card replacement procedures. Go to step 15.
- 21 For additional help, contact the next level of maintenance.
- 22 The procedure is complete. If other alarms appear at the MAP display, refer to the appropriate alarm clearing procedures.

5-112 RSC-S alarm clearing procedures

# PM LCME(RG) minor

## Alarm display

CM MS OD Not PM CCS This But	СМ	MS	IOD	Net	РМ	CCS	Lns	Trks	Ext	APPL
	•			·	1LCME	-	•	•	•	

## Indication

The alarm code 1LCME under the PM subsystem header indicates a minor alarm that involves an LCME ringing generator. This alarm code is at the MTC level of the MAP display.

## Meaning

One of the ringing generator units is in the in-service trouble (ISTb) state.

### Result


The ISTb state does not affect service. The system switches automatically to a backup ringing generator (SwRG). If the backup ringing generator fails, the system does not produce ringing.

### **Common procedures**

There are no common procedures.


## Action

This procedure contains a summary flowchart and a list of steps. Use the flowchart to review the procedure. Follow the steps to perform the procedure.



Summay of clearing a PM LCME (RG) minor alarm (flowchart 1 of 2)

#### Summay of clearing a PM LCME (RG) minor alarm (flowchart 2 of 2)



#### Clearing a PM LCME(RG) minor alarm

#### At the MAP display

1

#### ATTENTION

Enter this procedure from a PM system-level alarm clearing procedure step that identified an LCME-associated fault.

To silence the alarm, type

#### >MAPCI;MTC;PM;SIL

and press the Enter key.

2 To identify the LCME that has faults, type

>DISP STATE ISTB LCME

and press the Enter key.

Sample response on the MAP display:

ISTb LCME : 2

3 To post the ISTb LCME identified in step 2, type

>POST LCME lcme\_site\_name lcme\_frame\_no lcme\_no

and press the Enter key.

where

Icme\_site\_name is the site name for the LCME that has faults

Icme\_frame\_no is the number of the associated LCME equipment frame

lcme\_no

is the number of the LCME that has faults

Sample response on the MAP display:

( (	СМ	MS	I	OD	Net		PM	C	CS!	Ln	S	Trk	5	Ext	API	PL	
1	•	•			•		1LCM	C						•			
LCI	ЧE			S	ysB		ManB		Off	L	CB	sy	I	STb	]	InSv	
0	Quit		РМ		1		0			2		0		2		12	
2	Post_		LCME		0		0			2		0		2		9	
3	ListS	et															
4	SwRG		LCME	R	SCS	14 1	. IST	o I	inks	_00S	: C	Side	0	PSid	le	0	
5	Trnsl	_	Unit	0:	InS	v	Taked	over		/ R	G: 0						
6	Tst_		Unit	1:	IST	b				/ R	G: 1						
7	Bsy_								11	11	11	11	11	RG:Pr	ef 1	l Ins	Sv
8	RTS_	Dr	wr:	01	23	45	67	89	01	23	45	67	89	St	by (	) IST	Гb
9	OffL											••					
10	LoadP	M															
11	Disp_																
12	Next																
13																	
14	Query	PM															
15																	
16																	
17																	
18																	

4 To check for fault indicators, type >QUERYPM FLT and press the Enter key. Sample response on the MAP display:

297-8281-550 Standard 10.05 November 2000

	CM •	MS	-	Ne								ks	Ex	t.	APP	r /
LCI	ЧE			SysB	I	ManB		Of	£Г	C	Bsy		ISTb	)	I	nSv
0	Quit		PM	1		0			2		0		1			12
2	Post_		LCME	0		0			2		0		1			9
3	ListSe	et														
4	SwRG		LCME	RSCS	14	1 IS	Tb	Li	nks_	005:	CS	ide	0	PSi	de	0
5	Trnsl_	_	Unit0:	InS	v	Takeo	ver		/	RG:	1					
6	Tst_		Unit1:	IST	b				/	RG:	1					
7	Bsy_							11	11	11	11	11	RG:	Pref	1	InSv
8	RTS_	Drw	r: 01	23	45	67 8	9	01	23	45	67	89		Stby	0	ISTb
9	OffL													_		
10	LoadPN	4	QUERYP	M FLT												
11	Disp_		Node i	n-serv	ice	troub	les	ex	ist:							
12	Next		On	e or b	oth 1	Units	in	-se	rvic	e tr	oubl	е				
13			LCME	UNIT	0 II	n-ser	vic	e T	roub	les	Exis	t:				
14	Query	PM	Ringin	g Gene	rato	r Fai	lur	e :	Ring	Ger	nerat	or :	in Ex	cess	lo	ad
15			LCME	UNIT	1 II	n-ser	vic	e T	roub	les	Exis	t:				
16			Ring G	enerat	or i	n Exc	ess	10	ad							
17																
18																

If the system	Do
indicates a card that has faults	step 10
does not indicate a card that has faults	step 5

#### At the LCME

6

5 Make a visual inspection of the ringing generator. Check to see if the LED is on.

If LED	Do
is ON	step 6
is OFF	step 7
To power up the ringing gene position. The LED goes OF switches.	erator (RG), move the power switch to the ON F. The codes RG 0 and RG 1 identify these

lf	Do
swtiching ON the RG restores power	step 15

DMS-100 Family Switching Center-SONET Model B Maintenance Manual

At 7

8

9

## PM LCME(RG)

minor (continued)

lf				Do					
	ching ON re power	the RG d	oes not	step 14					
MAP di	splay								
To mai	nually busy	the LCME	unit that is	s ISTb, type					
>BSY	UNIT uni	it_no							
and pr	ess the En	iter key.							
where									
	it_no is the num	ber of the L	CME unit	posted in step 3					
To test	the ManB	LCME, type	е						
>TST	UNIT uni	it_no							
and pr	ess the En	iter key.							
where									
	it_no is the num	ber of the I	CME unit	manually busied in step 7					
		e on the MA							
LCME LCME		14 1 14 1	Unit 1	InSvce Test Initiated Tst Failed: (Reason for failure					
LCME LCME		- Or 14 1 14 1	Unit 1	InSvce Test Initiated Tst passed					
If TS	Г			Do					
passe	ed			step 9					
faile	d			step 10					
To retu	Irn the Mar	nB LCME to	service, t	уре					
>RTS	UNIT uni	it_no							
and pr	ess the En	iter key.							
where									
un	it_no is the num	ber of the L	CME teste	ed in step 8					
If RT	S			Do					
				step 15					
passe	Ju –								

## PM LCME(RG) minor (end)

**10** Check the card listing in the MAP display.

Sample response on the MAP display:

SITE	FLR	RPOS	BAY_ID		SHF	DESCR	IPTION	SI	LOT	EQPEC
RSCS0	01	A00	LCME	00	32	LCME	:000	:	21	BX34
RSCS0	01	A00	LCME	00	32	LCME	:000	:	19	BX35
RSCS0	01	A00	LCME	00	32	LCME	:000	:	20	BX35

lf you Do

replaced all the cards on the list step 11

did not replace all the cards on step 13 the list

11 Determine if you replaced the NT6X30 circuit card.

lf you	Do
replaced the NT6X30 card	step 15
did not replace the NT6X30 card	step 12

- 12 Go to the card replacement procedure for the NT6X30 circuit card in *Card Replacement Procedures.* Complete the card replacement procedures. Go to step 8 of this procedure.
- **13** Go to the card replacement procedure in *Card Replacement Procedures* for the next card on the card list. Complete the card replacement procedures. Go to step 8 of this procedure.
- 14 For additional help to clear this alarm, contact the next level of support.
- **15** The procedure is complete. If the system displays other alarms, reference the correct alarm clearing procedures for the indicated alarms.

# PM RCC2 critical

## Alarm display

 СМ	MS	IOD	Net	РМ	Lns	Trks	Ext	APPL
				nRCC2 *C*				

## Indication

An nRCC2 \*C\* under the PM subsystem header at the MTC level of the MAP display indicates an RCC2 critical alarm.

## Meaning

Both RCC2 units are in the system-busy (SysB) or in the C-side busy (CBsy) state.

### Result

Call processing ceases. The RCC2 can be in emergency stand-alone (ESA).


## **Common Procedures**

There are no common procedures.

## Action

This procedure contains a summary flowchart and a list of steps. Use the flowchart to review the procedure. Follow the steps to perform the procedure.

#### Summary of clearing a PM RCC2 critical alarm



#### Clearing a PM RCC2 critical alarm

#### At the MAP display

1

#### ATTENTION

Enter this procedure from the PM system-level alarm clearing procedure step that identified an RCC2-associated fault.

To silence the alarm, type

#### >MAPCI;MTC;SIL

and press the Enter key.

2 To identify the RCC2 that has faults type

>Pm;disp STATE cbsy RCC2 and press the Enter key. Example of a MAP response:

CBsy RCC2: 2 *or* 

None

If None appears on the MAP screen, display the SysB RCC2. To display the SysB RCCS, type

>disp STATE SYSB RCC2

and press the Enter key.

Example of a MAP response:

SysB RCC2: 2

3 To post the CBsy or SysB RCC2, type

>POST RCC2 rcc2\_no

and press the Enter key.

where

#### rcc2\_no

is the number of the RCC2 displayed in step 2

Example of a MAP response:

RCC2	SysB	ManB	Offl	CBsy	ISTb	InSv
PM	3	0	1	1	4	12
RCC2	0	0	2	1	2	9

4 To check for fault indicators, type
>querypm flT
and press the Enter key.
Example of a MAP display:

	СМ	MS	IOD		PM 1RCC2		Lns	Trks	Ext	APPL
	•		•	·	*C*	·	•		·	·
RCC	22		2	SysB	ManB	OffL	CB	sy	ISTb	InSv
0	Quit	PM		3	0	1		1	4	12
2	Post_	RC	22	0	0	2		1	2	9
3	ListSe	t								
4		RC	22 (	) CBsy	Links_0	os: csi	.de 1,	PSide	0	
5	TRNSL_	Un	LtO:	Act	CBsy					
б	Tst_	Un	itl:	Inact	CBsy					
7	Bsy_	QUI	ERYPM	FLT						
8	RTS_		Un	it0 Sta	atic dat	a not u <u>p</u>	bdated			
9	OffL		Un	itl Rea	set					
10	LoadPM	[								
	Disp_									
	Next									
13										
	QueryP	M								
15										
16										
17										
18										

5

6



#### DANGER

The RCC2 can be in ESA

A CBsy indicator can change to a SysB indicator. This change means that the RCC2 is in emergency stand-alone (ESA) mode. During ESA, the system generates PM180 and PM181 logs. These logs indicate ESA. The system supports only local calls.

Use the following information to determine the next step.

If the RCC2	Do
is SysB	step 6
is CBsy	step 15

Check for PM180 and PM181 logs. These logs indicate that the RCC2 is in emergency stand-alone (ESA). Perform this check according to local

operating company policy, and according to the type of device used to generate log reports.

	generate log reports.									
	If log reports	Do								
	are available	step 10								
	are not available	step 7								
7	To activate the LOGUTIL databas	se, type								
	>QUIT ALL;LOGUTIL PM									
	and press the Enter key.									
8	To display PM180 and PM181 log reports, type									
	>OPEN PM 180									
	>WHILE (BACK)(SLEEP 2)									
	and press the Enter key.									
	Note: Repeat the above comr	nand substituting PM181 for PM180.								
9	Check these reports to determine reasons for the critical alarm in the Re When the MAP display finishes scrolling and you have the necessary information, return to the CI command level. To return to the CI comm level, type									
	>QUIT									
	and press the Enter key.									
10	To post the RCC2 again, type									
	>MAPCI;MTC;PM;POST RCC2 1	rcc2_no								
	and press the Enter key.									
	where									
	rcc2_no is the number of the RCC2	2 displayed in step 2								
	If the PM logs	Do								
	indicate ESA	step 35								
	do not indicate ESA	step 11								
11	To manually busy the RCC2, type	3								
	>bsy pm									
	and press the Enter key.									
12	To restore PM service, type									
	>rts pm force									
	and press the Enter key.									

Example of a MAP response:

	UNIT unit_no in ESA MODE. THIS ACTION WILL CAUSE ESA EXIT AND ABORT n CALLS PLEASE CONFIRM ("YES" "Y" OR "NO" "N")										
	where										
	<pre>unit_no     is the number of the RCC2 identified in step 2</pre>										
	n is the number of calls in progress										
13	To confirm the command in step 12, type										
	>yes										
	and press the Enter key.										
	If RTS PM FORCE	Do									
	passed for both units	step 37									
	failed for both units	step 14									
	failed for one unit	The alarm changed, refer to the <i>Alarm Clearing Procedures</i> for an RCC2 ISTb major alarm.									
14	To perform an out-of-service (OOS) te	est on the ManB RCC2, type									
	>tst pm										
	and press the Enter key.										
	Example of a MAP response:										
	Test Passed										
	<i>or</i> Test Failed										
	If TST	Do									
	passed	step 27									
	failed because C-side links are clo	osed step 15									
	failed and the system generates a card list step 31										
15	To identify C-side links to the host PM that are CBsy, type >trns1 c and press the Enter key. A host PM is a line group controller (LGC) or a line trunk controller (LTC										
	the following example, the host PM is an LTC.										

#### Example of a MAP response:

LINK 0: LTC	1 0;CAP MS;STATUS:	OK,;MSGCOND: OPN,Restricted
LINK 1: LTC	1 1;CAP S;STATUS:	OK
LINK 2: LTC	1 2;CAP MS;STATUS:	OK,;MSGCOND:OPN,Unrestricted
LINK 4: LTC	1 4;CAP S;STATUS:	CBsy
LINK 5: LTC	1 4;CAP S;STATUS:	OK
LINK 6: LTC	1 4;CAP S;STATUS:	OK
LINK 7 :LTC	1 4;CAP S;STATUS:	OK

**16** To post the host PM identified in step 15, type

>post host\_pm host\_pm\_no

and press the Enter key.

where

host\_pm is an LGCI or an LTCI

host\_pm\_no

is the number of the LGCI or LTCI

Example of a MAP display:

		СМ •	MS ·	IOD	Net	PM 1RCC2 *C*		Lns			APPL
1	JTC	2		:	SysB	ManB	OffI	. (	CBsy	ISTb	InSv
	0	Quit	PM		3	0	1		1	4	12
	2	Post_	LTC		0	0	2		1	2	9
	3	ListSe	t								
	4		LTC		1 ISTb	Links_00	s: cs	ide (	0, PSide	1	
	5	Trnsl_	Uni	t0:	Act I	nSv					
	6	Tst_	Uni	t1:	Inact	InSv					
	7	Bsy_									
	8	RTS_									
	9	OffL									
1	0	LoadPM	<u> </u>								
1	.1	Disp_									
1	2	Next									
1	.3	SwAct									
1	.4	QueryP	М								
1	.5										
1	6										
1	7	Perfor	m								
( ]	.8										/

17 To identify the P-side links that have faults and choose a link that has faults, type

>TRNSL P

and press the Enter key.

Example of a MAP response:

LINK 0: RCC2 1 0; CAP MS; STATUS: OK,; MSGCOND: OPN, Restricted LINK 1: RCC2 1 1;CAP S;STATUS: OK LINK 2: RCC2 1 2; CAP MS; STATUS: OK, ; MSGCOND: OPN, Unrestricted LINK 4: RCC2 1 4;CAP S;STATUS: SysB LINK 5: RCC2 1 4; CAP S; STATUS: OK LINK 6: RCC2 1 4; CAP S; STATUS: OK LINK 7 :RCC2 1 4;CAP S;STATUS: OK To busy the link that has faults, type >bsy link link\_no and press the Enter key. where link no is the number of the P-side link identified in step 17 To test the link that has faults, type >TST link link no and press the Enter key. where link no is the number of the link manually made busy in step 18 If TST Do passed and the alarm clears step 25 failed step 20 To display any trunks that have faults, type >TRKS;carrier;post remote and press the Enter key. Example of a MAP response: CLASS ML OS ALARM SYSB MANB UNEQ OFFL CBSY PBSY INSV TRUNKS 0 0 0 0 Ο 0 0 0 Ο 0 REMOTE 0 0 0 5 1 0 0 1 0 10 NO CLASS SITE RCC2 CKT D ALARM SLIP FRAME BER SES STATE 0 TRUNKS BRSC 0 2 C 0 0 <-.7 0 INSV 1 REMOTE BRSC 0 12 C 0 0 <-.7 0 INSV 13 C 0 0 2 REMOTE BRSC 0 <-.7 0 MANB MORE . . .  $\it Note:$  The <code>MORE</code> . . . at the bottom of the display indicates that you can observe more links. To observe more links, type

18

19

20

23

24

### PM RCC2 critical (continued)

#### >NEXT

and press the Enter key.

**21** Carry out the repair or corrective procedure indicated in the MAP display in step 20.

*Note:* If the MAP display indicates message links that have faults, the links must be ManB before the links can be RTS.

22 To test the ManB link, type

#### >tst link\_no

and press the Enter key.

where

link\_no

is the number of the ManB link. This link number appears under the NO column as appears in the MAP display in step 20. The number for the ManB link in the example is two.

If TST		Do
passed and th	e alarm clears	step 23
failed		step 36
failed and the card list	system generat	tes a step 31
To post the host	PM, type	
>pm;post hos	t_pm host_pm	n_no
and press the E	nter key.	
where	2	
is the hos host_pm_n	0	ICI posted in step 16
is the nur	nber of the host	PM
	nber of the host tus of the P-side	
To verify the sta	tus of the P-side	
To verify the sta <i>&gt;TRNSL_P</i>	tus of the P-side nter key.	
To verify the sta <i>&gt;TRNSL P</i> and press the E	tus of the P-side nter key.	links, type
To verify the sta > <b>TRNSL P</b> and press the E <i>Example of a M</i>	tus of the P-side nter key. A <i>P response:</i> 1 0;CAP MS;ST	links, type
To verify the state >TRNSL P and press the E Example of a M. LINK 0: RCC2	tus of the P-side nter key. AP response: 1 0; CAP MS; ST 1 1; CAP S; ST 1 2; CAP MS; ST	Plinks, type CATUS: OK,;MSGCOND: OPN,Restricted CATUS: OK
To verify the state TRNSL P and press the E Example of a M. LINK 0: RCC2 LINK 1: RCC2 LINK 2: RCC2 LINK 2: RCC2 LINK 4: RCC2	tus of the P-side nter key. AP response: 1 0; CAP MS; ST 1 1; CAP S; ST 2; CAP MS; ST 1 4; CAP S; ST	Plinks, type CATUS: OK,;MSGCOND: OPN,Restricted CATUS: OK CATUS: OK,;MSGCOND:OPN,Unrestricted CATUS: OK
To verify the state TRNSL P and press the E Example of a M. LINK 0: RCC2 LINK 1: RCC2 LINK 2: RCC2	tus of the P-side nter key. AP response: 1 0; CAP MS; ST 1 1; CAP S; ST 1 2; CAP MS; ST 1 4; CAP S; ST 1 4; CAP S; ST	TATUS: OK,;MSGCOND: OPN,Restricted CATUS: OK CATUS: OK CATUS: OK,;MSGCOND:OPN,Unrestricted

	To notions the link to consider these								
25	To return the link to service, type								
	>RTS link link_no								
	and press the Enter key.								
	where								
	link_no is the number of the link identified in step 17								
	<i>Note:</i> You must perform this step for each link that has faults that was made busy.								
6	To post the inactive RCC2, type								
	>post RCC2 rcc2_no								
	and press the Enter key.								
	where								
	rcc2_no is the number of the RCC2 i	rcc2_no is the number of the RCC2 identified in step 2							
	Note: This RCC2 must be Sys	3.							
	To return the inactive PM unit to se	ervice, type							
	>RTS PM								
	and press the Enter key.								
	If RTS for both RCC2 units	Do							
	passed	step 37							
	failed	step 28							
3	failed To manually busy the inactive RCC	-							
5		-							
3	To manually busy the inactive RCC	-							
	To manually busy the inactive RCC <i>&gt;bsy INACTIVE</i>	2 unit, type							
	To manually busy the inactive RCC >bsy INACTIVE and press the Enter key.	2 unit, type							
	To manually busy the inactive RCC >bsy INACTIVE and press the Enter key. To perform an OOS test on the ina	2 unit, type							
	To manually busy the inactive RCC >bsy INACTIVE and press the Enter key. To perform an OOS test on the ina >TST UNIT unit_no	2 unit, type							
	To manually busy the inactive RCC >bsy INACTIVE and press the Enter key. To perform an OOS test on the inac >TST UNIT unit_no and press the Enter key.	2 unit, type ctive RCC2 unit, type							
	To manually busy the inactive RCC >bsy INACTIVE and press the Enter key. To perform an OOS test on the ina >TST UNIT unit_no and press the Enter key. where unit no	2 unit, type ctive RCC2 unit, type							
	To manually busy the inactive RCC >bsy INACTIVE and press the Enter key. To perform an OOS test on the inac >TST UNIT unit_no and press the Enter key. where unit_no is the number of the inactive	2 unit, type ctive RCC2 unit, type e RCC2 unit (0 or 1)							
29	To manually busy the inactive RCC >bsy INACTIVE and press the Enter key. To perform an OOS test on the inac >TST UNIT unit_no and press the Enter key. where unit_no is the number of the inactive If TST	2 unit, type ctive RCC2 unit, type e RCC2 unit (0 or 1) <b>Do</b>							

30 To return the inactive RCC2 unit to service, type

>RTS UNIT unit\_no

and press the Enter key.

where

unit\_no

is the number of the inactive RCC2 unit (0 or 1)

If RTS	Do	
passed	step 37	
failed	step 36	

31 Check the card listing that appears on the MAP display.

The RCC2s can have the optional NTAX74AA Cellular Access Processor (CAP). For RCC2s with the NTAX74AA CAP, the MAP response displays a card list that reflects AX74 in slot 03. For RCC2s that have the NTMX77AA Unified Processor (UP), the MAP response reflects MX77AA in slot 3. Both configurations appear in the following examples.

NTMX77

Example of a MAP response for an RCC2 configured with the NTMX77 Unified Processor:

SITE		FLR		RPOS	BAY_ID	SHF	DESCRIPTION	I SLOT	EQPEC
RSC0	01		A00	CRSC	00	05	RCC2 : 000	:03	MX77
RSC0	01		A00	CRSC	00	05	RCC2 : 000	:08	6X69
RSC0	01		A00	CRSC	00	05	RCC2 : 000	:11	MX73
RSC0	01		A00	CRSC	00	05	RCC2 : 000	:13	MX74
RSC0	01		A00	CRSC	00	05	RCC2 : 000	:05	6X78

NTAX74

Example of a MAP response for RCC2s configured with the optional NTAX74AA Cellular Access Processor:

SITE		FLR		RPOS	BAY_I	D	SHF		DE	SCRIP	TION	SLOT EQPEC
RSC0	01		A00	CRSC	00	05		RCC2	:	000	:03	AX74
RSC0	01		A00	CRSC	00	05		RCC2	:	000	:08	6X69
RSC0	01		A00	CRSC	00	05		RCC2	:	000	:11	MX73
RSC0	01		A00	CRSC	00	05		RCC2	:	000	:15	MX74
RSC0	01		A00	CRSC	00	05		RCC2	:	000	:05	6X78

Do

lf you

replaced all the cards on the list step 32

did not replace all the cards on step 34 the list

### PM RCC2 critical (end)

32	Determine if the NTMX81 circuit card	Determine if the NTMX81 circuit card has been replaced.									
	lf you	Do									
	replaced the NTMX81 card	step 36									
	did not replace the NTMX81 card	step 33									
33	Go to the card replacement procedure <i>Replacement Procedures</i> . When you procedures, go to step 23 of this proc	finish with the card replacement									
34	Go to the card replacement procedure the next card on the card list. When y procedures, go to step 29 of this proc										
35	Go to Recovery Procedures for instru you complete the recovery procedure alarm clearing procedure.	ctions on recovering the RCC2. When , return to step 4 and complete the									
36	Contact the next level of support to ob	otain more help to clear this alarm.									
37	The procedure is complete. If other al clearing procedures for the indicated	arms appear, refer to the correct alarm alarms.									

# PM RCC2 major

### Alarm display

CM MB OD Not PM CC8 This But	СМ	MS	IOD	Net		CCS		Trks	Ext	APPL
	-	-	•	•	1RCC2	-	-	•	•	•
					М					

### Indication

At the MTC level of the MAP display, the alarm code 1RCC2 M under the PM subsystem header indicates an RCC2 major alarm.

### Meaning

The indicated number of RCC2 units are in the system-busy (SysB) state.

#### Result

This alarm does not affect subscriber service. If both RCC2 units fail, subscriber service ends.


### **Common procedures**

There are no common procedures.

### Action

This procedure contains a summary flowchart and a list of steps. Use the flowchart to review the procedure. Follow the steps to perform the procedure.

#### Summary of clearing a PM RCC2 major alarm



# PM RCC2

major (continued)

#### Clearing a PM RCC2 major alarm

#### At the MAP display

1

#### ATTENTION

Enter this procedure from a PM system-level alarm clearing procedure step that identified an RCC2-associated fault.

To silence the alarm, if required, type

#### >MAPCI;MTC;PM;SIL

and press the Enter key.

2 To identify the RCC2 that has faults, type

>DISP STATE SYSB RCC2

and press the Enter key.

Sample response on the MAP display: SysB RCC2 : 2

3 To post the SysB RCC2, type

>POST RCC2 rcc2\_no

and press the Enter key.

where

rcc2\_no

is the number of the RCC2 displayed in step 2

Sample response on the MAP display:

RCC2	2	Sy	sB	ManB	Offl	CBsy	ISTb	InSv
	Ε	M	3	0	1	0	4	12
	F	RCC2	1	0	2	0	2	9

4 To check for fault indicators, type

#### >QUERYPM FLT

and press the Enter key.

Sample response on the MAP display:

/	/									
(	CI	4 MS	IOD	Net	PM	CCS	Lns	Trks	Ext	APPL
					1RCC2					
					М					
	RCO	22	2	SysB	ManB	OffI		CBsy	ISTb	InSv
	0	Quit	PM	1	0	1	_	0	0	12
	2	Post_	RCC2	1	0	2	2	0	0	9
	3	ListSet								
	4		RCC2 2	ISTb	Links	oos: cs	Side	0, PSide	0	
			Unit0:							
			Unit1:							
		_	QUERYPM		-					
			~ · Un:		fault e	xists				
		_	Un:							
		LoadPM								
	11	Disp_								
		Next								
	13									
	14	QueryPM								
	15	~ 1								
	16									
	17									
	18									
/										)

If the system	Do
indicates a card that has faults	step 24
does not indicate a card that has faults	step 5
To manually busy the SysB inactive R	CC2 unit, type
>BSY INACTIVE	
and press the Enter key.	
To test the ManB RCC2, type	
>TST UNIT unit_no	
and press the Enter key.	
where	
unit_no is the number of the ManB RC0	C2 unit (0 or 1)
Sample response on the MAP display	:

5

6

7

### PM RCC2 major (continued)

Test Passed or Test Failed If TST Do passes step 23 fails and the system generates a card list step 24 fails and the system does not generate a card list step 7 To identify C-side links to the host PM that is in a SysB condition, type >TRNSL C and press the Enter key. A host PM can be any of the following: a line group controller (LGC) a line group controller with ISDN (LGCI) a line trunk controller (LTC) a line trunk controller with ISDN (LTCI) In the following example, the host PM is an LTCI. Sample response on the MAP display: LINK 0: LTC(I) 1 0; CAP MS; STATUS: OK, ; MSGCOND: OPN, Restricted LINK 1: LTC(I) 1 1;CAP S;STATUS: OK LINK 2: LTC(I) 1 2; CAP MS; STATUS: SysB,; MSGCOND: CLS, Unrestricted LINK 4: LTC(I) 1 4; CAP S; STATUS: ISTb LINK 5: LTC(I) 1 4; CAP S; STATUS: OK LINK 6: LTC(I) 1 4; CAP S; STATUS: OK LINK 7: LTC(I) 1 4;CAP S;STATUS: OK If link Do is not busy step 28 is a message link or a speech link step 8 To post the host PM, type >POST host\_pm host\_pm\_no and press the Enter key. where host\_pm is either an LGCI or an LTCI

8

### host\_pm\_no is the number of the LGCI or LTCI

Sample response on the MAP display:

	(								
1	CI	M MS	IOI	D Ne	t PM	CCS	Lns	Trks	Ext
					1RCC2				
					М				
	LTC	C(I)		SysB	ManB	OffL	CBsy	ISTb	InSv
	0	Quit	PM	1	0	1	0	1	12
	2	Post_	LTC(I)	0	0	2	0	1	9
	3	ListSet							
	4		LTC(I)	1 ISTb	Links_00S	: CSide	0, PSide	1	
	5	Trnsl_	Unit0:	Act I	nSv				
	б	Tst_	Unit1:	Inact	InSv				
		Bsy_							
		RTS_							
		OffL							
		LoadPM_							
		Disp_							
		Next							
		SwAct							
		QueryPM							
	15								
	16								
		Perform							
1	18								)
	~								

9

To identify the P-side links that have faults, type

#### >TRNSL P

and press the Enter key.

Sample response on the MAP display:

LINK 0: RCC2 1 0;CAP MS;STATUS:OK,;MSGCOND:OPN,Restricted LINK 1: RCC2 1 1;CAP S;STATUS:OK LINK 2: RCC2 1 2;CAP MS;STATUS:SysB,;MSGCOND:CLS,Unrestricted LINK 4: RCC2 1 4;CAP S;STATUS:SysB LINK 5: RCC2 1 4;CAP S;STATUS:OK LINK 6: RCC2 1 4;CAP S;STATUS:OK LINK 7: RCC2 1 4;CAP S;STATUS:OK

**10** To busy the link that has faults, type

>BSY LINK link\_no

and press the Enter key.

```
where
```

#### link\_no

is the number of the P-side link selected in step 9

### PM RCC2

major (continued)

11	To test the link that has faults, type
----	--

>TST LINK link\_no

and press the Enter key.

where

link\_no

is the number of the link manually busied in step 10

If TST	Do
passes and alarm continues	step 28
passes and alarm clears	step 16
fails	step 12

12 To display links with possible faults, type

#### >TRKS;CARRIER;POST MANB

and press the Enter key.

Sample response on the MAP display:

CLA	SS ML	OS	ALARM	S	YSB	MAN	1B	UNE	Q OI	FFL	CBSY	PBSY	IN	ISV
TRU	NKS 0	0	0		0		0		0	0	0	0		0
REM	IOTE 0	0	0		5		1		0	0	0	0		10
NO	CLASS	5	SITE	RCC	CKT	D	ALAF	RM	SLIP		FRAME	BER	SES	STATE
0	TRUNKS	S E	BRSCS	0	0	С			0		0	1995262	2 0	INSV
1	REMOTE	E E	BRSCS	0	1	С			0		0	1995262	2 0	INSV
2	REMOTE	E E	BRSCS	0	2	С			0		0	1995262	2 0	MANB

MORE ....

 $\it Note:$  The <code>MORE</code> at the bottom of the display indicates that you can check more links. To check these links, type

#### >NEXT

and press the Enter key.

13 To test the ManB link, type

>TST link\_no

and press the Enter key.

where

#### link\_no

14

15

16

is the number of the ManB link listed under the NO column that appears in the MAP display in step 12. The number for the ManB link in the example is 2.

If TST	Do
passes and alarms clears	step 15
fails	step 14
fails and this is not first repair attempt	step 28
Perform the repair or corrective proce indicates in step 12.	edure on the link that the MAP display
	essage links with possible faults. These fore you can return the links to service
To post the host PM, type	
>PM;POST host_pm host_pm_:	no
and press the Enter key.	
where	
host_pm is the host PM (LGCI or LTCI)	posted in step 8
host_pm_no is the number of the host PM (	(LGCI or LTCI)
To return the link to service, type	
>RTS LINK link_no	
and press the Enter key.	
where	
link_no is the number of the link identi	fied in step 9
If RTS	Do
passes	step 17
fails	step 28

17 To post the RCC2, type

>POST RCC2 rcc2\_no

and press the Enter key.

where

rcc2\_no is the number of the RCC2 identified in step 2

# PM RCC2

major (continued)

8	<b>Note:</b> This RCC2 must To return the <i>inactive</i> unit t >RTS UNIT unit_no	•					
8		to service, type					
	>RTS UNIT unit_no						
	>RTS UNIT unit_no						
	and press the Enter key.						
	where						
	unit_no is the number of the	e RCC2 posted in step 17					
	If RTS	Do					
	passes	step 19					
	fails	step 28					
9	Switch activity (SwAct) of t is <i>inactive</i> ,. To switch activ	he RCC2 units to make sure that unit being tested ity, type					
	>SWACT						
	and press the Enter key.						
	Sample response on the N	/AP display:					
	RCC2 1 A Warm S Please confirm ("YES	SwAct will be performed S" "Y" or "NO" "N")					
20	To confirm the SwAct initia	ates in step 19, type					
	>YES						
	and press the Enter key.						
	After both units are in-serv where to proceed.	vice, use the following information to determine					
	If SWACT	Do					
	passes	step 21					
	fails	step 28					
21	To busy the inactive RCC2	2 unit, type					
	>BSY INACTIVE						
	and press the Enter key.						
22	To perform an out-of-servi	ce (OOS) test on the inactive RCC2 unit, type					
	>TST UNIT unit_no						
	and press the Enter key.						
	and pross the Liner Key.						

#### unit no

is the number of the inactive RCC2 unit (0 or 1)

If TST	Do
passes	step 23
fails	step 24

23 To return the inactive RCC2 unit to service, type

>RTS UNIT unit\_no

and press the Enter key.

where

unit\_no is the number of the inactive RCC2 unit (0 or 1)

If RTS	Do
passes	step 29
fails	step 28

24 Check the card list that appears in the following MAP display.

The following MAP display has two examples of provisioning. The first card list displays RCC2s provisioned with the NTMX77AA unified processor (UP), with MX77 in slot 03. The second card list displays RCC2s provisioned with the optional NTAX74AA cellular access processor (CAP), with AX74 in slot 03.

#### NTMX77

Example of a MAP response for an RCC2 configured with the NTMX77 Unified Processor:

RSC0	01 01 01 01 01	A00 A00 A00 A00	CRSC CRSC CRSC CRSC	BAY_ID 00 00 00 00 00	SHF 05 05 05 05 05	RCC2 : 0 RCC2 : 0 RCC2 : 0	ON SLOT 00 :03 00 :08 00 :11 00 :13 00 :05	MX77 6x69 MX73 MX74
RSC0	01	A00	CRSC	00	05	RCC2 : 0	00 :05	6X78

#### NTAX74

Example of a MAP response for RCC2s configured with the optional NTAX74AA Cellular Access Processor:

### PM RCC2 major (end)

SITE		FLR		RPOS	BAY_ID	SHF	DESCRIF	TION	SLOT	EQPEC
RSC0	01		A00	CRSC	00	05	RCC2 :	000	:03	AX74
RSC0	01		A00	CRSC	00	05	RCC2 :	000	:08	6X69
RSC0	01		A00	CRSC	00	05	RCC2 :	000	:11	MX73
RSC0	01		A00	CRSC	00	05	RCC2 :	000	:15	MX74
RSC0	01		A00	CRSC	00	05	RCC2 :	000	:05	6X78

lf you	
--------	--

Do

replaced all cards on the list step 25

did not replace all cards on the step 27 list

25 Determine if you replaced the NTMX81 circuit card.

lf you	Do
replaced the NTMX81 card	step 28
did not replace the NTMX81 card	step 26

- **26** Go to the card replacement procedure for the NTMX81 circuit card in *Card Replacement Procedures.* Complete the card replacement procedures. Go to step 13 of this procedure.
- **27** Go to the card replacement procedure in *Card Replacement Procedures* for the next card on the card list. Complete the card replacement procedures. Go to step 22 of this procedure.
- **28** For additional help contact the next level of support.
- **29** The procedure is complete. If other alarms occur, refer to the appropriate alarm clearing procedures for the indicated alarms.

### PM RCC2 minor

### Alarm display

IS IOD	Net		CCS	Lns	Trks	Ext	APPL
	·	1RCC2	•	•	•	•	

### Indication

At the MTC level of the MAP display, a 1RCC2 under the PM subsystem header indicates an RCC2 minor alarm.

#### Meaning

The indicated number of RCC2 units are in the in-service trouble (ISTb) state.

#### Impact

This condition does not affect subscriber service.

### **Common procedures**

There are no common procedures.


### Action

This procedure contains a summary flowchart and a list of steps. Use the flowchart to review the procedure. Follow the steps to perform the procedure.

# PM RCC2

minor (continued)

#### Summary of clearing a PM RCC2 minor alarm



#### **Clearing a PM RCC2 minor alarm**

#### At the MAP display

1

#### ATTENTION

Enter this procedure from a PM system-level alarm clearing procedure step that identified an RCC2-associated fault.

To silence the alarm, if required, type

#### >MAPCI;MTC;PM;SIL

and press the Enter key.

2 To identify the defective RCC2, type

>DISP STATE ISTB RCC2

and press the Enter key.

*Typical response on the MAP display:* ISTb RCC2 : 2

3 To post the ISTb RCC2, type

>POST RCC2 rcc2\_no

and press the Enter key.

where

rcc2\_no

is the number of the RCC2 in step 2

Typical response on the MAP display:

RCC2		SysB	ManB	Offl	CBsy	ISTb	InSv
	PM	0	0	1	0	4	12
	RCC2	0	0	2	0	2	9

4 To check for fault indicators, type

>QUERYPM FLT

and press the Enter key.

*Typical response on the MAP display:* 

CM ∙							Trks		
0 2	Quit	PM RCC2	SysB O O			L 1 2	CBsy 0 0	ISTb 1 1	InSv 12 9
5 6 7 9 10 11 12 13	TRNSL_ Tst_ Bsy_ RTS_	Unit0: Unit1: QUERYPP U: U:	Act I Inact	nSv ISTb fault e	exists		1, PSide	0	
15 16 17 18									)

	_
If the system	Do
indicates a defective card	step 26
does not indicate a defective card	step 5
To manually busy (ManB) the ISTb RC	CC2 unit, type
>BSY UNIT unit_no	
and press the Enter key.	
where	
unit_no is the number of the ISTb RCC	2 in step 4
To test the ManB RCC2, type	
>TST UNIT unit_no	
and press the Enter key.	
where	
unit_no is the number of the RCC2 unit	manually busied in step 5
Typical response on the MAP display:	

5

6

	If TST				Do			
pas	passes				25			
fails, and the system generates a card list					step 26			
	s, and the herate a can	-	em does n	ot step	step 7			
To id	entify C-sid	le links	to the host l	PM that a	are in a SysB condition, type			
>TRN	ISL C							
and p	press the E	nter ke	V.					
	st PM may		,					
	a line group		. ,					
• a	line group	contro	ller with ISD	N (LGCI	)			
• a	a line trunk (	control	er (LTC)					
• a	line trunk	control	er with ISD	N (LTCI)				
In the	e following (	exampl	e, the host F	PM is an	ITCI			
	•	-	e MAP displ					
- )								
INK 0:	LTC(I)		0;CAP MS;ST	ATUS:	OK,;MSGCOND: OPN,Restricted			
JINK 1: JINK 2:	LTC(I)			ATUS:	OK			
IINK Z.	LTC(I) LTC(I)		2;CAP MS;ST 4;CAP S;ST	ATUS:	OK,;MSGCOND:OPN,Unrestricte SysB			
INK 4:	LTC(I)			'ATUS:	OK			
		1	4.035 0.05		OK			
INK 5:	LTC(I)	-	4;CAP S;ST	ATUS:	010			
INK 4: INK 5: INK 6: INK 7:	LTC(I) LTC(I)			ATUS: ATUS:	OK			
INK 5: INK 6: INK 7:		1	4;CAP S;ST					
INK 5: INK 6: INK 7: To po	LTC(I)	⊥ PM, ty	4;CAP S;ST					
INK 5: INK 6: INK 7: To po >POS	LTC(I)	1 PM, ty om hos	4;CAP S;ST pe t_pm_no					
INK 5: INK 6: INK 7: To po >POS	LTC(I) ost the host ST host_p press the E	1 PM, ty om hos	4;CAP S;ST pe t_pm_no					

7

8

CM         MS         IOD         Net         PM         CCS         Lns         Trks         Ext         APP           .	
1RCC2	
	nSv
0 Quit PM 0 0 1 0 4	12
2 Post_ LTC(I) 0 0 2 0 2	9
3 ListSet	
4 LTC(I) 1 ISTb Links_OOS: CSide 0, PSide 1	
5 Trnsl_ Unit0: Act InSv	
6 Tst_ Unit1: Inact InSv	
7 Bsy_	
8 RTS_	
9 OffL	
10 LoadPM_	
11 Disp_	
12 Next	
13 SwAct	
14 QueryPM	
15	
16	
17 Perform	
	/

9 To identify the peripheral-side (P-side) links that have defects, type

#### >TRNSL P

and press the Enter key.

Typical response on the MAP display:

LINK 0:	RCC2	1	0;CAP	MS;STATUS:	OK,;MSGCOND: OPN,Restricted
LINK 1:	RCC2	1	1;CAP	S;STATUS:	OK
LINK 2:	RCC2	1	2;CAP	MS;STATUS:	OK,;MSGCOND:OPN,Unrestricted
LINK 4:	RCC2	1	4;CAP	S;STATUS:	ISTb
LINK 5:	RCC2	1	4;CAP	S;STATUS:	OK
LINK 6:	RCC2	1	4;CAP	S;STATUS:	OK
LINK 7:	RCC2	1	4;CAP	S;STATUS:	OK

**10** To busy the link that has defects, type

```
>BSY LINK link_no
```

and press the Enter key.

where

link\_no

is the number of the P-side link in step 9

**11** To test the defective link, type

>TST LINK link\_no

and press the Enter key.

#### where

#### link\_no

is the number of the link manually busied (ManB) in step 10

If TST	Do
passes and alarm persists	step 30
passes and alarm clears	step 17
fails	step 12

#### 12 To display any links that can have defects, type

>TRKS;CARRIER;POST;MANB

and press the Enter key.

Typical response on the MAP display:

CLA	SS ML	OS	ALAR	M	SYSB	М	ANB	UNEQ	OFFL	CBSY	PBSY	INSV
TRU	NKS 0	0	0		0		0	0	0	0	0	0
REM	IOTE 0	0	0		5		0	0	0	0	0	10
NO	CLASS	SIT	Έ	RCC	CKT	D	ALARM	SLIP	FRAME	BER	SES	STATE
0	TRUNKS	BRS	CS	0	0	С		0	0	1995262	2 0	INSV
1	REMOTI	BRS	CS	0	1	С		0	0	1995262	2 0	INSV
2	REMOTI	BRS	CS	0	2	С		0	0	1995262	2 0	MANB
										MORE		

*Note:* The <code>MORE</code> . . . at the bottom of the display indicates that you can observe more links. To observe more links, type

#### >NEXT

and press the Enter key.

13 To test the ManB link, type

>TST link\_no

and press the Enter key.

where

#### link\_no

is the number of the ManB link. This link number is listed under the NO column as in the MAP display in step 12. The number for the ManB link in the example is 2.

If TST	Do
passes and alarm clears	step 16
fails	step 30

## PM RCC2

minor (continued)

(indea)											
14	Carry out the repair/correct 12.	tive procedure the MAP display indicates in step									
	<i>Note:</i> If the system indic must be in a ManB state (RTS).	cates message links that have defects, these links before these links can be returned to service									
15	To post the host PM, type										
	>PM;POST host_pm hos	t_pm_no									
	and press the Enter key.										
	where										
	<b>host_pm</b> is the host PM (LGC	CI or LTCI) in step 8									
	host_pm_no is the number of the	host PM (LGCI or LTCI)									
16	Use the information in step 7 to determine which RCC2 unit associates with the SysB link. The unit identified must be <i>inactive</i> to continue.										
	If RCC2 unit	Do									
	is inactive	step 27									
	is active	step 17									
17	To RTS the link, type										
	>RTS LINK link_no										
	and press the Enter key.										
	where										
	link_no is the number of the	link in step 9									
18	To post the RCC2, type										
	>POST rcc2_no										
	and press the Enter key.										
	where										
	rcc2_no is the number of the	RCC2 in step 2									
	Note: This RCC2 must	be SysB.									
19	To RTS the <i>inactive</i> unit, ty	ре									
	>RTS UNIT unit_no										
	and press the Enter key.										
	where										
	unit_no is the number of the	RCC2 in step 18									

20 To post the host PM, type >POST host\_pm host\_pm\_no and press the Enter key. where host\_pm is an LGCI or an LTCI host\_pm\_no is the number of the LGCI or LTCI 21 To switch activity (SwAct) of the RCC2 units to verify that the unit you want to test is *inactive*, type >SWACT and press the Enter key. Typical response on the MAP display: RCC2 1 A Warm SwAct will be performed Please confirm ("YES" or "NO") 22 To confirm the SwAct initiated in step 21, type >YES and press the Enter key. After both units are in-service, proceed to the next step. If SWACT Do passes step 23 fails step 30 23 To busy the *inactive* RCC2 unit, type >BSY UNIT unit\_no and press the Enter key. where unit no is the number of the *inactive* RCC2 unit (from step 19) 24 To perform an out-of-service (OOS) test on the inactive RCC2 unit, type >TST UNIT unit\_no and press the Enter key. where

	i <b>t_no</b> s the numb	per of the RCC	2 uni	ts busied	in step 23						
If TST	-		Do								
passe	S			step 25							
fails				step 26	5						
To RTS	the inactiv	/e RCC2 unit, t									
>RTS 1	RTS UNIT unit_no										
and pre	ess the Ent	er key.									
where											
	i <b>t_no</b> s the numb	per of the RCC	2 uni	t tested ir	step 24						
If RTS	6			Do							
passe	S			step 31							
fails				step 30	)						
Observ	e the card	listing in the fo	llowir	wing MAP display.							
Typical	response	on the MAP dis	play.								
SITE	FLR	RPOS BAY_II		SHF	DESCRIPTION	SLOT E					
RSCS0 RSCS0	01 01	A00 RCE A00 RCE	00 00	32 32	RCC2 : 000 RCC2 : 000	: 09 : 08	MX8 6X6				
If all o	ards			Do							
are re	placed			step 27	,						
are no	ot replace	b		step 29	)						
Determ	ine if the N	ITMX81 circuit	card	was repla	aced.						
If the	NTMX81 c	ard		Do							
is rep	laced			step 30	)						
is not	replaced			step 28	5						
Perform	the card r	enlacement pr	red	ire for the	NTMX81 circu	it card in	<u>C</u> 2				

**28** Perform the card replacement procedure for the NTMX81 circuit card in *Card Replacement Procedures*. Finish the card replacement procedures and go to step 24.

### PM RCC2 minor (end)

- **29** Perform the card replacement procedure in *Card Replacement Procedures* for the next card on the card list. Finish with the card replacement procedures and go to step 24.
- **30** For additional help, contact the next level of support.
- **31** This procedure is complete. If the system displays other alarms, perform the appropriate alarm clearing procedures.

#### PM RMM major

### Alarm display

Call MS OD Not PM CCS The Ed LN7	СМ	MS	IOD	Net	РМ	Lns	Trks	Ext	APPL
	·	•	•	•	1SysB M	•			

### Indication

At the MTC level of the MAP, the alarm code 1SysB under the PM subsystem header indicates an alarm associated with a remote maintenance module (RMM). The letter M under the alarm code indicates that the alarm class is major.

### Meaning

The indicated number of RMM units are in the system busy (SysB) state.

#### Result

If the RMM unit fails, the system discontinues maintenance and line testing. The condition does not affect subscriber service.

#### **Common procedures**


There are no common procedures.

### Action

This procedure contains a summary flowchart and a list of steps. Use the flowchart to review the procedure. Follow the steps to perform the procedure.

### PM RMM major (continued)

#### Summary of clearing a PM RMM major alarm



# PM RMM

major (continued)

#### Clearing a PM RMM major alarm

#### ATTENTION

Enter this procedure from a PM system-level alarm clearing procedure step that identified an RMM-associated fault.

#### At the MAP terminal

1 To silence the alarm, type

#### >MAPCI;MTC;PM;SIL

and press the Enter key.

2 To identify the RMM that has faults, type

>disp STATE Sysb RMM

and press the Enter key.

*Example of a MAP response:* SysB RMM 2

- **3** To post the SysB RMM from step 2, type
  - >POST RMM rmm\_no

and press the Enter key.

where

#### rmm\_no

is the number of the RMM that has faults Example of a MAP display:

	CM	MS		Net			Lns	Trks	Ext	APPL
R	MM		SysB	Mar	ıB	OffL	CBsy	ISTb		InSv
	0 Quit	PM	3		0	1	1	4		12
	2 Post_ 3	RMM	1		0	2	1	2		9
	4	RMM	2	Sys	зB					
	5 Trnsl	_								
1	6 Tst_									
	7 Bsy_									
1	8 RTS_									
1	9 OffL 0 LoadPI									
1	1 Disp_	_								
1	2 Next_									
1	3									
	4 Queryl	PM								
1	5 5									
1	6									
1	7									
$\setminus 1$	8									

To check for fault indicators or cards that have faults, type

>querypm flt and press the Enter key. Example of a MAP display:

4

DMS-100 Family Switching Center-SONET Model B Maintenance Manual

## PM RMM

major (continued)

	CM	MS	TOD	Net	РM	CCS	Lns	Trks	Ext	
	•	•	•	•	TOYSD	•	•	•	•	•
RM	М		SysB	Ма	nB	OffL	CBsy	ISTb	InS	v
0	Quit	PM	3		0	1	1	4	1	2
2	Post_	RMM	1		0	2	1	2		9
3										
4		RMM	2 SysB							
5	Trnsl_									
6	Tst_									
7	Bsy_	QUEI	RYPM FL	Т						
8	RTS_									
9	OffL									
10	LoadPM	_								
11	Disp_									
12	Next_									
13										
14	QueryP	М								
15										
16										
17										
18										
$\overline{\ }$										

If the system	Do
indicates a card that has faults	step 16
does not indicate a card that has faults	step 5
To manually busy the RMM in step 3, t	type
>BSY	
and press the Enter key.	
To perform an in-service test on the R	MM that has faults, type
>tst	
and press the Enter key.	
Example of a MAP response:	
Test Passed	
or	
Test Failed	
If TST	Do
passes	step 15

5

6

8 -	> <b>trns1</b> and press <i>Example</i> LINK 22: LINK 23:	d the sy c C-side c the Ent	vstem g links to er key. P respor	enerates the RCC	s a ste	ep 7 ep 16 usy c	condition,	type	
8 -	card list To identify >trns1 and press Example LINK 22: LINK 23:	C-side C the Ent of a MA	links to er key. P respor	the RCC				type	
8 -	> <b>trns1</b> and press <i>Example</i> LINK 22: LINK 23:	C the Ent of a MA	er key. P respor	nse:	2 in a b	usy c	ondition,	type	
8 -	and press Example LINK 22: LINK 23:	the Ent of a MA	P respoi						
B -	Example	of a MA	P respoi						
8 -	LINK 22: LINK 23:	RCC2 2	-						
B <sup>-</sup>	LINK 23:		0;C1						
	To nost th		1;C	AP S;STA AP S;STA		OK, SYS	; MSGCOND : B	OPN, I	Restricted
	io post in	e RCC2	unit as	sociated	with the	RMI	M, type		
	>post R	<i>Cc2</i> rc	c2_no						
ä	and press	the Ent	er key.						
	where								
	rcc2_								
	is t	he numl	ber of th	e RCC2	unit fror	n ste	p 7		
1	Example	of a MA	P displa	<i>y:</i>					
	CM MS	IOD	Net	PM 1SysB	ccs	Lns	Trks	Ext	APPL
-	C2	DM	SysB	ManB	OffL		CBsy	ISTb	InSv
2	Quit Post_ ListSet	PM RCC2	3 0	0 0	1 2		1 1	4 2	12 9
4 5 6 7	TRNSL_		2 ISTb Act I Inact	STb	OS: CS	ide	0, PSide	1	

11 Disp\_ 12 Next 13 SwAct 14 QueryPM

### **PM RMM**

major (continued)

9	To identify the P-side links that have f >TRNSL P and press the Enter key. Example of a MAP response:	aults, type								
	LINK 22: RMM 2 0;CAP MS;STATU LINK 23: RMM 2 1;CAP S;STATU									
10	To choose and busy a link that has fa <pre>&gt;bsy link link_no</pre> and press the Enter key. <pre>where</pre> link_no is the number of the link (22 or)									
11	To test the ManB link, type <pre>&gt;TST link link_no and press the Enter key.</pre>									
	where									
	<pre>link_no     is the number of the link (22 or 23) manually busied in step 10</pre>									
	If TST	Do								
	passes	step 12								
	fails	step 20								
12	To return the link to service, type									
	>RTS link link_no									
	and press the Enter key.									
	where									
	link_no is the number of the link (22 or	23) tested in step 11								
	<i>Note:</i> The system can identify oth 11 through 13 for each link until all returned to service.	er links that have faults. Perform steps the links are busied, tested, and								
	If RTS	Do								
	passes	step 13								

а			MM r	mm_no	c						
		nress									
И	he	pica	s the I	Enter k	key.						
	me	re									
	I	rmm		umbor	of the		ousied in step 5				
Т	o te			M unit			usieu in step 5				
	ts		-		, ,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,						
а	nd	pres	s the I	Enter k	key.						
_	lf T	ST					Do				
_	pas	sses					step 15				
fails						step 16					
To return the ManB RMM to service, type											
>	RT	5									
а	nd	pres	s the I	Enter k	key.						
If RTS							Do				
	pas	sses									
	fai	ls									
C	he	ck the	e carc	l listing	g on th	ne MAP.					
E	xai	nple	of a N	MAP di	isplay.	:					
RS	TE CO	FLR 01 01	A00	BAY_I RCE RCE	D 00 00	SHF 32 32	DESCRIPTION RMM:000 RMM:000	SLOT : 00 : 04	EQPEC 6X23 6X51		
	C0	01		RCE	00	32	RMM:000	: 04	6X51		
RS	C0	01	A00	RCE	00	32	RMM:000	: 16	6X23		
	lf y	ou					Do				
	rep	lace	d all	the ca	rds o	n the li	st step 17				

### PM RMM major (end)

**17** Determine if the NTMX74 circuit card was replaced.

*Note:* If the display indicates the NTMX74 card, check if one link or several links have faults. Repeat the alarm clearing procedure.

lf you		Do
replaced the NTM	X74 card	step 20
did not replace t card	the NTMX74	step 18
		re for the NTMX74 circuit card in <i>Card</i> the card replacement procedures. Go
	ne card list. Finis	ure in <i>Card Replacement Procedures</i> th with the card replacement
For additional help, co	ontact the next le	vel of support.

21 The procedure is complete. If other alarms appear at the MAP, perform the appropriate alarm clearing procedures.

### PM RMM minor

### Alarm display

ĺ	CM MS OD Not PM CCB The Bat LIU7	СМ	MS	IOD	Net	РМ	Lns	Trks	Ext	APPL
		•	•	•	•	1CBsy	•	•	•	

#### Indication

At the peripheral module (PM) level of the MAP display, the 1CBsy under the PM subsystem header indicates a minor alarm associated with a remote maintenance module (RMM).

#### Meaning

The indicated number of units are in the C-side busy (CBsy) state.

#### Impact

This CBsy state does not affect subscriber service. Local RMM backup is not available if the unit (or both units if the RCE contains two RMMs) fails.

#### **Common procedures**

There are no common procedures.


#### Action

The procedure contains a summary flowchart and a list of steps. Use the flowchart to review the procedure. Follow the steps to perform the procedure.

### PM RMM

minor (continued)

#### Summary of clearing PM RMM minor alarms



#### **Clearing PM RMM minor alarms**

#### At the MAP display

1

#### ATTENTION

Enter this procedure from a PM system level alarm clearing procedure step that identifies an RMM-associated fault.

To silence the alarm, type

#### >MAPCI;MTC;PM;SIL

and press the Enter key.

2 To identify the RMM that has defects, type

>DISP STATE CBSY RMM

and press the Enter key.

*Example of a MAP response:* CBsy RMM: 1

**3** To post the CBsy RMM identified in step 2, type

>POST RMM rmm\_no

and press the Enter key.

where

rmm\_no

is the number of the RMM that has defects

Example of a MAP display:

(		СМ	MG	TOD	Not	DM	000	T in a	Trks	<b>D</b> +	APPL
1											APPL .
	RMM	1		SysB	Ma	nB	OffL	CBsy	ISTb	Ir	ıSv
	0	Quit	PM	3		0	0	1	4		12
	2	Post_	RMM	0		0	0	1	2		9
	3										
	4		RMM	1	CB	sy					
	5	Trnsl_									
	б	Tst_									
	7	Bsy_									
	8	RTS_									
	9	OffL									
	10	LoadPM	[								
	11	Disp_									
	12	Next_									
	13										
	14	QueryP	M								
	15										
	16										
	17										
	18										
											/

4 To check for fault indicators or cards that have defects, type

>QUERYPM FLT and press the Enter key. Example of a MAP display:

_										
(	СМ	MS	TOD	Net	DM	CCS	Lns	Trks	Fvt	APPL
	CIN	•						TTICS	DAC	ALLD
	•	•	•	•	10007	•	•	•	•	•
RMM	1		SysB	Ma	nB	OffL	CBsy	ISTb		InSv
0	Quit	PM	3		0	0	0	4		12
2	Post_	RMM	0		0	0	0	2		9
3										
4		RMM	1	CBs	У					
5	Trnsl_									
	Tst_									
		QUEI	RYPM FL	т						
	RTS_									
	OffL									
	LoadPM	_								
	Disp_									
	Next_									
13										
14 15	QueryP	М								
$15 \\ 16$										
17										
18										
10										
_										
	If the	syste	m			D	0			
_	in dia a	tac o	card th	ot ho	1. 6.					

does not indicate a card that has step 5 defects

5 To busy the RMM posted in step 3, type
>BSY

and press the Enter key.

6 To perform an in-service test on the RMM that has defects, type >TST

and press the Enter key.

Example of a MAP response:

Test	Passed
(	or
Test	Failed

If TST	Do
passes	step 15

DMS-100 Family Switching Center-SONET Model B Maintenance Manual

7

8

### PM RMM

minor (continued)

ITI	ST				Do			
fai	ls beca	use of	the C	C-side links	step	7		
	ls and t d list	he sys	tem g	generates a	a step	16		
To ic	lentify C	-side l	inks to	o the RCC2	in a bus	sy conditio	n, type	
>TR	NSL C							
		o Ente	r kov					
	press th							
Exa	mple of	a MAF	resp	onse:				
LINK LINK		C2 2 0 C2 2 1		S;STATUS: S;STATUS:	OK,;MS CBSY	GCOND: OP	N,Restricte	ed
To p	ost the	RCC2	unit a	ssociated w	ith the F	RMM. type		
	ST RCC					, ., ., .		
			_					
	press th	ie Ente	er key.					
whe	re							
I	rcc2_nc							
	is the	RCC2	2 unit i	in step 7				
Exa	mple of	a MAF	odispl	ay:				
CM ·	MS ·	IOD	Ne	t PM 1CBsy	CCS ·	LNS Trl	ks Ext · ·	APPL
		~	Ð	Marin	0557	CD	T CITI-	T C
Daao		S	ysB	ManB 0	OffL O	CBsy O	ISTb 4	InSv
	+ DM		()					10
RCC2 0 Qui 2 Pos			0 0	0	0	0	2	12 9
	t_ RC							

1000	22		DYDD	Hand	OIID	CDDy	TOTO	THOV
0	Quit	PM	0	0	0	0	4	12
2	Post_	RCC2	0	0	0	0	2	9
3	ListSet							
4		RCC2	2 ISTb	Links_009	S: CSide	0, PSide	1	
5	TRNSL_	Unit0:	Act I	STb				
б	TST_	Unit1:	Inact	InSv				
7	BSY_							
8	RTS_							
9	OffL							
10	LoadPM_							
11	Disp_							
12	Next							
13	SwAct							
14	QueryPM							
15								
16								
17								
18								

9	To identify the peripheral-side (P-side) links that have defects, type <b>&gt;TRNSL P</b> and press the Enter key. <i>Example of a MAP response:</i>										
	LINK 22: RMM 1 0;CAP MS;STATU LINK 23: RMM 1 1;CAP S;STATU										
10	To choose and busy link, type										
	>BSY LINK link_no										
	and press the Enter key.										
	where										
	link_no is the number of the link identi	fied in step 9 (22 or 23)									
11	To test the ManB link, type										
	>TST LINK link_no	_									
	and press the Enter key.										
	where										
	link no	<b>hk_no</b> is the number of the link (22 or 23) manually busied in step 10									
		23) manually busied in step 10									
		r 23) manually busied in step 10 Do									
	is the number of the link (22 or										
	is the number of the link (22 or If TST	Do									
12	is the number of the link (22 or If TST passes	Do step 12									
12	is the number of the link (22 or If TST passes fails	Do step 12									
12	is the number of the link (22 of If TST passes fails To RTS the ManB link, type	Do step 12									
12	is the number of the link (22 or If TST passes fails To RTS the ManB link, type >RTS LINK link_no	Do step 12									
12	is the number of the link (22 or If TST passes fails To RTS the ManB link, type >RTS LINK link_no and press the Enter key.	Do step 12 step 16									
12	is the number of the link (22 or If TST passes fails To RTS the ManB link, type >RTS LINK link_no and press the Enter key. where link_no	Do step 12 step 16									
12	is the number of the link (22 or If TST passes fails To RTS the ManB link, type >RTS LINK link_no and press the Enter key. where link_no is the number of the link (22 or	Do step 12 step 16									
12	is the number of the link (22 or If TST passes fails To RTS the ManB link, type >RTS LINK link_no and press the Enter key. where link_no is the number of the link (22 or If RTS	Do step 12 step 16									

*Note:* If the system identifies other links that have defects, perform the procedures in steps 10 through 12 for each link. Perform these procedures until the system busies, tests, and RTS all links.

### **PM RMM**

minor (continued)

6	To post	the Ma	anB RM	1M, type	•							
	>POST	RMM	rmm_r	10								
	and pre	ess the	Enter k	key.								
	where			-								
	rm	m_no										
	is the number of the RMM busied in step 5 To test the RMM unit, type											
ļ	To test	the RM	IM unit,	, type								
	>TST											
	and pre	ess the	Enter k	key.								
	If TST	-				D	0					
	passe	S				st	tep 15					
	fails					st	tep 16					
	To RTS the ManB RMM, type											
	>RTS											
	and pre	ess the	Enter k	key.								
	If RTS	5				D	0					
	passe	S				st	tep 21					
	fails					st	tep 20					
	Check the card listing in the following MAP display.											
	Examp	le of a	MAP re	esponse	:							
	SITE	FLR	RPOS	BAY_II		SHF	DESCRIPTION	SLOT	EQPE			
	RSCS0 RSCS0	01 01	A00 A00	RCE RCE	00 00	19 19	RMM:000 RMM:000	: 03 : 04	2X1 2X1			
	RSCS0	01	A00	RCE	00	19	RMM:000	: 05	0X1			
	RSCS0	01	A00	RCE	00	19	RMM:000	: 06	3X0			
	If all o	ards o	on the l	ist		D	0					
	are re	placed	l			st	tep 17					
	are no	ot repla	aced		step 19							
	Determ	ine if th	ne NTM	1X74 cir	cuit ca	ard wa	s replaced.					
	If the	NTMX	74 card	ł		D	0					
	is rep	laced				st	tep 20					

### PM RMM minor (end)

	If the NTMX74 card	Do							
	is not replaced	step 18							
	<b>Note:</b> If the system indicates the NTMX74 card, check to see if one link several links have defects Repeat the alarm clearing procedure as required.								
18		procedure for the NTMX74 circuit card in <i>Card</i> omplete the card replacement procedures and							
19	Perform the card replacement for the next card on the card list and go to step 14.	procedure in <i>Card Replacement Procedures</i> st. Complete the card replacement procedures							
20	For additional help, contact th	e next level of support.							
21	This procedure is complete. It appropriate alarm clearing pro	the system displays other alarms, perform the cedures.							

## 6 RSC-S card replacement procedures

This document contains the card replacement procedures for the DMS-100 Remote Switching Center-SONET (RSC-S). These procedures are used by maintenance personnel to remove and replace circuit cards.

### NT0X10 in an RSC-S (DS-1) Model B RMM

### Application

Use this procedure to replace an NT0X10 card in an RSC-S RMM.

PEC	Suffixes	Name
NT0X10	AA	Miscellaneous Scan Card (MSC)


#### **Common procedures**

None

### Action

The following flowchart is only a summary of the procedure. To replace the card, use the instructions in the procedure that follows the flowchart.

#### Summary of card replacement procedure for an NT0X10 card in RSC-S RMM



#### Replacing an NT0X10 card in RSC-S RMM

#### At the MAP terminal

- 1 Proceed only if you have been directed to this card replacement procedure from a step in a maintenance procedure, are using the procedure for verifying or accepting cards, or have been directed to this procedure by your maintenance support group.
- 2 Obtain a replacement card. Ensure that the replacement card has the same product equipment code (PEC), including suffix, as the card to be removed.

#### At the MAP

3 Access the PM level and post the RMM by typing

>MAPCI;MTC;PM;POST RMM rmm\_no

and pressing the Enter key.

where

#### rmm\_no

is the number of the RMM from which the card is to be removed

Example of a MAP display:

1	CM	MS	I	OD	Net	PM	CCS	LNS	Trks	Ext	Appl
	•	•		•	•	•	•	•	•	•	•
	RMI	Ч			SysB	ManB	OffL	CB	sy	ISTb	InSv
	0	Quit	PM		0	0	0		0	0	130
	2	Post_	RMM		0	0	0		0	0	0
	3										
	4		RMM	5	INSV						
	5	Trnsl									
	б	Tst									
	7	Bsy									
	8	RTS									
	9	OffL									
	10	LoadPM									
	11	Disp_									
		Next									
	13										
	14	QueryPM									
	15	~ •									
	16										
	17										
	18										)

4 Busy the RMM by typing

>BSY

and pressing the Enter key.

Example of a MAP display:

См	MS		OD		PM 1ManB		LNS	Trks	Ext	Appl
RM	М			SysB	ManB	OffL	CBs	зу	ISTb	InSv
0	Quit	PM		4	0	10		0	0	130
2	Post_	RMM		0	1	0		0	0	0
3										
4		RMM	5	INSV						
	Trnsl									
	Tst									
	Bsy									
	RTS									
	OffL									
	LoadPM									
	Disp_									
12	Next									
	QueryPM									
15	Querypm									
16										
17										
18										
\										/

At the RMM shelf

5

6




#### DANGER

**Static discharge may cause damage to circuit packs** Put on a wrist strap and connect it to the frame of the RMM before removing any cards. This protects the RMM against service degradation caused by static electricity.


Put on a wrist strap.

Remove the NT0X10 card as shown in the following figures.


a Locate the card to be removed on the appropriate shelf.



**b** Open the locking levers on the card to be replaced and gently pull the card toward you until it clears the shelf.



- **c** Ensure the replacement card has the same PEC, including suffix, as the card you just removed.
- **d** Set the switch settings on the card to match those of the card you are replacing.
- 7 Open the locking levers on the replacement card.
  - **a** Align the card with the slots in the shelf.
  - **b** Gently slide the card into the shelf.



8




#### DANGER Equipment damage

- Take these precautions when removing or inserting a card:
- 1. Do not apply direct pressure to the components.
- 2. Do not force the card into its slot.

Seat and lock the card.

- **a** Using your fingers or thumbs, push on the upper and lower edges of the faceplate to ensure the card is fully seated in the shelf.
- **b** Close the locking levers.



**9** Use the following information to determine what step to go to next in this procedure.

If you entered this procedure from	Do
alarm clearing procedures	step 12
other	step 10

- **10** Send any faulty cards for repair according to local procedure.
- 11 Record the date the card was replaced, the serial number of the card, and the symptoms prompted by replacement of the card. Go to step 14.
- 12 Return to the procedure that directed you to this procedure. At the point where a faulty card list was produced, identify the next faulty card on the list and go to the appropriate card replacement procedure for that card in this manual.
- **13** Obtain further assistance in replacing this card by contacting the personnel responsible for higher level of support.
- 14 You have successfully completed this procedure. Return to the maintenance procedure that directed you to this card replacement procedure and continue as directed.

### NT2X06 in an RSC-S (DS-1) Model B RMM

### Application

Use this procedure to replace an NT2X06 card in an RSC-S RMM.

PEC	Suffixes	Name
NT2X06	AB	5V/40A Power Converter


#### **Common procedures**

None

### Action

The following flowchart is only a summary of the procedure. To replace the card, use the instructions in the procedure that follows the flowchart.

#### Summary of card replacement procedure for an NT2X06 card in RSC-S RMM



#### Replacing an NT2X06 card in RSC-S RMM

#### At your Current Location

- 1 Proceed only if you have been directed to this card replacement procedure from a step in a maintenance procedure, are using the procedure for verifying or accepting cards, or have been directed to this procedure by your maintenance support group.
- 2 Obtain an NT2X06 replacement card. Ensure the replacement card has the same product equipment code (PEC), including suffix, as the card to be removed.

#### At the MAP terminal

3 Set the MAP display to PM level and post the RMM by typing

>MAPCI;MTC;PM;POST RMM rmm\_no

and pressing the Enter key.

where

rmm no

is the number of the RMM where the card is to be removed

Example of a MAP display:

CM	и м	S	IOD	Net	PM	CCS	LNS	Trks	Ext	Appl
•		•	•	•	•	•	•	•	•	•
RMM				SysB	ManB	OffL		CBsy	ISTb	InSv
0 Ç	uit	PM		4	0	10		3	3	130
2 F 3	ost_	RM	M	0	1	1		0	0	2
4		RM	м 5	INSV						
5 Т	rnsl									
6 І	'st									
7 E	Bsy									
8 F	TS									
9 C	)ffL									
10 I	oadPM									
11 E	isp_									
12 N	Iext									
13										
14 Ç	ueryP	М								
15										
16										
17										
18										

4 Busy the RMM by typing

>BSY

and pressing the Enter key.

Example of a MAP display:

	CM 1	MS		OD	Net	PM 1ManB	CCS	LNS	Trks	Ext	Appl
RMI	4				SysB	ManB	OffL	CB	зу	ISTb	InSv
0	Quit		PM		4	0	10		0	0	130
2	Post_		RMM		0	1	0		0	0	0
3											
4			RMM	5	ManB						
5	Trnsl										
6	Tst										
7	Bsy										
8	RTS										
9	OffL										
10	LoadPl	М									
11	Disp_										
12	Next										
13											
14	Query	РМ									
15											
16											
17											
18											)

At the RMM shelf

5



#### CAUTION

**Static discharge may cause damage to circuit packs** Put on a wrist strap and connect it to the frame of the RMM before removing any cards. This protects the RMM against service degradation caused by static electricity.


Put on a wrist strap.

6 Power down the unit by setting the ON/OFF switch on the power converter faceplate to the OFF position. Both the converter FAIL LED and FRAME FAIL lamp on the modular supervisory panel (MSP) will be ON. An audible alarm may sound. If an alarm does sound, return to the MAP terminal and silence the alarm by typing


>sil

and pressing the Enter key.

- 7 Remove the NT2X06 card as shown in the following figures.
  - a Locate the card to be removed on the appropriate shelf.




**b** Open the locking levers on the card to be replaced and gently pull the card toward you until it clears the shelf.



- **c** Ensure the replacement card has the same PEC, including suffix, as the card you just removed.
- Open the locking levers on the replacement card.
  - **a** Align the card with the slots in the shelf.
  - **b** Gently slide the card into the shelf.

8



9




#### DANGER Equipment damage

Take these precautions when removing or inserting a card:

- 1. Do not apply direct pressure to the components.
- 2. Do not force the card into its slot.

Seat and lock the card.

- **a** Using your fingers or thumbs, push on the upper and lower edges of the faceplate to ensure that the card is fully seated in the shelf.
- **b** Close the locking levers.



**10** Use the following information to determine where to proceed.

If you entered this procedure from	Do
alarm clearing procedures	step 23
other	step 11

#### At the RMM shelf

- **11** Power up the RMM as follows:
  - **a** Ensure the converter (NT2X06) is inserted. A major audible alarm may sound. This alarm is silenced when power is restored to the converter.
  - **b** Set the POWER switch to the ON position.

If MSP is equipped with	Do
fuses	step 12
circuit breakers	step 13

12 Press and hold the RESET button for 1 s. Both the converter FAIL LED and FRAME FAIL lamp on the MSP will be OFF.

Go to step 14.

**13** Press the RESET button while setting the circuit breaker to the ON position. Both the converter FAIL LED and FRAME FAIL lamp on the MSP will be ON.

Go to step 14.

#### At the MAP terminal

14 Reload the RMM by typing

>LOADPM

and pressing the Enter key.

lf	Do
message loadfile found in directory received	step 15
load passes	step 19
load fails	step 24

15	Use the following information to o	determine where to proceed.					
	If system load module	Do					
	version 1	step 16					
	version 2	step 17					
16	List the loadfile in the directory by	y typing					
	>DSKUT;LISTVOL D000 file	_name ALL					
	and pressing the Enter key.						
	or						
	> dskut;listvol d010 fil	e_name all					
	and pressing the Enter key.						
	where						
	file_name is the name of the loadfile						
	Local operating company policy o located.	determines where disk D000 or D010 is					
	Proceed to step 18.						
17	List the loadfile in the directory by	y typing					
	>DISKUT;LV S00D						
	and pressing the Enter key.						
	>LF SOOD file_name						
	and pressing the Enter key.						
	or						
	>DISKUT;LV S01D						
	and pressing the Enter key.						
	>LF S01D file_name						
	and pressing the Enter key.						
	where						
	file_name is the name of the loadfile						
18	Leave the disk utility by typing						
	>QUIT						
	and pressing the Enter key.						
	Return to step 14.						
19	Test the RMM by typing						
	>TST						

20

21

### NT2X06 in an RSC-S (DS-1) Model B RMM (end)

If TST	Do
passed	step 20
failed	step 23
Return the RMM to servi	ce by typing
>RTS	
and pressing the Enter ke	
	sy.
If RTS	Do

22 Record the date the card was replaced, the serial number of the card, and the symptoms prompted by replacement of the card. Go to step 25.

- **23** Return to the procedure that directed you to this procedure. At the point where a faulty card list was produced, identify the next faulty card on the list and go to the appropriate card replacement procedure for that card in this manual.
- 24 Obtain further assistance in replacing this card by contacting operating company maintenance personnel.
- 25 You have successfully completed this procedure. Return to the maintenance procedure that directed you to this card replacement procedure and continue as directed.

# NT2X09 in an RSC-S (DS-1) Model B RMM

### Application

Use this procedure to replace an NT2X09 card in an RSC-S RMM.

PEC	Suffixes	Name
NT2X09	AA	Power Converter


### **Common procedures**

None

### Action

The following flowchart is only a summary of the procedure. To replace the card, use the instructions in the procedure that follows the flowchart.

Summary of card replacement procedure for an NT2X09 card in RSC-S RMM



#### Replacing an NT2X09 card in RSC-S RMM

#### At your Current Location

- 1 Proceed only if you have been directed to this card replacement procedure from a step in a maintenance procedure, are using the procedure for verifying or accepting cards, or have been directed to this procedure by your maintenance support group.
- 2 Obtain an NT2X09 replacement card. Ensure the replacement card has the same product equipment code (PEC), including suffix, as the card to be removed.

#### At the MAP terminal

3 Set the MAP display to PM level by typing

>MAPCI;MTC;PM;POST RMM rmm\_no

and pressing the Enter key.

where

rmm no

is the number of the RMM unit where the card is to be removed *Example of a MAP display:* 

c	CM	MS	т	σD	Net	РМ	CCS	LNS	Trks	Ext	Appl
	•		-			•			•	- DAC	
RM	1			S	ysB	ManB	OffL	CBsy	ISTb		InSv
0	Quit		ΡM		4	0	10	3	3		130
	Post_	_	RMM		0	1	1	0	0		2
3											
4			RMM	5	INSV						
5	Trns	1									
6	Tst										
7	Bsy										
	RTS										
	OffL										
10	LoadI	PM									
	Disp_	_									
	Next										
13											
	Query	уРМ									
15											
16											
17											
18											

4 Busy the RMM by typing

>BSY

and pressing the Enter key.

Example of a MAP display:

CI	M MS	IOD	Net	PM	CCS	LNS	Trks Ext	Appl
	• •	•	•	1ManB	•	•	• •	•
RM	4		SysB	ManB	OffL	CBs	y ISTb	InSv
0	Quit	PM	4	0	10	0	0	130
	Post_	RMM	0	1	0	0	0	0
3								
4		RMM 5	5 ManB					
	Trnsl							
	Tst							
	Bsy							
	RTS							
	OffL							
	LoadPM							
	Disp_							
	Next							
13								
	QueryPM							
15								
16								
17								
18								

5



#### CAUTION

**Static discharge may cause damage to circuit packs** Put on a wrist strap and connect it to the frame of the RMM before removing any cards. This protects the RMM against service degradation caused by static electricity.


Put on a wrist strap.

6 Power down the unit by setting the ON/OFF switch on the power converter faceplate to the OFF position. Both the converter FAIL LED and FRAME FAIL lamp on the modular supervisory panel (MSP) will be ON. An audible alarm may sound. If an alarm does sound, return to the MAP terminal and silence the alarm by typing


>sil

and pressing the Enter key.

- 7 Remove the NT2X09 card as shown in the following figures.
  - **a** Locate the card to be removed on the appropriate shelf.




**b** Open the locking levers on the card to be replaced and gently pull the card toward you until it clears the shelf.



- **c** Ensure the replacement card has the same PEC, including suffix, as the card you just removed.
- Open the locking levers on the replacement card.
  - **a** Align the card with the slots in the shelf.
  - **b** Gently slide the card into the shelf.

8



9




#### DANGER Equipment damage

Take these precautions when removing or inserting a card:

- 1. Do not apply direct pressure to the components.
- 2. Do not force the card into its slot.

Seat and lock the card.

- **a** Using your fingers or thumbs, push on the upper and lower edges of the faceplate to ensure that the card is fully seated in the shelf.
- **b** Close the locking levers.



**10** Use the following information to determine where to proceed.

If you entered this procedure from	Do
alarm clearing procedures	step 23
other	step 11

11 Power up the RMM unit in the following sequence:

- **a** Ensure the converter (NT2X09) is inserted. A major audible alarm may sound. This alarm is silenced when power is restored to the converter.
- **b** Set the POWER switch to the ON position.

If MSP is equipped with	Do
fuses	step 12
circuit breakers	step 13

- 12 Press and hold the RESET button for 1 s. Both the converter FAIL LED and FRAME FAIL lamp on the MSP will be OFF. Go to step 14.
- 13 Press the RESET button while setting the circuit breaker to the ON position. Both the converter FAIL LED and FRAME FAIL lamp on the MSP will be ON.

### At the MAP terminal

15

14 Reload the RMM by typing

>LOADPM

and pressing the Enter key.

lf	Do
message loadfile no found in directory is received	ot step 15
load passes	step 19
load fails	step 24
Jse the following information to de	etermine where to proceed.
If system load module	Do
version 1	sten 16

version 1	step 16	
version 2	step 17	

16	List the loadfile in the directory by typ	ing
	>DSKUT;LISTVOL D000 volume_1	name ALL
	and pressing the Enter key.	
	or	
	>DSKUT;LISTVOL D010 volume_1	name ALL
	and pressing the Enter key.	
	where	
	volume_name is the name of the loadfile	
	Local operating company policy deter located.	mines where disk D000 or D010 is
	Proceed to step 18.	
17	List the loadfile in the directory by typ	ing
	>DISKUT;LV S00D	
	and pressing the Enter key.	
	>LF SOOD file_name	
	and pressing the Enter key.	
	or	
	>DISKUT;LV S01D	
	and pressing the Enter key.	
	>LF S01D file_name	
	and pressing the Enter key.	
	where	
	file_name is the name of the loadfile	
18	Leave the disk utility by typing	
	>QUIT	
	and pressing the Enter key.	
	Return to step 14.	
19	Test the RMM by typing	
	>TST	
	and pressing the Enter key.	
	If TST	Do
	passed	step 20
	failed	step 23

20 Return the RMM to service by typing

>RTS

and pressing the Enter key.

If RTS	Do	
passed	step 21	
failed	step 24	

- 21 Send any faulty cards for repair according to local procedure.
- 22 Record the date the card was replaced, the serial number of the card, and the symptoms prompted by replacement of the card. Go to step 25.
- **23** Return to the procedure that directed you to this procedure. At the point where a faulty card list was produced, identify the next faulty card on the list and go to the appropriate card replacement procedure for that card in this manual.
- 24 Obtain further assistance in replacing this card by contacting operating company maintenance personnel.
- 25 You have successfully completed this procedure. Return to the maintenance procedure that directed you to this card replacement procedure and continue as directed.

# NT2X10 in an RSC-S (DS-1) Model B RMM

### Application

Use this procedure to replace an NT2X10 card in an RSC-S RMM.

PEC	Suffixes	Name
NT2X10	BA	Line Test Unit (analog)


# **Common procedures**

None

# Action

The following flowchart is only a summary of the procedure. To replace the card, use the instructions in the procedure that follows the flowchart.

### Summary of card replacement procedure for an NT2X10 card in RSC-S RMM



#### Replacing an NT2X10 card in RSC-S RMM

#### At your current location

- 1 Proceed only if you have been directed to this card replacement procedure from a step in a maintenance procedure, are using the procedure for verifying or accepting cards, or have been directed to this procedure by your maintenance support group.
- 2 Obtain an NT2X10 replacement card. Ensure the replacement card has the same product equipment code (PEC), including suffix, as the card that is to be removed.

#### At the MAP terminal

3 Set the MAP display to the PM level and post the RMM by typing

>MAPCI;MTC;PM;POST RMM rmm\_no

and pressing the Enter key.

where

rmm\_no

is the number of the RMM where the card is to be removed

Example of MAP display:

CM	MS	I	OD	Net	PM	CCS	LNS	Trks	Ext Appl
•	•		•			•		•	
RMM				SysB	ManB	OffL	CBsy	ISTb	InSv
0 Q1	iit	PM		0	0	0	0	0	130
2 Po 3	ost_	RMM		0	0	0	0	0	0
4		RMM	5	INSV					
5 Ті	rnsl								
6 Та	st								
7 Ba	sy								
8 R.	ſS								
9 01	fL								
LO LO	DadPM								
L1 D:	lsp_								
L2 Ne	ext								
L3									
	leryPM								
15									
L6									
17									
18									

4 Busy the RMM by typing

>BSY

and pressing the Enter key.

Example of a MAP display:

CM	MS		IOD		Net	PM	CCS	LNS	Trks	Ext Appl
•	•		•		•	1ManB	•		•	
RWM				SveB		ManB	Off⊺.	CBay	- ISTb	InSv
	Quit			-				-		130
	Post_					1	0	0		
3		RMM		0		Ŧ	0	U	0	0
		-	-							
		RMM	5	Mani	3					
	Trnsl									
6	Tst									
7	Bsy									
8	RTS									
9	OffL									
10	LoadPM									
11	Disp_									
	Next									
13										
	QueryPM									
15	2001/111									
16										
10 17										
18										

### At the RMM shelf

5




### CAUTION


**Static discharge may cause damage to circuit packs** Put on a wrist strap and connect it to the frame of the RMM before removing any cards. This protects the RMM against service degradation caused by static electricity.

Put on a wrist strap.


- 6 Remove the NT2X10 card as shown in the following figures.
  - a Locate the card to be removed on the appropriate shelf.



**b** Open the locking levers on the card to be replaced and gently pull the card toward you until it clears the shelf.



- **c** Ensure the replacement card has the same PEC, including suffix, as the card you just removed.
- 7 Open the locking levers on the replacement card.
  - **a** Align the card with the slots in the shelf.
  - **b** Gently slide the card into the shelf.



8




#### DANGER Equipment damage

Take these precautions when removing or inserting a card:

- 1. Do not apply direct pressure to the components.
- 2. Do not force the card into its slot.

Seat and lock the card.

- **a** Using your fingers or thumbs, push on the upper and lower edges of the faceplate to ensure the card is fully seated in the shelf.
- **b** Close the locking levers.



9	Use the following information to deter	rmine where to proceed.
	If you entered this procedure from	Do
	alarm clearing procedures	step 14
	other	step 10
At the	MAP terminal	
10	Test the RMM by typing	
	>TST	
	and pressing the Enter key.	
	If TST	Do
	passed	step 11
	failed	step 14
11	Return the RMM to service by typing	
	>RTS	
	and pressing the Enter key.	
	If RTS	Do
	passed	step 12
	failed	step 15
12	Send any faulty cards for repair acco	rding to local procedure.
13	Record the date the card was replace symptoms the prompted replacemen	d, the serial number of the card, and the t of the card. Go to step 16.
14	Return to the procedure that directed where a faulty card list was produced and go to the appropriate card replac manual.	l, identify the next faulty card on the list
15	Obtain further assistance in replacing company maintenance personnel.	this card by contacting operating
16	You have successfully completed this procedure that directed you to this can as directed.	procedure. Return to the maintenance rd replacement procedure and continue

# NT2X11 in an RSC-S (DS-1) Model B RMM

# Application

Use this procedure to replace an NT2X11 card in an RSC-S RMM.

PEC	Suffixes	Name
NT2X11	BA	Line Test Unit (digital)


# **Common procedures**

None

# Action

The following flowchart is only a summary of the procedure. To replace the card, use the instructions in the procedure that follows the flowchart.

Summary of card replacement procedure for an NT2X11 card in RSC-S RMM



#### Replacing an NT2X11 card in RSC-S RMM

#### At your Current Location

- 1 Proceed only if you have been directed to this card replacement procedure from a step in a maintenance procedure, are using the procedure for verifying or accepting cards, or have been directed to this procedure by your maintenance support group.
- 2 Obtain an NT2X11 replacement card. Ensure the replacement card has the same product equipment code (PEC), including suffix, as the card that is to be removed.

#### At the MAP terminal

3 Set the MAP display to TTP level and post the RMM by typing

>MAPCI;MTC;TRKS;TTP;POST G MTADRIVER

and pressing the Enter key.

Example of a MAP display:

(												
CM MS	IOD	Net		PM	CCS	LNS	Trl	ks		Ext	App	1
•••	•	•		•	•	•		•		•	•	
TTP												
0 Quit	POST	1			DELQ		BUS	YQ			DIG	
2 Post_	TTP	6-009	)									
3 Seize_	CKT TY	PE	PM 3	NO.	COM LAN	G	STA	S	R	DOT	TE R	ESULT
4	MISC	RMM	0	16	MATDRIV	er 0	IDL					
5 Bsy_												
6 RTS_												
7 Tst_												
8												
9 CktInfo												
10 CktLoc												
11 Hold	TTP ID	IS:	б-	009								
12 Next_	NO CKT	, SET	IS	EMPTY								
13 Rls	TTP:											
14 Ckt	LAST C	KTN =	: 1									
15 Trnslvf_	SHORT (	CLLI I	s:	MTAI	DRI							
16 Stksdr												
17 Pads	- ,											
18 Level												

Busy the MTADRIVER by typing
 >BSY; BSY; INB; ALL
 and pressing the Enter key.

Example of a MAP display:

(	СМ	MS	IOD	Net	РМ	CCS	LNS	Trks	Ext	Appl
	•	•	•	•	•	•	•	•	•	•
TT	P									
0	Quit	5	POST	1		DELQ		BUSYQ		DIG
2	Post	:_	TTP	6-00	9					
3	Seiz	ze_	CKT TY	PE	PM NO	. COM LA	NG	STA S	R DOT	TE RESULT
4			MISC	RMM	0 16	MATDRI	ver 0	IDL		
5	Bsy_	-								
6	RTS_	_								
	Tst_	-								
8										
	CktI									
	CktI									
			TTP II							
		_	NO CKI	, SET	IS EM	PTY				
	_	-	TTP:		_					
	_	-	LAST C							
		_	SHORT			FADRI				
		_	OK, CK	T POS	TED					
	Pads	_								
(18	Leve	έτ_								,

5

Set the MAP display to the PM level and post the RMM by typing

### >MAPCI;MTC;PM;POST RMM rmm\_no

and pressing the Enter key.

where

rmm\_no

is the number of the RMM where the card is to be removed

Example of a MAP display:

( C1	a Ms		IOD	Net	РМ	CCS	LNS	Trks	Ext	Appl
· ·	• •		•	•	•	•	•	•	•	•
RMI	4		S	SysB	ManB	OffL	CBsy	ISTb		InSv
0	Quit	PM		0	0	0	0	0		130
	Post_	RMM		0	0	0	0	0		0
3		RMM	5	INSV						
5	Trnsl									
6	Tst									
7	Bsy									
8	RTS									
9	OffL									
10	LoadPM									
11	Disp_									
12	Next									
13										
14	QueryPM									
15										
16										
17										
( 18										)

6

### Busy the RMM by typing

>BSY

and pressing the Enter key.

Example of a MAP display:

CI	n MS		IOD		Net	PM		LNS	Trks	Ext	Appl
•	•		•		•	1Man	в.	•	•	•	•
RM	1			SysB		ManB	OffL	CBsy	IST	ľb	InSv
0	Quit	PM		4		0	10	0		0	130
2	Post_	RMM		0		1	0	0		0	0
3											
4		RMM	5	Man	3						
5	Trnsl										
	Tst										
	Bsy										
	RTS										
	OffL										
	LoadPM										
	Disp_										
	Next										
13											
	QueryPM										
15											
16											
17											
18											

#### At the RMM shelf

7

8



Static discharge may cause damage to circuit packs Put on a wrist strap and connect it to the frame of the RMM before removing any cards. This protects the RMM against service degradation caused by static electricity.

Put on a wrist strap.


Remove the NT2X11 card as shown in the following figures.

Locate the card to be removed on the appropriate shelf.

CAUTION

- b Open the locking levers on the card to be replaced and gently pull the card toward you until it clears the shelf.

а




c Ensure the replacement card has the same PEC, including suffix, as the card you just removed.

Open the locking levers on the replacement card.

- **a** Align the card with the slots in the shelf.
- **b** Gently slide the card into the shelf.

9



10




**DANGER** Equipment damage Take these precautions when removing or inserting a card:

- 1. Do not apply direct pressure to the components.
- 2. Do not force the card into the slot.

Seat and lock the card.

- **a** Using your fingers or thumbs, push on the upper and lower edges of the faceplate to ensure the card is fully seated in the shelf.
- **b** Close the locking levers.



11 Use the following information to determine where to proceed.

If you entered this procedure from	Do
alarm clearing procedures	step 18
other	step 12

### At the MAP terminal

**12** Test the RMM by typing

>TST

and pressing the Enter key.

	and pressing the Enter key.	
	If TST	Do
	passed	step 13
	failed	step 18
13	Return the RMM to service by typing	
	>RTS	
	and pressing the Enter key.	
	If RTS	Do
	passed	step 14
	failed	step 19
14	Post the MTADRIVER by typing	
	>TRKS;TTP;POST G MTADRIVER	
	and pressing the Enter key.	
15	Return the MTADRIVER to service by	typing
	>BSY ALL;RTS ALL	
	and pressing the Enter key.	
16	Send any faulty cards for repair accord	ding to local procedure.
17	Record the date the card was replaced symptoms that prompted replacement	l, the serial number of the card, and the t of the card. Go to step 20.
18	Return to the procedure that directed where a faulty card list was produced, and go to the appropriate card replace manual.	identify the next faulty card on the list,
19	Obtain further assistance in replacing company maintenance personnel.	this card by contacting operating
20		procedure. Return to the maintenance d replacement procedure and continue

# NT2X57 in an RSC-S (DS-1) Model B RMM

### Application

Use this procedure to replace an NT2X57 card in an RSC-S RMM.

PEC	Suffixes	Name
NT2X57	AA	Signal Distribution


### **Common procedures**

None

# Action

The following flowchart is only a summary of the procedure. To replace the card, use the instructions in the procedure that follows the flowchart.

### Summary of card replacement procedure for an NT2X57 card in RSC-S RMM



#### Replacing an NT2X57 card in RSC-S RMM

#### At Your Current Location

- 1 Proceed only if you have been directed to this card replacement procedure from a step in a maintenance procedure, are using the procedure for verifying or accepting cards, or have been directed to this procedure by your maintenance support group.
- 2 Obtain an NT2X57 replacement card. Ensure the replacement card has the same product equipment code (PEC), including suffix, as the card that is to be removed.

#### At the MAP terminal

3 Set the MAP display to PM level and post the RMM by typing

>MAPCI;MTC;PM;POST RMM rmm\_no

and pressing the Enter key.

where

rmm\_no

is the number of the RMM where the card is to be removed

Example of a MAP display:

CM	MS	IC	D	Net	PM	CCS	LNS	Trks Ext	Appl
•	•		•	•	•			· ·	•
RMM			Sys	зB	ManB	OffL	CBsy	ISTb	InSv
0 Qui	t	PM		0	0	0	0	0	130
2 Pos	t_	RM		0	0	0	0	0	0
3									
4		RMM	5	INSV					
5 Trn	sl								
6 Tst									
7 Bsy									
8 RTS									
9 Off	L								
10 Loa	dPM								
11 Dis	p_								
12 Nex	t								
13									
14 Que	ryPM	[							
15									
16									
17									
18									

4 Busy the RMM by typing

>BSY

and pressing the Enter key.

Example of a MAP display:

СМ					<b>PM</b> 1ManB		Trks	Ext	Appl
RMM	[		S	ysB	ManB	OffL	CBsy	ISTb	InSv
0	Quit	PM		4	0	10	0	0	130
2 3	Post_	RMM		0	1	0	0	0	0
4		RMM	5	ManB					
5	Trnsl								
б	Tst								
7	Bsy								
8	RTS								
9	OffL								
10	LoadPM								
11	Disp_								
	Next								
14	QueryPM								
15									
16									
17									
18									

### At the RMM shelf

5




#### CAUTION


**Static discharge may cause damage to circuit packs** Put on a wrist strap and connect it to the frame of the RMM before removing any cards. This protects the RMM against service degradation caused by static electricity.

Put on a wrist strap.


- 6 Remove the NT2X57 card as shown in the following figures.
  - a Locate the card to be removed on the appropriate shelf.



**b** Open the locking levers on the card to be replaced and gently pull the card toward you until it clears the shelf.



- **c** Ensure the replacement card has the same PEC, including suffix, as the card you just removed.
- **d** Set the switch settings on the card to match those of the card you are replacing.
- 7 Open the locking levers on the replacement card. Align the card with the slots in the shelf. Gently slide the card into the shelf.



8




#### DANGER Equipment damage

Take these precautions when removing or inserting a card:

- 1. Do not apply direct pressure to the components.
- 2. Do not force the card into the slot.

Seat and lock the card.

- **a** Using your fingers or thumbs, push on the upper and lower edges of the faceplate to ensure the card is fully seated in the shelf.
- **b** Close the locking levers.



9	Use the following information to det	ermine where to proceed.
	If you entered this procedure from	Do
	alarm clearing procedures	step 14
	other	step 10
At the	e MAP terminal	
10	Test the RMM by typing	
	>TST	
	and pressing the Enter key.	
	If TST	Do
	passed	step11
	failed	step 15
11	Return the RMM to service by typin	ng
	>RTS	
	and pressing the Enter key.	
	If RTS	Do
	passed	step 12
	failed	step 15
12	Send any faulty cards for repair acc	cording to local procedure.
13	Record the date the card was replace symptoms that prompted replacements and the symptoms that prompted replacements are specified as the symptometry of the symptometry of the symplectic	ed, the serial number of the card, and the ent of the card. Go to step 16.
14	where a faulty card list was produce	ed you to this procedure. At the point ed, identify the next faulty card on the list, acement procedure for that card in this
15	Obtain further assistance in replaci company maintenance personnel.	ng this card by contacting operating
16	You have successfully completed th procedure that directed you to this c as directed.	is procedure. Return to the maintenance and replacement procedure and continue

# NT2X59 in an RSC-S (DS-1) Model B RMM

# Application

Use this procedure to replace an NT2X59 card in an RSC-S RMM.

PEC	Suffixes	Name
NT2X59	AA	Group Codec


# **Common procedures**

None

# Action

The following flowchart is only a summary of the procedure. To replace the card, use the instructions in the procedure that follows the flowchart.

Summary of card replacement procedure for an NT2X59 card in RSC-S RMM



#### Replacing an NT2X59 card in RSC-S RMM

#### At your Current Location

- 1 Proceed only if you have been directed to this card replacement procedure from a step in a maintenance procedure, are using the procedure for verifying or accepting cards, or have been directed to this procedure by your maintenance support group.
- 2 Obtain an NT2X59 replacement card. Ensure the replacement card has the same product equipment code (PEC), including suffix, as the card that is to be removed.

#### At the MAP terminal

3 Set the MAP display to the PM level and post the RMM by typing

>MAPCI;MTC;PM;POST RMM rmm\_no

and pressing the Enter key.

where

rmm\_no

is the number of the RMM where the card is to be removed

Example of a MAP display:

CM	MS	IC	D	Net	PM	CCS	LNS	Trks E	kt Appl
·	•		·	•	•	•	•	•	• •
RMM			Sys	В	ManB	OffL	CBsy	ISTb	InSv
0 ζ	Quit	PM		0	0	0	0	0	130
2 E	Post_	RMM	0		0	0	0	0	0
3									
4		RMM	5	INSV					
5 1	「rnsl								
6 1	ſst								
7 E	Bsy								
8 F	RTS								
9 (	DffL								
10 I	LoadPM								
11 I	Disp_								
12 1	Jext								
13									
14 Ç	QueryPM								
15									
16									
17									
18									

4 Busy the RMM by typing

>BSY

and pressing the Enter key.

Example of a MAP display:

СМ					<b>PM</b> 1ManB			Ext	Appl
RMM			S	ysB	ManB	OffL	CBsy	ISTb	InSv
0	Quit	PM		4	0	10	0	0	130
2	Post_	RMM		0	1	0	0	0	0
3									
4		RMM	5	ManB					
5	Trnsl								
б	Tst								
7	Bsy								
8	RTS								
9	OffL								
10	LoadPM								
11	Disp_								
12	Next								
13									
14	QueryPM								
15									
16									
17									
18									

### At the RMM shelf

5




#### CAUTION


**Static discharge may cause damage to circuit packs** Put on a wrist strap and connect it to the frame of the RMM before removing any cards. This protects the RMM against service degradation caused by static electricity.

Put on a wrist strap.

- 6 Remove the NT2X59 card as shown in the following figures.
  - a Locate the card to be removed on the appropriate shelf.




**b** Open the locking levers on the card to be replaced and gently pull the card toward you until it clears the shelf.



- **c** Ensure the replacement card has the same PEC, including suffix, as the card you just removed.
- Open the locking levers on the replacement card.
  - **a** Align the card with the slots in the shelf.
  - **b** Gently slide the card into the shelf.

7



8




#### DANGER Equipment damage

Take these precautions when removing or inserting a card:

- 1. Do not apply direct pressure to the components.
- 2. Do not force the card into the slot.

Seat and lock the card.

- **a** Using your fingers or thumbs, push on the upper and lower edges of the faceplate to ensure the card is fully seated in the shelf.
- **b** Close the locking levers.



9	Use the following information to determine where to proceed.		
	If you entered this procedure from	Do	
	alarm clearing procedures	step 14	
	other	step 10	
At the	MAP terminal		
10	Test the RMM by typing		
	>TST		
	and pressing the Enter key.		
	If TST	Do	
	passed	step 11	
	failed	step 14	
11	Return the RMM to service by typing	g	
	>RTS		
	and pressing the Enter key.		
	If RTS	Do	
	passed	step 12	
	failed	step 15	
12	Send any faulty cards for repair according to local procedure.		
13	Record the date the card was replaced, the serial number of the card, and the symptoms that prompted replacement of the card. Go to step 16.		
14	Return to the procedure that directed you to this procedure. At the point where a faulty card list was produced, identify the next faulty card on the list and go to the appropriate card replacement procedure for that card in this manual.		
15	Obtain further assistance in replacir company maintenance personnel.	ng this card by contacting operating	
16	You have successfully completed this procedure. Return to the maintenance procedure that directed you to this card replacement procedure and continue as directed.		

# NT2X90 in an RSC-S (DS-1) Model B RMM

### Application

Use this procedure to replace an NT2X90 card in an RSC-S RMM.


PEC	Suffixes	Name
NT2X90	AD	Test Trunk Circuit

# **Common procedures**

None

# Action

The following flowchart is only a summary of the procedure. To replace the card, use the instructions in the procedure that follows the flowchart.



#### Summary of card replacement procedure for an NT2X90 card in RSC-S RMM

#### Replacing an NT2X90 card in RSC-S RMM

#### At your Current Location

- 1 Proceed only if you have been directed to this card replacement procedure from a step in a maintenance procedure, are using the procedure for verifying or accepting cards, or have been directed to this procedure by your maintenance support group.
- 2 Obtain an NT2X90 replacement card. Ensure the replacement card has the same product equipment code (PEC), including suffix, as the card that is to be removed.

#### At the MAP terminal

3 Set the MAP display to the TTP level and post the RMM by typing

>MAPCI;MTC;TRKS;TTP;POST P RMM

and pressing the Enter key.

Example of a MAP display:

CM	MC	TOD	Not	DM	000	TNO	Trals a	Pret	31
-					CCS				Abbī
•	•	•	•	•	•	·	•	·	•
TTP									
0 0	Quit	POST			DELQ		BUSYQ		DIG
2 E	Post_	TTP	6-018						
3 5	Seize_	СКТ ТҮ	PE PM	NO.	COM LANG	STA	S R	DOT TE	RESULT
4		OG	RMM	0 20	MLT		0 I	DL	
5 E	Bsy_								
	RTS_								
7 1	[st_								
8									
9 0	CktInfo								
10 C	CktLoc								
11 H	Iold								
12 N	lext_								
13 F	Rls_								
14 0	Ckt_								
15 I	Trnslvf_								
16 S	Stksdr_								
17 E	Pads_								
18 I	Level_								

4 Busy the trunk circuit on the RMM by typing

>BSY;BSY;INB;ALL

and pressing the Enter key.

Example of a MAP display:

CI	M MS	IOD	Net	PM	CCS	LN	IS I	'rks	Ext	Appl
•	•	•		•	•		•	•	•	•
TT	P									
0	Quit	POST			DELQ		BUSYQ		DIG	
2	Post_	TTP	6-018							
3	Seize_	CKT TY	PE PM	NO.	COM	LANG	STA	S R	DOT 7	TE RESULT
4		OG	RMM	0	20	MLT		0	INB	
5	Bsy_									
б	RTS_									
7	Tst_									
8										
9	CktInfo									
10	CktLoc									
11	Hold									
12	Next_									
13	Rls_									
14	Ckt_									
	Trnslvf_									
	Stksdr_									
	Pads_									
18	Level_									

At the RMM shelf

5

6




#### CAUTION


**Static discharge may cause damage to circuit packs** Put on a wrist strap and connect it to the frame of the RMM before removing any cards. This protects the RMM against service degradation caused by static electricity.

Put on a wrist strap.


- Remove the NT2X90 card as shown in the following figures.
  - a Locate the card to be removed on the appropriate shelf.



**b** Open the locking levers on the card to be replaced and gently pull the card toward you until it clears the shelf.



- **c** Ensure the replacement card has the same PEC, including suffix, as the card you just removed.
- 7 Open the locking levers on the replacement card.
  - **a** Align the card with the slots in the shelf.
  - **b** Gently slide the card into the shelf.



8




#### DANGER Equipment damage

Take these precautions when removing or inserting a card:

- 1. Do not apply direct pressure to the components.
- 2. Do not force the card into the slot.

Seat and lock the card.

- **a** Using your fingers or thumbs, push on the upper and lower edges of the faceplate to ensure the card is fully seated in the shelf.
- **b** Close the locking levers.



9	Use the following information to dete	ermine where to proceed.				
	If you entered this procedure from	Do				
	alarm clearing procedures	step 14				
	other	step 10				
At the	MAP terminal					
10	Test the RMM by typing					
	>TST					
	and pressing the Enter key.					
	If TST	Do				
	passed	step 11				
	failed	step 14				
11	Return the RMM to service by typing	]				
	>RTS					
	and pressing the Enter key.					
	If RTS	Do				
	passed	step 12				
	failed	step 15				
12	Send any faulty cards for repair acco	ording to local procedure.				
13	Record the date the card was replace symptoms that prompted replaceme	ed, the serial number of the card, and the nt of the card. Go to step 16.				
14	Return to the procedure that directed you to this procedure. At the point where a faulty card list was produced, identify the next faulty card on the list and go to the appropriate card replacement procedure for that card in this manual.					
15	Obtain further assistance in replacin company maintenance personnel.	g this card by contacting operating				
16	You have successfully completed this procedure that directed you to this ca as directed.	s procedure. Return to the maintenance and replacement procedure and continue				

## NT3X09 in an RSC-S (DS-1) Model B RMM

### Application

Use this procedure to replace an NT3X09 card in an RSC-S RMM.

PEC	Suffixes	Name
NT3X09	BA	Remote Metallic Test Access


### **Common procedures**

None

### Action

The following flowchart is only a summary of the procedure. To replace the card, use the instructions in the procedure that follows the flowchart.

Summary of card replacement procedure for an NT3X09 card in RSC-S RMM



#### Replacing an NT3X09 card in RSC-S RMM

#### At the MAP

- 1 Proceed only if you have been directed to this card replacement procedure from a step in a maintenance procedure, are using the procedure for verifying or accepting cards, or have been directed to this procedure by your maintenance support group.
- 2 Obtain an NT3X09 replacement card. Ensure the replacement card has the same product equipment code (PEC), including suffix, as the card that is to be removed.

#### At the MAP terminal

3 Set the MAP display to the TTP level and post the trunk by typing

>MAPCI;MTC;TRKS;TTP;POST G MTADRIVER

and pressing the Enter key.

Example of a MAP display:

MS IOD Net РМ CCS LNS CM Trks Ext Appl . . • • . . . . . . TTP 0 Quit POST 1 2 Post\_ TTP 6-009 DELQ BUSYQ DIG 3 Seize\_ CKT TYPE PM NO. COM LANG STA S R DOT TE RESULT MISC RMM 0 16 MATDRIVER 0 IDL 4 5 Bsy\_ 6 RTS\_ 7 Tst\_ 8 9 CktInfo 10 CktLoc TTP ID IS: 6-009 11 Hold 12 Next\_ NO CKT, SET IS EMPTY 13 Rls\_ TTP: 14 Ckt\_ LAST LAST CKTN = 1 15 Trnslvf\_ SHORT CLLI IS: MTADRI 16 Stksdr\_ OK, CKT POSTED 17 Pads\_ 18 Level\_

4 Busy the MTADRIVER by typing >BSY;BSY;INB;ALL and pressing the Enter key. Example of a MAP display:

C™	i MS	IOD	Net	РМ	CCS	LNS	Trks	Ext	Appl
		•							
TTF	<b>b</b>								
0	Quit	POST	1		DELQ		BUSY	2	DIG
2	Post_	TTP 6	-009						
3	Seize_	CKT TYPE	PM NO	. CON	I LANG	STA	S R	DOT TE	RESULT
4		MISC	RMM	0 16	5	MATDR	IVER	0 INB	
5	Bsy_								
6	RTS_								
7	Tst_								
8									
9	CktInfo								
10	CktLoc								
11	Hold	TTP I	D IS:	6-009	)				
12	Next_	NO CK	T, SET I	IS EMP	PTY				
13	Rls_	TTP:							
14	Ckt_	LAST	CKTN =	1					
15	Trnslvf_	_ SHORT	CLLI IS	5: MJ	ADRI				
16	Stksdr_	OK, C	KT POSTR	ED					
17	Pads_								
18	Level_								

Set the MAP display to the PM level and post the RMM by typing

>MAPCI;MTC;PM;POST RMM rmm\_no

and pressing the Enter key.

where

5

rmm\_no

is the number of the RMM where the card is to be removed *Example of a MAP display:* 

CM	MS	IOD	)	Net	PM	CCS	LNS	Trks	Ext	Appl
•	•	•		•	•	•	•	•	•	•
RMM			Sys	зB	ManB	OffL	CBs	У	ISTb	InSv
0 0	Quit	PM		0	0	0		0	0	130
2 : 3	Post_	RMM		0	0	0		0	0	0
4		RMM	5	INSV						
5 '	Trnsl									
6 '	Tst									
7	Bsy									
8 1	RTS									
9 (	OffL									
10 3	LoadPM									
11 1	Disp_									
	Next									
13										
14	QueryPM	1								
15	-									
16										
17										
18										

6

#### Busy the RMM by typing

>BSY

and pressing the Enter key. *Example of a MAP display:* 

										$\mathcal{A}$
CI	M MS	3 3	LOD	Net	PM	CCS	LNS	Trks	Ext Appl	
			•		1ManB	•	•	•		
RM	M		SysB	Ma	anB	OffL	CBsy	ISTb	InSv	
0	Quit	PM	4		0	10	0	0	130	
2	Post_	RMM	0		1	0	0	0	0	
3										
4		RMM	1							
5	ManB									
5	Trnsl									
б	Tst									
7	Bsy									
8	RTS									
	OffL									
	LoadPN									
11	Disp_									
12	Next									
13										
	QueryI	PM								
15										
16										
17										,
18										

At the RMM shelf

7



#### CAUTION


**Static discharge may cause damage to circuit packs** Put on a wrist strap and connect it to the frame of the RMM before removing any cards. This protects the RMM against service degradation caused by static electricity.

Put on a wrist strap.


Remove the NT3X09 card as shown in the following figures.

a Locate the card to be removed on the appropriate shelf.

8




**b** Open the locking levers on the card to be replaced and gently pull the card toward you until it clears the shelf.



- **c** Ensure the replacement card has the same PEC, including suffix, as the card you just removed.
- Open the locking levers on the replacement card.
  - a Align the card with the slots in the shelf.
  - **b** Gently slide the card into the shelf.

9



10




### DANGER

Equipment damage

- Take these precautions when removing or inserting a card:
- 1. Do not apply direct pressure to the components.
- 2. Do not force the card into the slot.

Seat and lock the card.

- **a** Using your fingers or thumbs, push on the upper and lower edges of the faceplate to ensure the card is fully seated in the shelf.
- **b** Close the locking levers.



11	Use the following information to determ	nine where to proceed.						
	If you entered this procedure from	Do						
	alarm clearing procedures	step 18						
	other	step 12						
At the	MAP terminal							
12	Test the RMM by typing							
	>TST							
	and pressing the Enter key.							
	If TST	Do						
	passed	step 13						
	failed	step 18						
13	Return the RMM to service by typing							
	>RTS							
	and pressing the Enter key.							
	If RTS	Do						
	passed	step 14						
	failed	step 19						
14	Post the MTADRIVER by typing							
	>TRKS;TTP;POST G MTADRIVER							
	and pressing the Enter key.							
15	Return the MTADRIVER to service by	typing						
	>BSY ALL;RTS ALL							
	and pressing the Enter key.							
16	Send any faulty cards for repair accord	ding to local procedure.						
17	Record the date the card was replaced symptoms that prompted replacement							
18	Return to the procedure that directed where a faulty card list was produced, and go to the appropriate card replace manual.	identify the next faulty card on the list						
19	Obtain further assistance in replacing this card by contacting operating company maintenance personnel.							

20 You have successfully completed this procedure. Return to the maintenance procedure that directed you to this card replacement procedure and continue as directed.

### NT6X17 in an RSC-S (DS-1) Model B LCME

### Application

Use this procedure to replace an NT6X17 card in an RSC-S LCME.

PEC	Suffixes	Name
NT6X17	AA, AB, AC	Standard Line Card Type A (POTS)
NT6X17	BA	World Line Card Type A

The NT6X17BA World Line Card Type A replaces the following cards:

- NT6X17AC, North America
- NT6X93AA, Turkey, Belize
- NT6X93BA, Caribbean
- NT6X93CA, China
- NT6X93EA, Australia
- NT6X99AA, UK ScopeDial
- NTMX29AA, British Telephone


### **Common procedures**

None

### Action

The following flowchart is only a summary of the procedure. To replace the card, use the instructions in the procedure that follows the flowchart.

#### Summary of card replacement procedure for an NT6X17 card in RSC-S LCME



#### Replacing an NT6X17 card in RSC-S LCME

#### At the MAP

- 1 Proceed only if you have been directed to this card replacement procedure from a step in a maintenance procedure, are using the procedure for verifying or accepting cards, or have been directed to this procedure by your maintenance support group.
- 2 Obtain an NT6X17 replacement card. Ensure the replacement card has the same product equipment code (PEC), including suffix, as the card that is to be removed.

#### At the MAP terminal

**3** Post the LEN of the card to be replaced by typing

## > mapci;mtc;lns;ltp;post l site lcme\_no unit\_no lsg\_no ckt\_no

and pressing the Enter key.

where

site

is the location name of the LCME with the faulty card

lcme\_no

is the number of the LCME with the faulty card

#### unit\_no

is the number of the LCME unit with the faulty card

#### lsg\_no

is the number of the LSG with the faulty card

#### ckt\_no

is the number of the circuit associated with the faulty card

Example of a MAP display:

СМ	MS	IOD	Net	РМ	CCS	LNS	Trk	- Evt	امدا
		TOD		PM	CCS		IIK	s Ext	Appl
·	•	•	•	•	•	•	•	•	•
LTP									
0 Qu	it	Post	D	ELQ	BUS	SYQ	PRI	EFIX	
2 Pc	st_								
3		LCC P	TY RNG.	LEN.	DN	STA F	S I	LTA TE	RESULT
4		1FR H	OST 00	0 03 03	3 49310	)82 IDL			
5 BS	Y								
6 RI	S								
7 DI	AG								
8									
9 AI	MStat								
10 CK	TLOC								
11 Hc	ld								
12 Ne	xt_								
13									
14									
15									
16 Pr	efix								
17 LC	!0								
18 Le	evel								

4 Busy the NT6X17 line card by typing

#### >BSY

and pressing the Enter key.

Example of a MAP display:

CI	1	MS	IOD	Net	PM	CCS	LNS	Trks	Ext	Appl
•		·	•	•	•	•	•	•	•	•
LTI	2									
0	Qui	t	Post		DELQ	BU	SYQ	PREFI	ĽΧ	
	Pos	t_								
3								STA F S I	LTA TE	RESULT
4			1FR (	HOST 00	0 03	03 4931	082 MB			
	BSY									
	RTS									
	DIA	G								
8										
		Stat								
	CKT									
	Hol									
13	Nex	L_								
14										
15										
	Pre	fix								
	LCO									
	Lev									,

#### At the LCE frame

5



#### WARNING Card damage—transport

Take the following precautions to protect circuit cards from electrical and mechanical damage during transport:

When handling a circuit card not in an electrostatic discharge (ESD) protective container, stand on a conductive floor mat and wear a wriststrap connected, through a 1-megohm resistor, to a suitably grounded object, such as a metal workbench or a DMS switch frame (Northern Telecom [Nortel] Corporate Standard 5028). Store and transport circuit cards in an ESD protective container.



#### WARNING Static electricity damage

Before removing any cards, put on a wriststrap and connect it to the wriststrap grounding point on the left side of the modular supervisory panel (MSP) of the LCME. This protects the equipment against damage caused by static electricity.



#### DANGER

Equipment damage

Take the following precautions when removing or inserting a card:

- 1. Do not apply direct pressure to the components.
- 2. Do not force the cards into the slots.

#### DANGER Hot materia

Hot materials Exercise care when handling the line card. The line feed

resistor may be very hot.



#### CAUTION

**Special tools required** Card shrouds and removal tools are required for removing cards from the line drawers. For descriptions of these tools, refer to the following notes.

Put on a wriststrap.

*Note:* Card shrouds are required for inserting or removing cards in line drawers. Two sizes are available for use with 3-inch and 6-inch cards, as shown in the following table.

Line card insertion / withdrawal tool for	Apparatus code	Common product code
3-inch cards	QTH56A	A0298291
6-inch cards	QTH58A	A0313317

*Note:* Card removal tools are required for removing cards from line drawers. Two sizes are available, as shown in the following table.

Card removal tool for	Apparatus code	Common product code		
3—4 inch cards	QTH57A	A0298292		
<i>Note:</i> For 4-inch or larger cards, use the large grip tool ITA9953.				

6

Prepare to remove the faulty card identified in step 1 by opening the line drawer and following these substeps:

- **a** Face the drawer shelf and grasp the handle at the bottom of the drawer with your right hand.
- **b** Push up on the drawer latch with your thumb and pull the drawer out until fully withdrawn. It is fully withdrawn when the drawer stop, at the top, prevents further travel.
- **c** Maintain a slight pull on the handle and lift the faceplate of the drawer approximately 2.5 cm (1.0 in).
- **d** While holding the drawer in this position, push the bottom of the drawer nearest the shelf with your left hand to a position about 1.0 cm (0.5 in) to the right.
- e Hold the drawer in this position with your left hand and lower the faceplate of the drawer by releasing the grip of your right hand.

- f Ensure a card shroud and line card extractor are available.
- 7 Remove the line card to be replaced by using the following substeps:
  - **a** Slide a card shroud over the card to be removed and an adjacent card. If there is not an adjacent card on either side, do not use the card shroud.
  - **b** Grasp the edge of the card with a line card extractor at a point midway between the top and bottom edges. Hold the extractor in your right hand.
  - **c** Squeeze the handles of the extractor together to grasp the card tightly.
  - **d** Hold the front cover of the line drawer to steady it using your left hand.
  - e Pull the extractor away from the drawer, and the card will become unplugged from its socket on the drawer backplane.
  - f Continue pulling the card with the extractor until the card is clear of the shroud.
  - **g** Insert the card removed into the ESD container and store using local procedures.
- 8 Replace the faulty card using the following substeps:
  - **a** Remove the replacement card from the ESD container.
  - **b** Slide the card in the shroud guide slots toward the drawer backplane.
  - c Hold the front cover of the line drawer with your left hand to steady it.
  - **d** Grasp the top and bottom edges of the card with the fingers of your right hand.
  - e Push the card toward the backplane until it plugs fully into the backplane socket.
- **9** Use the following information to determine where to proceed.

If you entered this procedure from	Do
alarm clearing procedures	step 14
other	step 10

#### At the MAP terminal

**10** Test the NT6X17 line card by typing

>DIAG

and pressing the Enter key.

If DIAG	Do	
passed	step 11	
failed	step 14	

11 Return the NT6X17 card to service by typing

>RTS

and pressing the Enter key.

If RTS	Do	
passed	step 12	
failed	step 15	

- 12 Send any faulty cards for repair according to local procedure.
- **13** Record the date the card was replaced, the serial number of the card, and the symptoms that prompted replacement of the card. Go to step 16.
- 14 Return to the procedure that directed you to this procedure. At the point where a faulty card list was produced, identify the next faulty card on the list and go to the appropriate card replacement procedure for that card in this manual.
- **15** Obtain further assistance in replacing this card by contacting operating company maintenance personnel.
- 16 You have successfully completed this procedure. Return to the maintenance procedure that directed you to this card replacement procedure and continue as directed.

### NT6X18 in an RSC-S (DS-1) Model B LCME

### Application

Use this procedure to replace an NT6X18 card in an RSC-S LCME.

PEC	Suffixes	Name
NT6X18	AA, AB	Line Card Type B (Coin/Ground Start)
NT6X18	BA	World Line Card Type B

The NT6X18BA World Line Card Type B replaces the following cards:

- NT6X18AA, North America
- NT6X94AB, Turkey, Belize, Guyana
- NT6X94BB, Caribbean
- NT6X94CA, China
- NT6X94DA, Morocco
- NT6X33AA, Japan Type A


### **Common procedures**

None

### Action

The following flowchart is only a summary of the procedure. To replace the card, use the instructions in the procedure that follows the flowchart.

#### Summary of card replacement procedure for an NT6X18 card in RSC-S LCME



#### Replacing an NT6X18 card in RSC-S LCME

#### At the MAP

- 1 Proceed only if you have been directed to this card replacement procedure from a step in a maintenance procedure, are using the procedure for verifying or accepting cards, or have been directed to this procedure by your maintenance support group.
- 2 Obtain a replacement card. Ensure the replacement card has the same product equipment code (PEC), including suffix, as the card that is to be removed.

#### At the MAP terminal

**3** Post the LEN of the card to be replaced by typing

>mapci;mtc;lns;ltp;post l site lcme\_no unit\_no lsg\_no
ckt\_no

and pressing the Enter key.

where

site

is the location name of the LCME with the faulty card

lcme\_no

is the number of the LCME with the faulty card

#### unit\_no

is the number of the LCME unit with the faulty card

#### lsg no

is the number of the LSG with the faulty card

#### ckt\_no

is the number of the circuit associated with the faulty card

Example of a MAP display:

CI	M MS	I	OD	Net	PM	CCS	I	LNS	Trks	3	Ext	Appl	
			•	•	•	•		•	•			•	
LTI	P												
0	Quit	Post		DELQ	2	BUSYÇ	2	P	REFIX	ζ			
2	Post_												
3		LCC	PTY F	RNG	LEN		DN	STA	FS	LTA	ΤE	RESULT	
4		CKT	TYPE	FL	HOST	00 0 03	8 03	NO D	IRN	IDL			
5	BSY												
6	RTS												
7	DIAG												
8													
9	AIMStat	:											
10	CKTLOC												
11	Hold												
12	Next_												
13													
14													
15													
16	Prefix												
17	LCO												
18	Level												

4 Busy the NT6X18 line card by typing

>BSY

and pressing the Enter key. *Example of a MAP display:* 

```
CM MS IOD Net PM CCS LNS Trks Ext Appl
     . . . . . . . .
 .
                                                .
LTP
0 Quit Post DELQ BUSYQ PREFIX
2 Post_
3-3LCC PTY RNG....LEN..... DNSTA F S LTA TE RESULT4CDF FLHOST 00 0 03 03 4931082 MB
5 BSY
6 RTS
7 DIAG
8
9 AIMStat
10 CKTLOC
11 Hold
12 Next_
13
14
15
16 Prefix
17 LCO
18 Level
```

#### At the LCE frame

5



#### WARNING Card damage—transport

Take these precautions to protect the circuit cards from electrical and mechanical damage while transporting cards.

When handling a circuit card not in an electrostatic discharge (ESD) protective container, stand on a conductive floor mat and wear a wrist strap connected, through a 1-megohm resistor, to a suitably grounded object, such as a metal workbench or a DMS switch frame.

Store and transport circuit cards in an ESD protective container.



#### DANGER Equipment damage

Take these precautions when removing or inserting a card:

- 1. Do not apply direct pressure to the components.
- 2. Do not force the card into the slot.

Put on a wrist strap.





#### DANGER Hot materials

Exercise care when handling the line card. The line feed resistor may be very hot.

### CAUTION



**Special tools required** Card shrouds and removal tools are required for removing cards from the line drawers.

Descriptions of these shrouds follow.

Line card insertion / withdrawal tool for	Apparatus code	Common product code
3-inch cards	QTH56A	A0298291
6-inch cards	QTH58A	A0313317

*Note:* Card removal tools are required for removing cards from line drawers. Two sizes are available. Descriptions of these tools follow.

Card removal tool for	Apparatus code	Common product code		
3-4 inch cards	QTH57A	A0298292		
<i>Note:</i> For 4-inch or larger cards, use the large grip tool ITA9953.				

Remove the faulty card by opening the line drawer that was determined instep 1 and following these substeps:

- **a** Face the drawer shelf and grasp the handle at the bottom of the drawer with your right hand.
- **b** Push up on the drawer latch with your thumb and pull out the drawer until fully withdrawn. It is fully withdrawn when the drawer stop, at the top, prevents further travel.
- **c** Maintain a slight pull on the handle and lift the faceplate of the drawer approximately 2.5 cm (1 in).
- **d** While holding the drawer in this position push the bottom of the drawer, nearest the shelf with your left hand to a position about 1 cm (.5 in) to the right.
- e Hold the drawer in this position with your left hand and lower the faceplate of the drawer by releasing the grip of your right hand.
- f Ensure a card shroud and line card extractor are available.
- 7 Remove the line card to be replaced by using the following substeps:
  - a Slide a card shroud over the card to be removed and an adjacent card. If there is not an adjacent card on either side, do not use the card shroud.
  - **b** Grasp the edge of the card with a line card extractor at a point midway between the top and bottom edges. Hold the extractor in your right hand.
  - **c** Squeeze the handles of the extractor together to grasp the card tightly.
  - **d** Hold the front cover of the line drawer to steady it using your left hand.
  - e Pull the extractor away from the drawer, and the card will become unplugged from its socket on the drawer backplane.

- **f** Continue pulling the card with the extractor until the card is clear of the shroud.
- **g** Insert the card removed into the ESD container and store using local procedures.
- 8 Replace the faulty card using the following substeps:
  - **a** Remove the replacement card from the ESD container.
  - **b** Slide the card in the shroud guide slots toward the drawer backplane.
  - c Hold the front cover of the line drawer with your left hand to steady it.
  - **d** Grasp the top and bottom edges of the card with the fingers of your right hand.
  - e Push the card toward the backplane until it plugs fully into the backplane socket.
- **9** Use the following information to determine where to proceed.

If you entered this procedure from	Do
alarm clearing procedures	step 14
other	step 10

#### At the MAP terminal

#### 10

#### ATTENTION

There is a new diagnostics test for NT6X18AA/AB cards. This NT6X18 card may be good. See the notes on line cards in the general maintenance section of this book for information on running an enhanced diagnostics.

Test the NT6X18 line card by typing

>DIAG

and pressing the Enter key.

If DIAG	Do
passed	step 11
failed	step 14

**Note:** If the suffix of the NT6X18 card is AA or AB, and the line is identified as ground start (GND=Y in table LNINV), rerun diagnostics if the initial diagnostics fails. This action is possible by adding service order (SERVORD) option NPGD (negate partial ground start diagnostics). This option allows the line to be tested against a smaller subset of ground start

diagnostics. Therefore, when option NPGD is set in table LENLINES, loop detector, reversal relay, and ground start relay are omitted. For more information about SERVORD and NPGD, refer to the *XPM Translations Guide*.

**11** Return the NT6X18 card to service by typing

and pressing the Enter key.

If RTS	Do	
passed	step 12	
failed	step 13	

- 12 Send any faulty cards for repair according to local procedure.
- **13** Record the date the card was replaced, the serial number of the card, and the symptoms that prompted replacement of the card. Go to step 16.
- 14 Return the procedure that directed you to this procedure. At the point where a faulty card list was produced, identify the next faulty card on the list and go to the appropriate card replacement procedure for that card in this manual.
- **15** Obtain further assistance in replacing this card by contacting operating company maintenance personnel.
- 16 You have successfully completed this procedure. Return to the maintenance procedure that directed you to this card replacement procedure and continue as directed.

# NT6X19 in an RSC-S (DS-1) Model B LCME

### Application

Use this procedure to replace an NT6X19 card in an RSC-S LCME.

PEC	Suffixes	Name
NT6X19	AA	Message Waiting Line Circuit


### **Common procedures**

None

### Action

The following flowchart is only a summary of the procedure. To replace the card, use the instructions in the procedure that follows the flowchart.

#### Summary of card replacement procedure for NT6X19 card in RSC-S LCME



#### Replacing an NT6X19 in RSC-S LCME

#### At your Current Location

- 1 Proceed only if you have been directed to this card replacement procedure from a step in a maintenance procedure, are using the procedure for verifying or accepting cards, or have been directed to this procedure by your maintenance support group.
- 2 Obtain an NT6X19 replacement card. Ensure the replacement card has the same product equipment code (PEC), including suffix, as the card that is to be removed.

#### At the MAP terminal

**3** Post the LEN of the card to be replaced by typing

>mapci;mtc;lns;ltp;post l site lcme\_no unit\_no lsg\_no
ckt\_no

and pressing the Enter key.

where

site

is the location name of the LCME with the faulty card

lcme\_no

is the number of the LCME with the faulty card

#### unit\_no

is the number of the LCME unit with the faulty card

#### lsg no

is the number of the LSG with the faulty card

#### ckt\_no

is the number of the circuit associated with the faulty card

Example of a MAP display:

CI	4 MS	IOD	Net	PM	CCS	LNS	Trks	Ext	Appl	
•	•	•	•	•	•	•	•	•	•	
LTI	5									
		Post	DEL	0	BUSYO		PREFIX	ζ		
	Post			~						
3	-	LCC PTY	RNG	.LEN.		DN	STA F S	LTA TE	RESULT	
4		CKT TYP	E FL	HOST	00 0 03	03	NO DIRN	IDL		
5	BSY									
б	RTS									
7	DIAG									
8										
	AIMStat									
	CKTLOC									
	Hold									
	Next_									
13										
14										
15	Prefix									
	LCO									
	Level									
±0	LC VCL									,

4 Busy the NT6X19 line card by typing

>BSY

and pressing the Enter key.

Example of a MAP display:

```
MS IOD Net PM CCS LNS Trks Ext Appl
 CM
 .
LTP
0 Quit Post DELQ BUSYQ PREFIX
2 Post_
3LCC PTY RNG....LEN..... DNSTA F S LTA TE RESULT4CKT TYPE FL HOST 00 0 03 03 NO DIRN MB
5 BSY
6 RTS
7 DIAG
8
9 AIMStat
10 CKTLOC
11 Hold
12 Next_
13
14
15
16 Prefix
17 LCO
18 Level
```

#### At the LCE frame

5



#### WARNING Card damage—transport

Take the following precautions to protect circuit cards from electrical and mechanical damage during transport:

When handling a circuit card not in an electrostatic discharge (ESD) protective container, stand on a conductive floor mat and wear a wriststrap connected, through a 1-megohm resistor, to a suitably grounded object, such as a metal workbench or a DMS switch frame (Northern Telecom [Nortel] Corporate Standard 5028). Store and transport circuit cards in an ESD protective container.



#### WARNING Static electricity damage

Before removing any cards, put on a wriststrap and connect it to the wriststrap grounding point on the left side of the modular supervisory panel (MSP) of the LCME. This protects the equipment against damage caused by static electricity.



### DANGER

Equipment damage

Take the following precautions when removing or inserting a card:

- 1. Do not apply direct pressure to the components.
- 2. Do not force the cards into the slots.

## DANGER

### Hot materials

Exercise care when handling the line card. The line feed resistor may be very hot.



### CAUTION

**Special tools required** Card shrouds and removal tools are required for removing cards from the line drawers. For descriptions of these tools, refer to the following notes.

Put on a wriststrap.

*Note:* Card shrouds are required for inserting or removing cards in line drawers. Two sizes are available for use with 3-inch and 6-inch cards, as shown in the following table.

Line card insertion / withdrawal tool for	Apparatus code	Common product code
3-inch cards	QTH56A	A0298291
6-inch cards	QTH58A	A0313317

*Note:* Card removal tools are required for removing cards from line drawers. Two sizes are available, as shown in the following table.

Card removal tool for	Apparatus code	Common product code	
3—4 inch cards	QTH57A	A0298292	
<i>Note:</i> For 4-inch or larger cards, use the large grip tool ITA9953.			

6

Prepare to remove the faulty card by opening the line drawer, identified instep 1, and following these substeps:

- **a** Face the drawer shelf and grasp the handle at the bottom of the drawer with your right hand.
- **b** Push up on the drawer latch with your thumb, and pull the drawer out until fully withdrawn. It is fully withdrawn when the drawer stop, at the top, prevents further travel.
- **c** Maintain a slight pull on the handle and lift the faceplate of the drawer approximately 2.5 cm (1.0 in).
- **d** While holding the drawer in this position, push the bottom of the drawer, nearest the shelf with your left hand, to a position about 1.0 cm (0.5 in) to the right.
- e Hold the drawer in this position with your left hand, and lower the faceplate of the drawer by releasing the grip of your right hand.

- f Ensure a card shroud and line card extractor are available.
- 7 Remove the line card to be replaced by using the following substeps.
  - a Slide a card shroud over the card to be removed and an adjacent card. If there is not an adjacent card on either side, do not use the card shroud.
  - **b** Grasp the edge of the card with a line card extractor at a point midway between the top and bottom edges. Hold the extractor in your right hand.
  - **c** Squeeze the handles of the extractor together to grasp the card tightly.
  - **d** Hold the front cover of the line drawer to steady it using your left hand.
  - e Pull the extractor away from the drawer until the card becomes unplugged.
  - f Continue pulling the card with the extractor until the card is clear of the shroud.
  - **g** Insert the card removed into the ESD container and store using local procedures.
- 8 Replace the faulty card using the following substeps:
  - **a** Remove the replacement card from the ESD container.
  - **b** Slide the card in the shroud guide slots toward the drawer backplane.
  - c Hold the front cover of the line drawer with your left hand to steady it.
  - **d** Grasp the top and bottom edges of the card with the fingers of your right hand.
  - e Push the card toward the backplane until it plugs fully into the backplane socket.

#### At the MAP terminal

10

**9** Use the following information to determine where to proceed.

If you entered this procedure from	Do
alarm clearing procedures	step 14
other	step 10
Test the NT6X19 line card by typing	
>DIAG	
and pressing the Enter key.	
If DIAG	Do
passed	step 11
	step 14

### NT6X19 in an RSC-S (DS-1) Model B LCME (end)

**11** Return the NT6X19 card to service by typing

>RTS

and pressing the Enter key.

If RTS	Do	
passed	step 12	
failed	step 16	

- 12 Send any faulty cards for repair according to local procedure.
- **13** Record the date the card was replaced, the serial number of the card, and the symptoms that prompted replacement of the card. Go to step 16.
- 14 Return to the procedure that directed you to this procedure. If necessary, go to the point where a faulty card list was produced, identify the next faulty card on the list, and go to the appropriate card replacement procedure for that card in this manual.
- **15** Obtain further assistance in replacing this card by contacting operating company maintenance personnel.
- 16 You have successfully completed this procedure. Return to the maintenance procedure that directed you to this card replacement procedure and continue as directed.

# NT6X20 in an RSC-S (DS-1) Model B LCME

### Application

Use this procedure to replace an NT6X20 card in an RSC-S LCME.

PEC	Suffixes	Name
NT6X20	AA	Message Waiting Converter


### **Common procedures**

None

### Action

The following flowchart is only a summary of the procedure. To replace the card, use the instructions in the procedure that follows the flowchart.

### Summary of card replacement procedure for an NT6X20 card in an RSC-S LCME



#### Replacing an NT6X20 card in an RSC-S LCME

#### At your Current Location

- 1 Proceed only if you have been directed to this card replacement procedure from a step in a maintenance procedure, are using the procedure for verifying or accepting cards, or have been directed to this procedure by your maintenance support group.
- 2 Obtain a replacement card. Ensure the replacement card has the same product equipment code (PEC), including suffix, as the card that is to be removed.

#### At the MAP terminal

**3** Post the LEN of the card to be replaced by typing

>mapci;mtc;lns;ltp;post lCME site lcme\_no unit\_no lsg\_no
ckt\_no

and pressing the Enter key.

where

site

is the location name of the LCME with the faulty card

lcme\_no

is the number of the LCME with the faulty card

#### unit\_no

is the number of the LCME unit with the faulty card

#### lsg no

is the number of the LSG with the faulty card

#### ckt\_no

is the number of the circuit associated with the faulty card

Example of a MAP display:

CI	M MS	IOD	Net	PM	CCS	LNS	Trks	Ext	Appl	
•	•	•	•	•	•	•	•	•	•	
LTI	C									
		Post	DEL	0	BUSYO		PREFIX	ζ		
	Post_			~	~					
3		LCC PTY	RNG	.LEN		DN	STA F S	LTA TE	RESULT	
4		CKT TYPE	5 FL	HOST	00 0 03	03 N	IO DIRN	IDL		
5	BSY									
	RTS									
	DIAG									
8	A TMOL									
	AIMStat CKTLOC									
	Hold									
	Next_									
13	nono_									
14										
15										
16	Prefix									
	LCO									
18	Level									

4 Busy the NT6X20 line card by typing

>BSY

and pressing the Enter key. *Example of a MAP display:* 

CM MS IOD Net PM CCS LNS Trks Ext Appl . . . . . . . . . . . . LTP 0 Quit Post DELQ BUSYQ PREFIX 3 5 BSY 6 RTS 7 DIAG 8 9 AIMStat 10 CKTLOC 11 Hold 12 Next\_ 13 14 15 16 Prefix 17 LCO 18 Level

#### At the LCE frame

5



#### WARNING Card damage—transport

Take the following precautions to protect circuit cards from electrical and mechanical damage during transport:

When handling a circuit card not in an electrostatic discharge (ESD) protective container, stand on a conductive floor mat and wear a wriststrap connected, through a 1-megohm resistor, to a suitably grounded object, such as a metal workbench or a DMS switch frame (Northern Telecom [Nortel] Corporate Standard 5028). Store and transport circuit cards in an ESD protective container.



#### WARNING Static electricity damage

Before removing any cards, put on a wriststrap and connect it to the wriststrap grounding point on the left side of the modular supervisory panel (MSP) of the LCME. This protects the equipment against damage caused by static electricity.



### DANGER

Equipment damage

Take the following precautions when removing or inserting a card:

- 1. Do not apply direct pressure to the components.
- 2. Do not force the cards into the slots.

## DANGER

### Hot materials

Exercise care when handling the line card. The line feed resistor may be very hot.



#### CAUTION

**Special tools required** Card shrouds and removal tools are required for removing cards from the line drawers. For descriptions of these tools, refer to the following notes.

Put on a wriststrap.

*Note:* Card shrouds are required for inserting or removing cards in line drawers. Two sizes are available for use with 3-inch and 6-inch cards, as shown in the following table.

Line card insertion / withdrawal tool for	Apparatus code	Common product code
3-inch cards	QTH56A	A0298291
6-inch cards	QTH58A	A0313317

*Note:* Card removal tools are required for removing cards from line drawers. Two sizes are available, as shown in the following table.

Card removal tool for	Apparatus code	Common product code	
3—4 inch cards	QTH57A	A0298292	
<i>Note:</i> For 4-inch or larger cards, use the large grip tool ITA9953.			

6

Prepare to remove the faulty card by opening the line drawer, identified instep 1, and following these substeps:

- **a** Face the drawer shelf and grasp the handle at the bottom of the drawer with your right hand.
- **b** Push up on the drawer latch with your thumb, and pull the drawer out until fully withdrawn. It is fully withdrawn when the drawer stop, at the top, prevents further travel.
- **c** Maintain a slight pull on the handle and lift the faceplate of the drawer approximately 2.5 cm (1.0 in).
- **d** While holding the drawer in this position, push the bottom of the drawer, nearest the shelf with your left hand, to a position about 1.0 cm (0.5 in) to the right.
- e Hold the drawer in this position with your left hand and lower the faceplate of the drawer by releasing the grip of your right hand.

- f Ensure a card shroud and line card extractor are available.
- 7 Remove the line card to be replaced by following these substeps:
  - **a** Slide a card shroud over the card to be removed and an adjacent card. If there is not an adjacent card on either side, do not use the card shroud.
  - **b** Grasp the edge of the card with a line card extractor at a point midway between the top and bottom edges. Hold the extractor in your right hand.
  - **c** Squeeze the handles of the extractor together to grasp the card tightly.
  - **d** Hold the front cover of the line drawer to steady it using your left hand.
  - e Pull the extractor away from the drawer until the card becomes unplugged from its socket on the drawer backplane.
  - f Continue pulling the card with the extractor until the card is clear of the shroud.
  - **g** Insert the card removed into the ESD container and store using local procedures.
- 8 Replace the faulty card using the following substeps:
  - a Remove the replacement card from the ESD container.
  - **b** Slide the card in the shroud guide slots toward the drawer backplane.
  - c Hold the front cover of the line drawer with your left hand to steady it.
  - **d** Grasp the top and bottom edges of the card with the fingers of your right hand.
  - e Push the card toward the backplane until it plugs fully into the backplane socket.
- **9** Use the following information to determine where to proceed.

If you entered this procedure from	Do
alarm clearing procedures	step 14
other	step 10

#### At the MAP terminal

**10** Test the NT6X20 line card by typing

>DIAG

and pressing the Enter key.

If DIAG	Do
passed	step 11
failed	step 14

11 Return the NT6X20 card to service by typing

>RTS

and pressing the Enter key.

If RTS	Do	
passed	step 12	
failed	step 15	

- 12 Send any faulty cards for repair according to local procedure.
- **13** Record the date the card was replaced, the serial number of the card, and the symptoms that prompted replacement of the card. Go to step 16.
- 14 Return to the procedure that directed you to this procedure. If necessary, go to the point where a faulty card list was produced, identify the next faulty card on the list, and go to the appropriate card replacement procedure for that card in this manual.
- **15** Obtain further assistance in replacing this card by contacting operating company maintenance personnel.
- 16 You have successfully completed this procedure. Return to the maintenance procedure that directed you to this card replacement procedure and continue as directed.

# NT6X21 in an RSC-S (DS-1) Model B LCME

### Application

Use this procedure to replace an NT6X21 card in an RSC-S LCME.

PEC	Suffixes	Name
NT6X21	AA, AB, AC	Line Card Type C (IBN Electronic Business Set)
NT6X21	AD	Enhanced EBS Line Card for Universal Digital Loop Carriers


### **Common procedures**

None

### Action

The following flowchart is only a summary of the procedure. To replace the card, use the instructions in the procedure that follows the flowchart.

### Summary of card replacement procedure for an NT6X21 card in RSC-S LCME



#### Replacing an NT6X21 card in an RSC-S LCME

#### At your Current Location

- 1 Proceed only if you have been directed to this card replacement procedure from a step in a maintenance procedure, are using the procedure for verifying or accepting cards, or have been directed to this procedure by your maintenance support group.
- 2 Obtain an NT6X21 replacement card. Ensure the replacement card has the same product equipment code (PEC), including suffix, as the card that is to be removed.

#### At the MAP terminal

**3** Post the LEN of the card to be replaced by typing

>mapci;mtc;lns;ltp;post l site lcme\_no unit\_no lsg\_no
ckt\_no

and pressing the Enter key.

where

#### site

is the location name of the LCME with the faulty card

#### lcme\_no

is the number of the LCME with the faulty card

unit\_no

is the number of the LCME unit with the faulty card

#### lsg no

is the number of the LSG with the faulty card

#### ckt\_no

is the number of the circuit associated with the faulty card

Example of a MAP display:

CM MS IOD Net PM CCS LNS Trks Ext Appl • . . . . . . · · . LTP Post DELQ 0 Quit BUSYQ PREFIX 2 Post\_ LCC PTY RNG....LEN..... DN STA F S LTA TE RESULT 3 CKT TYPE FL HOST 00 0 03 03 NO DIRN IDL 4 5 BSY 6 RTS 7 DIAG 8 9 AIMStat 10 CKTLOC 11 Hold 12 Next\_ 13 14 15 16 Prefix 17 LCO 18 Level

4 Busy the NT6X21 line card by typing

>BSY

and pressing the Enter key. Example of a MAP display:

```
MS IOD Net PM CCS LNS Trks Ext
                                             Appl
CM
          .
                        . .
               . .
                                    .
                                         .
.
     .
                                               .
LTP
0 Quit Post DELQ BUSYQ
                                 PREFIX
2 Post_
       LCC PTY RNG....LEN..... DN STA F S LTA TE RESULT
3
       CKT TYPE FL HOST 00 0 03 03 NO DIRN MB
4
5 BSY
6 RTS
7 DIAG
8
9 AIMStat
10 CKTLOC
11 Hold
12 Next_
13
14
15
16 Prefix
17 LCO
18 Level
```

#### At the LCE frame

5



### WARNING

**Card damage—transport** Take the following precautions to protect circuit cards from electrical and mechanical damage during transport:

When handling a circuit card not in an electrostatic discharge (ESD) protective container, stand on a conductive floor mat and wear a wriststrap connected, through a 1-megohm resistor, to a suitably grounded object, such as a metal workbench or a DMS switch frame (Northern Telecom [Nortel] Corporate Standard 5028). Store and transport circuit cards in an ESD protective container.



#### WARNING Static electricity damage

Before removing any cards, put on a wriststrap and connect it to the wriststrap grounding point on the left side of the modular supervisory panel (MSP) of the LCME. This protects the equipment against damage caused by static electricity.



### DANGER

Equipment damage

Take the following precautions when removing or inserting a card:

- 1. Do not apply direct pressure to the components.
- 2. Do not force the cards into the slots.

#### DANGER Hot materia

Hot materials Exercise care when handling the line card. The line feed

resistor may be very hot.



#### CAUTION

**Special tools required** Card shrouds and removal tools are required for removing cards from the line drawers. For descriptions of these tools, refer to the following notes.

Put on a wriststrap.

*Note:* Card shrouds are required for inserting or removing cards in line drawers. Two sizes are available for use with 3-inch and 6-inch cards, as shown in the following table.

Line card insertion / withdrawal tool for	Apparatus code	Common product code
3-inch cards	QTH56A	A0298291
6-inch cards	QTH58A	A0313317

*Note:* Card removal tools are required for removing cards from line drawers. Two sizes are available, as shown in the following table.

Card removal tool for	Apparatus code	Common product code
3—4 inch cards	QTH57A	A0298292
Note: For 4-inch or larg	ger cards, use the large g	rip tool ITA9953.

6

Prepare to remove the faulty card by opening the line drawer and following these substeps:

- **a** Face the drawer shelf and grasp the handle at the bottom of the drawer with your right hand.
- **b** Push up on the drawer latch with your thumb and pull the drawer out until fully withdrawn. It is fully withdrawn when the drawer stop, at the top, prevents further travel.
- **c** Maintain a slight pull on the handle and lift the faceplate of the drawer approximately 2.5 cm (1.0 in).
- **d** While holding the drawer in this position, push the bottom of the drawer, nearest the shelf with your left hand, to a position about 1.0 cm (0.5 in) to the right.
- e Hold the drawer in this position with your left hand and lower the faceplate of the drawer by releasing the grip of your right hand.

- f Ensure a card shroud and line card extractor are available.
- 7 Remove the line card to be replaced by following these substeps:
  - **a** Slide a card shroud over the card to be removed and an adjacent card. If there is not an adjacent card on either side, do not use the card shroud.
  - **b** Grasp the edge of the card with a line card extractor at a point midway between the top and bottom edges. Hold the extractor in your right hand.
  - c Squeeze the handles of the extractor together to grasp the card tightly.
  - **d** Hold the front cover of the line drawer to steady it using your left hand.
  - e Pull the extractor away from the drawer until the card becomes unplugged from its socket on the drawer backplane.
  - **f** Continue pulling the card with the extractor until the card is clear of the shroud.
  - **g** Insert the card removed into the ESD container and store using local procedures.
- 8 Replace the faulty card using the following substeps:
  - a Remove the replacement card from the ESD container.

If the line card suffix is	Do
AA, AB, or AC	step c
AD	step b

**b** Make DIP switch changes to the replacement NT6X21AD card to match DIP switch settings of the card being replaced, or as defined in the following table.

	D/A voi	ce S1	Balanc	e S2	Signaling levels S3 and S4				
	Switch position ON OFF		Switch position ON OFF		Both ON S4 ON S3 O			Both N OFF	
Recommended application	0dB	-3.5 dB	NL	9+2	1.3 Vpp	0.8 Vpp	0.6 Vpp	0.14 Vpp	
P-phone sets long loop: 19-24dB EML	Х		Х		Х				
P-phone sets medium loop: 17-19dB EML	Х		Х			Х			
P-phone sets medium loop: 4-17dB EML		Х		х			х		
P-phone sets short loops: 0-4dB EML		Х		Х				Х	
Nortel UDLCs		Х	Х					Х	
Other vendors UDLCs	Х			Х			Х		
6X21AC equivalent mode		Х	Х		Х				

#### Recommended NT6X21AD S1 DIP switch settings

*Note:* dB=decibel, NL=nonloaded, Vpp=voltage peak to peak, EML=estimated measured loss, as defined in NTP 297-2011-180, BCS35 version 01.02

- c Slide the card in the shroud guide slots toward the drawer backplane.
- **d** Hold the front cover of the line drawer with your left hand to steady it.
- **e** Grasp the top and bottom edges of the card with the fingers of your right hand.
- f Push the card toward the backplane until it plugs fully into the backplane socket.

9 Use the following information to determine where to proceed. If you entered this procedure Do from alarm clearing procedures step 14 other step 10 At the MAP terminal 10 Test the NT6X21 line card by typing >DIAG and pressing the Enter key. If DIAG Do step 11 passed failed step 15 11 Return the NT6X21 card to service by typing >RTS and pressing the Enter key. If RTS Do passed step 12 failed step 15 12 Send any faulty cards for repair according to local procedure. 13 Record the date the card was replaced, the serial number of the card, and the symptoms that prompted replacement of the card. Go to step16. 14 Return to the procedure that directed you to this procedure. If necessary, go to the point where a faulty card list was produced, identify the next faulty card on the list, and go to the appropriate card replacement procedure for that card in this manual. 15 Obtain further assistance in replacing this card by contacting operating company maintenance personnel. 16 You have successfully completed this procedure. Return to the maintenance

procedure that directed you to this card replacement procedure and continue

as directed.

### NT6X30 in an RSC-S (DS-1) Model B LCME

### Application

Use this procedure to replace an NT6X30 card in an RSC-S LCME.

PEC	Suffixes	Name
NT6X30	HA	Ringing Generator


### **Common procedures**

None

### Action

The following flowchart is only a summary of the procedure. To replace the card, use the instructions in the procedure that follows the flowchart.

#### Summary of replacing an NT6X30 card in RSC-S LCME



#### Replacing an NT6X30 in RSC-S LCME

At your Current Location

1



### CAUTION

Loss of service

This procedure includes directions to manually busy one or more peripheral module (PM) units. Since manually busying a PM unit can cause service degradation, perform this procedure only if necessary to restore out-of-service components. Otherwise, carry out this procedure during periods of low traffic.

Proceed only if you were either directed to this card replacement procedure from a step in a maintenance procedure, are using the procedure for verifying or accepting cards, or were directed to this procedure by your maintenance support group.

2 Obtain an approved replacement card.

#### At the MAP terminal

3 Access the PM level and post the LCME by typing

>MAPCI;MTC;PM;POST LCME lcme\_site\_name lcme\_frame\_no lcme\_no

and pressing the Enter key.

where

Icme\_site\_name

is the name of the site at which the LCME is located

Icme\_frame\_no is the number of the frame in which the LCME is located

lcme\_no

is the number of the LCME with the faulty card


Example of a MAP display

4 Check the state of the PM units.

5

If the PM or PM units are	e Do
offl or SysB	step 5
One unit is InSv or 3 or SysB	ISTb the other unit is ISTb step 6
heck the state of the othe	r PM in the frame.
heck the state of the othe	r PM in the frame. <b>Do</b>

Record the numbers of the PM units serviced by the faulty RG you are replacing. 6



7 The next action depends on the type of LCM alarm indicated.

If the alarm is	Do
critical	step 9
major or minor	step 8

8 Switch ringing generator activity from the faulty unit, if necessary, by typing >SWRG UNIT unit\_no and pressing the Enter key.

#### where

unit\_no

is the PM unit number (0 or 1) assigned to the faulty RG

If the SWRG command	Do
passed	step 9
failed	step 38

9

10

Manually-busy (ManB) the PM unit associated with the faulty RG by typing

>BSY UNIT unit\_no

and pressing the Enter key.

where

unit no

is the PM unit number (0 or 1) associated with the faulty RG

*Note:* If clearing a critical alarm choose either unit to work on.

Example of a MAP response:

LCME RSC-S 14 0 Unit 0 Bsy Passed

*Note:* Repeat this command for the other PM in the frame.

The next action depends on how many LCMEs are provisioned in the equipment frame.

If there	Do
is one LCME provisioned in the frame	step 14
two LCMEs provisioned in the frame, and you have not switched RG activity for both LCMEs	step 11
two LCMEs provisioned in the frame, and you have switched RG activity for both LCMEs	step 12
Repeat step 3 through step 10 for the other LCME provisio equipment frame.	oned in the
Post both PMs in the frame and ensure all units are now or typing	n the good RG by
>POST LCME site frame_no lcme_no site frame	_no lcme_no
and pressing the Enter key.	
where	
site	

is the PM location (alphanumeric) of the first LCME

#### frame no

is the frame number (00 to 511) of the first LCME

#### Icme no

is the number of the first LCM (0 or 1) in the frame,

#### site

is the LCM location (alphanumeric) of the second LCME

#### frame\_no

is the frame number (00 to 511) of the second LCME

#### Icme no

is the number of the second LCM (0 or 1) in the frame,

#### Example of command

>POST LCME RSC-S 14 0 RSC-S 14 1

#### Example of a MAP display:

LCME RSC-S 14 0 ISTb Links OOS: Cside 0 Pside 0 Unit 0:ISTb /RG:1 Jnit 1: InSv /RG:1 11 11 11 RG: Pref 0 ISTb Drwr: 01 23 45 67 89 023 45 Stby 1 InSv .. .. .. .. .. .. ..

Examine the other PM in the frame by typing

#### >NEXT

and pressing the Enter key.

Example of a MAP display:

LCME R	SC-S	14	1 IS	Tb L	inks	003	s: C	side (	) Pside O
Unit 0:ISTb /RG:1									
Unit 1	: In	Sv		/RG:	1				
									3: Pref O ISTb
Drwr:	01	23	45	67	89	023	45		Stby 1 InSv
			••						

If both PMs are	Do
on the good RG	step 14
not on the good RG	step 13

<sup>13</sup> Repeat step 3 through step 12 for the other PM provisioned in the equipment frame.

#### At the RCE/LCEI frame

14



#### WARNING Static electricity damage

Before removing any cards, put on a wrist strap and connect it to the wrist strap grounding point on the left side of the modular supervisory panel (MSP) of the LCME. This protects the equipment against damage caused by static electricity.

Put on a wrist strap.

#### 15



### DANGER

Risk of personal injury

Ensure that you switch off the correct circuit breaker on the MSP as described below. Do not proceed until you have located and switched OFF the correct circuit breaker for the RG you are replacing.

Turn the circuit breaker that powers the faulty ringing generator OFF. Ensure that ringing generator 0 is on circuit breaker 03-65-01. Ensure that ringing generator 1 is on circuit breaker 03-65-02.

16




### WARNING


#### Do not hold the card by the levers only

Holding a card by the locking levers only may break one or both levers. Once the card has been pulled half way out of the shelf, carefully grasp the card underneath for more secure support and continue to remove the card from the shelf. Avoid touching any wires or internal parts on the card.

Open the locking levers on the face of the card.



17 While grasping the locking levers, gently pull the card towards you until it protrudes approximately halfway out of the shelf.



- 18 While grasping the card by the face plate with one hand and supporting the card from the bottom with the other hand, gently pull the card towards you until it clears the shelf.
- **19** Place the card you have removed in an electrostatic discharge (ESD) protective container.

20



#### CAUTION Loss of service

Incorrect DIP switch setting can result in a service outage. Check the DIP switch layout for the switch numbering and for the ON and OFF position.



### WARNING

Potential equipment damage

The newer versions of the ringing generator (versions with suffixes BB, CA, DB, HA, or JA) use switch 8. Ensure that switch 8 is in the ON position on the replacement card.

Set the DIP switch settings on the replacement card.

*Note:* If you are replacing an older version of the NT6X30 with a newer version (newer versions have suffixes BB, CA, DB, HA, or JA), switch 8 must be in the ON position on the replacement card. If in doubt, contact your next level of support.

### 21




### WARNING

Equipment damage


Take the following precautions when removing or inserting a card:

- 1. Do not apply direct pressure to the components.
- 2. Do not force the cards into the slots.

Open the locking levers on the replacement card. Align the card with the right slot in the shelf and gently slide the card into the shelf.



- 22 Seat and lock the card.
  - **a** Using your fingers or thumbs, push on the upper and lower edges of the faceplate to ensure that the card is fully seated in the shelf.
  - **b** Close the locking levers to secure the card.



**23** Turn circuit breakers back ON. Ensure that ringing generator 0 is on circuit breaker 03-65-01. Ensure that ringing generator 1 is on circuit breaker 03-65-02.

	lf	Do
	the circuit breaker remains switched and the LED light on the FSP goes out	step 24
	the circuit breaker trips or the LED light on the FSP does not go out	step 38
24	The next action depends on your reason for performing this	procedure.
	If you were	Do
	directed to this procedure from a maintenance proce- dure	step 25
	not directed to this procedure from a maintenance procedure	step 26
25	Return to the maintenance procedure that sent you to this p continue as directed.	rocedure and
At the	MAP terminal	
26	Post an LCME in the frame by typing	
	>POST LCME site frame_no lcme_no	
	and pressing the Enter key.	
	where	
	site is the PM location (alphanumeric)	
	frame_no is the frame number (00 to 511)	
	Icme_no is the number of the LCME unit posted in step 3	
27	Wait until there is no system-initiated maintenance on the un	nit.
28	Return the ManB unit to service by typing	
	>RTS UNIT unit_no	
	and pressing the Enter key.	
	where	
	unit_no is the number (0 or 1) of the LCME unit	

29 Switch ringing generator activity to the new NT6X30 card by typing >SWRG UNIT unit\_no and pressing the Enter key. where unit no is the PM unit number (0 or 1) Example of a MAP display: LCME RSC-S 14 0 InSv Links OOS: Cside 0 Pside 0 Unit 0: InSv /RG:1 Unit 1: InSv /RG:1 11 11 11 RG: Pref 0 InSv Drwr: 01 23 45 67 89 023 45 Stby 1 InSv . . . . .. .. . . .. .. If the SWRG command Do passed, and RG activity must be switched for the othstep 30 er unit passed, and RG activity is acceptable for both PM step 31 units failed step 38 30 Repeat step 29 for the other PM unit. 31 Test the new RG by typing >TST PM and pressing the Enter key. Example of a MAP response: LCME RSC-S 14 0 Unit 1 InSvce Tests Initiated LCME RSC-S 14 0 Unit 0 InSvce Tests Initiated LCME RSC-S 14 0 Unit1 Tst Passed LCME RSC-S 14 0 Unit 0 Tst Passed If the TST command Do passed step 32 failed step 35 32 Align RG activity to the preferred RG by typing >SWRG UNIT unit\_no

and pressing the Enter key.

where

as directed.

unit\_no

is the PM unit number (0 or 1)

Example of a MAP display:

Unit	0:	InSv		/R	G:0	008	5: C:	side	0 Pside 0
Unit 1	: In	Sv		/RG:	0				
Drwr:	01	23	45	67	89				RG: Pref 0 InSv Stby 1 InSv
	••	••	••	••	••	••	••	••	

**33** The next action depends on how many LCMEs are provisioned in the equipment frame.

If there	Do
one LCME provisioned in the frame	step 35
two LCMEs provisioned in the frame, and you have not switched RG activity for both LCMEs	step 34
two LCMEs provisioned in the frame, and you have switched RG activity for both LCMEs	step 35
Repeat steps 28 to 33 for the other LCME provisioned in the frame.	equipment
Send any faulty cards for repair according to local procedure	
Record the date the card was replaced, the serial number of the symptoms that prompted replacement of the card. Go to step	
Consult office personnel to determine why the component is c as directed by office personnel.	offline. Continue
Obtain further assistance in replacing this card by contacting responsible for higher level of support.	the personnel
You have successfully completed this procedure. Return to the procedure that directed you to this card replacement procedu	

### NT6X51 in an RSC-S (DS-1) Model B LCME

### Application

Use this procedure to replace an NT6X51 card in an RSC-S LCM.


PEC	Suffixes	Name
NT6X51	AB, AC	Extended LCM Processor


### **Common procedures**

None

### Action

The following flowchart is only a summary of the procedure. To replace the card, use the instructions in the procedure that follows the flowchart.





## Replacing an NT6X51 card in an RSC-S LCM

## ATTENTION

Proceed only if you have been directed to this card replacement procedure from a step in a maintenance procedure, are using the procedure for verifying or accepting cards, or have been directed to this procedure by your maintenance support group.

## At your Current Location

1



#### CAUTION Loss of service

This procedure includes directions to manually busy one or more peripheral module (PM) units. Since manually busying a PM unit can cause service degradation, perform this procedure only if necessary to restore out-of-service components. Otherwise, carry out this procedure during periods of low traffic.

Obtain an NT6X51 replacement card. Ensure the replacement card has the same product equipment code (PEC), including suffix, as the card that is to be removed.

## At the MAP terminal

2 Access the PM level of the MAP display and post the LCM with the faulty NT6X51 card by typing

>MAPCI;MTC;PM;POST LCM lcm\_site\_name lcm\_frame\_no lcm\_no

and pressing the Enter key.

Example of a MAP response:

where

Icm site name

is the name of the site at which the LCM is located

lcm\_frame\_no

is the number of the frame in which the LCM is located

lcm\_no

is the number of the LCM with the faulty card

**3** Busy the LCM unit associated with the faulty card by typing

>BSY UNIT lcm\_unit\_no

and pressing the Enter key.

#### where

#### lcm\_unit\_no

is the number of the LCM unit associated with the faulty NT6X51 card

Example of a MAP response:

LCM	RemL OO O IS	3Tb Links	_00S: CSide	1 PSide 0
Unit-0	: InSv Mtce	Take0ver	/RG: 0	
Unit-1	: ManB Mtce		/RG: 0	
		11 11 11	11 11	RG:Pref:0 InSv
Drwr:	01 23 45 67 8	39 01 23 45	67 89	Stby:1 InSv

## At the LCE frame

4

5



## DANGER

Card damage—transport

Take the following precautions to protect circuit cards from electrical and mechanical damage during transport:

When handling a circuit card not in an electrostatic discharge (ESD) protective container, stand on a conductive floor mat and wear a wriststrap connected, through a 1-megohm resistor, to a suitably grounded object, such as a metal workbench or a DMS switch frame (Northern Telecom [Nortel] Corporate Standard 5028). Store and transport circuit cards in an ESD protective container.




#### DANGER

Static electricity damage


Before removing any cards, put on a wriststrap and connect it to the wriststrap grounding point on the left side of the modular supervisory panel (MSP) of the LCM. This protects the equipment against damage caused by static electricity.

Put on a wriststrap.


- Remove the NT6X51 card as shown in the following figures.
  - a Locate the card to be removed on the appropriate shelf.



**b** Open the locking levers on the card to be replaced and gently pull the card toward you until it clears the shelf.



- **c** Ensure the replacement card has the same PEC, including suffix, as the card just removed.
- 6 Open the locking levers on the replacement card.
  - **a** Align the card with the slots in the shelf.
  - **b** Gently slide the card into the shelf.



7



## DANGER


Equipment damage

Take the following precautions when removing or inserting a card:

- 1. Do not apply direct pressure to the components.
- 2. Do not force the cards into the slots.

Seat and lock the card.

- **a** Using your fingers or thumbs, push on the upper and lower edges of the faceplate to ensure the card is fully seated in the shelf.
- **b** Close the locking levers



8 Use the following information to determine where to proceed.

If you entered this procedure from	Do
alarm clearing procedures	step 13
other	step 9

## At the MAP terminal

9 Load the inactive LCM unit by typing

>loadpm unit lcm\_unit\_no CC

and pressing the Enter key.

where

## lcm\_unit\_no

is the number of the LCM unit busied in step 3

If load	Do
passed	step10
failed	step 14

## **10** Return the LCM unit to service by typing

>RTS UNIT lcm\_unit\_no

and pressing the Enter key.

where

Icm\_unit\_no
 is the number of the LCM unit busied in step 3

If RTS	Do				
passed	step 11				
failed	step 14				
Send any faulty cards for repair according to local procedure.					
Record the date the card was replaced, the serial number of the card, and the					

- symptoms that prompted replacement of the card. Go to step 15.13 Return to the Alarm Clearing Procedures that directed you to this procedure
- and continue as directed.
- 14 Obtain further assistance in replacing this card by contacting operating company maintenance personnel.
- 15 You have successfully completed this procedure. Return to the maintenance procedure that directed you to this card replacement procedure and continue as directed.

11 12

# NT6X52 in an RSC-S (DS-1) Model B LCME

# Application

Use this procedure to replace an NT6X52 card in an RSC-S LCME.

PEC	Suffixes	Name
NT6X52	AA	Digroup Control card


# **Common procedures**

None

# Action

The following flowchart is only a summary of the procedure. To replace the card, use the instructions in the procedure that follows the flowchart.

Summary of card replacement procedure for an NT6X52 card in RSC-S LCME



#### Replacing an NT6X52 card in RSC-S LCME

#### At your Current Location

- 1 Proceed only if you have been directed to this card replacement procedure from a step in a maintenance procedure, are using the procedure for verifying or accepting cards, or have been directed to this procedure by your maintenance support group.
- 2 Obtain a replacement card. Ensure the replacement card has the same product equipment code (PEC), including suffix, as the card that is to be removed.

#### At the MAP terminal

3 Set the MAP to the PM level and post the LCME by typing

>MAPCI;MTC;PM;POST LCME lcme\_site\_name lcme\_frame\_no lcme\_no

and pressing the Enter key.

where

Icme\_site\_name is the name of the site at which the LCME is located

lcme\_frame\_no

is the number of the frame in which the LCME is located

Icme no

is the number of the LCME unit with the faulty card

Example of a MAP response:

(	CM MS	IOD	Net		CCS	LNS	Trks	Ext	Appl
		•	•	•	•	·	•	•	
	LCME	SΣ	/sB	ManB	OffL	CE	sy	ISTb	InSv
	0 Quit	PM	0	0	0		0	0	130
	2 Post_ 3	LCME	0	0	0		0	0	0
	3 4 Swrg_ 5 Trnsl_ 6 Tst_ 7 Bsy_ 8 RTS_ 9 OffL_ 10 LoadPM_ 11 Disp_ 12 Next_ 13 14 QueryPM 15 16 17 18	Unit 0: Unit 1:	InSv InSv		11 11 1	/RG: /RG: 1	0 1 RG:Pr	ef:0 InSv by:1 InSv	

4 Busy the LCME by typing

>BSY UNIT lcme\_unit\_no

and pressing the Enter key.

where

## lcm\_unit\_no

is the number of the LCME posted in step 3

Example of a MAP response:

_										
C	M MS	IOD	Net	PM	CCS	LNS	Trks	Ext	Appl	
	•	•		1LCME		•		•	•	
LC	ME		SysB	ManB	OffL	CE	sy	ISTb	InSv	
0	Quit	PM	0	1	0		0	0	130	
2	Post_	LCME	0	1	0		0	0	0	
3										
4	SwRg	LCME	RemL O	0 0 ISTE	Links_C	oos: cs	Side 1 E	Side 0		
5	Trnsl	Unit-0	): InSv	Mtce I	ake0ver	/RG:	0			
6	Tst	Unit-1	: ManB	Mtce		/RG:	0			
7	Bsy				11 11 11	L	RG:Pref	:0 InSv		
8	RTS	Drwr:	01 23 4	5 67 89	01 23 45	5	Stby	v:1 InSv		
9	OffL						_			
10	LoadPM									
11	Disp_									
12	Next									
13										
14	QueryPM									
15										
16										
17										
18										
$\overline{}$										/

## At the LCE frame

5



#### DANGER Card damage—transport

Take the following precautions to protect circuit cards from electrical and mechanical damage during transport:

When handling a circuit card not in an electrostatic discharge (ESD) protective container, stand on a conductive floor mat and wear a wriststrap connected, through a 1-megohm resistor, to a suitably grounded object, such as a metal workbench or a DMS switch frame (Northern Telecom [Nortel] Corporate Standard 5028). Store and transport circuit cards in an ESD protective container.



# DANGER

#### Static electricity damage

Before removing any cards, put on a wriststrap and connect it to the wriststrap grounding point on the left side of the modular supervisory panel (MSP) of the LCME. This protects the equipment against damage caused by static electricity.



## DANGER

Equipment damage

Take the following precautions when removing or inserting a card:


- 1. Do not apply direct pressure to the components.
- 2. Do not force the cards into the slots.

Put on a wriststrap.


6

Remove the NT6X52 card as shown in the following figures.


a Locate the card to be removed on the appropriate shelf.



**b** Open the locking levers on the card to be replaced and gently pull the card toward you until it clears the shelf.



- **c** Ensure the replacement card has the same PEC, including suffix, as the card you just removed.
- 7 Open the locking levers on the replacement card.
  - **a** Align the card with the slots in the shelf.
  - **b** Gently slide the card into the shelf.



8




#### DANGER Equipment damage

Take the following precautions when removing or inserting a card:

- 1. Do not apply direct pressure to the components.
- 2. Do not force the cards into the slots.

Seat and lock the card.

- **a** Using your fingers or thumbs, push on the upper and lower edges of the faceplate to ensure the card is fully seated in the shelf.
- **b** Close the locking levers



At the	MAP terminal						
9	Load the inactive LCME unit by typin	ıg					
	<i>&gt;loadpm unit</i> lcme_unit_no C	C					
	and pressing the Enter key.						
	where						
	Icme_unit_no is the number of the LCME ur	nit busied in step 4					
	If load	Do					
	passed	step 10					
	failed	step 16					
10	Test the LCME unit by typing						
	>TST UNIT lcme_unit_no						
	and pressing the Enter key.						
	where						
	lcme_unit_no is the number of the LCME ur	nit loaded in step 9					
	If TST	Do					
	passed	step 11					
	failed	step 15					
11	Use the following information to dete	rmine where to proceed.					
	If you entered this procedure from	Do					
	alarm clearing procedures	step 15					
	other	step 12					
12	Return the LCME unit to service by t	yping					
	<pre>&gt;RTS UNIT lcme_unit_no</pre>						
	and pressing the Enter key.						
	where						
	Icme_unit_no is the number of the LCME ur	nit tested in step 10					
	If RTS	Do					
	passed	step 13					

If RTS	Do			
failed	step 16			
Send any faulty of	ards for repair according to local procedure.			
	he card was replaced, the serial number of the card, and the compted replacement of the card. Go to step 17.			
Return to the procedure that directed you to this procedure. At the point where a faulty card list was produced, identify the next faulty card on the list and go to the appropriate card replacement procedure for that card in <i>Card Replacement Procedures</i> .				
Obtain further as company mainte	sistance in replacing this card by contacting operating nance personnel.			
	sfully completed this procedure. Return to the maintenance rected you to this card replacement procedure and continue			

# NT6X53 in an RSC-S (DS-1) Model B LCM(E)

## Application

Use this procedure to replace an NT6X53 card in an RSC-S LCM(E).

PEC	Suffixes	Name
NT6X53	CA	Power Converter


# **Common procedures**

None

# Action

The following flowchart is only a summary of the procedure. To replace the card, use the instructions in the procedure that follows the flowchart.

## Summary of card replacement procedure for an NT6X53 card in RSC-S LCM(E)



### Replacing an NT6X53 card in RSC-S LCM(E)

#### At your Current Location

- 1 Proceed only if you have been directed to this card replacement procedure from a step in a maintenance procedure, are using the procedure for verifying or accepting cards, or have been directed to this procedure by your maintenance support group.
- 2 Obtain an NT6X53 replacement card. Ensure the replacement card has the same product equipment code (PEC), including suffix, as the card that is to be removed.

#### At the MAP terminal

3 Set the MAP display to the PM level and post the LCM(E) unit by typing

>MAPCI;MTC;PM;POST LCM(E) lcm(e)\_site\_name lcm(e)\_frame\_no lcm(e)\_no

and pressing the Enter key.

where

**Icm(e)\_site\_name** is the name of the site at which the LCM(E) is located

lcm(e)\_frame\_no

is the number of the frame in which the LCM(E) is located

lcm(e)\_no

is the number of the LCM(E) with the faulty card

Example of a MAP response:

CI	i MS	IOD	Net	РМ	CCS	LNS	Trks	Ext	Appl
•	•	•	•	•	•	•	•	•	•
LCM	Œ		SysB	ManB	OffL	CE	sy	ISTb	InSv
0	Quit	PM	4	0	10	)	3	3	130
	Post_	LCME	1	0	!	5	0	1	9
3 4	Swrg_	LCME	RemL	00 0 IS	STb Lin	ks_00S:	CSid	e 1	
5	Trnsl_	Unit-	-0: In:	Sv			/RG:	0	
6	Tst_	Unit-	-1: In:	Sv			/RG:	0	
7	Bsy_				11 11	11		RG:Pref:	0 InSv
8	RTS_	Drwr	: 01 23	45 67 89	9 01 23	45		Stby:	l InSv
9	OffL_					••			
10	LoadPM_								
11	Disp_								
	Next_								
13									
	QueryPM								
15									
16									
17									
18									

4 Busy the LCM(E) by typing

>BSY UNIT lcm(e)\_unit\_no

and pressing the Enter key.

where

lcm(e)\_unit\_no

is the number of the LCM(E) unit

Example of a MAP response:

Cī	n MS	IOD	Net	PM 1LCME		LNS	Trks	Ext	Appl
•	•	•	•	100110	•	•	•	•	•
LCN	(E	Sy	rsB	ManB	OffL	CBsy	ISTb		InSv
0	Quit	PM	4	1	10	3	3		130
	Post_	LCME	1	1	5	0	1		9
3									
	SwRg	LCME	RemL C	0 0 ISTE	o Link	s_00S:	CSide 1		
	Trnsl					/RG: 0			
	Tst Bsy	Unit-1:	ManB			/RG: 0			
	RTS			-	.1 11 11		Pref:0 I		
	OffL	Drwr: 0	1 23 45	67 89 (	01 23 45		Stby:1 I	nSv	
	LoadPM	•		•••••					
11	Disp_								
12	Next								
13									
	QueryPM								
15									
16									
17 18									
18									

## At the LCE frame

5



#### DANGER Card damage—transport

Take the following precautions to protect circuit cards from electrical and mechanical damage during transport:

When handling a circuit card not in an electrostatic discharge (ESD) protective container, stand on a conductive floor mat and wear a wriststrap connected, through a 1-megohm resistor, to a suitably grounded object, such as a metal workbench or a DMS switch frame (Northern Telecom [Nortel] Corporate Standard 5028). Store and transport circuit cards in an ESD protective container.



# DANGER

Static electricity damage

Before removing any cards, put on a wriststrap and connect it to the wriststrap grounding point on the left side of the modular supervisory panel (MSP) of the LCME. This protects the equipment against damage caused by static electricity.



## DANGER

Equipment damage

Take the following precautions when removing or inserting a card:

- 1. Do not apply direct pressure to the components.
- 2. Do not force the cards into the slots.


Put on a wrist strap.

6 Power down the shelf by setting the ON/OFF switch on the circuit breaker shelf to the OFF position. Both the converter FAIL LED and FRAME FAIL lamp on the MSP will be ON. An audible alarm may sound. If an alarm does sound, silence it by typing


>sil

and pressing the Enter key.


- 7 Remove the NT6X53 card as shown in the following figures.
  - a Locate the card to be removed on the appropriate shelf.




- **b** Open the locking levers on the card to be replaced and gently pull the card toward you until it clears the shelf.
- **c** Ensure the replacement card has the same PEC, including suffix, as the card you just removed.



- 8
- Open the locking levers on the replacement card.
  - a Align the card with the slots in the shelf.
  - **b** Gently slide the card into the shelf.



- 9 Seat and lock the card.
  - **a** Using your fingers or thumbs, push on the upper and lower edges of the faceplate to ensure the card is fully seated in the shelf.
  - **b** Close the locking levers.



- **10** Power up the LCM(E) unit as follows:
  - **a** Ensure the power converter (NT6X53) is inserted. A major audible alarm may sound. This alarm is silenced when power is restored to the converter.
  - **b** Set the POWER switch on the circuit breaker to the ON position.

## At the MAP terminal

- 11 Load the LCM(E) unit by typing
  - >LOADPM UNIT lcm(e)\_unit\_no CC
  - and pressing the Enter key.
  - where

12

13

14

15 16 lcm(e)\_unit\_no
 is the number of the LCM(E) unit busied in step 4

If load	Do
passed	step 12
failed	step 18
Test the LCM(E) unit by typing	
>TST UNIT lcm(e)_no	
and pressing the Enter key.	
where	
<pre>lcm(e)_unit_no     is the number of the LCM(E)</pre>	unit loaded in step 11
If TST	Do
passed	step 13
failed	step 17
If you entered this procedure from	Do
alarm clearing procedures	step 17
	1
	stop 1/
other	step 14
Return the LCM(E) unit to service b	-
Return the LCM(E) unit to service b	-
Return the LCM(E) unit to service b >RTS UNIT lcm(e)_unit_no and pressing the Enter key.	-
Return the LCM(E) unit to service b	y typing
Return the LCM(E) unit to service b >RTS UNIT lcm(e)_unit_no and pressing the Enter key. where lcm(e) unit no	y typing
Return the LCM(E) unit to service b >RTS UNIT lcm(e)_unit_no and pressing the Enter key. where lcm(e)_unit_no is the number of the LCM(E)	y typing unit tested in step 12
Return the LCM(E) unit to service b >RTS UNIT lcm(e)_unit_no and pressing the Enter key. where lcm(e)_unit_no is the number of the LCM(E) If RTS	y typing unit tested in step 12 <b>Do</b> step 15
Return the LCM(E) unit to service b >RTS UNIT lcm(e)_unit_no and pressing the Enter key. where lcm(e)_unit_no is the number of the LCM(E) If RTS passed	y typing unit tested in step 12 <b>Do</b> step 15 step 18

- **17** Return to *Alarm Clearing Procedures* or the other procedure that directed you to this procedure. At the point where a faulty card list was produced, identify the next faulty card on the list and go to the appropriate card replacement procedure for that card in this manual.
- **18** Obtain further assistance in replacing this card by contacting operating company maintenance personnel.
- **19** You have successfully completed this procedure. Return to the maintenance procedure that directed you to this card replacement procedure and continue as directed.

# NT6X54 in an RSC-S (DS-1) Model B LCM(E)

# Application

Use this procedure to replace an NT6X54 card in an RSC-S LCM(E).

PEC	Suffixes	Name
NT6X54	AA	Bus Interface Card (BIC)


# **Common procedures**

None

# Action

The following flowchart is only a summary of the procedure. To replace the card, use the instructions in the procedure that follows the flowchart.

Summary of card replacement procedure for an NT6X54 card in RSC-S LCM(E)



#### Replacing an NT6X54 card in RSC-S LCM(E)

#### At your current location

- 1 Proceed only if you have been directed to this card replacement procedure from a step in a maintenance procedure, are using the procedure for verifying or accepting cards, or have been directed to this procedure by your maintenance support group.
- 2 Obtain a replacement card. Ensure that the replacement card has the same product equipment code (PEC), including suffix, as the card that is to be removed.

#### At the MAP terminal

**3** Post the LCME with the LCA shelf containing the card to be replaced by typing

#### >MAPCI;MTC;PM;POST LCME lcme\_site\_name lcme\_frame\_no lcme\_no

and pressing the Enter key.

#### where

Icme\_site\_name is the name of the site at which the LCME is located

Icme\_frame\_no

is the number of the frame in which the LCME is located

#### Icme no

is the number of the LCME with the faulty card

Example of a MAP display:

CI	i MS	IOD	Net	PM	CCS	LNS	Trks	Ext	Appl
•	•	•	•	1LCM	•	•	•	•	•
LCN	1		SysB	ManB	OffL	CBsy	ISTb		InSv
0	Quit	PM	0	0	0	0	0		130
2	Post_	LCME	0	0	0	0	0		0
3									
4	SwRg	LCME	RemL	00 0 IST	o Links	_00S: C	Side 1		
5	Trnsl	Unit	): Ins	Sv		/RG: 0			
6	Tst	Unit:	l: In:	Sv		/RG: 0			
7	Bsy				11 11 11	RG:	Pref 0 In	nSv	
	RTS	Drwr	: 01 23	45 67 89	01 23 45	RG:	Stby:1 I	nSv	
	OffL								
	LoadPM								
	Disp_								
	Next								
13									
	QueryPM								
15									
16									
17									
18									)

**4** Busy both line subgroups (LSG) associated with the LCME drawer in which the card is being replaced by typing

>BSY DRWR lsg

and pressing the Enter key.

where

lsg

is a line subgroup associated with the drawer

*Example of a MAP response:* Please confirm ("YES" or "NO")

Confirm the system prompt by typing

>YES

and pressing the Enter key.

Repeat this step for other line subgroups associated with the drawer.

5 Offline the LSGs busied in step 4 by typing

>OFFL DRWR lsg

and pressing the Enter key.

where

lsg

is a line subgroup busied in step 4

## At the LCE frame

- 6 Remove the -48V fuse for the line drawer containing the bus interface card (BIC) to be replaced.
- 7 Remove the +15V fuse for the line drawer containing the BIC to be replaced.
- 8



#### DANGER Static electricity damage

Before removing any cards, put on a wriststrap and connect it to the wriststrap grounding point on the left side of the modular supervisory panel (MSP) of the LCME. This protects the equipment against damage caused by static electricity.



#### DANGER Card damage—transport

Take the following precautions to protect circuit cards from electrical and mechanical damage during transport:

When handling a circuit card not in an electrostatic discharge (ESD) protective container, stand on a conductive floor mat and wear a wriststrap connected, through a 1-megohm resistor, to a suitably grounded object, such as a metal workbench or a DMS switch cabinet (Northern Telecom [Nortel] Corporate Standard 5028). Store and transport circuit cards in an ESD protective container.



## DANGER

Equipment damage

Take the following precautions when removing or inserting a card:

- 1. Do not apply direct pressure to the components.
- 2. Do not force the cards into the slots.



#### DANGER Hot materials

Exercise care when handling the line card. The line feed resistor may be very hot.

Put on a wriststrap.

- 9 Open the line drawer by following these substeps:
  - **a** Face the drawer shelf and grasp the lip at the bottom of the drawer.
  - **b** Push up on the drawer latch with your thumb and pull the drawer out approximately 15.0 cm (about 6.0 in).
- **10** Remove the BIC to be replaced by following these substeps:
  - **a** Open the locking levers on the BIC.
  - **b** Grasping the open locking levers, remove the card from the line drawer in one steady motion. The card will unplug from its socket.

*Note:* Do not use a rocking motion to remove the card.

- **11** Replace the faulty card by following these substeps:
  - **a** Remove the replacement card from the ESD container.

- **b** Close the locking levers on the card.
- **c** Position the card in its backplane socket. In one steady motion, push against the closed locking levers with your thumbs until the card plugs fully into the backplane socket.
  - *Note:* Do not use a rocking motion to insert the card.
- d Close the line drawer.
- **12** Replace the +15V fuse associated with the line drawer.
- **13** Replace the -48V fuse associated with the line drawer.
- 14 Use the following information to determine what step to go to next in this procedure.

If you entered this procedure from	Do
an alarm clearing procedure	step 19
other	step 15

## At the MAP terminal

**15** Busy the offline LSGs associated with the LCME drawer by typing

>BSY DRWR lsg

and pressing the Enter key.

where

lsg

is a line subgroup associated with the drawer

Repeat this step for other LSGs associated with the drawer.

Return the LSGs to service by typing

>RTS DRWR lsg

and pressing the Enter key.

## where

16

is a line subgroup associated with the drawer

If RTS	Do
passed	step 17
failed	step 20

17 Send any faulty cards for repair according to local procedure.

**18** Record the date the card was replaced, the serial number of the card, and the symptoms that prompted replacement of the card. Go to step 21.

- **19** Return to *Alarm Clearing Procedures* or the other procedure that directed you to this procedure. At the point where a faulty card list was produced, identify the next faulty card on the list and go to the appropriate card replacement procedure for that card in this manual.
- 20 Obtain further assistance in replacing this card by contacting the personnel responsible for higher level of support.
- 21 You have successfully completed this procedure. Return to the maintenance procedure that directed you to this card replacement procedure and continue as directed.

# NT6X69 in an RSC-S (DS-1) Model B RCC2

## Application

Use this procedure to replace an NT6X69 card in an RSC-S RCC2.

PEC	Suffixes	Name
NT6X69	AC, AD, QA	Message and Tone Card


## **Common procedures**

None

## Action

The following flowchart is only a summary of the procedure. To replace the card, use the instructions in the procedure that follows the flowchart.

## Summary of card replacement procedure for an NT6X69 card in RSC-S RCC2



## Replacing an NT6X69 card in an RSC-S RCC2

## At your Current Location

1 Proceed only if you have been directed to this card replacement procedure from a step in a maintenance procedure, are using the procedure for verifying or accepting cards, or have been directed to this procedure by your maintenance support group.

2



#### CAUTION Loss of service

When replacing a card in the RCC2, ensure that the unit in which you are replacing the card is *inactive* and that the mate unit is *active*.

Obtain a replacement card. Ensure that the replacement card has the same product equipment code (PEC), including suffix, as the card that is to be removed.

## At the MAP terminal

3 Set the MAP display to the PM level and post the RCC2 unit by typing

>MAPCI;MTC;PM;POST RCC2 rcc2\_no

and pressing the Enter key.

where

rcc2\_no

is the number of the rcc2 with the faulty card

Example of a MAP display:

(									
CM	MS	IOD	Net	PM	CCS	LNS	Trks	Ext	Appl
•	•	•	•	•	•	•	•	•	•
RCO	22		SvsB	ManB	OffL	CBsy	ISTb	,	InSv
0	Quit	PM	-	0	0	0	0		25
2	Post_	RCC2	0	0	0	0	0		0
3	ListSet								
4		RCC2	0 InSv	Links_	00S:				
5	TRNSL	Unit0:	Inact	InSv					
6	TST	Unit1:	Act Ir	ıSv					
7	BSY								
8	RTS								
	OffL								
	LoadPM_								
	Disp_								
	Next_								
13									
	QueryPM								
15									
16									
17									
18									

**4** By observing the MAP display, be sure that the card to be removed is on the inactive unit.

If faulty card is on	Do	
active unit	step 5	
inactive unit	step 7	

**5** Switch the processing activity (SWACT) to the inactive unit by typing

>SWACT

and pressing the Enter key.

6 Confirm the system prompt by typing

>YES

and pressing the Enter key.

After both units are in service, proceed to the next step.

## At the RCE

7 Place a sign on the active unit bearing the words *Active unit—Do not touch.* This sign should not be attached by magnets or tape.

## At the MAP terminal

8 Busy the inactive PM unit by typing

>bsy unit rcc2\_unit\_no

and pressing the Enter key.

where

rcc2\_unit\_no is the number of the inactive RCC2 unit (0 or 1)

**9** Set the PM to the read-only memory (ROM) level and inhibit messaging by typing

>PMRESET UNIT rcc2\_unit\_no NORUN

and pressing the Enter key.

where

rcc2\_unit\_no

is the number of the inactive RCC2 unit (0 or 1)

At the RCE

10



#### DANGER Static electricity damage

Before removing any cards, put on a wrist strap and connect it to the wrist strap grounding point on the left side of the modular supervisory panel (MSP) of the RCC2. This protects the equipment against damage caused by static electricity.




#### DANGER Equipment damage

Take these precautions when removing or inserting a card:


1. Do not apply direct pressure to the components. 2. Do not force the card into its slot.

Put on a wrist strap.


- 11 Remove the NT6X69 card as shown in the following figures.
  - a Locate the card to be removed on the appropriate shelf.



**b** Open the locking levers on the card to be replaced and gently pull the card toward you until it clears the shelf.



- **c** Ensure the replacement card has the same PEC, including suffix, as the card you just removed.
- 12 Open the locking levers on the replacement card.
  - **a** Align the card with the slots in the shelf.
  - **b** Gently slide the card into the shelf.




13



#### **CAUTION** Loss of subscriber service Subscriber service may be lost in the *active* unit when reseating the NT6X69 card. It is recommended that this procedure be performed during low traffic periods.

Seat and lock the card.

- **a** Using your fingers or thumbs, push on the upper and lower edges of the faceplate to ensure that the card is fully seated in the shelf.
- **b** Close the locking levers.



### At the MAP terminal

14 Perform a full reset of the inactive unit by typing

>PMRESET UNIT rcc2\_unit\_no

and pressing the Enter key.

where

rcc2\_unit\_no
is the number of the inactive RCC2 unit (0 or 1)

If PMRESET	Do				
passed	step 17				
fails, try reloading this unit	step 15				
fails with a card list	step 20				
Load the inactive unit by typing					
>LOADPM UNIT rcc2_unit_no CC					
and pressing the Enter key.					

15

### NT6X69 in an RSC-S (DS-1) Model B RCC2 (end)

#### where

16

17

18 19

#### rcc2\_unit\_no

is the number of the inactive RCC2 unit (0 or 1)

If LOADPM	Do					
passed	step 16					
failed	step 21					
fails with a card list	step 20					
Use the following information to det procedure.	termine what step to go to next in this					
If you entered this procedure from	Do					
alarm clearing procedures	step 20					
other	step 17					
Return the inactive RCC2 unit to se	ervice by typing					
>RTS UNIT rcc2_unit_no						
and pressing the Enter key.						
where						
rcc2_unit_no is the number of the inactive	RCC2 unit (0 or 1)					
If RTS	Do					
passed	step 18					
failed	step 21					
Send any faulty cards for repair acc	cording to local procedure.					
Record the date the card was replace symptoms that prompted replacements	ced, the serial number of the card, and th ent of the card. Go to step 22.					
	ed you to this procedure. At the point					

- **20** Return to the procedure that directed you to this procedure. At the point where a faulty card list was produced, identify the next faulty card on the list and go to the appropriate card replacement procedure for that card in *Card Replacement Procedures*.
- 21 Obtain further assistance in replacing this card by contacting the personnel responsible for higher level of support.
- 22 You have successfully completed this procedure. Remove the sign from the active unit and return to the maintenance procedure that directed you to this card replacement procedure and continue as directed.

# NT6X71 in an RSC-S (DS-1) Model B LCME

### Application

Use this procedure to replace an NT6X71 card in an RSC-S LCME.

PEC	Suffixes	Name
NT6X71	AA, AB	Data Line card (DLC)


# **Common procedures**

None

# Action

The following flowchart is only a summary of the procedure. To replace the card, use the instructions in the procedure that follows the flowchart.

### Summary of card replacement procedure for an NT6X71 card in RSC-S LCME



### Replacing an NT6X71 card in RSC-S LCME

#### At your Current Location

- 1 Proceed only if you have been directed to this card replacement procedure from a step in a maintenance procedure, are using the procedure for verifying or accepting cards, or have been directed to this procedure by your maintenance support group.
- 2 Obtain a replacement card. Ensure the replacement card has the same product equipment code (PEC), including suffix, as the card that is to be removed.

#### At the MAP terminal

**3** Post the LEN of the card to be replaced by typing

>MAPCI;MTC;LNS;LTP;POST L site lcme\_no unit\_no lsg\_no ckt\_no

and pressing the Enter key.

where

#### site

is the location name of the LCME with the faulty card

#### lcme\_no

is the number of the LCME with the faulty card

unit\_no

is the number of the LCME unit with the faulty card

#### lsg\_no

is the number of the LSG with the faulty card

#### ckt\_no

is the number of the circuit associated with the faulty card

Example of a MAP display:

(	СМ	М	S	IOD	Net	PM	CCS	LNS	Trks	Ext	Appl \
	·	•		•	•	•	•	•	•	•	•
L	TP										
	0 Q	uit	P	ost	DEL	Q	BUSYQ		PREFIX		
	2 P	ost_									
	3		L	CC PTY	Y RNG	.LEN	. D	N	STA F S	LTA TE	RESULT
	4		C	KT TYP	PE FL	HOST	00 0 03	03 49	931082	IDL	
	5В	SY									
	6 R	TS									
	7 D	IAG									
	8										
	9 A	IMStat									
1	0 C	KTLOC									
1	1 H	old									
1	2 N	ext_									
1	3										
1	4										
	5										
		refix									
	7 L										
( 1	8 L	evel									,

4 Busy the NT6X71 line card by typing

>BSY and pressing the Enter key.

Example of a MAP display:

CI	4 MS	IOD	Net	PM	CCS	LNS	Trks	Ext	Appl
•	•	•	•	•	•		•	•	·
LTI	?								
0	Quit	Post	E	ELQ	BUSY	ΥQ	PREFIX		
2	Post_								
3									TE RESULT
4		CKT 7	FYPE FL	HOST	00 0 03	03 493	1082 IDL		
5	BSY								
6	RTS								
7	DIAG								
8									
9	AIMStat								
10	CKTLOC								
11	Hold								
12	Next_								
13									
14									
15									
16	Prefix								
17	LCO								
18	Level								)

DMS-100 Family Switching Center-SONET Model B Maintenance Manual

#### At the LCE frame

5



#### DANGER Card damage—transport

Take these precautions to protect the circuit cards from electrical and mechanical damage while transporting cards.

When handling a circuit card not in an electrostatic discharge (ESD) protective container, stand on a conductive floor mat and wear a wrist strap connected, through a 1-megohm resistor, to a suitably grounded object, such as a metal workbench or a DMS switch frame.

Store and transport circuit cards in an ESD protective container.



### DANGER

Equipment damage

Take these precautions when removing or inserting a card:

- 1. Do not apply direct pressure to the components.
- 2. Do not force the cards into the slots.



#### DANGER Hot materials

Exercise care when handling the line card. The line feed resistor may be very hot.

### CAUTION



**Special tools required** Card shrouds and removal tools are required for removing cards from the line drawers.

Put on a wrist strap.

*Note:* Card shrouds are required for inserting or removing cards in line drawers. Two sizes are available for use with 3-inch and 6-inch cards.

Descriptions of these shrouds follow.

Line card insertion / withdrawal tool for	Apparatus code	Common product code
3-inch cards	QTH56A	A0298291
6-inch cards	QTH58A	A0313317

*Note:* Card removal tools are required for removing cards from line drawers. Two sizes are available. Descriptions of these tools follow.

Card	rem	oval tool for	Apparatus code	Common product code					
3-4 inc	ch ca	ards	QTH57A	A0298292					
Note:	For	· 4-inch or larger	er cards, use the large grip tool ITA9953.						
6	Pre step	pare to remove to 1, and following	the faulty card by opening the line drawer, determined in g these substeps:						
	а	Face the drawer with your right h		e at the bottom of the drawer					
	b		It is fully withdrawn when	ur thumb and pull the drawer out until when the drawer stop, at the top,					
	C	Maintain a sligh approximately 2		ndle and lift the faceplate of the drawer					
	d	While holding th nearest the shel right.	the drawer in this position, push the bottom of the drawe elf with your left hand, to a position about 1 cm (.5 in) to th						
	е		in this position with your lef releasing the grip of your	t hand and lower the faceplate right hand.					
	f	Ensure a card s	hroud and line card extrac	tor are available.					
7	Rer	move the line car	ard to be replaced by following these substeps:						
	а		nroud over the card to be removed and an adjacent can adjacent can adjacent can adjacent card sh						
	b	Grasp the edge of the card with a line card extractor at a point min between the top and bottom edges. Hold the extractor in your righ							
	С	Squeeze the handles of the extractor together to grasp the card tig							
	d	Hold the front co	over of the line drawer to s	teady it using your left hand.					
	е		or away from the drawer, ar its socket on the drawer b						

- f Continue pulling the card with the extractor until the card is clear of the shroud.
- **g** Insert the removed card into the ESD container and store using local procedures.
- 8 Replace the faulty card by following these substeps:
  - **a** Remove the replacement card from the ESD container.
  - **b** Slide the card in the shroud guide slots toward the drawer backplane.
  - c Hold the front cover of the line drawer with your left hand to steady it.
  - **d** Grasp the top and bottom edges of the card with the fingers of your right hand.
  - **e** Push the card toward the backplane until it plugs fully into the backplane socket.
- **9** Use the following information to determine where to proceed.

If you entered this procedure from	Do
alarm clearing procedures	step 14
other	step 10

### At the MAP terminal

**10** Test the NT6X71 line card by typing

>DIAG

and pressing the Enter key.

If DIAG	Do				
passed	step 11				
failed	step 14				
Return the NT6X71 card to service by typing					
RTS					
RTS	key.				
	key. Do				
and pressing the Enter	-				

12 Send any faulty cards for repair according to local procedure.

**13** Record the date the card was replaced, the serial number of the card, and the symptoms that prompted replacement of the card. Go to step 16.

11

- **14** Return to *Alarm Clearing Procedures* or another procedure that directed you to this procedure. If necessary, go to the point where a faulty card list was produced, identify the next faulty card on the list, and go to the appropriate card replacement procedure for that card in this manual.
- **15** Obtain further assistance in replacing this card by contacting operating company maintenance personnel.
- 16 You have successfully completed this procedure. Return to the maintenance procedure that directed you to this card replacement procedure and continue as directed.

# NT6X74 in an RSC-S (DS-1) Model B RMM

### Application

Use this procedure to replace an NT6X74 card in an RSC-S RMM.


PEC	Suffixes	Name
NT6X74	AB	RMM Control Card (RMMC)


# **Common procedures**

None

# Action

The following flowchart is only a summary of the procedure. To replace the card, use the instructions in the procedure that follows the flowchart.





### Replacing an NT6X74 card in an RSC-S RMM

#### At your Current Location

1 Proceed only if you have been directed to this card replacement procedure from a step in a maintenance procedure, are using the procedure for verifying or accepting cards or have been directed to this procedure by your maintenance support group.

### At the MAP terminal

2 Set the MAP display to the TTP level and post the RMM by typing

>MAPCI;MTC;TRKS;TTP;POST TM rmm\_no

and pressing the Enter key.

where

rmm\_no

is the number of the RMM in which the card is to be replaced

**3** Busy all trunks in the RMM by typing

>BSY INB ALL

and pressing the Enter key.

4 At the PM level, busy the RMM shelf by typing

>PM;POST RMM rmm\_no;BSY

and pressing the Enter key.

where

rmm no

is the number of the RMM in which the card is to be replaced *Example of a MAP display:* 

См				Net	PM 4SysB		Trks	3	Ext	AF	
RMI				SysB			CBsy		ISTb		nSv
0	Quit	PM		4	1	10	3		3	1	.30
2	Post_	RMM		0	1	1	0		0		2
3											
4		RMM	5	ManB							
5	Trnsl										
6	Tst										
7	Bsy										
8	RTS										
9	OffL										
10	LoadPM										
11	Disp_										
12	Next										
13											
14	QueryPM										
15											
16											
17											
18											,

At the RMM shelf

5

6



### DANGER

Static electricity damage

Before removing any cards, put on a wrist strap and connect it to the wrist strap grounding point on the left side of the modular supervisory panel (MSP) of the RMM. This protects the equipment against damage caused by static electricity.




DANGER

**Improper insertion may cause damage to circuit packs** 1. Do not apply direct pressure to the components.


2. Do not force the card into its slot.

Put on a wrist strap.


- Remove the NT6X74 card as shown in the following figures.
  - **a** Locate the card to be removed on the appropriate shelf.



**b** Open the locking levers on the card to be replaced and gently pull the card toward you until it clears the shelf.



- **c** Ensure the replacement card has the same PEC, including suffix, as the card you just removed.
- 7 Open the locking levers on the replacement card.
  - **a** Align the card with the slots in the shelf.
  - **b** Gently slide the card into the shelf.



8




#### DANGER Equipment damage

Take these precautions when removing or inserting a card:

- 1. Do not apply direct pressure to the components.
- 2. Do not force the card into its slot.

Seat and lock the card.

- **a** Using your fingers or thumbs, push on the upper and lower edges of the faceplate to ensure the card is fully seated in the shelf.
- **b** Close the locking levers.



9	Reload the RMM by typing >LOADPM	
	and pressing the Enter key.	
10	Use the following information to dete	rmine where to proceed.
	lf	Do
	loadfile not found in directory	step 11
	load passes	step 15
	load fails	step 22
11	Refer to the following table to determ	ine the next step in this procedure.
	If the system load module is	Do
	version 1	step 12
	version 2	step 13
12	List the loadfile in the directory by typ	bing
	> DSKUT;LISTVOL D000 ALL	
	and pressing the Enter key.	
	or	
	> DSKUT;LISTVOL D010 ALL	
	and pressing the Enter key.	
	Local operating company policy determined loadfile will be on.	ermines which disk, D000 or D010, the
	Proceed to step14.	
13	List the loadfile in the directory by typ	bing
	>DISKUT;LV S00D	
	>LF	
	and pressing the Enter key.	
	or	
	> DISKUT;LV S01D	
	>LF	
	and pressing the Enter key.	
14	Leave the disk utility by typing	
	>QUIT	
	and pressing the Enter key.	
	Return to step 9.	

**15** Return the RMM shelf to service by typing

>RTS

16

and pressing the Enter key.

If RTS	Do
passed	step 16
failed	step 22
<b>x</b>	
If directed to this procedure	on where you were directed to this
procedure.	

#### At the MAP terminal

17 Post all trunks in the RMM in order to return to them service by typing

>TRKS;TTP;POST TM RMM rmm\_no

and pressing the Enter key.

where

#### rmm\_no

is the number of the RMM in which the card has been replaced

**18** Busy and return to service all trunks by typing

>BSY ALL ; RTS ALL

and pressing the Enter key.

**19** Use the following information to determine where to proceed.

If RTS	Do
passed	step 20
failed	step 22

**20** Observe the alarm that is produced and go to the appropriate alarm clearing procedure in *Alarm Clearing Procedures*. Go to step 23.

21 Return to the procedure that directed you to this procedure. At the point where a faulty card list was produced, identify the next faulty card on the list and go to the appropriate card replacement procedure for that card in *Card Replacement Procedures*.

22 Obtain further assistance in replacing this card by contacting the personnel responsible for higher level of support.

23 You have successfully completed this procedure. Return to the maintenance procedure that directed you to this procedure and continue as directed.

# NT6X76 in an RSC-S (DS-1) Model B LCME

# Application

Use this procedure to replace the following card in an RSC-S LCME.

PEC	Suffixes	Name
NT6X76	AC	Asynchronous Interface Line card


# **Common procedures**

None

# Action

The following flowchart is only a summary of the procedure. To replace the card, use the instructions in the procedure that follows the flowchart.

### Summary of card replacement procedure for an NT6X76 card in RSC-S LCME



#### Replacing an NT6X76 card in RSC-S LCME

#### At your Current Location

- 1 Proceed only if you have been directed to this card replacement procedure from a step in a maintenance procedure, are using the procedure for verifying or accepting cards, or have been directed to this procedure by your maintenance support group.
- 2 Obtain a replacement card. Ensure the replacement card has the same product equipment code (PEC), including suffix, as the card that is to be removed.

#### At the MAP terminal

**3** Post the LEN of the card to be replaced by typing

>MAPCI;MTC;LNS;LTP;POST LCME site lcm(e)\_no unit\_no lsg\_no ckt\_no

and pressing the Enter key.

where

site

is the location name of the LCME with the faulty card

#### lcm(e)\_no

is the number of the LCME with the faulty card

unit\_no

is the number of the LCME unit with the faulty card

#### lsg no

is the number of the LSG with the faulty card

#### ckt\_no

is the number of the circuit associated with the faulty card

Example of a MAP display:

Сп	M MS	IOD	Net	PM	CCS	LNS	Trks	Ext	Appl	
· ·	•		•	•	•	•		•	•	
LTI	P									
0	Quit	Post	DEL	Q	BUSYQ		PREFIX			
1	Post_									
							STA F S	LTA TE	RESULT	
4		CKT TYP	E FL	HOST	00 0 03	03	SB			
5	BSY									
6	RTS									
	DIAG									
8										
-	AIMStat									
	CKTLOC									
	Hold									
1	Next_									
13										
14										
15										
	Prefix									
1	LCO									
\ 18	Level									,

4 Busy the NT6X76 line card by typing

>BSY

and pressing the Enter key.

Example of a MAP display:

	a		Ma	TOD	Net	DM	000	TNO	maala e	Test	7 7	
(	C№			TOD		₽М	CCS	LINS	Irks	Ext		1
	·		•	·	•	•	•	•	•	•	•	
	LTF	<b>)</b>										
				Post	DELO		BUSYQ		PREFIX			
		Post_		1000	2220		20010					
	3			LCC PTY	RNG	LEN	DN		STA F S	LTA TE	RESULT	
	4			CKT TYPE	FL HO	ST 00	0 03 03		MB			
	5	BSY										
	6	RTS										
	7	DIAG										
	8											
	9	AIMSt	at									
		CKTLO	С									
		Hold										
		Next_										
	13											
	14											
	15											
		Prefi	х									
		LCO										
$\langle$	тo	Level										

#### At the LCE frame

5



#### DANGER Card damage—transport

Take the following precautions to protect circuit cards from electrical and mechanical damage during transport:

When handling a circuit card not in an electrostatic discharge (ESD) protective container, stand on a conductive floor mat and wear a wriststrap connected, through a 1-megohm resistor, to a suitably grounded object, such as a metal workbench or a DMS switch frame (Northern Telecom [Nortel] Corporate Standard 5028). Store and transport circuit cards in an ESD protective container.



### DANGER

Static electricity damage

Before removing any cards, put on a wriststrap and connect it to the wriststrap grounding point on the left side of the modular supervisory panel (MSP) of the LCME. This protects the equipment against damage caused by static electricity.



### DANGER

Equipment damage

Take the following precautions when removing or inserting a card:

- 1. Do not apply direct pressure to the components.
- 2. Do not force the cards into the slots.

### DA Hot

#### DANGER Hot materials

Exercise care when handling the line card. The line feed resistor may be very hot.



### CAUTION

**Special tools required** Card shrouds and removal tools are required for removing cards from the line drawers. For descriptions of these tools, refer to the following notes.

Put on a wrist strap.

*Note:* Card shrouds are required for inserting or removing cards in line drawers. Two sizes are available for use with 3-inch and 6-inch cards, as shown in the following table.

Line card insertion / withdrawal tool for	Apparatus code	Common product code
3-inch cards	QTH56A	A0298291
6-inch cards	QTH58A	A0313317

*Note:* Card removal tools are required for removing cards from line drawers. Two sizes are available, as shown in the following table.

Card removal tool for	Apparatus code	Common product code	
3—4 inch cards	QTH57A	A0298292	
Note: For 4-inch or	larger cards, use the	large grip tool ITA9953.	

6 Prepare to remove the faulty card by opening the line drawer and following these substeps:

- **a** Face the drawer shelf and grasp the handle at the bottom of the drawer with your right hand.
- **b** Push up on the drawer latch with your thumb and pull the drawer out until fully withdrawn. It is fully withdrawn when the drawer stop, at the top, prevents further travel.
- **c** Maintain a slight pull on the handle and lift the faceplate of the drawer approximately 2.5 cm (1.0 in).
- **d** While holding the drawer in this position, push the bottom of the drawer, nearest the shelf with your left hand, to a position about 1.0 cm (0.5 in) to the right.

- e Hold the drawer in this position with your left hand and lower the faceplate of the drawer by releasing the grip of your right hand.
- f Ensure a card shroud and line card extractor are available.
- 7 Remove the line card to be replaced by following these substeps:
  - **a** Slide a card shroud over the card to be removed and an adjacent card. If there is not an adjacent card on either side, do not use the card shroud.
  - **b** Grasp the edge of the card with a line card extractor at a point midway between the top and bottom edges. Hold the extractor in your right hand.
  - c Squeeze the handles of the extractor together to grasp the card tightly.
  - d Hold the front cover of the line drawer to steady it using your left hand.
  - e Pull the extractor away from the drawer, and the card will become unplugged from its socket on the drawer backplane.
  - f Continue pulling the card with the extractor until the card is clear of the shroud.
  - **g** Insert the card removed into the ESD container and store using local procedures.
  - Replace the faulty card by following these substeps:
    - a Remove the replacement card from the ESD container.
    - **b** Slide the card in the shroud guide slots toward the drawer backplane.
    - c Hold the front cover of the line drawer with your left hand to steady it.
    - **d** Grasp the top and bottom edges of the card with the fingers of your right hand.
    - e Push the card toward the backplane until it plugs fully into the backplane socket.
- **9** Use the following information to determine where to proceed.

If you entered this procedure from	Do
alarm clearing procedures	step 14
other	step 10

### At the MAP terminal

8

10 Test the NT6X76 line card by typing

>DIAG

and pressing the Enter key.

If DIAG	Do	
passed	step 11	
failed	step 15	

DMS-100 Family Switching Center-SONET Model B Maintenance Manual

11 Return the NT6X76 card to service by typing

>RTS

and pressing the Enter key.

If RTS	Do	
passed	step 12	
failed	step 15	

- 12 Send any faulty cards for repair according to local procedure.
- **13** Record the date the card was replaced, the serial number of the card, and the symptoms that prompted replacement of the card. Go to step 16.
- 14 Return to the procedure that directed you to this procedure. If necessary, go to the point where a faulty card list was produced, identify the next faulty card on the list, and go to the appropriate card replacement procedure for that card in this manual.
- **15** Obtain further assistance in replacing this card by contacting operating company maintenance personnel.
- 16 You have successfully completed this procedure. Return to the maintenance procedure that directed you to this card replacement procedure and continue as directed.

# NT6X78 in an RSC-S (DS-1) Model B RCC2

# Application

Use this procedure to replace an NT6X78 card in a Remote Switching Center (RSC)-SONET Remote Cluster Controller (RCC) 2.

PEC	Suffixes	Name
NT6X78	AA, AB, BA	CLASS Modem Resource (CMR)


# **Common procedures**

None

## Action

The following flowchart is only a summary of the procedure. To replace the card, use the instructions in the procedure that follows the flowchart.

Summary of card replacement procedure for an NT6X78 card in RSC-S RCC2



#### Replacing an NT6X78 card in an RSC-S RCC2

#### At your Current Location

- 1 Proceed only if you have been directed to this card replacement procedure from a step in a maintenance procedure, are using the procedure for verifying or accepting cards, or have been directed to this procedure by your maintenance support group.
- 2



#### CAUTION Loss of service

When replacing a card in the RCC2, ensure that the unit in which you are replacing the card is *inactive* and that the mate unit is *active*.

Obtain an NT6X78 replacement card. Ensure that the replacement card has the same product engineering code (PEC), including suffix, as the card to be removed.

#### At the MAP terminal

3 Access the PM level and find out which RCC2 is ISTb by typing

>MAPCI;MTC;PM;DISP ISTB RCC2

and pressing the Enter key.

4 Access the ISTb RCC2 by typing

>POST RCC2 rcc2\_no

and pressing the Enter key.

where

rcc2 no

is the number of the ISTB RCC2 identified in step 4.

5 Busy the CMR card by typing

>bsy UNIT unit\_no CMR

and pressing the Enter key.

where

#### unit\_no

is the number of the unit containing the faulty CMR card

### At the RCE

6

7



#### WARNING Static electricity damage

Before removing any cards, put on a wrist strap and connect it to the wrist strap grounding point on the left side of the modular supervisory panel (MSP) of the RCC2. This protects the equipment against damage caused by static electricity.




### DANGER

Equipment damage Take the following precautions when removing or inserting a card:


- 1. Do not apply direct pressure to the components.
- 2. Do not force the card into its slot.

Put on a wrist strap.


- Remove the NT6X78 card as shown in the following figures.
  - a Locate the card to be removed on the appropriate shelf.



**b** Open the locking levers on the card to be replaced and gently pull the card toward you until it clears the shelf.




- **c** Ensure the replacement card has the same PEC, including suffix, as the card you just removed.
- Open the locking levers on the replacement card.
  - a Align the card with the slots in the shelf.
  - **b** Gently slide the card into the shelf.



9 Seat and lock the card.

8

- **a** Using your fingers or thumbs, push on the upper and lower edges of the faceplate to ensure the card is fully seated in the shelf.
- **b** Close the locking levers.



#### unit\_no

is the number of the unit containing the faulty CMR card

If TST	Do	
passed	step 13	
failed	step 17	

**13** Return the CMR card to service by typing

>RTS UNIT unit\_no CMR

and pressing the Enter key.

where

unit\_no

is the number of the unit containing the faulty CMR card

If RTS	Do
passed	step 14
failed	step 17

- 14 Send any faulty cards for repair according to local procedure.
- **15** Record the date the card was replaced, the serial number of the card, and the symptoms that prompted replacement of the card. Go to step 18.
- **16** Return to the procedure that directed you to this procedure. At the point where a faulty card list was produced, identify the next faulty card on the list and go to the appropriate card replacement procedure for that card in *Card Replacement Procedures*.
- **17** Obtain further assistance in replacing this card by contacting operating company maintenance personnel.
- **18** You have successfully completed this procedure. Return to the maintenance procedure that directed you to this card replacement procedure and continue as directed.

# NT6X87 in an RSC-S (DS-1) Model B LCME

### Application

Use this procedure to replace an NT6X87 card in an RSC-S LCME.

PEC	Suffixes	Name
NT6X87	AA	Data Voice Line card


# **Common procedures**

None

# Action

The following flowchart is only a summary of the procedure. To replace the card, use the instructions in the procedure that follows the flowchart.

### Summary of card replacement procedure for an NT6X87 card in RSC-S LCME



### Replacing an NT6X87 card in an RSC-S LCME

### At your Current location

- 1 Proceed only if you have been directed to this card replacement procedure from a step in a maintenance procedure, are using the procedure for verifying or accepting cards, or have been directed to this procedure by your maintenance support group.
- 2 Obtain a replacement card. Ensure the replacement card has the same product equipment code (PEC), including suffix, as the card that is to be removed.

### At the MAP terminal

**3** Post the line equipment number (LEN) of the card to be replaced by typing

# >MAPCI;MTC;LNS;LTP;POST L site lcme\_no unit\_no lsg\_no ckt\_no

and pressing the Enter key.

where

#### site

is the location name of the LCME with the faulty card

lcme\_no

is the number of the LCME with the faulty card

#### unit\_no

is the number of the LCME unit with the faulty card

### lsg no

is the number of the LSG with the faulty card

### ckt\_no

is the number of the circuit associated with the faulty card

Example of a MAP response:

(	CI	M MS	IOD	Net	PM	CCS	LNS	Trks	Ext	Appl
	•	•	•	•	-	•	•	•	•	•
	LTI	2								
	0	Quit	Post	DEL	Q	BUSYQ		PREFIX		
	2	Post_								
	3		LCC PTY					STA F S I	LTA TE	RESULT
	4		CKT TYPE	E FL	HOST	00 0 03	03 4	931082 II	DL	
		BSY								
		RTS								
		DIAG								
	8									
		AIMStat								
		CKTLOC								
		Hold								
		Next_								
	13									
	14 15									
		Prefix								
		LCO								
		Level								
$\backslash$	10	TCACT								

4 Busy the NT6X87 line card by typing

>BSY

and pressing the Enter key.

Example of a MAP display:

	M MS	IOD	Net	PM	CCS	LNS	Trks	Ext	laaA
	•					•		•	
LTI	2								
0	Quit	Post	DEI	QL	BUSYQ		PREFIX		
	Post_								
							STA F S	LTA TE	RESULT
		CKT TY	PE FL H	IOST 00	0 03 0	3 49310	82 IDL		
-	BSY								
	RTS								
	DIAG								
8									
	AIMStat								
	CKTLOC								
	Hold								
13	Next_								
14									
15									
	Prefix								
	LCO								
	Level								/

### At the LCE frame

5



### WARNING

Card damage—transport Take the following precautions to protect circuit cards from

electrical and mechanical damage during transport:

When handling a circuit card not in an electrostatic discharge (ESD) protective container, stand on a conductive floor mat and wear a wriststrap connected, through a 1-megohm resistor, to a suitably grounded object, such as a metal workbench or a DMS switch frame (Northern Telecom [Nortel] Corporate Standard 5028). Store and transport circuit cards in an ESD protective container.



#### WARNING Static electricity damage

Before removing any cards, put on a wriststrap and connect it to the wriststrap grounding point on the left side of the modular supervisory panel (MSP) of the LCME. This protects the equipment against damage caused by static electricity.



### DANGER

Equipment damage

Take the following precautions when removing or inserting a card:

- 1. Do not apply direct pressure to the components.
- 2. Do not force the cards into the slots.

# DANGER

### Hot materials

Exercise care when handling the line card. The line feed resistor may be very hot.



### CAUTION

**Special tools required** Card shrouds and removal tools are required for removing cards from the line drawers. For descriptions of these tools, refer to the following notes.

Put on a wriststrap.

*Note:* Card shrouds are required for inserting or removing cards in line drawers. Two sizes are available for use with 3-inch and 6-inch cards, as shown in the following table.

Line card insertion / withdrawal tool for	Apparatus code	Common product code
3-inch cards	QTH56A	A0298291
6-inch cards	QTH58A	A0313317

*Note:* Card removal tools are required for removing cards from line drawers. Two sizes are available, as shown in the following table.

Card removal tool for	Apparatus code	Common product code			
3—4 inch cards	QTH57A	A0298292			
<i>Note:</i> For 4-inch or larger cards, use the large grip tool ITA9953.					

6

- Prepare to remove the faulty card by opening the line drawer and following these substeps:
  - **a** Face the drawer shelf and grasp the handle at the bottom of the drawer with your right hand.
  - **b** Push up on the drawer latch with your thumb and pull the drawer out until fully withdrawn. It is fully withdrawn when the drawer stop, at the top, prevents further travel.
  - **c** Maintain a slight pull on the handle and lift the faceplate of the drawer approximately 2.5 cm (1.0 in).
  - **d** While holding the drawer in this position, push the bottom of the drawer, nearest the shelf with your left hand, to a position about 1.0 cm (0.5 in) to the right.
  - e Hold the drawer in this position with your left hand and lower the faceplate of the drawer by releasing the grip of your right hand.

- f Ensure a card shroud and line card extractor are available.
- 7 Remove the line card to be replaced by following these substeps:
  - **a** Slide a card shroud over the card to be removed and an adjacent card. If there is not an adjacent card on either side, do not use the card shroud.
  - **b** Grasp the edge of the card with a line card extractor at a point midway between the top and bottom edges. Hold the extractor in your right hand.
  - c Squeeze the handles of the extractor together to grasp the card tightly.
  - **d** Hold the front cover of the line drawer to steady it using your left hand.
  - e Pull the extractor away from the drawer, and the card will become unplugged from its socket on the drawer backplane.
  - f Continue pulling the card with the extractor until the card is clear of the shroud.
  - **g** Insert the card removed into the ESD container and store using local procedures.
- 8 Replace the faulty card by following these substeps:
  - a Remove the replacement card from the ESD container.
  - **b** Slide the card in the shroud guide slots toward the drawer backplane.
  - c Hold the front cover of the line drawer with your left hand to steady it.
  - **d** Grasp the top and bottom edges of the card with the fingers of your right hand.
  - e Push the card toward the backplane until it plugs fully into the backplane socket.
- **9** Use the following information to determine where to proceed.

If you entered this procedure from	Do
alarm clearing procedures	step 14
other	step 10

### At the MAP terminal

**10** Test the NT6X87 line card by typing

>DIAG

and pressing the Enter key.

If DIAG	Do	
passed	step 11	
failed	step 15	

**11** Return the NT6X87 card to service by typing

>RTS

and pressing the Enter key.

If RTS	Do	
passed	step 12	
failed	step 15	

- 12 Send any faulty cards for repair according to local procedure.
- **13** Record the date the card was replaced, the serial number of the card, and the symptoms that prompted replacement of the card. Go to step 16.
- 14 Return to procedure that directed you to this procedure. If necessary, go to the point where a faulty card list was produced, identify the next faulty card on the list, and go to the appropriate card replacement procedure for that card in this manual.
- **15** Obtain further assistance in replacing this card by contacting operating company maintenance personnel.
- 16 You have successfully completed this procedure. Return to the maintenance procedure that directed you to this card replacement procedure and continue as directed.

# NT6X92 in an RSC-S (DS-1) Model B RCC2

# Application

Use this procedure to replace an NT6X92 card in an RSC-S RCC2.

### ATTENTION

To ensure peak performance, do not install the UTR and GTR on the same RSC-S RCC2. Presently, there is no way of knowing which receiver is used to interpret tones. Some call processing tones may be degraded if designed for use with a GTR.

PEC	Suffixes	Name
NT6X92	BB,BC	Universal Tone Receiver (UTR)
NT6X92	EA	Global Tone Receiver (GTR)


### **Common procedures**

None

# Action

The following flowchart is only a summary of the procedure. To replace the card, use the instructions in the procedure that follows the flowchart.

### Summary of card replacement procedure for an NT6X92 card in RSC-S RCC2



#### Replacing an NT6X92 card in an RSC-S RCC2

#### At your Current Location

- 1 Proceed only if you have been directed to this card replacement procedure from a step in a maintenance procedure, are using the procedure for verifying or accepting cards, or have been directed to this procedure by your maintenance support group.
- 2



#### CAUTION Loss of service

When replacing a card in the RCC2, ensure that the unit in which you are replacing the card is *inactive* and that the mate unit is *active*.

Obtain an NT6X92 replacement card. Ensure the replacement card has the same product equipment code (PEC), including suffix, as the card that is to be removed.

### At the MAP terminal

3 Ensure that the PM level of the MAP display is currently displayed and that the RCC2 is posted by typing

>MAPCI;MTC;PM;POST RCC2 rcc2\_unit\_no

and pressing the Enter key.

where

#### rcc2\_unit\_no

is the number of the RCC2 with the faulty card

Example of a MAP display:

СМ	MS			PM 1RCC2		LNS •		Ext •	Appl •
02		PM RCC2	0	ManB 0 0	OffL 2 0	CBsy 0 0	)	Tb 2 1	InSv 25 1
5 6 7 8 9 10 11 12 13	TRNSL	Unit0:	0 ISTb Inact Act In		os: csi	ide 1,	PSide	1	

4 By observing the MAP display, ensure that the card to be removed is on the inactive unit.

If faulty card is on	Do
active unit	step 7
inactive unit	step 5

5 Switch the processing activity (SWACT) to the inactive unit by typing >SWACT

and pressing the Enter key.

6 Answer the prompt by typing

>YES

and pressing the Enter key.

### At the RCE frame

7 Place a sign on the active unit bearing the words *Active unit—Do not touch.* This sign should not be attached by magnets or tape.

### At the MAP terminal

8 Busy the inactive PM unit by typing

>bsy unit rcc2\_unit\_no

and pressing the Enter key.

where

#### rcc2\_unit\_no

is the number of the inactive RCC2 unit (0 or 1)

### At the RCE frame

9

10



### WARNING

Static electricity damage

Before removing any cards, put on a wrist strap and connect it to the wrist strap grounding point on the left side of the modular supervisory panel (MSP) of the RCC2. This protects the equipment against damage caused by static electricity.




#### DANGER Equipment damage

Take these precautions when removing or inserting a card:


1. Do not apply direct pressure to the components.2. Do not force the card into its slot.

Put on a wrist strap.


- Remove the NT6X92 card as shown in the following figures.
  - a Locate the card to be removed on the appropriate shelf.




**b** Open the locking levers on the card to be replaced and gently pull the card toward you until it clears the shelf.



- **c** Ensure the replacement card has the same PEC, including suffix, as the card you just removed.
- 11 Open the locking levers on the replacement card.
  - **a** Align the card with the slots in the shelf.
  - **b** Gently slide the card into the shelf.



- 12 Seat and lock the card.
  - **a** Using your fingers or thumbs, push on the upper and lower edges of the faceplate to ensure the card is fully seated in the shelf.
  - **b** Close the locking levers.



**13** Use the following information to determine the next step in this procedure.

If you entered this procedure from	Do
alarm clearing procedures	step 17
other	step 14

### At the MAP terminal

14 Return the inactive RCC2 unit to service by typing

>RTS UNIT rcc2\_unit\_no

and pressing the Enter key.

where

rcc2\_unit\_no is the number of the inactive RCC2 unit

If RTS	Do
passed	step 15
failed	step 18

- **15** Send any faulty cards for repair according to local procedure.
- 16 Record the date the card was replaced, the serial number of the card, and the symptoms that prompted replacement of the card. Go to step 19.
- 17 Return to the procedure that directed you to this procedure. At the point where a faulty card list was produced, identify the next faulty card on the list and go to the appropriate card replacement procedure for that card in this manual.
- **18** Obtain further assistance in replacing this card by contacting operating company maintenance personnel.
- **19** You have successfully completed this procedure. Remove the sign from the active unit and return to the maintenance procedure that directed you to this card replacement procedure and continue as directed.

# NT6X99 in an RSC-S (DS-1) Model B LCME

# Application

Use this procedure to replace an NT6X99 card in an RSC-S LCME.

PEC	Suffixes	Name
NT6X99	AA	Datapath Bit Error Rate Tester Line Card


# **Common procedures**

None

# Action

The following flowchart is only a summary of the procedure. To replace the card, use the instructions in the procedure that follows the flowchart.

### Summary of card replacement procedure for an NT6X99 card in RSC-S LCME



### Replacing an NT6X99 card in RSC-S LCME

### At your Current Location

- 1 Proceed only if you have been directed to this card replacement procedure from a step in a maintenance procedure, are using the procedure for verifying or accepting cards, or have been directed to this procedure by your maintenance support group.
- 2 Obtain an NT6X99 replacement card. Ensure the replacement card has the same product equipment code (PEC), including suffix, as the card that is to be removed.

### At the MAP terminal

3 Post the line equipment number (LEN) from the line test position by typing

> MAPCI;MTC;LNS;LTP;POST L site lcme\_no unit\_no lsg\_no ckt\_no

and pressing the Enter key.

where

```
site
```

is the site name assigned to the remote location

lcme\_no

is the number of the LCME

### unit\_no

is the number of the LCME unit (0 or 1)

### lsg\_no

is the number of line subgroup (00—19)

### ckt\_no

is the circuit number (00-31)

```
LNS
                                                       Trks EXT Appl
 CM
               IOD
                                       CCS
        MS
                       Net
                                PM
 .
        .
               •
                       •
                                •
                                       •
                                               •
                                                       •
                                                                .
                                                                       •
LTP
0 Quit
2 Post_
2 POST DELQ BusyQ PREFIX

    r
    5
    Bsy_
    LCC
    PTY RNG
    LEN
    DN
    STA FS LTA TE RESULT

    6
    RTS_
    CKT TYPE FL Host 00 0 03 03 No DIRN Idl

7 Diag_
8
9 Almstat
10 CKTLOC
11 Hold
12 Next_
13
14
15
16 Prefix_
17 LCO_
18 Level_
```

4 Busy the LEN posted by typing

>BSY and pressing the Enter key.

Example of a MAP display:

CI	M MS	IOD	Net	PM	CCS	LNS	Trks	Ext	Appl	/
	• •	•	•	•	•	•	•		•	
LT	P									
	Quit Post_	POST	DELQ	BusyQ	PRI	EFIX				
3	_	LCC	PTY RNG	LEN	1	ON ST	TA FS LTA	TE RE	SULT	
4 5	Bsy_	CKT TYP	E FL Host	00 0 0						
6	RTS_									
8	Diag_									
	Almstat CKTLOC									
	Hold									
12 13	Next_									
14										
15 16	Prefix_									
	LCO_									
18	Level_								_	Ϊ

### At the LCE frame

5



### WARNING

Card damage—transport

Take the following precautions to protect circuit cards from electrical and mechanical damage during transport:

When handling a circuit card not in an electrostatic discharge (ESD) protective container, stand on a conductive floor mat and wear a wriststrap connected, through a 1-megohm resistor, to a suitably grounded object, such as a metal workbench or a DMS switch frame (Northern Telecom [Nortel] Corporate Standard 5028). Store and transport circuit cards in an ESD protective container.



#### WARNING Static electricity damage

Before removing any cards, put on a wriststrap and connect it to the wriststrap grounding point on the left side of the modular supervisory panel (MSP) of the LCME. This protects the equipment against damage caused by static electricity.



### DANGER

Equipment damage

Take the following precautions when removing or inserting a card:

- 1. Do not apply direct pressure to the components.
- 2. Do not force the cards into the slots.



### DANGER

**Possible injury from hot materials** Exercise care when handling the line card. The line feed resistor may be hot.



### CAUTION

**Special tools required** Card shrouds and removal tools are required for removing cards from the line drawers. For descriptions of these tools, refer to the following notes.

Put on a wrist strap.

6

*Note:* Card shrouds are required for inserting or removing cards in line drawers. Two sizes are available for use with 3-inch and 6-inch cards. The following table describes card shrouds.

Line card insertion / withdrawal tool for	Apparatus code	Common product code
3-inch cards	QTH56A	A0298291
6-inch cards	QTH58A	A0313317

*Note:* Card removal tools are required for removing cards from line drawers. Two sizes are available. The following table describes these tools.

Card removal tool for	Apparatus code	Common product code		
3—4 inch cards	QTH57A	A0298292		
Note: For 4-inch or larger cards use the large grip tool ITA0053				

*Note:* For 4-inch or larger cards, use the large grip tool ITA9953.

Open the line drawer and prepare to remove the faulty card by following these substeps:

- **a** Face the drawer shelf and grasp the handle at the bottom of the drawer with your right hand.
- **b** Push up on the drawer latch with your thumb and pull the drawer out until fully withdrawn. It is fully withdrawn when the drawer stop, at the top, prevents further travel.
- **c** Maintain a slight pull on the handle and lift the faceplate of the drawer approximately 2.5 cm (1.0 in).
- **d** While holding the drawer in this position, push the bottom of the drawer, nearest the shelf with your left hand, to a position about 1.0 cm (0.5 in) to the right.
- e Hold the drawer in this position with your left hand and lower the faceplate of the drawer by releasing the grip of your right hand.

- f Ensure a card shroud and line card extractor are available.
- 7 Remove the line card to be replaced by following these substeps:
  - **a** Slide a card shroud over the card to be removed and an adjacent card. If there is not an adjacent card on either side, do not use the card shroud.
  - **b** Grasp the edge of the card with a line card extractor at a point midway between the top and bottom edges. Hold the extractor in your right hand.
  - c Squeeze the handles of the extractor together to grasp the card tightly.
  - d Hold the front cover of the line drawer to steady it using your left hand.
  - e Pull the extractor away from the drawer, and the card will become unplugged from its socket on the drawer backplane.
  - f Continue pulling the card with the extractor until the card is clear of the shroud.
  - **g** Insert the card removed into the ESD container and store using local procedures.
- 8 Replace the faulty card by following these substeps:
  - a Remove the replacement card from the ESD container.
  - **b** Slide the card in the shroud guide slots toward the drawer backplane.
  - c Hold the front cover of the line drawer with your left hand to steady it.
  - **d** Grasp the top and bottom edges of the card with the fingers of your right hand.
  - e Push the card toward the backplane until it plugs fully into the backplane socket.
- 9 Continue this procedure depending on where you were when you were directed to this procedure.

If you entered this procedure from	Do	
alarm clearing procedures	step 14	
other	step 10	
est the line card just replaced by ty	ping	
DIAG		
nd pressing the Enter key.		
If DIAG	Do	
passes	step 11	
fails	step 15	
Return the line card to service by ty	bing	

10

11

and pressing the Enter key.

If RTS	Do
passes	step 12
fails	step 15

- 12 Send any faulty cards for repair according to local procedure.
- **13** Record the date the card was replaced, the serial number of the card, and the symptoms that prompted replacement of the card. Go to step 16.
- 14 Return to the procedure that directed you to this procedure. At the point where a faulty card list was produced, identify the next faulty card on the list and go to the appropriate card replacement procedure for that card in this manual.
- **15** Obtain further assistance in replacing this card by contacting the personnel responsible for higher level of support.
- 16 You have successfully completed this procedure. Return to the maintenance procedure that directed you to this card replacement procedure and continue as directed.

# NT7X05 in an RSC-S (DS-1) Model B RCC2

# Application

Use this procedure to replace the following cards in an RSC-RCC2.


PEC	Suffixes	Name
NT7X05	AA	Peripheral/Remote Loader-16


# **Common procedures**

None

# Action

The following flowchart is a summary of the procedure. To replace the card, use the instructions in the procedure that follows the flowchart.





### Replacing an NT7X05 in an RSC-S RCC2

### At your Current Location

- 1 Proceed only if you were either directed to this card replacement procedure from a step in a maintenance procedure, are using the procedure to verify or accept cards, or were directed to this procedure by your maintenance support group.
- 2



#### CAUTION Loss of service

When replacing a card in the RCC2 ensure the unit where you are replacing the card is INACTIVE and the mate unit is ACTIVE by observing the INSV and ACTIVE LEDs on each NTMX77 card.

Obtain a replacement card. Ensure the replacement card has the same product equipment code (PEC) including suffix, as the card to be removed.

### At the MAP display

3 Access the PM level and post the RCC2 by typing

>MAPCI;MTC;PM;POST RCC2 rcc2\_no

and pressing the Enter key.

where

rcc2\_no

is the number of the RCC2 to be busied

Example of a MAP display:

	CM ·	MS			PM 1RCC2				s Ext	APPL
RC	22			SysB	ManB	OffL	CB	sy	ISTb	InSv
0	Quit		PM	0	0	2		0	2	25
2	Post_		RCC2	0	0	0		0	1	1
3	ListS	et								
4			RCC2	0 IS	Tb Links	s_00S:	CSide	0, P	Side 0	
5	TRNSL	_	Unit0:	: Inac	t ISTb					
6	TST_		Unit1:	: Act	InSv					
7	BSY_									
8	RTS_									
9	OffL									
10	LoadPl	M_								
11	Disp_									
12	Next									
13										
14	Query	РМ								
15										
16	IRLIN	K								
17	Perfo	rm								
18										/

4 By observing the MAP display, be sure the card to be removed is on the inactive unit.

If the faulty card is on an	Do	
ACTIVE unit	step 5	
INACTIVE unit	step 9	

5 Switch the processing activity to the inactive unit by typing

### >SWACT

and pressing the Enter key.

If SwAct	Do
cannot continue at this time	step 6
can continue at this time	step 7

**6** Do not switch activity of the units. Reject the switch by typing

>NO

and pressing the Enter key.

The system discontinues the switch of activity.

Return to step 5 during a period of low traffic.

7 Switch the activity of the unit by typing

>YES

and pressing the Enter key.

The system runs a pre-SwAct audit to determine the ability of the inactive unit to accept activity reliably.

*Note:* A maintenance flag appears when maintenance tasks are in progress. Wait until the flag disappears before proceeding with the next maintenance action.

If the message is	Do
SwAct passed	step 9
SwAct failed	step 8
SwAct refused by SwAct con- troller	step 8

8 Return to the *Alarm Clearing Procedure*, to clear the alarm condition on the inactive unit. When the alarm is cleared, return to step 1 of this procedure.

### At the RCE frame

9 Put a sign on the active unit bearing the words *Active unit—Do not touch.* 

### At the MAP display

**10** Busy the inactive RCC2 unit by typing

>BSY INACTIVE

and pressing the Enter key.

### At the RCE frame

11



#### WARNING Static electricity damage

Before removing any cards, put on a wrist strap and connect it to the wrist strap grounding point on the left side of the frame supervisory panel of the RCC2. This protects the equipment against damage caused by static electricity.



### DANGER


card:

**Equipment damage** Take the following precautions when removing or inserting a


- 1. Do not apply direct pressure to the components.
- 2. Do not force the cards into the slots.

Put on a wrist strap.

- 12 Remove the NT7X05 card as shown in the following figures.
  - a Locate the card to be removed on the appropriate shelf.




**b** Open the locking levers on the card to be replaced and gently pull the card towards you until it clears the shelf.




c Ensure the replacement card has the same PEC, including suffix, as the card you just removed.

13 Open the locking levers on the replacement card.

**a** Align the card with the slots in the shelf and gently slide the card into the shelf.



- 14 Seat and lock the card.
  - **a** Using your fingers or thumbs, push on the upper and lower edges of the faceplate to ensure the card is fully seated in the shelf.
  - **b** Close the locking levers.



### At the MAP display

**15** Test the inactive RCC2 unit by typing

>TST UNIT unit\_no

and pressing the Enter key.

where

### rcc2\_unit\_no

is the number of the inactive RCC2 unit

*Example of a MAP response:* Test Passed

or Test Failed

If TST	Do	
passed	step 16	
failed	step 20	

16

Return the inactive RCC2 unit to service by typing

>RTS UNIT unit\_no and pressing the Enter key.

where

### unit\_no

is the number of the RCC2 unit (0 or 1) tested in step 15

If the RTS	Do
passed	step 17
failed	step 20

17 Load the inactive NT7X05 card by typing

>XPMSTOR INACTIVE CC load\_file \_name

and pressing the Enter key.

where

### load\_file\_name

is the name of the file datafilled in field LOAD of the inventory table. The default load\_file\_name is the file currently datafilled.

Obtain further assistance in replacing this card by contacting personnel responsible for higher level of support.

If load	Do
passed	step 18
failed	step 20

- **18** Send any faulty cards for repair according to local procedure.
- **19** Record the following items in office records:
  - date the card was replaced
  - serial number of the card
  - symptoms that prompted replacement of the card

Go to step 21.

- **20** Obtain further assistance in replacing this card by contacting personnel responsible for higher level of support.
- 21 You have successfully completed this procedure. Return to the maintenance procedure that directed you to this card replacement procedure and continue as directed.

# NTAX74 in an RSC-S (DS-1) Model B RCC2

# Application

Use this procedure to replace an NTAX74 card in an RCC2.

PEC	Suffixes	Name
NTAX74	AA	Cellular Access Processor with 16Mb Memory


# **Common procedures**


Does not apply

# Action

This procedure contains a summary flowchart and a list of steps. Use the flowchart to review the procedure. Follow the steps to perform the procedure.

### Summary of card replacement procedure for an NTAX74 card in RSC-S RCC2





### Summary of card replacement procedure for an NTAX74 card in RSC-S RCC2 (continued)

### To replace an NTAX74 in RSC-S RCC2

### At your current location

- 1 Proceed if one of the following conditions apply:
  - a step in a maintenance procedure directed you to this card replacement procedure
  - you use this procedure to verify or accept cards
  - the maintenance support group directed you to this procedure.
- 2



#### WARNING Loss of service

When you replace a card in an RCC2, make sure the unit in which you replace the card is *inactive* and the mate unit is *active*.

Obtain an NTAX74 replacement card. Make sure the replacement card has the same product engineering code (PEC) and PEC suffix, as the card to be removed.

### At the MAP terminal

**3** To make sure the current MAP display is at the peripheral module (PM) level and to post the RCC2, type:

>MAPCI;MTC;PM;POST RCC2 rcc2\_no

and press the Enter key.

where

#### rcc2\_no

is the number of the RCC2 to be busied

Example of a MAP display:

				PM 1RCC2	CCS		Trks	Ext	APPL ·
R	CC2		SysB	ManB	Of	fL	CBsy	ISTb	InSv
0	Quit	PM	0	0		2	0	2	25
2	Post_	RCC2	0	0		0	0	1	1
3	ListSet								
4		RCC2	0 ISTb	Links_C	00S:	CSide	0, PSide	0	
5	TRNSL_	Unit0:	Inact	SysB					
6	TST_	Unitl:	Act	InSv					
7	BSY_								
8	RTS_								
9	OffL								
10	LoadPM_								
11	Disp_								
12	Next_								
13	SwAct								
	QueryPM								
15									
	IRLINK								
1	Perform								
18									

4 To verify the defective NTAX74 card is in the inactive unit, make sure the light-emitting diode (LED) labled ACTIVE is OFF or check the MAP display.

If the defective card	Do
is in the active unit	step 5
is in the inactive unit	step 9

5 To switch the processing activity (SWACT) to the inactive unit, type:

#### >SWACT

and press the Enter key.

A confirmation prompt for the SWACT command appears at the MAP terminal.

If SWACT	Do
cannot continue at this time	step 6
can continue at this time	step 7

**6** To reject the prompt to SWACT the units, type:

>NO

and press the Enter key.

The system stop the SWACT.

Return to step 5 during periods of low traffic.

7 To confirm the system prompt, type:

>YES

and press the Enter key.

The system runs a pre-SWACT audit to determine if the inactive unit can accept activity accurately.

*Note:* A maintenance flag appears when maintenance tasks are in progress. Wait until the flag disappears before you proceed with the next maintenance action.

If the message	Do
is SWACT passed	step 9
is SWACT failed Reason: XPM SWACTback	step 8
is SWACT refused by SWACT Controller	step 8

8 To clear the alarm condition on the inactive unit return to the *Clearing an Alarm Procedures* when you clear the alarm, return to step 1 of this procedure.

#### At the RCE frame

**9** Place a sign with the words *Active unit-Do not touch* on the active unit. Do not attach this sign with magnets or tape.

#### At the MAP terminal

**10** Check the MAP display and determine the state of the inactive unit.

If the state	Do		
is SysB, CBsy, ISTb, or InSv	step 11		
is ManB	step 12		
To busy the inactive PM unit, type:			
>BSY INACTIVE			
and press the Enter key.			
To prevent the PM from trapping, type:			
>PMRESET UNIT rcc2_unit_no NORUN			
and press the Enter key.			
where			
<pre>rcc2_unit_no is the number of the inactive RCC2 unit zero and one</pre>			

11

12

#### At the RCE frame

13



#### WARNING Static electricity damage

Before you remove cards, wear a wrist strap that connects to the wrist-strap grounding point on the left side of the frame supervisory panel (FSP) of the RCC2. This protects the equipment against static electricity damage.



#### DANGER


Equipment damage

Take the following precautions when you remove or insert a card:


- 1. Do not apply direct pressure to the components.
- 2. Do not force the cards into the slots.

Wear a wrist strap.

- 14 The following figures show how to remove the NTAX74 card:
  - a Locate the card to be removed on the appropriate shelf.



**b** Open the locking levers on the card to be replaced. Carefully pull the card toward you until the card clears the shelf.



**c** Make sure the replacement card has the same PEC and PEC suffix, as the card you removed. Make sure all replacement card DIP switch settings match settings of the card you removed.

*Note:* If the NTAX74 circuit card has a DIP switch, set the DIP switch S1 to the common peripheral module (CPM).






#### DANGER

Possible loss of P-side nodes

When you install the replacement NTAX74, monitor the LEDs on the faceplate of the NTAX74 for the following indicators:1. The INSV and ESA LEDs come ON and remain ON until loading begins.2. The ACT LED can come ON and light for less than 1 s. If the ACT LED remains ON for more than 1 s, remove the NTAX74 circuit card and return to this step. If the NTAX74 circuit card remains with both units that have an active processor, a condition of dual activity occurs. This condition causes the loss of P-side nodes.

Open the locking levers on the replacement card.

- a Align the card with the slots in the shelf.
- **b** Carefully slide the card in the shelf.



If you were directed here from	Do
Clearing an alarm procedures	step 26
other	step 18

#### At the MAP terminal

**18** To load the inactive RCC2 unit, type:

#### >LOADPM INACTIVE

and press the Enter key.

If load	Do
passed	step 19
failed	step 27

**19** To query the XMS-based peripheral module (XPM) counters for the firmware load on the NTAX74, type:

#### >QUERYPM CNTRS

and press the Enter key.

Example of a MAP response

Unsolicitited MSG limit = 250, Unit 0 = 0, Unit 1 = 0 Unit 0:
Ram Load: WRI07BE
EPRom Version: AB02
EEPRom Load: Loadable: AX74XE01, Executable: AX74XE01
CMR Load: CMR03A
CAP:AX74AA
Unit 1:
Ram Load: WRI07BE
EPRom Version: AB02
EEPRom Load: Loadable: AX74XE01, Executable: AX74XE01
CMR Load: CMR03A
CAP: AX74AA

└── NTAX74 firmware load name ──

If firmware	Do	
is valid	step 22	
is invalid	step 20	
To load the inactive unit find	7 51	
LOADFW INACTIVE and press the Enter key.		
LOADFW INACTIVE	Do	
LOADFW INACTIVE and press the Enter key.		

20

21 To upgrade the inactive unit firmware, type:

#### >LOADFW INACTIVE UPGRADE

and press the Enter key.

If LOADFW UPGRADE	Do
passed	step 22
failed	step 27
To return the inactive RCC2 un	nit to service, type:
<pre>&gt;RTS UNIT unit_no</pre>	
and press the Enter key.	
where	
unit_no is the number of the ina	ctive RCC2 unit (0 or 1)
If RTS	Do
passes	step 23
fails	step 27

#### At the RCE frame

22

- 23 Remove the sign from the active RCC2 unit.
- 24 Send the defective cards for repair according to local procedure.
- **25** Note the following in the office records:
  - date the card is replaced
  - serial number of the card
  - problems that prompted replacement of the card.

Go to step 27.

- **26** Return to the *Alarm Clearing Procedure* or other procedure that directed you to this procedure. If necessary, go to the point where the system produced the defective card list. Identify the next defective card on the list, and go to the appropriate procedure for that card in this manual.
- 27 For additional help, contact the next level of support.
- **28** This procedure is complete. Return to the maintenance procedure that directed you to this card replacement procedure. Continue as directed.

# NTBX01 in an RSC-S (DS-1) Model B RCC2

# Application

Use this procedure to replace an NTBX01 card in an RSC-S RCC2.


PEC	Suffixes	Name
NTBX01	AB	ISDN Preprocessor
<i>Note:</i> NTBX01AC or NTBX01BA is required when the RCC2 is configured with the optional processor NTAX74AA instead of the NTMX77AA.		


# **Common procedures**

None

# Action

The following flowchart is only a summary of the procedure. To replace the card, use the instructions in the procedure that follows the flowchart.





#### Replacing an NTBX01 card in RSC-S RCC2

#### At your Current Location

1 Proceed only if you have been directed to this card replacement procedure from a step in a maintenance procedure, are using the procedure for verifying or accepting cards, or have been directed to this procedure by your maintenance support group.

2



#### CAUTION Loss of service

When replacing a card in the RCC2, ensure that the unit in which you are replacing the card is *inactive* and that the mate unit is *active*.

Obtain an NTBX01 replacement card. Ensure the replacement card has the same product equipment code (PEC), including suffix, as the card that is to be removed.

#### At the MAP terminal

3 Ensure the PM level of the MAP display is currently displayed and the RCC2 is posted by typing

>MAPCI;MTC;PM;POST RCC2 rcc2\_unit\_no

and pressing the Enter key.

where

rcc2\_unit\_no

is the number of the RCC2 with the faulty card

Example of a MAP display:

#### СМ IOD CCS MS Net РМ LNS Trks Ext Appl . . • • . . . • • . OffL ISTb RCC2 SysB ManB CBsy InSv 0 0 Quit РМ 0 0 0 25 0 2 Post\_ 0 RCC2 0 0 0 0 0 3 ListSet RCC2 0 ISTb Links\_OOS: CSide 0, PSide 0 4 5 TRNSL Unit0: Inact InSv Unit1: Act InSv 6 TST 7 BSY 8 RTS 9 OffL 10 LoadPM\_ 11 Disp\_ 12 Next\_ 13 14 QueryPM 15 16 17 18

### NTBX01 in an RSC-S (DS-1) Model B RCC2 (continued)

4 By observing the MAP display, ensure that the card to be removed is on the inactive unit.

If faulty card is on	Do
active unit	step 5
inactive unit	step 7

5 Switch the processing activity (SWACT) to the inactive unit by typing >SWACT

and pressing the Enter key.

6 Confirm the system prompt by typing

>YES

and pressing the Enter key.

After both units are in service, proceed to the next step.

#### At the RCE frame

7 Place a sign on the active unit bearing the words *Active unit—Do not touch.* This sign should not be attached by magnets or tape.

#### At the MAP terminal

8 Busy the inactive PM unit by typing

>bsy unit rcc2\_unit\_no

and pressing the Enter key.

where

#### rcc2\_unit\_no

is the number of the inactive RCC2 unit (0 or 1)

#### At the RCE frame

9

10



#### DANGER

Static electricity damage

Before removing any cards, put on a wrist strap and connect it to the wrist strap grounding point on the left side of the modular supervisory panel (MSP) of the RCC2. This protects the equipment against damage caused by static electricity.




#### DANGER Equipment damage

Take these precautions when removing or inserting a card:


- 1. Do not apply direct pressure to the components.
- 2. Do not force the card into its slot.

Put on a wrist strap.


- Remove the NTBX01 card as shown in the following figures.
  - a Locate the card to be removed on the appropriate shelf.




**b** Open the locking levers on the card to be replaced and gently pull the card toward you until it clears the shelf.



- **c** Ensure the replacement card has the same PEC, including suffix, as the card you just removed.
- 11 Open the locking levers on the replacement card.
  - **a** Align the card with the slots in the shelf.
  - **b** Gently slide the card into the shelf.



- **12** Seat and lock the card.
  - **a** Using your fingers or thumbs, push on the upper and lower edges of the faceplate to ensure the card is fully seated in the shelf.
  - **b** Close the locking levers.



#### At the MAP terminal

13 After replacing the faulty card, load the inactive RCC2 unit by typing >LOADPM UNIT rcc2\_unit\_no CC

SLOADPM UNIT TEEZ\_UIIIL\_IIO C

and pressing the Enter key.

where

rcc2\_unit\_no
is the number of the RCC2 unit busied in step 8

If load	Do		
passed	step 15		
failed	step 23		
est the inactive unit by typing			
<i>TST UNIT</i> rcc2_unit_no			
nd pressing the Enter key.			
vhere			
<b>rcc2_unit_no</b> is the number of the RCC2 ເ	init loaded in step 13		
se the following information to de	letermine where to proceed.		
If TST	Do		
passed	step 17		
failed	step 22		
Ise the following information to de	ermine where to proceed.		
If you entered this procedure from	Do		
alarm clearing procedures	step 22		
other	step 18		
Return the inactive RCC2 unit to se	ervice by typing		
RTS UNIT rcc2_unit_no			
and pressing the Enter key.			
vhere			
<b>rcc2_unit_no</b> is the number of the RCC2 ເ	init tested in step 15		
Ise the following information to de	ermine where to proceed.		
If RTS	Do		
passed	step 20		
failed	step 23		

- **21** Record the date the card was replaced, the serial number of the card, and the symptoms that prompted replacement of the card. Go to step 24.
- 22 Return to the procedure that directed you to this procedure. At the point where a faulty card list was produced, identify the next faulty card on the list and go to the appropriate card replacement procedure for that card in *Card Replacement Procedures*.
- 23 Obtain further assistance in replacing this card by contacting operating company maintenance personnel.
- 24 You have successfully completed this procedure. Remove the sign from the active unit and return to the maintenance procedure that directed you to this card replacement procedure and continue as directed.

# NTBX02 in an RSC-S (DS-1) Model B RCC2

# Application

Use this procedure to replace an NTBX02 card in an RSC-S RCC2.

PEC	Suffixes	Name			
NTBX02	AA, BA	D-Channel Handler			
<i>Note:</i> NTBX02BA is required when the RCC2 is configured with the optional processor NTAX74AA instead of the NTMX77AA.					


# **Common procedures**

None

# Action

The following flowchart is only a summary of the procedure. To replace the card, use the instructions in the procedure that follows the flowchart.

Summary of card replacement procedure for an NTBX02 card in an RSC-S RCC2



#### Replacing an NTBX02 card in an RSC-S RCC2

#### At your Current Location

- 1 Proceed only if you have been directed to this card replacement procedure from a step in a maintenance procedure, are using the procedure for verifying or accepting cards, or have been directed to this procedure by your maintenance support group.
- 2



#### CAUTION Loss of service

When replacing a card in the RCC2, ensure that the unit in which you are replacing the card is *inactive* and that the mate unit is *active*.

Obtain a replacement card. Ensure that the replacement card has the same product equipment code (PEC), including suffix, as the card that is to be removed.

If the faulty card is	Do
in an extension (EXT) shelf	step 3
not in an EXT shelf	step 4

#### At the MAP terminal

**3** For an extension shelf, refer to the slot positions in the following table to determine which unit contains the faulty NTBX02 card, and proceed to step 4.

IfEXT shelf slot number	DoCPM unit number	
3 / 24	0	
4 / 23	0	
5 / 22	0	
6 / 21	0	
7 / 20	0	
8 / 19	1	
9 / 18	1	

IfEXT shelf slot number	DoCPM unit number	
10 / 17	1	
11 / 16	1	
12 / 15	1	

4 Ensure the PM level of the MAP display is currently displayed and the RCC2 with the faulty DCH card is posted by typing

>MAPCI;MTC;PM;POST RCC2 rcc2\_no

and pressing the Enter key.

where

rcc2\_no

is the number of the RCC2 with the faulty card

Example of a MAP display:

(									
СМ	MS	IOD	Net	PM	CCS	LN	S Trks	Ext	Appl
•	•	•	•	•	•	•	•	•	•
RCC2			SvsB	ManB	0.	FfT,	CBsy	ISTb	InSv
		PM	-	0		0	0	0	25
	ost_		0	0		0	0	0	0
	istSet		0	0		Ũ	0		0
			0	Links_00	s: C	Side	0, PSide	0	
5 т	RNSL	Unit0:	Inad	ct InSv					
6 т	ST	Unit1:	Act	InSv					
7В	SY								
8 R	TS								
90	ffL								
10 L	oadPM_								
11 D	isp_								
12 N	ext_								
13									
14 Q	ueryPM								
15 D	CH -								
16									
17									
18									

5 Refer to the MAP display posted in step 4 to see if the faulty NTBX02 card is in the active or inactive unit.

If faulty card is in	Do
active unit	step 6
inactive unit	step 11

6 Switch the processing activity (SWACT) to the inactive unit by typing

and pressing the Enter key.

If SWACT	Do
cannot continue at this time	step 7
can continue at this time	step 8

7 Do not switch activity of the units. Reject the SWACT by typing

>NO

and pressing the Enter key.

The system discontinues the SWACT.

Return to step 1 during a period of low traffic.

8 Confirm the system prompt by typing

>YES

and pressing the Enter key.

The system runs a pre-SWACT audit to determine the ability of the inactive unit to accept activity reliably.

*Note:* A maintenance flag appears when maintenance tasks are in progress. Wait until the flag disappears before proceeding to the next maintenance action.

If the message is	Do
SWACT passed	step 10
SWACT failed	step 9
SWACT refused by SWACT controller	step 9

9 Return to the *Alarm Clearing Procedures* to clear the alarm condition on the inactive unit. When the alarm is cleared, return to step 1 of this procedure.

#### At the RCE frame

**10** Place a sign on the active unit bearing the words *Active unit—Do not touch.* This sign should not be attached by magnets or tape.

#### At the MAP terminal

**11** Busy the inactive PM unit by typing

*>bsy unit* unit\_no

and pressing the Enter key.

where

unit\_no

is the number of the inactive RCC2 unit (0 or 1) containing the faulty BX02 card

12 Access the DCH level of the MAP display by typing

>DCH

and pressing the Enter key.

Example of a MAP display:

/									
	CM MS	IOD	Net	PM	CCS	LNS	Trks	Ext	Appl
	• •	•	•	•	•	•	•	•	•
D	СН		SysB	ManB	OffL		CBsy	ISTb	InSv
0	Quit	PM	0	0	0		0	0	25
	~ Post_	RCC2	0	0	0		0	0	0
4		RCC2 0	Li	nks_00S:	CSide	Ο,	PSide	0	
5	TRNSL		InSv	-					
6	TST	Unit1:	InSv						
7	BSY								
8	RTS	DCH	0	0	0		1	0	0
9	OffL								
10	LoadPM_								
11	Disp_								
12	Next_								
13	SwAct								
14	QueryPM								
15	DCH								
16									
	Perform								
18									)

**13** Using the information in the MAP display in step 12, identify and post the faulty DCH card state by typing

>POST dch\_card\_state

and pressing the Enter key.

where

#### dch\_card\_state

is either CBsy, SysB or ISTb. The example in step 12 shows the DCH card as being CBsy.

Example of a MAP display:

c	m ms	IOD	Net	PM	ccs	LNS	Trks	Ext	Appl
	• •	•	•	•	•	•	•	•	•
D	СН	2	SysB	ManB	Of	fL	CBsy	ISTb	InSv
	Quit		0	0		0	0	0	25
2	Post_	RCC2	0	0		0	0	0	0
4		RCC2 0		s_00s:	CSid	e 0,	PSide	0	
		Unit0:							
		Unit1:	InSv						
	BSY								
	RTS	DCH	0	0		0	1	0	0
	OffL								
10	LoadPM_	DCH	0 ISC	51	CBSY	RCC2	2	PORT 15	
11	Disp_								
12	Next_								
13	SwAct								
14	QueryPM								
15	DCH								
16									
17	Perform								
18									)

#### 14 Identify the DCH load file name by typing

>QUERYPM and pressing the Enter key. Example of a MAP response

16

Site	Flr	RPos Bay_id	Shf	Description	Slot	EqPEC
HOST	01	R09 LTEI 00	32	LTC : 002	02	BX02

Loadnames : DCHINV - DCH32BT : INTL INDEX : 8

The DCH load file name in the example is DCH32BT.

**15** Use the following information to determine the next step in this procedure.

If system load module is	Do	
version 1	step 16	
version 2	step 17	
List the loadfile in the directory by	/ typing	
>DSKUT;LISTVOL D000 DCH	load_file_name ALL	
and pressing the Enter key.		
or		

>DSKUT;LISTVOL D010 DCH\_load\_file\_name ALL

and pressing the Enter key.

Local operating company policy determines which disk, D000 or D010, the loadfile will be on.

*Example of a MAP response* TAPE\$DIR DCH32BT

Proceed to step 18.

17 List the loadfile in the directory by typing

>DISKUT;LV SOOD

and pressing the Enter key.

>LF SOOD file\_name

and pressing the Enter key.

or

>DISKUT;LV S01D

and pressing the Enter key.

>LF S01D file\_name

and pressing the Enter key.

**18** Leave the disk utility by typing

>quit

and pressing the Enter key.

- **19** Compare the information in the example in step 14 with the information in the example in step 16 to verify the DCH file name exists. For instance, the file name in step 16 is *DCH32BT*, which corresponds to the file name in step 14.
- 20 Busy the faulty card by typing

>BSY

and pressing the Enter key.

#### At the RCE frame

21



#### CAUTION

**Static discharge may cause damage to circuit packs** Put on a wrist strap and connect it to the frame of the RMM before removing any cards. This protects the RMM against service degradation caused by static electricity.




# DANGER

**Equipment damage** Take these precautions when removing or inserting a card:


1. Do not apply direct pressure to the components.2. Do not force the cards into the slots.

Put on a wrist strap.


- 22 Remove the NTBX02 card as shown in the following figures.
  - a Locate the card to be removed on the appropriate shelf.



**b** Open the locking levers on the card to be replaced and gently pull the card toward you until it clears the shelf.



- c Ensure the replacement card has the same PEC, including suffix, as the card you just removed.
- 23 Open the locking levers on the replacement card.
  - a Align the card with the slots in the shelf.
  - **b** Gently slide the card into the shelf.



24




**CAUTION** Loss of subscriber service Subscriber service may be lost in the active unit when reseating the NTBX02 card.

It is recommended that this procedure be performed during low traffic periods.

Seat and lock the card.

- **a** Using your fingers or thumbs, push on the upper and lower edges of the faceplate to ensure that the card is fully seated in the shelf.
- **b** Close the locking levers.



#### At the MAP terminal

25 Load the DCH card by typing >LOADPM

and pressing the Enter key.

26 Use the following information to determine the next step in this procedure.

If load	Do	
passed	step 27	
failed	step 34	

27 Return the DCH card to service by typing >RTS

28

29

30

# NTBX02 in an RSC-S (DS-1) Model B RCC2 (continued)

and pressing the Enter key.	
-----------------------------	--

If RTS	Do
passed	step 28
failed	step 34
Leave the DCH level of the typing	MAP display and return to the RCC2 level by
>QUIT	
and pressing the Enter key.	
Return to service the PM u	nit busied in step 11 by typing
<pre>&gt;RTS unit unit_no</pre>	
and pressing the Enter key.	
where	
unit_no is the number of the BX02 card	inactive RCC2 unit (0 or 1) containing the new
	is in convice by typing
Ensure that the RCC2 unit	is in service by typing
Ensure that the RCC2 unit >QUERYPM FLT and pressing the Enter key.	

CI	i MS	IOD	Net	PM C	CS Lns	Trks	Ext	Appl
•	•	•	•	•	• •	•	•	•
RC	C2		SysB	ManB	OffL	CBsy	ISTb	InSv
(	Quit	PM	0	0	0	0	0	25
2	Post_	RCC2	0	0	0	0	0	1
1	ListSet							
4		RCC2 0	InSv	Links_0	OS: CSide	0, PSide	0	
5	TRNSL_	Unit0:	Act I	nSv				
e	Tst_	Unit1:	Inact	InSv				
7	Bsy_	QUERYPM	FLT					
8	RTS_	Un	it0 No	trouble	s exist			
9	OffL	Un	itl No	trouble	s exist			
10	LoadPM_							
11	Disp_							
12	Next							
13								
14	QueryPM							
15	DCH							
16								
17								
_18								

Use the following information to determine the next step in this procedure.

If faults are	Do				
not indicated	step 31				
indicated	step 34				
Send any faulty cards for repair according to local procedure.					
Record the date the card was replaced, the serial number of the card, and the symptoms that prompted replacement of the card.					

31 32

If you entered this procedure from	Do
alarm clearing procedures	step 33
other	step 35

- **33** Return to *Alarm Clearing Procedures* or other procedure that directed you to this procedure. At the point where a faulty card list was produced, identify the next faulty card on the list and go to the appropriate card replacement procedure for that card in this manual.
- **34** Obtain further assistance in replacing this card by contacting the personnel responsible for higher level of support.
- **35** You have successfully completed this procedure. Remove the sign from the active unit and return to the maintenance procedure that directed you to this card replacement procedure and continue as directed.

# NTBX26 in an RSC-S (DS-1) Model B LCME

# Application

Use this procedure to replace an NTBX26 card in an RSC-S LCME.

PEC	Suffixes	Name
NTBX26	AA	ISDN S/T Interface Line card


# **Common procedures**

None

# Action

The following flowchart is only a summary of the procedure. To replace the card, use the instructions in the procedure that follows the flowchart.

#### Summary of card replacement procedure for an NTBX26 card in an RSC-S LCME



#### Replacing an NTBX26 card in an RSC-S LCME

#### At your Current Location

- 1 Proceed only if you have been directed to this card replacement procedure from a step in a maintenance procedure, are using the procedure for verifying or accepting cards, or have been directed to this procedure by your maintenance support group.
- 2 Obtain an NTBX26 replacement card. Ensure the replacement card has the same product equipment code (PEC), including suffix, as the card that is to be removed.

#### At the MAP terminal

**3** Post the line equipment number (LEN) of the card to be replaced by typing

# >MAPCI;MTC;LNS;LTP;POST L site lcme\_no unit\_no lsg\_no ckt\_no

and pressing the Enter key.

where

site

is the location name of the LCME with the faulty card

lcme\_no

is the number of the LCME with the faulty card

#### unit\_no

is the number of the LCME unit with the faulty card

#### lsg no

is the number of the LSG with the faulty card

#### ckt\_no

is the number of the circuit associated with the faulty card

Example of a MAP display:

/	СM	i Ms	IC	DD Net	: PM	CCS	LNS	Trks	Ext	Appl
	•	•	•	•	•	•	•	•	•	•
L	ТΡ	,								
	0	Quit	Pc	ost I	DELQ	BUSYQ	PR	EFIX		
	2	Post_								
	3		LC	C PTY RI	NGLE	ND	N	STA F S	LTA TE	RESULT
	4		IS	SDN Loop	HOST 00	0 03 03	49310	82 IDL		
	5	BSY								
	6	RTS								
	7	DIAG								
	8									
		AIMSta								
		CKTLOC								
		Hold								
		Next_								
	3									
	4									
1										
		Prefix								
		LCO								
$\backslash$ <sup>1</sup>	8	Level								

4 Busy the NTBX26 line card by typing

>BSY

and pressing the Enter key. *Example of a MAP display:* 

CM       MS       IOD       Net       PM       CCS       LNS       Trks       Ext       Appl         . <th>~</th> <th></th>	~										
LTP 0 Quit Post DELQ BUSYQ PREFIX 2 Post_ 3 LCC PTY RNGLENDN STA F S LTA TE RESULT 4 ISDN Loop HOST 00 0 03 03 4931082 MB 5 BSY 6 RTS 7 DIAG 8 9 AIMStat 10 CKTLOC 11 Hold 12 Next_ 13 14 15 16 Prefix 17 LCO	/	CM	i MS	IOD	Net	PM	CCS	LNS	Trks	Ext	Appl
0       Quit       Post       DELQ       BUSYQ       PREFIX         2       Post		•	•	•	•	•	•	•	•	•	•
<pre>2 Post_ 3 LCC PTY RNGLENDN STA F S LTA TE RESULT 4 ISDN Loop HOST 00 0 03 03 4931082 MB 5 BSY 6 RTS 7 DIAG 8 9 AIMStat 10 CKTLOC 11 Hold 12 Next_ 13 14 15 16 Prefix 17 LCO</pre>		LTF	<b>b</b>								
<pre>3 LCC PTY RNGLENDN STA F S LTA TE RESULT 4 ISDN Loop HOST 00 0 03 03 4931082 MB 5 BSY 6 RTS 7 DIAG 8 9 AIMStat 10 CKTLOC 11 Hold 12 Next_ 13 14 15 16 Prefix 17 LCO</pre>		0	Quit	Post	DE	LQ	BUSY	Q	PREFIX		
4 ISDN Loop HOST 00 0 03 03 4931082 MB 5 BSY 6 RTS 7 DIAG 8 9 AIMStat 10 CKTLOC 11 Hold 12 Next_ 13 14 15 16 Prefix 17 LCO		2	Post_								
5 BSY 6 RTS 7 DIAG 8 9 AIMStat 10 CKTLOC 11 Hold 12 Next_ 13 14 15 16 Prefix 17 LCO		3		LCC PT	Y RNG	LEN.	DN		STA F S	LTA TE	RESULT
6 RTS 7 DIAG 8 9 AIMStat 10 CKTLOC 11 Hold 12 Next_ 13 14 15 16 Prefix 17 LCO		4		ISDN L	oop HO	ST 00	0 03 03	493108	2 MB		
<pre>7 DIAG 8 9 AIMStat 10 CKTLOC 11 Hold 12 Next_ 13 14 15 16 Prefix 17 LCO</pre>		5	BSY								
<pre>8 9 AIMStat 10 CKTLOC 11 Hold 12 Next_ 13 14 15 16 Prefix 17 LCO</pre>		б	RTS								
9 AIMStat 10 CKTLOC 11 Hold 12 Next_ 13 14 15 16 Prefix 17 LCO			DIAG								
10 CKTLOC 11 Hold 12 Next_ 13 14 15 16 Prefix 17 LCO		8									
11 Hold 12 Next_ 13 14 15 16 Prefix 17 LCO											
12 Next_ 13 14 15 16 Prefix 17 LCO											
13 14 15 16 Prefix 17 LCO											
14 15 16 Prefix 17 LCO			Next_								
15 16 Prefix 17 LCO											
16 Prefix 17 LCO											
17 LCO											
18 Level											
		18	Level								

#### At the LCE frame

5



### WARNING

Card damage—transport

Take the following precautions to protect circuit cards from electrical and mechanical damage during transport:

When handling a circuit card not in an electrostatic discharge (ESD) protective container, stand on a conductive floor mat and wear a wriststrap connected, through a 1-megohm resistor, to a suitably grounded object, such as a metal workbench or a DMS switch frame (Northern Telecom [Nortel] Corporate Standard 5028). Store and transport circuit cards in an ESD protective container.



#### WARNING Static electricity damage

Before removing any cards, put on a wriststrap and connect it to the wriststrap grounding point on the left side of the modular supervisory panel (MSP) of the LCME. This protects the equipment against damage caused by static electricity.



#### DANGER

Equipment damage

Take the following precautions when removing or inserting a card:

- 1. Do not apply direct pressure to the components.
- 2. Do not force the cards into the slots.

# DANGER

### Hot materials

Exercise care when handling the line card. The line feed resistor may be very hot.



#### CAUTION

**Special tools required** Card shrouds and removal tools are required for removing cards from the line drawers. For descriptions of these tools, refer to the following notes.

Put on a wriststrap.

*Note:* Card shrouds are required for inserting or removing cards in line drawers. Two sizes are available for use with 3-inch and 6-inch cards, as shown in the following table.

Line card insertion / withdrawal tool for	Apparatus code	Common product code
3-inch cards	QTH56A	A0298291
6-inch cards	QTH58A	A0313317

*Note:* Card removal tools are required for removing cards from line drawers. Two sizes are available, as shown in the following table.

Card removal tool for	Apparatus code	Common product code			
3—4 inch cards	QTH57A	A0298292			
<i>Note:</i> For 4-inch or larger cards, use the large grip tool ITA9953.					

6

To prepare to remove the faulty card, open the line drawer and do the following substeps:

- **a** Face the drawer shelf and grasp the handle at the bottom of the drawer with your right hand.
- **b** Push up on the drawer latch with your thumb and pull the drawer out until fully withdrawn. It is fully withdrawn when the drawer stop, at the top, prevents further travel.
- **c** Maintain a slight pull on the handle and lift the faceplate of the drawer approximately 2.5 cm (1.0 in).
- **d** While holding the drawer in this position, push the bottom of the drawer, nearest the shelf with your left hand, to a position about 1.0 cm (0.5 in) to the right.
- e Hold the drawer in this position with your left hand and lower the faceplate of the drawer by releasing the grip of your right hand.

- f Ensure a card shroud and line card extractor are available.
- 7 Remove the line card to be replaced by following these substeps:
  - **a** Slide a card shroud over the card to be removed and an adjacent card. If there is not an adjacent card on either side, do not use the card shroud.
  - **b** Grasp the edge of the card with a line card extractor at a point midway between the top and bottom edges. Hold the extractor in your right hand.
  - **c** Squeeze the handles of the extractor together to grasp the card tightly.
  - d Hold the front cover of the line drawer to steady it using your left hand.
  - e Pull the extractor away from the drawer, and the card will become unplugged from its socket on the drawer backplane.
  - f Continue pulling the card with the extractor until the card is clear of the shroud.
  - **g** Insert the card removed into the ESD container and store using local procedures.
- 8 Replace the faulty card by following these substeps:
  - a Remove the replacement card from the ESD container.
  - **b** Slide the card in the shroud guide slots toward the drawer backplane.
  - c Hold the front cover of the line drawer with your left hand to steady it.
  - **d** Grasp the top and bottom edges of the card with the fingers of your right hand.
  - e Push the card toward the backplane until it plugs fully into the backplane socket.
- **9** Use the following information to determine where to proceed.

If you entered this procedure from	Do
alarm clearing procedures	step 15
other	step 10

#### At the MAP terminal

**10** Test the NTBX26 line card by typing

>DIAG

and pressing the Enter key.

11 Use the following information to determine where to proceed.

If DIAG	Do	
passed	step 12	
failed	step 15	

### NTBX26 in an RSC-S (DS-1) Model B LCME (end)

**12** Return the NTBX26 card to service by typing

>RTS

and pressing the Enter key.

If RTS	Do	
passed	step 13	
failed	step 16	

- **13** Send any faulty cards for repair according to local procedure.
- 14 Record the date the card was replaced, the serial number of the card, and the symptoms that prompted replacement of the card. Go to step 17.
- **15** Return to the procedure that directed you to this procedure. At the point where a faulty card list was produced, identify the next faulty card on the list and go to the appropriate card replacement procedure for that card in this manual.
- **16** Obtain further assistance in replacing this card by contacting operating company maintenance personnel.
- 17 You have successfully completed this procedure. Return to the maintenance procedure that directed you to this card replacement procedure and continue as directed.

## NTBX27 in an RSC-S (DS-1) Model B LCME

### Application

Use this procedure to replace an NTBX27 card in an RSC-S LCME.

PEC	Suffixes	Name
NTBX27	AA	ISDN 2B1Q U Interface Line card


## **Common procedures**

None

## Action

The following flowchart is only a summary of the procedure. To replace the card, use the instructions in the procedure that follows the flowchart.

### Summary of card replacement procedure for an NTBX27 card in an RSC-S LCME



#### Replacing an NTBX27 card in an RSC-S LCME

#### At your Current Location

- 1 Proceed only if you have been directed to this card replacement procedure from a step in a maintenance procedure, are using the procedure for verifying or accepting cards, or have been directed to this procedure by your maintenance support group.
- 2 Obtain an NTBX27 replacement card. Ensure the replacement card has the same product equipment code (PEC), including suffix, as the card that is to be removed.

#### At the MAP terminal

**3** Post the LEN of the card to be replaced by typing

>MAPCI;MTC;LNS;LTP;POST L site lcme\_no unit\_no lsg\_no
ckt\_no

and pressing the Enter key.

where

site

is the location name of the LCME with the faulty card

lcme\_no

is the number of the LCME with the faulty card

#### unit\_no

is the number of the LCME unit with the faulty card

#### lsg no

is the number of the LSG with the faulty card

#### ckt\_no

is the number of the circuit associated with the faulty card

Example of a MAP display:

(	CM	i MS	IOD	Net	PM	CCS	LNS	Trks	Ext	Appl
	•	•	•	•	•	•	•	•	•	•
	LTF	<b>)</b>								
		Quit	Post	DE	LO	BUSYO		PREFIX		
		Post_			~	~~~~~				
	3		LCC PT	Y RNG	LEN.	DN		STA F S	LTA TE	RESULT
	4		ISDN L	oop	HOST 0	0 0 03 0	3 493	31082 ID	L	
		BSY								
		RTS								
		DIAG								
	8	A TMOL + +								
		AIMStat CKTLOC								
		Hold								
		Next_								
	13									
	14									
	15									
	16	Prefix								
		LCO								
	18	Level								

4 Busy the NTBX27 line card by typing

>BSY and pressing the Enter key.

Example of a MAP display:

								_		_
C	'M	MS	IOD	Net	PM	CCS	LNS	Trks	Ext	Appl
•		•	•	•	•	•	•	•	•	•
LI	סי									
		+	Dogt	ਸ	τo	DIICV	2	PREFIX		
			POSL		цQ	DUSI	2	PREFIX		
2	? Pos	_			TINT	DN				
								STA F S	LIAIL	RESULI
			ISDN L	оор но	ST 00	0 03 03	493108	Z MB		
	BSY									
	RTS									
	DIA	G								
8										
	AIM									
	) CKT									
11	. Hol	d								
12	2 Nex	t_								
13	3									
14	ł									
15	5									
16	Pre	fix								
17	LCO									
18	Lev	el								

### At the LCE frame

5



### WARNING

Card damage—transport Take the following precautions to protect circuit cards from

electrical and mechanical damage during transport:

When handling a circuit card not in an electrostatic discharge (ESD) protective container, stand on a conductive floor mat and wear a wriststrap connected, through a 1-megohm resistor, to a suitably grounded object, such as a metal workbench or a DMS switch frame (Northern Telecom [Nortel] Corporate Standard 5028). Store and transport circuit cards in an ESD protective container.



#### WARNING Static electricity damage

Before removing any cards, put on a wriststrap and connect it to the wriststrap grounding point on the left side of the modular supervisory panel (MSP) of the LCME. This protects the equipment against damage caused by static electricity.



### DANGER

Equipment damage

Take the following precautions when removing or inserting a card:

- 1. Do not apply direct pressure to the components.
- 2. Do not force the cards into the slots.

# DANGER

### Hot materials

Exercise care when handling the line card. The line feed resistor may be very hot.



### CAUTION

**Special tools required** Card shrouds and removal tools are required for removing cards from the line drawers. For descriptions of these tools, refer to the following notes.

Put on a wriststrap.

*Note:* Card shrouds are required for inserting or removing cards in line drawers. Two sizes are available for use with 3-inch and 6-inch cards, as shown in the following table.

Line card insertion / withdrawal tool for	Apparatus code	Common product code		
3-inch cards	QTH56A	A0298291		
6-inch cards	QTH58A	A0313317		

*Note:* Card removal tools are required for removing cards from line drawers. Two sizes are available, as shown in the following table.

Card removal tool for	Apparatus code	Common product code				
3—4 inch cards	QTH57A	A0298292				
<i>Note:</i> For 4-inch or larger cards, use the large grip tool ITA9953.						

6

To prepare to remove the faulty card, open the line drawer and follow these substeps:

- **a** Face the drawer shelf and grasp the handle at the bottom of the drawer with your right hand.
- **b** Push up on the drawer latch with your thumb and pull the drawer out until fully withdrawn. It is fully withdrawn when the drawer stop, at the top, prevents further travel.
- **c** Maintain a slight pull on the handle and lift the faceplate of the drawer approximately 2.5 cm (1.0 in).
- **d** While holding the drawer in this position, push the bottom of the drawer, nearest the shelf with your left hand, to a position about 1.0 cm (0.5 in) to the right.
- e Hold the drawer in this position with your left hand and lower the faceplate of the drawer by releasing the grip of your right hand.

- f Ensure a card shroud and line card extractor are available.
- 7 Remove the line card to be replaced by following these substeps:
  - **a** Slide a card shroud over the card to be removed and an adjacent card. If there is not an adjacent card on either side, do not use the card shroud.
  - **b** Grasp the edge of the card with a line card extractor at a point midway between the top and bottom edges. Hold the extractor in your right hand.
  - **c** Squeeze the handles of the extractor together to grasp the card tightly.
  - **d** Hold the front cover of the line drawer to steady it using your left hand.
  - e Pull the extractor away from the drawer, and the card will become unplugged from its socket on the drawer backplane.
  - f Continue pulling the card with the extractor until the card is clear of the shroud.
  - **g** Insert the card removed into the ESD container and store using local procedures.
- 8 Replace the faulty card by following these substeps:
  - a Remove the replacement card from the ESD container.
  - **b** Slide the card in the shroud guide slots toward the drawer backplane.
  - c Hold the front cover of the line drawer with your left hand to steady it.
  - **d** Grasp the top and bottom edges of the card with the fingers of your right hand.
  - e Push the card toward the backplane until it plugs fully into the backplane socket.
- **9** Use the following information to determine where to proceed.

If you entered this procedure from	Do
alarm clearing procedures	step 15
other	step 10

### At the MAP terminal

10 Test the NTBX27 line card by typing

>DIAG

and pressing the Enter key.

11 Use the following information to determine where to proceed.

If DIAG	Do	
passed	step 12	
failed	step 16	

**12** Return the NTBX27 card to service by typing

>RTS

and pressing the Enter key.

If RTS	Do	
passed	step 13	
failed	step 16	

- **13** Send any faulty cards for repair according to local procedure.
- 14 Record the date the card was replaced, the serial number of the card, and the symptoms that prompted replacement of the card. Go to step 17.
- **15** Return to the procedure that directed you to this procedure. At the point where a faulty card list was produced, identify the next faulty card on the list and go to the appropriate card replacement procedure for that card in this manual.
- **16** Obtain further assistance in replacing this card by contacting operating company maintenance personnel.
- 17 You have successfully completed this procedure. Return to the maintenance procedure that directed you to this card replacement procedure and continue as directed.

## NTBX34 in an RSC-S (DS-1) Model B LCME

## Application

Use this procedure to replace an NTBX34 card in an RSC-S LCME.

PEC	Suffixes	Name
NTBX34	BA	ISDN Enhanced LCM Processor


## **Common procedures**

None

## Action

The following flowchart is only a summary of the procedure. To replace the card, use the instructions in the procedure that follows the flowchart.

### Summary of card replacement procedure for an NTBX34 card in an RSC-S LCME



#### Replacing an NTBX34 card in an RSC-S LCME

#### At your Current Location

- 1 Proceed only if you have been directed to this card replacement procedure from a step in a maintenance procedure, are using the procedure for verifying or accepting cards, or have been directed to this procedure by your maintenance support group.
- 2 Obtain an NTBX34 replacement card. Ensure the replacement card has the same product equipment code (PEC), including suffix, as the card that is to be removed.

#### At the MAP terminal

3 Set the MAP display to the PM level and post the LCME by typing

### >MAPCI;MTC;PM;POST LCME site frame\_no lcme\_no

and pressing the Enter key.

where

#### site

is the name of the site at which the LCME is located

#### frame no

is the number of the frame at which the LCME is located

#### lcme\_no

is the number of the LCME with the faulty card

Example of a MAP display:

			Net					Ext	Appl	
· ·	·	·	•	•	•	•	·	•		
LCN	4E		SysB	ManB	Of	fL	CBsy	ISTb	InSv	
0	Quit	PM	0	0		0	0	0	130	
2	Post_	LCME	0	0		0	0	0	0	
4	Swrg_	LCM	E RemL	00 0	Links	_00S:	CSide 0			
5	Trnsl_	Uni	t-0: I	nSv		/R	G: 0			
6	Tst_	Uni	Unit-1: InSv /RG: 0							
7	Bsy_	RG:	Preferre	ed 0: I	nSv S	tandby	1: InSv			
8	RTS_									
9	OffL_									
10	LoadPM_									
11	Disp_									
12	Next_									
13										
14	QueryPM									
15										
16										
17										
18									)	

4

Busy the LCME unit by typing

>BSY UNIT unit\_no

and pressing the Enter key.

where

unit\_no

is the number of the LCME unit with the faulty card

Example of a MAP display:

	СМ	MS	IOD	Net	PM	CCS	LNS	Trks	Ext	Appl
	•	•	•	•		•	•		•	•
I	CME	]		SysB	ManB	Of	fL	CBsy	ISTb	InSv
	0 Ç	Quit	PM	0	0		0	0	0	130
	2 F	ost_	LCME	0	1		0	0	0	0
	3									
	4 S	Swrg_	LCM	E RemL	00 0	Links	_00S:	CSide 0		
	5 Т	rnsl_	Uni	t-0: I	nSv Mto	e Take	eover /	RG: 0		
	6 Т	"st_	Uni	t-1: M	lanB Mtc	ce	/:	RG: 0		
	7 E	Bsy_	RG:	Preferre	d 0: I	inSv S	Standby	1: InSv		
	8 F	RTS_								
	9 C	)ffL_								
1	0 I	loadPM_								
1	1 C	)isp_								
1	2 N	lext_								
1	3									
1	4 Ç	QueryPM								
1	5									
1	6									
1	7									
$\begin{pmatrix} 1 \end{pmatrix}$	8									

### At the LCE frame

5



### WARNING

Card damage—transport

Take the following precautions to protect circuit cards from electrical and mechanical damage during transport:

When handling a circuit card not in an electrostatic discharge (ESD) protective container, stand on a conductive floor mat and wear a wriststrap connected, through a 1-megohm resistor, to a suitably grounded object, such as a metal workbench or a DMS switch frame (Northern Telecom [Nortel] Corporate Standard 5028). Store and transport circuit cards in an ESD protective container.



#### WARNING Static electricity damage

Before removing any cards, put on a wriststrap and connect it to the wriststrap grounding point on the left side of the modular supervisory panel (MSP) of the LCME. This protects the equipment against damage caused by static electricity.



### DANGER

Equipment damage

Take the following precautions when removing or inserting a card:


- 1. Do not apply direct pressure to the components.
- 2. Do not force the cards into the slots.

Put on a wriststrap.


6

Remove the NTBX34 card as shown in the following figures.


а Locate the card to be removed on the appropriate shelf.




**b** Open the locking levers on the card to be replaced and gently pull the card toward you until it clears the shelf.



- **c** Ensure the replacement card has the same PEC, including suffix, as the card you just removed.
- 7 Open the locking levers on the replacement card.
  - a Align the card with the slots in the shelf.
  - **b** Gently slide the card into the shelf.



- 8 Seat and lock the card.
  - **a** Using your fingers or thumbs, push on the upper and lower edges of the faceplate to ensure the card is fully seated in the shelf.
  - **b** Close the locking levers.



### At the MAP terminal

- 9 Load the LCME unit by typing
  - >loadpm unit unit\_no CC
  - and pressing the Enter key.

where

- unit\_no
  - is the number of the LCME unit busied in step 4

If load	Do				
passed	step 11				
failed	step 19				
est the LCME unit by typing					
T UNIT unit_no					
nd pressing the Enter key.					
vhere					
unit_no is the number of the LCME	unit loaded in step 9				
lse the following information to de	etermine where to proceed.				
If TST	Do				
passed	step 13				
failed	step 18				
Jse the following information to de	etermine where to proceed.				
If you entered this procedure from	Do				
alarm clearing procedures	step 18				
other	step 14				
Return the LCME unit to service b	y typing				
RTS UNIT lcme_unit_no					
and pressing the Enter key.					
vhere					
Icme_unit_no is the number of the LCME	unit tested in step 12				
Jse the following information to de	etermine where to proceed.				
If RTS	Do				
passed	step 16				
failed	step 19				

- **17** Record the date the card was replaced, the serial number of the card, and the symptoms that prompted replacement of the card. Go to step 20.
- **18** Return to the procedure that directed you to this procedure. At the point where a faulty card list was produced, identify the next faulty card on the list and go to the appropriate card replacement procedure for that card in this manual.
- **19** Obtain further assistance in replacing this card by contacting operating company maintenance personnel.
- 20 You have successfully completed this procedure. Return to the maintenance procedure that directed you to this card replacement procedure and continue as directed.

## NTBX35 in an RSC-S (DS-1) Model B LCME

## Application

Use this procedure to replace an NTBX35 card in an RSC-S LCME.

PEC	Suffixes	Name
NTBX35	AA	ISDN LCM Digroup Controller


## **Common procedures**

None

## Action

The following flowchart is only a summary of the procedure. To replace the card, use the instructions in the procedure that follows the flowchart.





#### Replacing an NTBX35 card in an RSC-S LCME

#### At your Current Location

- 1 Proceed only if you have been directed to this card replacement procedure from a step in a maintenance procedure, are using the procedure for verifying or accepting cards, or have been directed to this procedure by your maintenance support group.
- 2 Obtain an NTBX35 replacement card. Ensure the replacement card has the same product equipment code (PEC), including suffix, as the card that is to be removed.

#### At the MAP terminal

3 Set the MAP to the PM level and post the LCME by typing

### >MAPCI;MTC;PM;POST LCME site frame\_no unit\_no

and pressing the Enter key.

#### where

site

is the name of the site at which the LCME is located

#### frame no

is the number of the frame in which the LCME is located

#### unit\_no

is the number of the LCME with the faulty card

Example of a MAP display:

4

Busy the LCME unit by typing

>BSY UNIT unit\_no

and pressing the Enter key.

where

unit\_no

is the number of the LCME unit with the faulty card

Example of a MAP display:

(									<i></i>
CI	M MS	IOD	Net	PM	CCS	LNS	Trks	Ext	Appl
•	•	•	•	•	•	•	•	•	•
LCI	<b>A</b> T	C.		ManD	0551	,		TOMP	Tre Coo
			-		OffL		-		InSv
	Quit		0	0	0		0	0	130
2	Post_	LCME	0	1	0		0	0	0
3									
4	SwRg	LCME	RemL (	0 00	Links_00	s: c	Side 0		
5	Trnsl				TakeOver				
б	Tst				rancover				
7	Bsy	RG: Pre							
	RTS	KG. PIE	rerrea	0. 111	SV SLA	Παργι	• 1115V		
	OffL								
	LoadPM								
	Disp_								
	Next								
13									
14	QueryPM								
15									
16									
17									
18									,
$\overline{\ }$									

### At the LCE frame

5



### WARNING

**Card damage—transport** Take the following precautions to protect circuit cards from electrical and mechanical damage during transport:

When handling a circuit card not in an electrostatic discharge (ESD) protective container, stand on a conductive floor mat and wear a wriststrap connected, through a 1-megohm resistor, to a suitably grounded object such as a metal workbench or a DMS switch frame (Northern Telecom [Nortel] Corporate Standard 5028). Store and transport circuit cards in an ESD protective container.



#### WARNING Static electricity damage

Before removing any cards, put on a wriststrap and connect it to the wriststrap grounding point on the left side of the modular supervisory panel (MSP) of the LCME. This protects the equipment against damage caused by static electricity.



### DANGER

Equipment damage

Take the following precautions when removing or inserting a card:

- 1. Do not apply direct pressure to the components.
- 2. Do not force the cards into the slots.


Put on a wriststrap.

|


6

Remove the NTBX35 card as shown in the following figures.


a Locate the card to be removed on the appropriate shelf.




**b** Open the locking levers on the card to be replaced and gently pull the card toward you until it clears the shelf.



- **c** Ensure the replacement card has the same PEC, including suffix, as the card you just removed.
- 7 Open the locking levers on the replacement card.
  - a Align the card with the slots in the shelf.
  - **b** Gently slide the card into the shelf.



- 8 Seat and lock the card.
  - **a** Using your fingers or thumbs, push on the upper and lower edges of the faceplate to ensure the card is fully seated in the shelf.
  - **b** Close the locking levers.



### At the MAP terminal

9 Load the LCME unit by typing >loadpm uNIT unit\_no CC and pressing the Enter key. where

If load	Do					
passed	step 10					
failed	step 16					
est the LCME unit by typing						
TST UNIT unit_no						
nd pressing the Enter key.						
where						
unit_no is the number of the LCME u	nit loaded in step 9					
If TST	Do					
passed	step 11					
failed	step 15					
Use the following information to dete	ermine where to proceed.					
If you entered this procedure from	Do					
alarm clearing procedures	step 15					
other	step 12					
Return the LCME unit to service by	typing					
>RTS UNIT lcme_unit_no						
and pressing the Enter key.						
where						
<pre>lcme_unit_no     is the number of the LCME u </pre>	nit tested in step 10					
If RTS	Do					
passed	step 13					
failed	step 16					

14 symptoms that prompted replacement of the card. Go to step 17.

- **15** Return to the procedure that directed you to this procedure. At the point where a faulty card list was produced, identify the next faulty card on the list and go to the appropriate card replacement procedure for that card in this manual.
- **16** Obtain further assistance in replacing this card by contacting operating company maintenance personnel.
- 17 You have successfully completed this procedure. Return to the maintenance procedure that directed you to this card replacement procedure and continue as directed.

## NTBX36 in an RSC-S (DS-1) Model B LCME

## Application

Use this procedure to replace an NTBX36 card in an RSC-S LCME.


PEC	Suffixes	Name
NTBX36	BA	Bus Interface Card (BIC)


## **Common procedures**

None

## Action

The following flowchart is only a summary of the procedure. To replace the card, use the instructions in the procedure that follows the flowchart.





### Replacing an NTBX36 card in RSC-S LCME

### At your Current Location

- 1 Proceed only if you were either directed to this card replacement procedure from a step in a maintenance procedure, are using the procedure for verifying or accepting cards, or were directed to this procedure by your maintenance support group.
- 2 Obtain a replacement card. Ensure that the replacement card has the same product equipment code (PEC) including suffix, as the card that is to be removed.

### At the MAP terminal

3 Access the LTP level and post the first line subgroup (LSG) of the line drawer that contains the bus interface card (BIC) to be replaced by typing

>MAPCI;MTC;LNS;LTP;POST L site frame\_no unit\_no lcm\_dr LSG

and pressing the Enter key.

where

### site\_

is the name of the site at which the LCME is located

### frame\_no

is the number of the frame in which the LCME is located

### unit\_no

is the number of the LCME unit with the faulty card

### lcm\_dr

is the number of the drawer with the faulty card

4 Busy all lines in the first LSG by typing

>BSY ALL

and pressing the Enter key.

**5** Post the next LSG of the same line drawer by typing

### >NEXT D

and pressing the Enter key.

- 6 Repeat steps 4 and 5 until all LSGs of the same line drawer are busied.
- 7 Post the LCME with the LCA shelf containing the card to be replaced by typing

>PM;POST LCME site frame\_no unit\_no

and pressing the Enter key.

where

site

is the name of the site at which the LCME is located

#### frame\_no

is the number of the frame in which the LCME is located

unit no

is the number of the LCME unit with the faulty card

Example of a MAP display:

См	MS	IOD	Ne		PM 1LCME		5	LNS	Trks	Ext	Appl
LCN	ΙE		SysB	Ma	nB	OffI	-	CBsy	ISTb	InSv	
0	Quit	PM	0		0	C	)	0	0	130	
2	Post_	LCME	0		0	C	)	0	0	0	
-	SwRg	LCM	E R	eml	00	0 15	STb	Links	_00S:	CSide 1	
5	Trnsl	Uni	t0:	InSV				/RG	: 0		
6	Tst	Uni	t1:	InSv				/RG	: 0		
7	Bsy					11	11	11	RG:Pre	ef 0 InSv	
8	RTS	Drw	r: 01	23 45	67 8	9 01	23	45	St	oy:1 InSv	
9	OffL		• •						•		
10	LoadPM										
11	Disp_										
12	Next										
13											
14	QueryPM										
15											
16											
17											
18											)

8

- Busy all LSGs associated with the LCME drawer in which the card is being replaced by typing

9 Confirm the busied LSGs by typing

>YES

and pressing the Enter key.

Example of a MAP display:

Сп	M MS	IOD	Ne	t PM		CCS	LNS	Trks	Ext	Appl
·	•			. 11	LCME	•			•	•
LCI	ЧE		SysB	Manl	3	OffL	C	Bsy	ISTb	InSv
0	Quit	PM	0	1		0		0	0	130
	Post_	LCME	0	1		0		0	0	0
3										
	SwRg					IST		_	CSic	le l
	Trnsl			InSv				/RG: 0		
	Tst	Unit	1:	InSv				/RG: 0		
	Bsy							RG:	Pref 0	InSv
8	RTS	Drwr	: 01 2	3 45 46	67 8	9 01 3	23 45		Stby:1	InSv
9	OffL			. MM						
10	LoadPM									
11	Disp_									
12	Next									
13										
14	QueryPM									
15										
16										
17										
18										,

### At the LCE frame

10



### WARNING

Card damage—transport

Take the following precautions to protect circuit cards from electrical and mechanical damage during transport.

When handling a circuit card not in an electrostatic discharge (ESD) protective container, stand on a conductive floor mat and wear a wriststrap connected, through a 1-megohm resistor, to a suitably grounded object, such as a metal workbench or a DMS switch frame (Northern Telecom [Nortel] Corporate Standard 5028). Store and transport circuit cards in an ESD protective container.



#### WARNING Static electricity damage

Before removing any cards, put on a wriststrap and connect it to the wriststrap grounding point on the left side of the modular supervisory panel (MSP) of the LCME. This protects the equipment against damage caused by static electricity.



### DANGER

Equipment damage

Take the following precautions when removing or inserting a card:

- 1. Do not apply direct pressure to the components.
- 2. Do not force the cards into the slots.

# DANGER

### Hot materials

Exercise care when handling the line card. The line feed resistor may be very hot.



#### **CAUTION Special tools required** Card shrouds and removal tools are required for removing cards from the line drawers.

Remove the -48V, +5V, and +15V fuses (in that order) for the line drawer containing the BIC to be replaced.

Put on a wriststrap.

*Note:* Card shrouds are required for inserting or removing cards in line drawers. Two sizes are available for use with 3-inch and 6-inch cards, as shown in the following table.

Line card insertion / withdrawal tool for	Apparatus code	Common product code
3-inch cards	QTH56A	A0298291
6-inch cards	QTH58A	A0313317

*Note:* Card removal tools are required for removing cards from line drawers. Two sizes are available, as shown in the following table.

Card removal tool for	Apparatus code	Common product code			
3—4 inch cards	QTH57A	A0298292			
<i>Note:</i> For 4-inch or larger cards, use the large grip tool ITA9953.					

**11** To prepare to remove the faulty card, open the line drawer and follow these substeps:

- **a** Face the drawer shelf and grasp the handle at the bottom of the drawer with your right hand.
- **b** Push up on the drawer latch with the thumb and pull the drawer out until fully withdrawn. It is fully withdrawn when the drawer stop, at the top, prevents further travel.
- **c** Maintain a slight pull on the handle and lift the faceplate of the drawer approximately 2.5 cm (1.0 in).
- **d** While holding the drawer in this position, push the bottom of the drawer, nearest the shelf with your left hand, to a position about 1.0 cm (0.5 in) to the right.

- e Hold the drawer in this position with your left hand and lower the faceplate of the drawer by releasing the grip of your right hand.
- f Ensure a card shroud and line card extractor are available.
- 12 Remove the line card to be replaced by following these substeps:
  - **a** Slide a card shroud over the card to be removed and an adjacent card. If there is not an adjacent card on either side, do not use the card shroud.
  - **b** Grasp the edge of the card with a line card extractor at a point midway between the top and bottom edges. Hold the extractor in your right hand.
  - c Squeeze the handles of the extractor together to grasp the card tightly.
  - d Hold the front cover of the line drawer to steady it using your left hand.
  - e Pull the extractor away from the drawer, and the card will become unplugged from its socket on the drawer backplane.
  - f Continue pulling the card with the extractor until the card is clear of the shroud.
  - **g** Insert the card removed into the ESD container and store using local procedures.
- **13** Replace the faulty card by following these substeps:
  - a Remove the replacement card from the ESD container.
  - **b** Slide the card in the shroud guide slots toward the drawer backplane.
  - c Hold the front cover of the line drawer with your left hand to steady it.
  - **d** Grasp the top and bottom edges of the card with the fingers of your right hand.
  - e Push the card toward the backplane until it plugs fully into the backplane socket.
  - f Close the line drawer.
- **14** Replace the -48V, +5V, and +15V fuses (in that order) for the line drawer containing the BIC that was replaced.
- **15** Use the following information to determine the next step in this procedure.

If you entered this procedure from	Do
alarm clearing procedures	step 26
other	step 16

At the	MAP terminal
16	Return the LSGs to service by typing
	>RTS DRWR x
	and pressing the Enter key.
	>RTS DRWR y
	and pressing the Enter key.
	where
	x
	is the first line subgroup busied in step 8
	<b>y</b> is the next line subgroup busied in step 8
17	Access the PM level of the MAP display and post the first LSG of the line drawer that contains the BIC to be replaced by typing
	>MAPCI;MTC;PM;LNS;LTP;POST L site frame_no unit_no lcm_dr
	and pressing the Enter key.
	where
	site
	is the name of the site at which the LCME is located
	<pre>frame_no     is the number of the frame in which the LCME is located</pre>
	<pre>unit_no     is the number of the LCME unit with the faulty card</pre>
	<pre>lcm_dr is the number of the drawer with the faulty card</pre>
18	Return the busied lines in the first LSG to service by typing
	>RTS ALL
	and pressing the Enter key.
19	Post the next LSG of the same line drawer by typing
	>NEXT D
	and pressing the Enter key.
20	Repeat steps 18 and 19 until all busied lines in the drawer are returned to service.
21	Post the LCME with the LCA shelf containing the replaced card by typing
	>PM;POST LCME site frame_no unit_no
	and pressing the Enter key.
	where
	site is the name of the site at which the LCME is located

## NTBX36 in an RSC-S (DS-1) Model B LCME (end)

#### frame\_no

is the number of the frame in which the LCME is located

unit\_no

is the number of the LCME unit with the faulty card

22 Test the LCME unit by typing

>TST UNIT lcm\_unit\_no

and pressing the Enter key.

where

#### lcm\_unit\_no

is the number of the LCME unit posted in step 21

If TST	Do	
passed	step 23	
failed	step 26	

23 Return the LCME unit to service by typing

>RTS lcm\_unit\_no

and pressing the Enter key.

where

is the number of the LCME unit tested in step 22

If RTS	Do
passed	step 24
failed	step 27

24 Send any faulty cards for repair according to local procedure.

**25** Record the date the card was replaced, the serial number of the card, and the symptoms that prompted replacement of the card. Go to step 28.

**26** Return to the alarm clearing or other procedure that directed you to this procedure. If necessary, go to the point where the faulty card list was produced, identify the next faulty card on the list and go to the appropriate card replacement procedure for that card in this manual.

- 27 Obtain further assistance in replacing this card by contacting personnel responsible for a higher level of support.
- 28 You have successfully completed this procedure. Return to the maintenance procedure that directed you to this card replacement procedure and continue as directed.

## NTBX72 in an RSC-S (DS-1) Model B LCME

## Application

Use this procedure to replace an NTBX72 card in an RSC-S LCME.

PEC	Suffixes	Name
NTBX72	AA	ISDN LCME Battery and Ring Router


## **Common procedures**

None

## Action

The following flowchart is only a summary of the procedure. To replace the card, use the instructions in the procedure that follows the flowchart.

#### Summary of card replacement procedure for an NTBX72 card in an RSC-S LCME



#### Replacing an NTBX72 card in an RSC-S LCME

#### At your Current Location

- 1 Proceed only if you have been directed to this card replacement procedure from a step in a maintenance procedure, are using the procedure for verifying or accepting cards, or have been directed to this procedure by your maintenance support group.
- 2 Obtain an NTBX72 replacement card. Ensure the replacement card has the same product equipment code (PEC), including suffix, as the card that is to be removed.

#### At the MAP terminal

3 Set the MAP display to the PM level and post the LCME by typing

#### >MAPCI;MTC;PM;POST LCME site frame\_no unit\_no

and pressing the Enter key.

#### where

site

is the name of the site at which the LCME is located

#### frame no

is the number of the frame in which the LCME is located

#### unit\_no

is the number of the LCME with the faulty card

Example of a MAP display:

( CI	M MS	IOD	Net	: :	PM	CCS	L	ns	Tr	ks	Ex	t	Ap	pl '
.		•	•	1L	CME			•					•	
LC	ME		SysB	Ma	nB	Off	L	CB	sy	]	ISTb		In	Sv
0	Quit	PM	1		0		2		0		2		-	12
2	Post_	LCME	0		0		2		0		2			9
3	ListSet													
4	SwRG	LCME	RSC-S	14 1	ISTb	Lin	ks_0	OS:	CSi	de	0	PSide	5	0
5	Trnsl_	Unit0:	InSv	7			/R	G: 1						
6	Tst_	Unit1:	InSv	7			/R	G: 1						
7	Bsy_					11	11	11	11	11	RG:	Pref	1 :	ISTB
8	RTS_	Drwr: (	01 23	45 6	7 89	01	23	45	67	89		Stby	0 3	InSv
	OffL													
	LoadPM_													
	Disp_													
	Next													
13														
	QueryPM													
15														
16														
17														
18														
														/
$\sim$														

Check for fault indicators by typing >QUERYPM FLT and pressing the Enter key. Example of a MAP display:

4

	/										
1	CM	MS	IOD	Net	PM	CC	Lns	Trks	Ext	Appl	)
	•	•	•	•	1LCME	•	•	•	•	•	
	LCME	2		SysB	ManB	OffL	(	CBsy	ISTb	InSv	
	0 0	Quit		-	0			0	2	12	
	2 I	Post	LCME	0	0	2		0	2	9	
	3 I	 ListSet									
	4 5	SwRG	LCME	RSC-S 1	4 1 ISTk	D Links	_00S:	CSide	0 PS	Side 0	
	5 1	[rnsl_	Unit0:	InSv	Takeove	er	/RG:	1			
	6 1	[st_	Unit1:	ISTb			/RG:	1			
	7 E	Bsy_				11	11	11 RG	:Pref :	l ISTb	
	8 F	RTS_	Drwr:	01 23	45 67	89 01	23	45	Stby (	) InSv	
	9 (	OffL									
	10 I	LoadPM_	QUERYP	M FLT							
	11 I	Disp_	Node i	nservice	trouble	es exist	:				
	12 ľ	Jext	On	e or bot	h Units	inservi	ce tro	ouble			
	13		LCME	UNIT 0	Inservi	ce					
	14 Ç	QueryPM	LCME	UNIT 1	Inservi	ce					
	15		Ringin	g Genera	tor 1 fa	ailure					
	16										
	17										
	18										,
	\										

5 Switch ringing generator activity from the unit with the faulty NTBX72 card by typing

>SWRG PM

and pressing the Enter key.

If SWRG	Do
passed	step 6
failed	step 20

6 Busy the LCME unit by typing

>BSY UNIT lcme\_unit\_no

and pressing the Enter key.

where

Icme\_unit\_no

is the number of the LCME unit with the faulty card

#### At the RCE

7



#### WARNING Static electricity damage

Before removing any cards, put on a wrist strap and connect it to the wrist strap grounding point on the left side of the modular supervisory panel (MSP) of the LCME. This protects the equipment against damage caused by static electricity.

Put on a wrist strap.

#### 8

9



### DANGER

Equipment damage


Take these precautions when removing or inserting a card:

- 1. Do not apply direct pressure to the components.
- 2. Do not force the cards into the slots.


Power down the NT6X53 power converter by setting the POWER switch to the OFF position.

Remove the NTBX72 card as shown in the following figures.


a Locate the card to be removed on the appropriate shelf.




**b** Open the locking levers on the card to be replaced and gently pull the card toward you until it clears the shelf.



- c Ensure the replacement card has the same PEC, including suffix, as the card you just removed.
- **10** Open the locking levers on the replacement card.
  - a Align the card with the slots in the shelf.
  - **b** Gently slide the card into the shelf.



- **11** Seat and lock the card.
  - **a** Using your fingers or thumbs, push on the upper and lower edges of the faceplate to ensure the card is fully seated in the shelf.
  - **b** Close the locking levers.



12 Power up the LCME unit as follows:

- **a** Ensure the power converter (NT6X53) is inserted. A major audible alarm may sound. This alarm is silenced when power is restored to the converter.
- **b** Set the circuit breaker switch to the ON position.
- **13** Use the following information to determine the next step in this procedure.

If you entered this procedure from	Do
alarm clearing procedures	step 19
other	step 14

#### At the MAP terminal

**14** Test the unit by typing

>TST UNIT lcme\_unit\_no

and pressing the Enter key.

where

Icme\_unit\_no

is the number of the LCME unit posted in step 3

If TST	Do	
passed	step 15	
failed	step 19	

**15** Return the LCME unit to service by typing

>RTS UNIT lcme\_unit\_no

and pressing the Enter key.

where

#### lcme\_unit\_no

is the number of the LCME unit tested in step 14

If RTS	Do	
passed	step 16	
failed	step 20	

16 Switch ringing generator activity to the new NTBX72 card by typing

>SWRG PM

and pressing the Enter key.

If SWRG	Do
passed	step 17
failed	step 20

- 17 Send any faulty cards for repair according to local procedure.
- **18** Record the date the card was replaced, the serial number of the card, and the symptoms that prompted replacement of the card. Go to step 21.
- **19** Return to the procedure that directed you to this procedure. At the point where a faulty card list was produced, identify the next faulty card on the list and go to the appropriate card replacement procedure for that card in this manual.
- **20** Obtain further assistance in replacing this card by contacting operating company maintenance personnel.
- 21 You have successfully completed this procedure. Return to the maintenance procedure that directed you to this card replacement procedure and continue as directed.

## NTEX17 in an RSC-S (DS-1) Model B LCM

## Application

Use this procedure to replace the following card in an RSC-S LCM line drawer.

PEC	Suffixes	Name
NTEX17	AA	xDSL line card
NTEX17	BA	xDSL line card
NTEX17	CA	xDSL line card


## **Common procedures**

None

## Action

The following flowchart is only a summary of the procedure. To replace the card, use the instructions in the step-action procedure that follows the flowchart.

#### Summary of replacing an NTEX17 in RSC-S LCM



#### Replacing an NTEX17 in RSC-S LCM

#### At your current location

- 1 Proceed only if you were either directed to this card replacement procedure from a step in a maintenance procedure, are using the procedure for verifying or accepting cards, or were directed to this procedure by your maintenance support group.
- 2 Obtain a replacement card. Make sure that the replacement card and the card that you remove have the same product engineering code (PEC) and PEC suffix.

#### At the xEMS workstation

- **3** Go to the submap of the LCM line drawer with the NTEX17 card that you will replace.
- 4 Place the cursor on the XLC you want to busy and use the mouse to select

Maintenance : XLC -> MB

and press the Enter key.

#### At the MAP terminal

5 To access the LTP level of the MAP display, type

>MAPCI;MTC;LNS;LTP

and press the Enter key.

Example of a MAP display:

POST	DELQ	BUSYQ		P	REFI	Х
LCC PTY RNG	LEN	Ņ STA	FS	LTA	ΤE	RESULT

*Note:* If you worked at the LTP level of the MAP display, a posted line can be present. A posted line does not interfere with this maintenance procedure.

6 To post the line for the card to be replaced, type

>POST L site frame\_no unit\_no drawer\_no slot\_no and press the Enter key.

where

site

is the PM location (alphanumeric)

frame\_no is the frame number (0 to 511)

unit\_no is the PM unit number (0 or 1)

#### drawer no

is the line drawer number (0 to 19)

#### ckt\_no

is the card slot number (0 to 31) Example of a MAP display:

LCC PTY	RNGLEN	D!	N STA H	F S LTA	TE	RESULT
1FR	REM1 01 0 01 01	21 11	34 IDL	i		

#### 7 Determine the state of the posted line.

	If the state of the line	Do
	is CPB, CPD	step 8
	is Cut, haz, idl, lo, plo, sb	step 9
	is MB	step 10
	is NEQ	To determine why the compo- nent is offline or not equipped, consult operating company per- sonnel. Continue as directed by operating company personnel.
	is del, dmb, inb, lmb	step 19
8	Wait until the line state changes. Go t	to step 7.
9	To manually busy the line circuit, type >BSY and press the Enter key. <i>Example of a MAP display:</i>	
LCC P 1FR	TY RNGLEN HOST 01 0 01 01 62	DN STA F S LTA TE RESULT 1 1134 MB
	<i>Note:</i> Observe that the state that a to MB.	ppears under the STA header changed
	If BSY command	Do
	passed	step 10

step 19

failed

#### At the MAP terminal

10 To display the cabinet location of the faulty line card, type >CKTLOC and press the Enter key. *Example of a MAP display:* 

Site	Flr	RPos	Bay_	id	Shf	Desc	ription	Slot	EqPEC
REM1	01	В04	LCE	01	04	LCM	01 0	01:00	EX17CA

GRD START	2DB LOSS	BAL NETWORK	MAN OVR SET
NO	NO	NON LOADED	NO

*Note:* In the example MAP display, the line card is an NTEX17CA and the location of the card is

#### Site

in the remote site

#### Flr

on the 1st floor

#### RPos

row B is the location of the line equipment bay 04

#### Bay\_id

in line concentrating equipment, bay 01

#### Shf

in shelf 04

#### Description

in hardware device LCM, bay 01

#### Slot

in line drawer 01, slot 00

#### At the shelf

11



#### DANGER Static electricity damage

Wear a wrist strap that connects to a wrist-strap grounding point to handle circuit cards. The wrist-strap grounding point is on a frame supervisory panel (FSP) or a modular supervisory panel (MSP). The wrist strap protects the cards against static electricity damage.



#### DANGER

Risk of equipment damage

Take these precautions when removing or inserting a card:1. Do not apply direct pressure to the components.2. Do not force the card into its slot.



#### DANGER Risk of equipment damage

Proceed only if a step in a maintenance procedure directs you here. If you perform this procedure without permission, equipment damage can occur.



### DANGER

**Risk of electrocution** 

Proceed only if a step in a maintenance procedure directs you here. If you perform this procedure without permission, personal injury can occur.


Put on a wriststrap.

*Note 1:* A card shroud is required to insert or remove an NTEX17 card in line drawers. This is a 6-inch (152 mm) card, and requires the card shroud with apparatus code QTH58A and common product code A0313317.

*Note 2:* A card removal tool is required to remove the NTEX17 card from line drawers. The apparatus code for the grip tool is QTH57A, and the common product code is A0298292. You can also use the large grip tool ITA9953.

**12** Use the information you obtained in step 6 to locate the physical location of the line card.

**13** Prepare to remove the faulty card identified in step 6 by opening the line drawer and following these substeps.



- **a** Face the drawer shelf and grasp the handle at the bottom of the drawer with your right hand.
- **b** Push up on the drawer latch with your thumb and pull the drawer out until fully withdrawn. It is fully withdrawn when the drawer stop, at the top, prevents further travel.
- **c** Maintain a slight pull on the handle and lift the faceplate of the drawer approximately 2.5 cm (1.0 in.).
- **d** While holding the drawer in this position, push the bottom of the drawer nearest the shelf with your left hand to a position about 1.0 cm (0.5 in.) to the right.
- **e** Hold the drawer in this position with your left hand and lower the faceplate of the drawer by releasing the grip of your right hand.
- f Ensure a card shroud and line card extractor are available.


14



#### DANGER

**Risk of personal injury** Make sure you handle the line card carefully. The line feed resistor can be very hot. To avoid injury, use the insertion/withdrawal tool to remove the card as shown in the figure that follows.

Remove the line card to be replaced by using the following substeps.



- **a** Slide a card shroud over the card to be removed and an adjacent card. If there is not an adjacent card on either side, do not use the card shroud.
- **b** Grasp the edge of the card with a line card extractor at a point midway between the top and bottom edges. Hold the extractor in your right hand.
- c Squeeze the handles of the extractor together to grasp the card tightly.

- **d** Hold the front cover of the line drawer to steady it using your left hand.
- e Pull the extractor away from the drawer, and the card will become unplugged from its socket on the drawer backplane.
- **f** Continue pulling the card with the extractor until the card is clear of the shroud.
- **g** Insert the card removed into the ESD container and store using local procedures.
- **15** Replace the faulty card using the following substeps:
  - a Remove the replacement card from the ESD container.
  - **b** Slide the card in the shroud guide slots toward the drawer backplane.
  - c Hold the front cover of the line drawer with your left hand to steady it.
  - **d** Grasp the top and bottom edges of the card with the fingers of your right hand.
  - e Push the card toward the backplane until it plugs fully into the backplane socket.
- 16 Close the line drawer.

#### At the MAP terminal

- 17 To perform a diagnostic test on the line, type
  - >DIAG

18

and press the Enter key.

Example of a MAP response:

ECOME004AH \*\*\*+LINE100 DEC17 10:04:26 0200 PASS LN\_DIAG LEN HOST 01 0 11 02 NO DIRN DIAGNOSTIC RESULT Card Diagnostic OK ACTION REQUIRED None CARD TYPE EX17BA

If the DIAG command	Do	
passed	step 18	
failed	step 19	
To return the line to service, type		
>RTS		
and press the Enter key.		
If RTS command	Do	
passed	step 20	

DMS-100 Family Switching Center-SONET Model B Maintenance Manual

19

## NTEX17 in an RSC-S (DS-1) Model B LCM (end)

If RTS command	Do
failed	step 19
Dbtain further assistance i esponsible for a higher lev	n replacing this card by contacting personnel

#### At the xEMS workstation

- **20** Go to the submap of the LCM line drawer with the NTEX17 card that you replaced.
- 21 Place the cursor on the the XLC card you want to return the card to service and use the mouse to select

Maintenance : XLC -> IDL

and press the Enter key.

**22** The procedure is complete.

## NTEX54 in an RSC-S (DS-1) Model B LCM

## Application

Use this procedure to replace the following cards in an RSC-S LCM line drawer.

PEC	Suffixes	Name
NTEX54	AA	Data enhanced bus interface card (DBIC)
NTEX54	AB	Data enhanced bus interface card (DBIC)
NTEX54	BA	Data enhanced bus interface card (DBIC)


## **Common procedures**

None

## Action

The following flowchart is only a summary of the procedure. To replace the card, use the instructions in the step-action procedure that follows the flowchart.

#### Summary of replacing an NTEX54 in RSC-S LCM



#### Replacing an NTEX54 in RSC-S LCM

#### At your current location

1



#### CAUTION Loss of service

This procedure directs you to manually busy a line drawer. Removal of a line drawer from service can cause the system to drop calls in progress. Perform this procedure only if you need to restore out-of-service components. Unless it is urgent, perform this procedure during periods of low traffic.

Obtain a replacement card. Make sure that the replacement card and the card that you remove have the same product engineering code (PEC) and PEC suffix.

2



#### CAUTION

Transport network must know new MAC address Work with the network administrator during this procedure. The transport network must know the MAC adress of the new DBIC before the DBIC can support 1MMS.

Write down the 12-digit number stamped on the new NTEX54 card. This number is the media access control (MAC) address. You will use the MAC address later in this procedure.

#### At the xEMS workstation

- **3** Go to the submap of the LCM line drawer with the NTEX54 card that you will replace.
- 4 Place the cursor on the DBIC you want to busy and use the mouse to select Maintenance -> DBIC -> ManB

from the pop-up menu.

#### At the MAP terminal

5 To access the peripheral module (PM) level of the MAP (maintenance and administration position) display and post the LCM, type

>MAPCI;MTC;PM;POST LCM site frame\_no lcm\_no

and press the Enter key.

where

site is the PM location (alphanumeric)

frame\_no

is the equipment frame number (00 to 511)

lcm no

is the number of the LCM (0 or 1)

Example of a MAP display:

LCM	REM	1 01 1	ISTb	Link	s O	DS:	Csi	de 0	Psic	de O	
Unit0:				/RG:	•						
Unit1:	ISTb N	/tce	/	RG: 1	Rir	ng g	en 1	Test			
			1	1 11	11	11	11	RG: F		1 InS	
Drwr:	01 23	45 67	89 0	1 23	45	67	89	St	by	0 InS	V
		MN	I						-		

6 Record the numbers of the logical drawers for the NTEX54.

*Note:* Logical drawers configure in pairs for the physical drawer. The NTEX54 services the physical drawer. Both logical drawers must be manually busy to perform this card replacement procedure.

7 Check the state of the affected logical drawers.

If the state for	Do
one or both logical drawers is I, S, or . (dot)	step 8
both logical drawers is M	step 11
one or both logical drawers is 0 or –	Determine why the drawer is of- fline. If necessary, contact the next level of support.
To manually busy the logical drawer, ty	уре
>BSY DRWR drwr_no	
and press the Enter key.	
where	
drwr_no is the logical drawer number (0	to 23)

8

Example of a MAP response:

 $\tt LCM$  REM1 01 1 Drwr 0 will be taken out of service Please confirm ("YES", "Y", "NO", or "N"):

9 To confirm the command, type

10

>YES and press the Enter key. Example of a MAP response:

LCM REM1 01 1 Drwr 0 Bsy Passed

lf	Do
you must busy the other logical drawer of the pair	step 10
both logical drawers are now M	step 11
Busy the other logical drawer of the pa	air.
>BSY DRWR drwr_no	
and press the Enter key.	
where	
<b>drwr_no</b> is the logical drawer number (0	to 23)

LCM REM1 01 1 Drwr 0 Bsy Passed

#### At the shelf

11



#### WARNING

Static electricity damage

Wear a wrist strap that connects to the wrist-strap grounding point to handle circuit cards. The wrist-strap grounding point is on a frame supervisory panel (FSP) or a modular supervisory panel (MSP). The wrist strap protects the cards against static electricity damage.



#### DANGER

Potential equipment damage

Note the fuses that you remove from the fuse panel. If you do not insert fuses in the correct location on the fuse panel, equipment damage occurs.



#### DANGER Equipment damage


Take these precautions when removing or inserting a card:

- 1. Do not apply direct pressure to the components.
- 2. Do not force the card into its slot.

Remove fuses for the line drawer containing the faulty DBIC. Perform the following steps. Refer to the figure that follows to identify the correct fuses.


*Note:* Fuse markings do not always identify voltage. Make sure that you note the fuses and the location of the fuses in the fuse panel.

- a Remove the -48V fuse for the line drawer that contains the faulty DBIC.
- **b** Remove the +15V fuse for the line drawer that contains the faulty DBIC.
- **c** Remove the +5V fuse for the line drawer that contains the faulty DBIC.



12

Identify the drawer. Press the small thumb-latch button on the lower left edge of the drawer. Pull the drawer out. To secure the drawer in a steady horizontal position, tip the drawer until the catch rests on the line drawer track.



**13** Disconnect the data cable from the RJ-45 connector on the DBIC. The RJ-45 connector is located at slot position 16 of the odd LSG (connector slot). Refer to the following figure.

# Connector slot (16), always unequipped when NTEX54 **DBIC** is installed Data cable trough assembly DBIC RJ-45 connector DBIC

## NTEX54 in an RSC-S (DS-1) Model B LCM (continued)


14



#### DANGER

Do not hold the card by the levers only


If you hold a card by the locking levers only, the levers can break. Pull the card half way out of the slot. Carefully grasp the card from below for more support. Continue to remove the card from the drawer. Make sure that you do not touch any wires or internal parts on the card.



Open the locking levers on the face of the card.


**15** Grasp the locking levers. Carefully pull the card toward you until the card clears the drawer.

*Note:* Do not use a rocking motion to remove the card.




- **16** Place the card that you removed in an electrostatic discharge (ESD) protective container.
- 17 Make sure that the replacement card and the card that you remove have the same PEC and PEC suffix.
- **18** Close the locking levers on the replacement card. Align the card with the pin slots in the drawer. Carefully slide the card into the drawer.
- **19** Support the drawer with your left hand. Use your right hand to push on the upper and lower edges of the card. Make sure that the card sits completely in the drawer.

*Note:* Do not use a rocking motion to insert the card.



**20** Connect the data cable RJ-45 connector that you disconnected in step 13. Refer to the following figure.



DANGER

## NTEX54 in an RSC-S (DS-1) Model B LCM (continued)


Close the line drawer.

22



Potential equipment damage Make sure you insert the fuses in the correct location on the fuse panel to prevent equipment damage.

Insert the fuses that you removed in step 11. Refer to the following figure.



 $\it Note:$  Fuses are coded for position. The colored square on the face of the fuse identifies the top edge.

- a Insert the +5V fuse.
- **b** Insert the +15V fuse.
- c Insert the -48V fuse.

### At the MAP terminal

**23** A maintenance flag (Mtce) can appear. This flag indicates that system-initiated maintenance tasks are in progress. To stop the system-initiated maintenance tasks, type

### >ABTK

and press the Enter key.

**24** To return the logical drawer to service, type

>RTS DRWR drwr\_no

and press the Enter key.

where

25 26 drwr\_no is the logical drawer number (0 to 19)

Example of a MAP response:

OSvce Tests Initiated LCM REM1 00 0 Drwr 0 Tst Passed LCM REM1 00 0Drwr 0 Rts Passed

If the RT	S command	Do
• ·	and you must return the gical drawer to service	step 25
± ·	and the other logical s in service	step 26
failed		step 39
	ep 24 for the other logical di	awer in the pair.
Update tak	ble LCMDRINV.	
	Make sure you have the new recorded in step 2.	v MAC address from the replacemen
а То оре	en table LCMDRINV, type	
>TABI	E LCMDRINV	
and pr	ess the Enter key.	
	ess the Enter key. ition on the tuple for the LC	:M, type
<b>b</b> To pos	•	
b To pos	ition on the tuple for the LC	
b To pos >POS	ition on the tuple for the LC site_name frame_no ess the Enter key.	

is the name of the site

### frame\_no

is the number of the frame

lcm\_no

is the number of the LCM

**c** To begin changing the tuple, type

>CHA

and press the Enter key.

d To continue processing, type

>Y

and press the Enter key.

- e Press the Enter key to scroll through the fields until you access the field with the MAC address.
- f Enter the new MAC address. Type

```
>drwr_id card_pec drwr_pec mac_address ip_address
```

and press the Enter key.

where

drwr\_id is the physical number of the drawer

card\_pec is NTEX54AA, NTEX54AB, or NTEX54BA

drwr\_pec

is the PEC of the drawer

mac\_address is the MAC address of the new NTEX54

ip\_address

is the IP address of the new NTEX54

- g Press the Enter key to scroll through remaining fields.
- h Confirm the change. Type

>Y

and press the Enter key.

i Exit the table. Type

>QUIT

and press the Enter key.

## NTEX54 in an RSC-S (DS-1) Model B LCM (end)

### At the xEMS workstation

27



#### CAUTION Transport network must know new MAC address

Before you return the DBIC to service, you must provide the MAC address for the DBIC to the transport network. Contact the network administrator for assistance.

Go to the submap of the LCM line drawer with the new NTEX54 card.

- 28 Select the card by placing the cursor on the DBIC.
- **29** From the pop-up menu select Describe/Modify Object. The Object Description dialog box appears.
- **30** From the Object Description dialog box, select HSTP Application from the fields under Object Attributes.
- 31 Select View/Modify Object Attributes.
- **32** Enter the new MAC address in the %LAC MAC Address field, for example, 0060381120a1.
- **33** Click the Verify button to verify the information.
- 34 Click the OK button to close the Attributes dialog box.
- 35 Click OK to close the Object Description dialog box.
- **36** Place the cursor on the DBIC you want to return to service and use the mouse to select

### Maintenance -> DBIC -> Rts

from the pop-up menu.

- 37 Send any faulty cards for repair according to local procedure.
- **38** Record the following items in office records:
  - date the card was replaced
  - serial number of the card
  - symptoms that prompted replacement of the card

Go to step 40.

- **39** Obtain further assistance in replacing this card by contacting the personnel responsible for higher level of support.
- 40 You have successfully completed this card replacement procedure.

# NTMX72 in an RSC-S (DS-1) Model B RCC2

## Application

Use this procedure to replace an NTMX72 card in an RSC-S RCC2.

PEC	Suffixes	Name
NTMX72	AA, AB	Power Converter


# **Common procedures**

None

# Action

The following flowchart is only a summary of the procedure. To replace the card, use the instructions in the procedure that follows the flowchart.

### Summary of card replacement procedure for an NTMX72 card in an RSC-S RCC2



DMS-100 Family Switching Center-SONET Model B Maintenance Manual

### Replacing an NTMX72 card in an RSC-S RCC2

### At your Current Location

- 1 Proceed only if you have been directed to this card replacement procedure from a step in a maintenance procedure, are using the procedure for verifying or accepting cards, or have been directed to this procedure by your maintenance support group.
- 2



### CAUTION Loss of service

When replacing a card in the RCC2, ensure that the unit in which you are replacing the card is *inactive* and that the mate unit is *active*.

Obtain an NTMX72 replacement card. Ensure the replacement card has the same product engineering code (PEC), including suffix, as the card that is to be removed.

### At the MAP terminal

3 Set the MAP display to the PM level and post the RCC2 by typing

>MAPCI;MTC;PM;POST RCC2 rcc2\_no

and pressing the Enter key.

where

rcc2\_no

is the number of the RCC2 with the faulty card

Example of a MAP display:

#### CM IOD CCS MS Net РМ LNS Trks Ext Appl • • • • • • • • • • ISTb OffL CBsy RCC2 SysB ManB InSv 0 0 Quit PM 0 0 0 25 0 0 0 0 2 Post\_ RCC2 0 0 0 3 ListSet RCC2 0 ISTb Links\_OOS: CSide 0, PSide 0 4 5 TRNSL Unit0: Inact InSv 6 TST Unit1: Act InSv 7 BSY 8 RTS 9 OffL 10 LoadPM\_ 11 Disp\_ 12 Next\_ 13 14 QueryPM 15 16 17 18

## NTMX72 in an RSC-S (DS-1) Model B RCC2 (continued)

4 By observing the MAP display, be sure that the card that is to be removed is on the inactive unit.

If faulty card is on	Do
active unit	step 5
inactive unit	step 7

5 Switch the processing activity (SWACT) to the inactive unit by typing >SWACT

and pressing the Enter key.

6 Answer the prompt by typing

>YES

and pressing the Enter key.

- 7 Place a sign on the active unit bearing the words *Active unit—Do not touch.* This sign should not be attached by magnets or tape.
- 8 Busy the inactive PM unit by typing

>bsy INACTIVE

Example of a MAP response:

9

## NTMX72 in an RSC-S (DS-1) Model B RCC2 (continued)

RCC2 0 ISTb Links\_OOS: CSide 0 , PSide 1
Unit0: Inact ManB
Unit1: Act ISTb
bsy unit 0
RCC2 0 Unit 0 Bsy Passed
Reset the inactive RCC2 unit by typing

>PMRESET UNIT unit\_no NORUN

and pressing the Enter key.

where

unit\_no is the RCC2 unit number (0 or 1)

Example of a MAP response:

RCC2 0 Unit 0 PMReset Passed

### At the RSCE frame

- **10** Place a sign on the active unit bearing the words *Active unit—Do not touch.* This sign should not be attached by magnets or tape.
- 11 Use the following information to determine where to proceed:

If the card you are replacing has a suffix of	Do
AA	step 12
AB	step 13
anything else	step 14

- 12 Power down the NTMX72AA power converter by setting the POWER switch on the NTMX72 card to the OFF position.
- 13 Power down the NTMX72AB power converter by setting the circuit breaker on the MSP for the inactive unit to the OFF position.

14

### WARNING



Before removing any cards, put on a wrist strap and connect it to the wrist strap grounding point on the left side of the modular supervisory panel (MSP). This protects the equipment against damage caused by static electricity.




## DANGER

**Equipment damage** Take the following precautions when removing or inserting a card:


- 1. Do not apply direct pressure to the components.
- 2. Do not force the cards into the slots.

Remove the NTMX72 card as shown in the following figures.

a Locate the card to be removed on the appropriate shelf.




**b** Open the locking levers on the card to be replaced and gently pull the card toward you until it clears the shelf.




- **c** Ensure the replacement card has the same PEC, including suffix, as the card you just removed.
- 15 Open the locking levers on the replacement card.
  - **a** Align the card with the slots in the shelf.

**b** Gently slide the card into the shelf.



- 16 Seat and lock the card.
  - **a** Using your fingers or thumbs, push on the upper and lower edges of the faceplate to ensure the card is fully seated in the shelf.
  - **b** Close the locking levers.



- 17 Power up the inactive RCC2 unit as follows:
  - a Ensure the NTMX72 circuit card is fully inserted. A major audible alarm may sound. The alarm is silenced when power is restored to the NTMX72 circuit card.

### Note:

**b** If the power converter replaced is an NTMX72AA, set the switch on the power converter to the Reset position. Set the associated circuit breaker on the MSP to the ON position.

If both the converter FAIL LED and FRAME FAIL lamp on the MSP go OFF, go to step 18.

If both the converter FAIL LED and FRAME FAIL lamp on the MSP do not go OFF, hold the switch on the NTMX72AA power converter in the Reset position and simultaneously set the associated circuit breaker on the MSP to the ON position. Go to step 18.

- **c** If the power converter replaced is an NTMX72AB, set the associated circuit breaker on the MSP to the ON position for the NTMX72AB converter that was powered down in step 13.
- 18 After replacing the faulty card, load the inactive RCC2 unit by typing

>LOADPM UNIT unit\_no

and pressing the Enter key.

where

19

20

21

unit\_no is the number of the inactive RCC2 unit

If load	Do
passed	step 19
failed	step 26
Test the inactive unit by typing	
>TST UNIT unit_no	
and pressing the Enter key.	
where	
unit_no is the number of the inactive	RCC2 unit
If TST	Do
passed	step 20
failed	step 25
Use the following information to dete	ermine where to proceed.
If you entered this procedure from	Do
alarm clearing procedures	step 25
other	step 21
	vice by typing
Return the inactive RCC2 unit to ser	
Return the inactive RCC2 unit to ser >RTS UNIT unit_no and pressing the Enter key.	

# NTMX72 in an RSC-S (DS-1) Model B RCC2 (end)

### unit\_no

is the number of the inactive RCC2 unit

If RTS	Do	
passed	step 22	
failed	step 26	

- 22 Remove the sign from the active RCC2 unit.
- 23 Send any faulty cards for repair according to local procedure.
- 24 Record the date the card was replaced, the serial number of the card, and the symptoms that prompted replacement of the card. Go to step 27.
- 25 Return to the procedure that directed you to this procedure. At the point where a faulty card list was produced, identify the next faulty card on the list and go to the appropriate card replacement procedure for that card in this manual.
- **26** Obtain further assistance in replacing this card by contacting operating company maintenance personnel.
- 27 You have successfully completed this procedure. Return to the maintenance procedure that directed you to this card replacement procedure and continue as directed.

# NTMX73 in an RSC-S (DS-1) Model B RCC2

# Application

Use this procedure to replace an NTMX73 card in an RSC-S RCC2.

PEC	Suffixes	Name
NTMX73	AA, AB	PCM Signaling Processor


# **Common procedures**

None

# Action

The following flowchart is only a summary of the procedure. To replace the card, use the instructions in the procedure that follows the flowchart.

Summary of card replacement procedure for an NTMX73 card in RSC-S RCC2



### Replacing an NTMX73 card in RSC-S RCC2

### At your Current Location

- 1 Proceed only if you have been directed to this card replacement procedure from a step in a maintenance procedure, are using the procedure for verifying or accepting cards, or have been directed to this procedure by your maintenance support group.
- 2



### CAUTION Loss of service

When replacing a card in the RCC2, ensure that the unit in which you are replacing the card is *inactive* and that the mate unit is *active*.

Obtain an NTMX73 replacement card. Verify that the replacement card has the same product engineering code (PEC), including suffix, as the card that is to be removed.

### At the MAP display

3 Set the MAP display to the PM level and post the RCC2 by typing

>MAPCI;MTC;PM;POST RCC2 rcc2\_no

and pressing the Enter key.

where

rcc2\_no

is the number of the RCC2 with the faulty card

Example of a MAP display:

4

## NTMX73 in an RSC-S (DS-1) Model B RCC2 (continued)

6	CM	MS	IOD	Net	PM	ccs	LNS	Trks	Ext	Appl
•	•	•	•	•	•	•	•	•	•	•
R	CC2			SysB	ManB	Of	fL	CBsy	ISTb	InSv
(	) Qı	uit	PM	0	0		0	0	0	25
		ost_ istSet	RCC2	0	0		0	0	0	0
9 9 10 11 12	5 TI 5 TS 7 BS 3 RT 9 Of 0 Lo 2 No 3 4 QU 5	RNSL ST SY FS	Unit0:	0 ISTb Inact Act Ir	InSv	_005:	CSide	0, PSic	de O	
18										/

By observing the MAP display, be sure the card that is to be removed is on the inactive unit.

Example of a MAP display:

C1	n MS	IOD	Net	PM	CCS	LNS	Trks	Ext	Appl	
•	•	•	•	•	•	•	•	•	•	
RCC	22		SysB	ManB	Of	fL	CBsy	ISTb	InSv	
0	Quit	PM	0	0		0	0	0	25	
2	Post_	RCC2	0	0		0	0	0	0	
3	ListSet									
4		RCC2	0 ISTb	Links	s_00S:	CSide	0, PSid	de O		
5	TRNSL	Unit0:	Inact	InSv						
6	TST	Unit1:	Act In	ıSv						
7	BSY									
8	RTS									
9	OffL									
10	LoadPM_									
11	Disp_									
12	Next_									
13										
14	QueryPM									
15										
16										
17										
18										

If the faulty card is on the	Do
active unit	step 5
inactive unit	step 7

5 Switch the processing activity (SWACT) to the inactive unit by typing

>SWACT

and pressing the Enter key.

6 Confirm the system prompt by typing

>YES

and pressing the Enter key.

After both units are in-service, proceed to the next step.

7 Place a sign on the active unit bearing the words *Active unit—Do not touch.* This sign should not be attached by magnets or tape.

### At the MAP display

8 Busy the inactive PM unit by typing

>bsy unit unit\_no

and pressing the Enter key.

where

unit\_no

is the number of the unit to be busied (0 or 1) When both units are in-service, proceed to the next step.

### At the frame

9



### WARNING

Static electricity damage

Before removing any cards, put on a wrist strap and connect it to the wrist strap grounding point on the left side of the modular supervisory panel (MSP) of the RCC2. This protects the equipment against damage caused by static electricity.

Put on a wrist strap.

10




### DANGER Equipment damage

Take the following precautions when removing or inserting a card:


- 1. Do not apply direct pressure to the components.
- 2. Do not force the cards into the slots.

Remove the NTMX73 card as shown in the following figures.


**a** Locate the card to be removed on the appropriate shelf.




**b** Open the locking levers on the card to be replaced and gently pull the card toward you until it clears the shelf.



- **c** Ensure the replacement card has the same PEC, including suffix, as the card you just removed.
  - Note: Set dip switch S1 toward IC U1.
- 11 Open the locking levers on the replacement card.
  - a Align the card with the slots in the shelf.
  - **b** Gently slide the card into the shelf.



- 12 Seat and lock the card.
  - **a** Using your fingers or thumbs, push on the upper and lower edges of the faceplate to ensure the card is fully seated in the shelf.
  - **b** Close the locking levers.



### At the MAP display

13 Load the inactive RCC2 unit by typing >loadpm unit unit\_no CC and pressing the Enter key. where

If load	Do
passed	step 14
failed	step 18
Test the inactive unit by typing	
>TST UNIT unit_no	
and pressing the Enter key.	
where	
unit_no is the number of the faulty	RCC2 unit
If TST	Do
passed	step 15
failed	step 17
Jse the following information to de	etermine where to proceed.
If you entered this procedure from	Do
alarm clearing procedures	step 17
other	step 16
Return the inactive RCC2 unit to s	service by typing
RTS UNIT unit_no	
and pressing the Enter key.	
where	
unit_no is the number of the faulty	RCC2 unit
	Do
If RTS	
If RTS passed	step 19

- **18** Obtain further assistance in replacing this card by contacting operating company maintenance personnel.
- **19** Remove the sign from the active RCC2 unit.
- 20 Send any faulty cards for repair according to local procedure.
- 21 Note in office records the date the card was replaced, the serial number of the card, and the symptoms that prompted replacement of the card.
- 22 You have successfully completed this procedure. Return to the maintenance procedure that directed you to this card replacement procedure and continue as directed.

# NTMX74 in an RSC-S (DS-1) Model B RCC2

# Application

Use this procedure to replace an NTMX74 card in an RSC-S RCC2.

PEC	Suffixes	Name
NTMX74	AA	DS30A Interface card


# **Common procedures**

None

# Action

The following flowchart is only a summary of the procedure. To replace the card, use the instructions in the procedure that follows the flowchart.

Summary of card replacement procedure for an NTMX74 card in RSC-S RCC2



### Replacing an NTMX74 card in RSC-S RCC2

### At your Current Location

- 1 Proceed only if you have been directed to this card replacement procedure from a step in a maintenance procedure, are using the procedure for verifying or accepting cards, or have been directed to this procedure by your maintenance support group.
- 2



### CAUTION Loss of service

When replacing a card in the RCC2, ensure that the unit in which you are replacing the card is *inactive* and that the mate unit is *active*.

Obtain an NTMX74 replacement card. Verify the replacement card has the same product engineering code (PEC), including suffix, as the card that is to be removed.

### At the MAP terminal

3 Set the MAP display to the PM level and post the RCC2 by typing

>MAPCI;MTC;PM;POST RCC2 rcc2\_no

and pressing the Enter key.

where

rcc2\_no

is the number of the RCC2 with the faulty card

Example of a MAP display:

(	CI ·	M MS	IOD		Net	PM 1RCC2			LNS		Trks	Ex	t	Appl	
	RCO	22		S	ysB	ManB	0	ffL		CB	зу	ISTb		InSv	7
	0	Quit	PM	(	C	0		2		0		2		25	
	2	Post_	RCC2	(	C	0		0		0		1		1	
	3	ListSet													
	4		RCC2	0	ISTb	Links_00	)S:	CSic	le	1,	PSide	1			
	5	TRNSL	Unit0:		Inact	InSv									
	б	TST	Unit1:		Act I	nSv									
	7	BSY													
	8	RTS													
	9	OffL													
	10	LoadPM_													
	11	Disp_													
	12	Next_													
	13														
	14	QueryPM													
	15														
	16														
	17														
	18														
~															

**4** By observing the MAP display, ensure that the card to be removed is on the inactive unit.

If faulty card is on	Do
active unit	step 5
inactive unit	step 7

5 Switch the processing activity (SWACT) to the inactive unit by typing >SWACT

and pressing the Enter key.

6 Confirm the system prompt by typing

>YES

and pressing the Enter key.

After both units are in-service, proceed to the next step.

### At the RCE frame

7 Place a sign on the active unit bearing the words *Active unit—Do not touch.* This sign should not be attached by magnets or tape.

### At the MAP terminal

8 Busy the inactive PM unit by typing >bsy INACTIVE

and pressing the Enter key.

9 Set the ManB RCC2 unit to the ROM level to prevent trapping by typing >PMRESET UNIT unit\_no NORUN and pressing the Enter key.

where

unit no

is the number of the inactive RCC2 unit busied in step 8

### At the RCE frame

10



## WARNING

Static electricity damage

Before removing any cards, put on a wrist strap and connect it to the wrist strap grounding point on the left side of the modular supervisory panel (MSP) of the RCC2. This protects the equipment against damage caused by static electricity.

Put on a wrist strap.

11




## DANGER

**Equipment damage** Take the following precautions when removing or inserting a card:


- 1. Do not apply direct pressure to the components.
- 2. Do not force the cards into the slots.

Remove the NTMX74 card as shown in the following figures.


a Locate the card to be removed on the appropriate shelf.



**b** Open the locking levers on the card to be replaced and gently pull the card toward you until it clears the shelf.




- c Ensure the replacement card has the same PEC, including suffix, as the card you just removed.
- 12 Open the locking levers on the replacement card.
  - a Align the card with the slots in the shelf.
  - **b** Gently slide the card into the shelf.



**13** Seat and lock the card.

15

- **a** Using your fingers or thumbs, push on the upper and lower edges of the faceplate to ensure the card is fully seated in the shelf.
- **b** Close the locking levers.



14 Refer to the following table to determine the next step

If you entered this procedure from	Do	
alarm clearing procedure	step 20	
other	step 15	

	and pressing the Enter key. <i>where</i> <b>unit_no</b> is the number of the inactive Re	CC2 unit (0 or 1)						
	If the PMRESET command	Do						
	passed	step 17						
	failed	step 16						
16	Reload the inactive RCC2 unit by typing >LOADPM UNIT unit_no							
	and pressing the Enter key.							
	where							
	unit_no is the number of the inactive RCC2 unit (0 or 1)							
	If the LOADPM command	Do						
	passed	step 17						
	failed	step 21						
17	Return the inactive RCC2 unit to service by typing							
	<pre>&gt;RTS UNIT rcc2_unit_no</pre>							
	and pressing the Enter key.							
	where							
	<pre>rcc2_unit_no     is the number of the RCC2 unit (0 or 1)</pre>							
	If RTS	Do						
	passed	step 18						
	failed	step 21						
18	Send any faulty cards for repair accord	ding to local procedure.						
19	Record the date the card was replaced symptoms that prompted replacement	l, the serial number of the card, and the t of the card. Go to step 22.						
20	Return to the procedure that directed you to this procedure. At the point where a faulty card list was produced, identify the next faulty card on the list and go to the appropriate card replacement procedure for that card in this manual.							
21	Obtain further assistance in replacing company maintenance personnel.	this card by contacting operating						

22 You have successfully completed this procedure. Remove the sign from the active unit and return to the maintenance procedure that directed you to this card replacement procedure and continue as directed.

# NTMX75 in an RSC-S (DS-1) Model B RCC2

## Application

Use this procedure to replace an NTMX75 card in an RSC-S RCC2.

PEC	Suffixes	Name
NTMX75	AA, DA	Enhanced Matrix


# **Common procedures**

None

# Action

The following flowchart is only a summary of the procedure. To replace the card, use the instructions in the procedure that follows the flowchart.

### Summary of card replacement procedure for NTMX75 card in RSC-S RCC2



### Replacing an NTMX75 card in an RSC-S RCC2

### At your Current Location

1 Proceed only if you have been directed to this card replacement procedure from a step in a maintenance procedure, are using the procedure for verifying or accepting cards, or have been directed to this procedure by your maintenance support group.

2



### CAUTION Loss of service

When replacing a card in the RCC2, ensure that the unit in which you are replacing the card is *inactive* and that the mate unit is *active*.

Obtain an NTMX75 replacement card. Verify the replacement card has the same product equipment code (PEC), including suffix, as the card that is to be removed.

### At the MAP terminal

3 Set the MAP display to the PM level and post the RCC2 by typing

>MAPCI;MTC;PM;POST RCC2 rcc2\_no

and pressing the Enter key.

where

rcc2\_no

is the number of the RCC2 to be busied

Example of a MAP display:

CM MS	-		PM 1RCC2		LNS ·	Trks	Ext Appl
RCC2	Sy	sВ	ManB	OffL	CBsy	ISTb	InSv
0 Quit	PM	0	0	2	0	2	25
2 Post_ 3 ListSet		0	0	0	0	1	1
4		InSv	Links OC	s: csid	de 1.P	Side 1	
5 TRNSL			_		, -		
6 TST							
7 BSY							
8 RTS							
9 OffL							
10 LoadPM_							
11 Disp_							
12 Next_							
13							
14 QueryPM							
15							
16							
17							
18							/

4 Determine from the MAP display if the card that is to be removed is on the inactive unit.

If faulty card is on	Do
active unit	step 5
inactive unit	step 7

5 Switch the processing activity (SWACT) to the inactive unit by typing

### >SWACT

and pressing the Enter key.

6 Confirm the system prompt by typing

>YES

and pressing the Enter key.

After both units are in-service, proceed to the next step.

### At the RCE frame

7 Place a sign on the active unit bearing the words *Active unit—Do not touch.* Place this sign in an electostatic discharge (ESD) bag. Do not attach the sign with magnets or tape.

### At the MAP terminal

8 Busy the inactive PM unit by typing

>bsy unit\_no

and pressing the Enter key.

### where

unit\_no is the number of the unit to be busied (0 or 1)

When both units are in-service, proceed to the next step.

**9** Reset the inactive unit by typing

>PMRESET unit\_no NORUN

and pressing the Enter key.

where

### unit no

is the number of the unit to be reset (0 or 1)

### At the RCE frame

### 10



## DANGER

### Static electricity damage

Before removing any cards, put on a wrist strap and connect it to the wrist strap grounding point on the left side of the modular supervisory panel (MSP) of the RCC2. This protects the equipment against damage caused by static electricity.



### DANGER


### Equipment damage

Take the following precautions when removing or inserting a card:


- 1. Do not apply direct pressure to the components.
- 2. Do not force the cards into the slots.

Put on a wrist strap.


- 11 Remove the NTMX75 card as shown in the following figures.
  - a Locate the card to be removed on the appropriate shelf.




**b** Open the locking levers on the card to be replaced and gently pull the card toward you until it clears the shelf.



- **c** Ensure that the replacement card has the same PEC, including suffix, as the card you just removed.
- 12 Open the locking levers on the replacement card.
  - **a** Align the card with the slots in the shelf.
  - **b** Gently slide the card into the shelf.



- **13** Seat and lock the card.
  - **a** Using your fingers or thumbs, push on the upper and lower edges of the faceplate to ensure the card is fully seated in the shelf.
  - **b** Close the locking levers.



#### At the MAP terminal

- 14 Reset the inactive unit by typing
  - >PMRESET unit\_no

and pressing the Enter key.

where

- unit\_no
  - is the number of the unit to be reset (0 or 1)

### NTMX75 in an RSC-S (DS-1) Model B RCC2 (end)

**15** Use the following information to determine what step to go to next in this procedure.

16

17 18

19

20

If you entered this procedure from	Do			
alarm clearing procedures	step 19			
other	step 16			
Return the inactive RCC2 unit to se	ervice by typing			
>RTS UNIT rcc2_unit_no				
and pressing the Enter key.				
where				
rcc2_unit_no is the number of the RCC2 u	unit being returned to service			
If RTS	Do			
passed	step 17			
failed	step 19			
Send any faulty cards for repair acc	cording to local procedure.			
Send any faulty cards for repair acc Record the date the card was replace symptoms that prompted replacem	ced, the serial number of the card, and the			
Record the date the card was replaced symptoms that prompted replacem Return to the procedure that direct where a faulty card list was product	ced, the serial number of the card, and the			

21 You have successfully completed this procedure. Remove the sign from the active unit and return to the maintenance procedure that directed you to this card replacement procedure and continue as directed.

# NTMX76 in an RSC-S (DS-1) Model B RCC2

### Application

Use this procedure to replace the following card in an RSC-S RCC2.

PEC	Suffixes	Name
NTMX76	AA	Message and Tone card

If you cannot identify the PEC, suffix, and shelf or frame for the card you want to replace, refer to the Index for a list of cards, shelves, and frames documented in this card replacement NTP.

### **Common procedures**


Two common procedures are referenced in this section:

- replacing a card
- returning a card

### Action

The following flowchart is only a summary of the procedure. To replace the card, use the instructions in the procedure that follows the flowchart.

#### Summary of card replacement procedure for an NTMX76 card in RSC-S RCC2



#### Replacing an NTMX76 card in RSC-S RCC2

#### At your Current Location

- 1 Proceed only if you have been directed to this card replacement procedure from a step in a maintenance procedure, are using the procedure for verifying or accepting cards, or have been directed to this procedure by your maintenance support group.
- 2



#### CAUTION Loss of service

When replacing a card in the RCC2, ensure that the unit in which you are replacing the card is *inactive* and that the mate unit is *active*.

Obtain an NTMX76 replacement card. Verify the replacement card has the same product engineering code (PEC), including suffix, as the card that is to be removed.

#### At the MAP terminal

3 Set the MAP display to the PM level and post the RCC2 by typing

>MAPCI;MTC;PM;POST RCC2 rcc2\_no

and pressing the Enter key.

where

rcc2\_no

is the number of the RCC2 to be busied (0 or 1)

Example of a MAP response:

RCC2 0 ISTb Links\_OOS: CSide 1, PSide Unit0: Inact ISTb Unit1: Act InSv

4 Determine the location of the RCC2 containing the faulty NTMX76 card by typing

#### >QUERYPM

and pressing the Enter key. Example of a MAP response:

PM Type: RCC2 PM No.: 0 PM Int. No.: 9 Node\_No: 24 PMs Equipped: 53 Loadname: CRI07BRI1 EEPRom Load: MX77NB03 WARM SWACT is supported and available RCC2 0 is included in the REX schedule. REX on RCC2 0 has not been performed. Node Status: {OK, FALSE} Unit 0 Act, Status: {OK, FALSE} Unit 1 Inact, Status: {OK, FALSE} Site Flr RPos Bay\_id Shf Description Slot EqPEC RSC0 00 C02 RSC 00 05 RCC2: 000 MX85AA RSC0 00 C02 RSC 00 47 EXT:LEFT 01:13 MX86AA

**5** Determine the state of the RCC2 unit associated with the faulty NTMX76 card..

If the RCC2 unit is	Do
active	step 6
inactive	step 8

6

7

Switch the processing activity (SWACT) to the inactive unit by typing

>SWACT

and pressing the Enter key.

and pressing the Enter key.

Example of a MAP response:

RCC2 0 A Warm SwAct will be performed after data sync of active terminals. Please confirm ("YES", "Y", "NO", or "N"):

lf	Do
you are prompted to confirm a warm SWACT	step 7
the system rejects the SWACT	step 20
Confirm the system prompt by typing	
>YES	
and pressing the Enter key.	
Example of a MAP response:	

UnitO: Unitl:	Inact SysB Act ISTb	Mtce	
RCC2 0	SwAct Pass	sed	
If the MA	P response is		Do
If the MA SWACT	•		Do step 8

#### At the RCE frame

8 Place a sign on the active unit bearing the words *Active unit—Do not touch.* This sign should not be attached by magnets or tape.

#### At the MAP terminal

**9** Busy the inactive PM unit by typing

>bsy INACTIVE

and pressing the Enter key.

10 Reset the inactive RCC2 unit to the ROM level by typing

>PMRESET UNIT rcc2\_unit\_no NORUN

and pressing the Enter key.

where

rcc2\_unit\_no is the number of the inactive RCC2 unit (0 or 1)

#### At the RCE frame

#### 11



#### WARNING

Static electricity damage

Before removing any cards, put on a wrist strap and connect it to the wrist strap grounding point on the left side of the modular supervisory panel (MSP) of the RCC2. This protects the equipment against damage caused by static electricity.

Locate the circuit card to be replaced.

**12** Replace the card using the common replacing a card procedure in this document. When you have completed the procedure, return to this point.

*Note:* If the circuit card you are replacing has switches, ensure the switches on the replacement circuit card have the same settings as the card replaced.

#### At the MAP terminal

13 Reset the inactive RCC2 unit by typing

>PMRESET UNIT unit\_no

and pressing the Enter key.

where

unit\_no

is the number of the RCC2 busied in step 9

If PMRESET	Do	
passed	step 14	
failed	step 19	

14 Use the following information to determine what step to go to next in this procedure.

If you entered this procedure from	Do
alarm clearing procedures	step 18
other	step 15

#### 15 Return the inactive RCC2 unit to service by typing

#### >RTS INACTIVE

and pressing the Enter key.

If RTS	Do	
passed	step 16	
failed	step 19	

- **16** Remove the sign from the active unit.
- 17 Go to the common returning a card procedure in this document.

Go to step 21.

- **18** Return to *Alarm Clearing Procedures* or other procedure that directed you to this procedure and continue as directed.
- **19** Obtain further assistance in replacing this card by contacting operating company maintenance personnel.

- **20** For further assistance with switch of activity, contact the personnel responsible for the next level of support.
- 21 You have successfully completed this procedure.

# NTMX77 in an RSC-S (DS-1) Model B RCC2

# Application

Use this procedure to replace an NTMX77 card in an RSC-S RCC2.

PEC	Suffixes	Name
NTMX77	AA	Unified Processor


# **Common procedures**

None


# Action

The following flowchart is only a summary of the procedure. To replace the card, use the instructions in the procedure that follows the flowchart.

Summary of card replacement procedure for an NTMX77 card in RSC-S RCC2 (1 of 2)



#### Summary of card replacement procedure for an NTMX77 card in RSC-S RCC2 (2 of 2)



#### Replacing an NTMX77 card in RSC-S RCC2

#### At your Current Location

1 Proceed only if you have been directed to this card replacement procedure from a step in a maintenance procedure, are using the procedure for verifying or accepting cards, or have been directed to this procedure by your maintenance support group.

2



#### CAUTION Loss of service

When replacing a card in the RCC2, make sure the unit in which the card is being replaced is *inactive* and the mate unit is *active*.

Get a replacement card. Make sure the replacement card has the same product equipment code (PEC), including suffix, as the card to be removed.

#### At the MAP terminal

3 Access the PM level of the MAP terminal and post the RCC2. To post the RCC2, type

>MAPCI;MTC;PM;POST RCC2 rcc2\_no

and press the Enter key.

where

rcc2\_no

is the number of the RCC2 to be busied (0 or 1)

Example of a MAP display:

CN			Net				Trks	Ext	APPL .
RC	C2		SysB	ManB	Off	L	CBsy	ISTb	InSv
0	Quit	PM	0	0		2	0	2	25
2	Post_	RCC2	0	0		0	0	1	1
3	ListSet								
4		RCC2	0 ISTb	Links_(	oos: c	Side	0, PSide	0	
5	TRNSL_	Unit0:	Inact	SysB					
б	TST_	Unitl:	Act	InSv					
7	BSY_								
8	RTS_								
9	OffL								
10	LoadPM_								
11	Disp_								
12	Next_								
13	SwAct								
14	QueryPM								
15									
16	IRLINK								
17	Perform								
18									

4 Check that the NTMX77AA card with faults is in the inactive unit. Make sure the LED labeled ACTIVE is OFF or observe the MAP display.

If the NTMX77AA card with faults is in	Do
active unit	step 5
inactive unit	step 9

5 Switch the processing activity (SWACT) to the inactive unit. To SWACT the unit, type

#### >SWACT

and press the Enter key.

If SWACT	Do
cannot continue at this time	step 6
can continue at this time	step 7

6 Do not switch activity of the units. To reject the SWACT, type

>NO

and press the Enter key.

The system discontinues the SWACT.

Return to step 5 during a period of low traffic.

7 To confirm the system prompt, type

>YES

and press the Enter key.

The system runs a pre-SWACT audit to determine the ability of the inactive unit to accept activity reliably.

*Note:* A maintenance flag appears when maintenance tasks are in progress. Wait until the flag disappears before proceeding to the next maintenance action.

If the message is	Do
SWACT passed	step 9
SWACT failed	step 8
SWACT refused by SWACT controller	step 8

8 Return to the Alarm Clearing Procedures in this manual to clear the alarm condition on the inactive unit. When the alarm is cleared, return to step 1 of this procedure.

#### At the RCE frame

**9** Place a sign on the active unit with the words *Active unit—Do not touch*. This sign must not be attached by magnets or tape.

#### At the MAP terminal

**10** Busy the inactive PM unit. To busy the unit, type

>BSY INACTIVE

and press the Enter key.

11 Set the inactive unit to the ROM level. To set the unit to the ROM level, type

>PMRESET UNIT rcc2\_unit\_no NORUN

and press the Enter key.

where

rcc2 unit no

is the number of the inactive RCC2 unit (0 or 1)

#### At the RCE frame

12



#### DANGER Static electricity damage

Before removing any cards, put on a wrist strap and connect it to the wrist strap grounding point on the left side of the frame supervisory panel (MSP) of the RCC2. This protects the equipment against damage caused by static electricity.



### DANGER


Equipment damage

Take the following precautions when removing or inserting a card:


- 1. Do not apply direct pressure to the components.
- 2. Do not force the cards into the slots.

Put on a wrist strap.

- **13** Unseat the NTMX73 and NTMX74 circuit cards.
- 14 Remove the NTMX77 card as shown in the following figures.
  - a Locate the card to be removed on the appropriate shelf.




**b** Open the locking levers on the card to be replaced and gently pull the card toward you until it clears the shelf.



**c** Make sure the replacement card has the same PEC, including suffix, as the card you just removed. Also make sure the DIP switch settings on the replacement card match the settings of the card just removed.

*Note:* If the NTMX77 card has a DIP switch, set DIP switch S1 to CPM.

- 15 Open the locking levers on the replacement card.
  - **a** Align the card with the slots in the shelf.
  - **b** Gently slide the card into the shelf.



16



#### DANGER


**Possible loss of P-side nodes** Monitor LEDs on the faceplate of the replacement NTMX77 when installing.

1. INSV and ESA LEDs may come ON and must go OFF in less than 4 seconds.

2. The ACT LCD may come ON and light for less than 1 second. If the ACT LED remains ON for more than 1 second, immediately remove the NTMX77 card and return to step 14c with a new NTMX77 card. If the NTMX77 card is allowed to remain with both units having an active processor, this is a condition of dual activity, which results in the loss of P-side nodes.

Seat and lock the card.

- **a** Use your fingers or thumbs to push on the upper and lower edges of the faceplate to make sure the card is fully seated in the shelf.
- **b** Close the locking levers.



17 Reseat the NTMX73 and NTMX74 circuit cards.

18 Use the following information to determine the next step in this procedure.

If you entered this procedure from	Do	
an alarm clearing procedure	step 28	

If you entered this procedure from	Do
other	step 19

#### At the MAP terminal

**19** The peripheralremote loader-16 card (NT7X05) allows local loading of RCC2 data, which reduces recovery time. To check if the NT7X05 card is provisioned, type

>QUERYPM FILES

and press the Enter key.

Example of a MAP display:

(	CM	MS	IOD	Net	PM	CCS	LNS	Trks	Ext	APPL
	•	•	•	•		•	•	•		
					*C*					
R	CC2		Sv	sB	ManB	OffL	CBsy	, I	STb	InSv
0	Quit		-		0	2	0		2	25
2	Post	5	RCC2	1	0	0	0		1	1
3	List	Set								
4						ks_00S:	CSide	0, P	Side	0
	_	-	Unit 1	: A	ct InSv					
	_	-								
		_	~		5					
-		-								
		_					V			
	-	_			-	:				
		_			CMR03A					
						г — —	٦.,			
	Quer	ryPM								
					-					
			CMR	Load:	CMR03A					
	Perf	form				(N	T7X05 l	oad file	name)	
18										
	RC 0 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16	0 Quit 2 Post 3 List 4 5 TRNS 6 TST 7 BSY 8 RTS 9 OffI 10 Load 11 Disp 12 Next 13 SwAd 14 Quen 15 16 IRL 17 Perf	RCC2 0 Quit 2 Post 3 ListSet 4 5 TRNSL_ 6 TST_ 7 BSY_ 8 RTS_ 9 OffL 10 LoadPM_ 11 Disp_ 12 Next_ 13 SwAct 14 QueryPM 15 16 IRLINK 17 Perform	RCC2System0 QuitPM2 PostRCC23 ListSet44RCC25 TRNSLUnit 06 TST_Unit 17 BSY_8 RTS_QUERYPI9 OffLUnit 010 LoadPM_NT7711 Disp_NT7712 Next_CMR13 SwActUnit 114 QueryPMNT7715NT7716 IRLINKCMR17 Perform	RCC2SysB0 QuitPM22 PostRCC213 ListSet4RCC204RCC2015 TRNSLUnit 0:Inac6 TSTUnit 1:Ac7 BSY_8RTS_QUERYPM files9 OffLUnit 0:1010 LoadPM_NT7X05 load11 Disp_NT7X05 load12 Next_CMR Load:13 SwActUnit 1:14 QueryPMNT7X05 load15NT7X05 load16 IRLINKCMR Load:17 Perform	.       .       .       IRCC2 *C*         RCC2       SysB       ManB         0 Quit       PM       2       0         2 Post       RCC2       1       0         3 ListSet       4       RCC2       0 ISTb Lin         5 TRNSL_       Unit 0:       Inact ManB         6 TST_       Unit 1:       Act InSv         7 BSY_       8       RTS_       QUERYPM files         9 OffL       Unit 0:       10       LoadPM_         10 LoadPM_       NT7X05 load File:       11         12 Next_       CMR Load: CMR03A       13         13 SwAct       Unit 1:       14         14 QueryPM       NT7X05 load File:       15         15       NT7X05 Image File         16 IRLINK       CMR Load: CMR03A         17 Perform       2	.       .       .       IRCC2       *C*         RCC2       SysB       ManB       OffL         0 Quit       PM       2       0       2         2 Post       RCC2       1       0       0         3 ListSet       4       RCC2       0 ISTb       Links_OOS:         5 TRNSL       Unit 0:       Inact       ManB         6 TST_       Unit 1:       Act       InSv         7 BSY_       8       RTS_       QUERYPM files         9 OffL       Unit 0:       10       LoadPM_         10 LoadPM_       NT7X05       Image File:         12 Next_       CMR       CMR load:       CMR03A         13 SwAct       Unit 1:       It       QueryPM       NT7X05         14 QueryPM       NT7X05       Image File:       CRI05AW         15       NT7X05       Image File:       It         16 IRLINK       CMR Load:       CMR03A       (N         17 Perform       (N       (N       (N	.       .       .       IRCC2       .         *C*         RCC2       SysB       ManB       OffL       CBsy         0       Quit       PM       2       0       2       0         2       Post       RCC2       1       0       0       0         3       ListSet       4       RCC2       0       ISTb       Links_OOS:       CSide         5       TRNSL_       Unit 0:       Inact       ManB       6       TST       Unit 1:       Act       InSv         7       BSY       8       RTS       QUERYPM files       9       OffL       Unit 0:         10       LoadPM       NT7X05       Inage File:       CRI05AW         10       LoadPM       NT7X05       Image File:       12         12       Next_       CMR       CMR03A       13         13       SwAct       Unit 1:       14       QueryPM       NT7X05       Image File:         16       IRLINK       CMR       CMR03A       17       Perform       (NT7X05 M	.       .       .       IRCC2       .       .       *C*         RCC2       SysB       ManB       OffL       CBsy       I         0 Quit       PM       2       0       2       0         2 Post       RCC2       1       0       0       0         3 ListSet       4       RCC2       0 ISTb       Links_OOS:       CSide       0, P         5 TRNSL_       Unit 0:       Inact       ManB       6       TST       Unit 1:       Act       InSv         7 BSY_       8       RTS       QUERYPM files       9       OffL       Unit 0:         10       LoadPM       NT7X05       Image File:       CRI05AW         11       Disp_       NT7X05       Image File:       1         12       Next_       CMR Load:       CMR03A         13       SwAct       Unit 1:       1       4         14       QueryPM       NT7X05       Image File:       1         15       NT7X05       Image File:       1       1         16       IRLINK       CMR Load:       CMR03A       1       1         17       Perform       (NT7X05 load file)	.       .       .       IRCC2       .

Note: If the NT7X05 card is not provisioned, the MAP response is:  $\tt NT7X05$  not datafilled, <code>QueryPm</code> files invalid

If the NT7X05 card is	Do	
provisioned	step 20	
not provisioned	step 21	

20

21



#### DANGER Possible service interruption

The LOCAL LOADFILE option of the LOADPM command has a parameter of [<file> string}]. When this parameter is used, the loadfile named in the parameter is not patched. Do not use this parameter unless the NOPATCH option of the loadfile is desired.

Load the inactive RCC2 unit from the local loadfile. To load the inactive RCC2 unit from the local loadfile, type

>LOADPM UNIT rcc2\_unit\_no LOCAL LOADFILE

and press the Enter key.

where

rcc2\_unit\_no is the number of the inactive RCC2 unit

If the load	Do		
passed	step 22		
failed	step 21		
To load the inactive RCC2 unit, type			
>LOADPM INACTIVE			
and press the Enter key.			
If load	Do		
passed	step 22		

step 29

22 Query the XPM counters for the firmware load on the NTMX77. To query the XPM counters, type

#### >QUERYPM CNTRS

failed

and press the Enter key.

Example of a MAP response

23

24

25

# NTMX77 in an RSC-S (DS-1) Model B RCC2 (continued)

CMR Load: CMR03A UP:MX77AA Unit 1: Ram Load: CRI05AW EPRom Version: AB02	X77NG03, Executable: MX77NG03 X77NG03, Executable: MX77NG0 NTMX77 firmware load name
If firmware is	Do
valid	step 25
invalid To load the firmware on the inactiv >LOADFW INACTIVE and press the Enter key.	step 23 ve unit, type
To load the firmware on the inactiv	
To load the firmware on the inactiv >LOADFW INACTIVE and press the Enter key.	<i>r</i> e unit, type
To load the firmware on the inactiv >LOADFW INACTIVE and press the Enter key. If LOADFW	ve unit, type <b>Do</b>
To load the firmware on the inactiv >LOADFW INACTIVE and press the Enter key. If LOADFW passed	ve unit, type           Do           step 24           step 29
To load the firmware on the inactiv >LOADFW INACTIVE and press the Enter key. If LOADFW passed failed	ve unit, type           Do           step 24           step 29
To load the firmware on the inactiv >LOADFW INACTIVE and press the Enter key. If LOADFW passed failed To upgrade the firmware on the ina	ve unit, type           Do           step 24           step 29
To load the firmware on the inactiv >LOADFW INACTIVE and press the Enter key. If LOADFW passed failed To upgrade the firmware on the ina >LOADFW INACTIVE UPGRADE	ve unit, type           Do           step 24           step 29
To load the firmware on the inactiv >LOADFW INACTIVE and press the Enter key. If LOADFW passed failed To upgrade the firmware on the inactive >LOADFW INACTIVE UPGRADE and press the Enter key.	Do step 24 step 29 active unit, type

and press the Enter key.

If RTS	Do
passed	step 26
failed	step 29

- 26 Send any cards with faults for repair according to local procedure.
- 27 Record the following information in office records:
  - date the card was replaced
  - serial number of the card
  - indications that prompted replacement of the card

Go to step 30.

- **28** Return to the alarm clearing procedure that directed you to this procedure. At the point where a card list was produced, identify the next card on the list and go to the appropriate card replacement procedure for that card in this manual.
- **29** Get additional help in replacing this card by contacting operating company maintenance personnel.
- **30** You have correctly completed this procedure. Remove the sign from the active unit and return to the maintenance procedure that directed you to this card replacement procedure and continue as directed.

# NTMX79 in an RSC-S (DS-1) Model B EXT

### Application

Use this procedure to replace an NTMX79 card in an RSC-S EXT.


PEC	Suffixes	Name
NTMX79	AA	DS60 Extender

# **Common procedures**

None

# Action

The following flowchart is only a summary of the procedure. To replace the card, use the instructions in the procedure that follows the flowchart.



Summary of card replacement procedure for an NTMX79 card in RSC-S EXT

#### Replacing an NTMX79 card in an RSC-S EXT

#### At your Current Location

- 1 Proceed only if you have been directed to this card replacement procedure from a step in a maintenance procedure, are using the procedure for verifying or accepting cards, or have been directed to this procedure by your maintenance support group.
- 2



#### CAUTION Loss of service

When replacing a card in the RCC2, ensure that the unit in which you are replacing the card is *inactive* and that the mate unit is *active*.

Obtain an NTMX79 replacement card. Verify the replacement card has the same product engineering code (PEC), including suffix, as the card that is to be removed.

#### At the MAP terminal

3 Set the MAP display to the PM level and post the RCC2 by typing

>MAPCI;MTC;PM;POST RCC2 rcc2\_no

and pressing the Enter key.

where

rcc2\_no

is the number of the RCC2 with the faulty card

4 Determine on which side of the extension shelf (right or left side) the faulty card is located by typing

#### QUERYPM

and pressing the Enter key.

Example of a MAP response:

PM Type: RCC2 PM Nol.: 0 PM Int. No.: 2 Node\_No.: 126
PMs Equipped: 61 Loadname: CRI05AW
ESA equipped: YES IntraSwitching is ON
WARM SWACT is supported and available.
REX on RCC2 0 is included in the REX schedule.
Node Status; {OK, FALSE}
Unit 0 Act, Status; {OK, FALSE}
Unit 1 Inact, Status; {OK, FALSE}
Site Flr RPos Bay\_id Shf Description Slot EqPEC
R113 01 AA00 CRSC 00 05 RCC2 : 000 MX85AA
R113 01 AA01 CEXT 00 05 EXT : LEFT MX86AA
(Extension shelf location of faulty card)

5 By observing the LED on the extension shelf, be sure that the card to be removed is on the inactive unit. The LED is lit (ON) on the active unit, and not lit (OFF) on the inactive unit.

If faulty card is on	Do
active unit	step 6
inactive unit	step 8

6 Switch the processing activity (SWACT) to the inactive unit by typing

>SWACT

and pressing the Enter key.

*Note:* If the system recommends using the SWACT command with the FORCE option, consult office personnel to determine if use of the FORCE option is advisable.

7 Confirm the system prompt by typing

>YES

and pressing the Enter key.

After both units are in service, proceed to the next step.

#### At the RCE frame

8 Place a sign on the active unit bearing the words *Active unit—Do not touch.* This sign should not be attached by magnets or tape.

#### At the MAP terminal

**9** Busy the inactive RCC2 unit by typing

>bsy unit rcc2\_unit\_no

and pressing the Enter key.

where

#### rcc2\_unit\_no

is the number of the RCC2 unit to be busied (0 or 1)

#### At the RCE frame

10



#### WARNING Static electricity damage

Before removing any cards, put on a wrist strap and connect it to the wrist strap grounding point on the left side of the frame supervisory panel (MSP) of the RCC2. This protects the equipment against damage caused by static electricity.

Put on a wrist strap.

#### 11



### DANGER

Equipment damage

Take the following precautions when removing or inserting a card:

- 1. Do not apply direct pressure to the components.
- 2. Do not force the cards into the slots.

Power down the NTMX72 card in the inactive RCC2.

#### 12




#### CAUTION Loss of subscriber service


To prevent the D-channel handler (DCH) card from being set system busy (SysB), which causes a loss of subscriber service, make sure the toggle switch on the NTMX79 card is set to the ON position before removing the NTMX79 card.

Remove the NTMX79 card as shown in the following figures.


a Locate the card to be removed on the appropriate shelf.



**b** Open the locking levers on the card to be replaced and gently pull the card toward you until it clears the shelf.



- **c** Ensure the replacement card has the same PEC, including suffix, as the card you just removed.
- 13 Open the locking levers on the replacement card.
  - **a** Align the card with the slots in the shelf.
  - **b** Gently slide the card into the shelf.



14




### CAUTION

Loss of subscriber service To prevent the D-channel handler (DCH) card from being set system busy (SysB), which causes a loss of subscriber

service, make sure the toggle switch on the NTMX79 card is set to the OFF position before seating the NTMX79 card.

Seat and lock the NTMX79 card.

- **a** Using your fingers or thumbs, push on the upper and lower edges of the faceplate to ensure the card is fully seated in the shelf.
- **b** Close the locking levers.



**15** Power up the inactive RCC2 unit as follows:

**a** Ensure that the power converter (NTMX72) is fully inserted. A major audible alarm may sound. The alarm is silenced when power is restored to the converter.

Note:

**b** If the power converter replaced is an NTMX72AA, set the switch on the power converter to the Reset position. Set the associated circuit breaker on the MSP to the ON position.

If both the converter FAIL LED and FRAME FAIL lamp on the MSP go OFF, go to step 16.

If both the converter FAIL LED and FRAME FAIL lamp on the MSP do not go OFF, hold the switch on the NTMX72AA power converter in the Reset position and simultaneously set the associated circuit breaker on the MSP to the ON position. Both the converter FAIL LED and FRAME FAIL lamp on the MSP will go OFF. Go to step 16.

- **c** If the power converter replaced is an NTMX72AB, set the associated circuit breaker on the MSP to the ON position. Both the converter FAIL LED and FRAME FAIL lamp on the MSP will go OFF. Go to step 16.
- **16** The peripheral/remote loader-16 card (NT7X05) allows local loading of RCC2 data, which reduces recovery time. Check to see if the NT7X05 card is provisioned by typing

>QUERYPM FILES

and pressing the Enter key.

Example of a MAP display:

(	СМ	MS	IOD	Net	PM	CCS	LNS	Trks	Ext	APPL	
					1RCC2						
					*C*						
R	CC2		Sys	sB M	lanB	OffL	CBsy	IS	STb	InSv	
0	Qui	t	PM	2	0	2	0		2	25	
2	Pos	t	RCC2	1	0	0	0		1	1	
3	Lis	tSet									
4	:		RCC2	0 IS1	'b Lin	ks_00S:	CSide	0, PS	Side	0	
5	TRN	SL_	Unit O	: Inact	ManB						
6	TST	_	Unit 1	: ACT I	nSv						
7	BSY.	_									
8	RTS	_	QUERYPI	M files							
9	Off	L	Unit O	:							
						CRI06AY					
11	Dis	p_	NT7	X05 Imag	re File	:					
12	Nex	t_	CMR	Load:	CMR03A						
13	SwA	ct	Unit 1	:							
14	Que	ryPM	NT7	X05 load	l File:	CRI06AY					
15				X05 Imag							
16	IRL	INK	CMR	Load:	CMR03A						
	Per	form									
18											
$\overline{\ }$											

**Note:** If the NT7X05 card is not provisioned the MAP response is:NT7X05 not datafilled, QueryPm files invalid

If the NT7X05 card is	Do
provisioned	step 17
not provisioned	step 18

17



#### DANGER Possible service interruption

The LOCAL LOADFILE option of the LOADPM command has a parameter of [<file> string}]. When this parameter is used, the loadfile named in the parameter is not patched. Do not use this parameter unless the NOPATCH option of the loadfile is desired.

Load the inactive RCC2 unit from the local load file by typing

#### >LOADPM UNIT unit\_no LOCAL LOADFILE

and pressing the Enter key.

where

#### rcc2 unit no

is the number of the inactive RCC2 unit

If the load	Do
passed	step 19
failed	step 18

18 Load the inactive RCC2 unit (from the CM) by typing

>LOADPM UNIT rcc2\_unit\_no

and pressing the Enter key.

where

#### rcc2\_unit\_no

is the number of the inactive RCC2 unit

If load	Do
passed	step 19
failed	step 27

	in an RSC-S (DS	S-1) Model B EXT (continued)		
19	Test the inactive RCC2 unit by typing			
	>TST UNIT rcc2_unit_no			
	and pressing the Enter key.			
	where			
	<pre>rcc2_unit_no     is the number of the inactive RCC2 unit</pre>			
	If TST	Do		
	passed	step 20		
	failed	step 26		
20	Use the following information to dete procedure.	following information to determine what step to go to next in this re.		
	If you entered this procedure from	Do		
	alarm clearing procedures	step 26		
	other	step 21		
21	Return the inactive RCC2 unit to service by typing			
	>RTS UNIT rcc2_unit_no			
	and pressing the Enter key.			
	where			
	<pre>rcc2_unit_no     is the number of the inactive RCC2 unit</pre>			
22	Use the following information to determine where to proceed.			
	If RTS	Do		
	passed	step 23		
	failed	step 27		
23	Remove the sign from the active RCC2 unit.			
24	Send any faulty cards for repair according to local procedure.			
25	Record the date the card was replaced, the serial number of the card, and the symptoms that prompted replacement of the card. Go to step 28.			
26	Return to the procedure that directed you to this procedure. At the point where a faulty card list was produced, identify the next faulty card on the list and go to the appropriate card replacement procedure for that card in this manual.			
27	Obtain further assistance in replacing this card by contacting operating company maintenance personnel.			

28 You have successfully completed this procedure. Return to the maintenance procedure that directed you to this card replacement procedure and continue as directed.

# NTMX81 in an RSC-S (DS-1) Model B RCC2

# Application

Use this procedure to replace the following card in an RSC-S RCC2.

PEC	Suffixes	Name
NTMX81	AA, BA	Dual DS-1 Interface


# **Common procedures**

None

# Action

The following flowchart is only a summary of the procedure. To replace the card, use the instructions in the procedure that follows the flowchart.

#### Summary of card replacement procedure for an NTMX81 card in RSC-S RCC2



#### Replacing an NTMX81 card in RSC-S RCC2

#### At your Current Location

1 Proceed only if you have been directed to this card replacement procedure from a step in a maintenance procedure, are using the procedure for verifying or accepting cards, or have been directed to this procedure by your maintenance support group.

2



#### CAUTION Loss of service

When replacing a card in the RCC2, ensure that the unit in which you are replacing the card is *inactive* and that the mate unit is *active*.

Obtain an NTMX81 replacement card. Ensure that the replacement card has the same product equipment code (PEC), including suffix, as the card that is to be removed.

#### At the MAP terminal

3 Ensure the PM level of the MAP display is currently displayed by typing

>MAPCI;MTC;PM;POST RCC2 rcc2\_no

and pressing the Enter key.

where

rcc2\_no

is the number of the RCC2 with the faulty card

Example of a MAP display:

(	см	MS	IOD		PM 1RCC2		LNS	Trks	Ext	Appl
RC	22			SysB	ManB	OffL	CBsy	ISTb		InSv
0	Quit		PM	0	0	2	0	2		25
2	Post	_	RCC2	0	0	0	0	1		1
3	List	Set								
4			RCC2	0 ISTb	Links_00S	: CSide	1, PS	ide 1		
5	TRNS	L	Unit0:	Inact	InSv					
6	TST		Unit1:	Act I	nSv					
7	BSY									
	RTS									
	OffL									
	Load	_								
	Disp									
	Next	_								
13										
	Quer	уРМ								
15										
16										
17										
(18										)

4 By observing the MAP display, be sure the card to be removed is in the inactive unit.

If faulty card is in the	Do
active unit	step 5
inactive unit	step 7

5 Switch the processing activity (SWACT) to the inactive unit by typing

#### >SWACT

and pressing the Enter key.

6 Confirm the system prompt by typing

>YES

and pressing the Enter key.

After both units are in-service, proceed to the next step.

#### At the RCE frame

7 Place a sign on the active unit bearing the words *Active unit—Do not touch.* This sign should not be attached by magnets or tape.

If faulty card is	Do
C-side of RCC2	step 21

# NTMX81

in an RSC-S (DS-1) Model B RCC2 (continued)

If faulty card is	Do
P-side faulty	step 8

#### At the MAP terminal

8 Determine if the RCC2 is in a single or dual configuration by typing

>POST RCC2 rcc2\_no ;IRLINK

and pressing the Enter key.

where

#### rcc2 no

is the number of the RCC2 associated with the faulty NTMX87 card

*Note:* If the posted RCC2 is in a single RCC2 configuration, the system responds with:

NO IRLINKS DATAFILLED, IRLINK LEVEL CANNOT BE ENTERED.

**9** Before reconfiguring (adding, removing, or moving) interlinks of a posted RCC2 of a DRCC2, enter the following command from the IRLINK MAP level to disable interswitching capability:

#### >INTERSW DISABLE

*Note:* If the INTERSW DISABLE command is not entered before an attempt is made to busy (BSY) a specified IRLINK, the MAP terminal displays the following response:

interswitched calls should be disabled before an interlink is busied.

**10** To confirm that interswitching is disabled, enter the QUERYIR command. The QUERYIR command displays the status of interswitching capability for the posted RCC2:

>QUERYIR

Example of a MAP display

(											
Interswitching is DISABLED											
IR	FROM		TO			С	ALRM	SLIP	FRME	BER	STATE
0	RCC2	0, 0	RCC2	1,	0			0	0		OK
1	RCC2	0,8	RCC2	1,	8			0	0		OK
2	RCC2	0,4	RCC2	1,	7			0	0		OK
3	RCC2	0,9	RCC2	1,	12			0	0		OK

11 When the interswitching capability has been disabled, begin reconfiguring the IRLINKS by entering the BSY command with the IRLINK number(s), to be reconfigured. The BSY command is enhanced to display the number of interswitched calls that will be reverted to the network using available C-side channels, as seen in the following example:

>BSY 3

#### Example of a MAP response

67 interswitched calls will be reverted to the network. Potential loss of calls on the interlink if there are no available C-side channels.

- 12 Since the C-side channels of the RCC2 is a limited resource, reconfiguring IRLINKS should only be performed during periods of low traffic, otherwise some interswitched calls can be lost if there is an insufficient number of available C-side channels.
- 13 With the IRLINKS manually-busied (ManB), enter table IRLNKINV and make link changes for the desired IRLINK configuration. Static data is immediately downloaded to both units of both RCC2s of the DRCC2, if the units are InSv.
- 14 After DRCC2 IRLINKS are reconfigured, return to service the IRLINKS by entering the enhanced RTS command. The MAP terminal displays the following response to indicate interswitching is disabled.

>RTS 3

Example of a MAP response

Be aware that Interswitching is Disabled.

**15** To enable interswitching, enter the following command from the IRLINK MAP level:

>INTERSW ENABLE

16 To confirm interswitching is enabled for the posted RCC2, enter the QUERYIR command from the IRLINK MAP level:

#### >QUERYIR

Example of a MAP display

Í	Inte	erswitc	hing	g is	ENABL	ED							
	IR	FROM			TO			С	ALRM	SLIP	FRME	BER	STATE
	0	RCC2	Ο,	0	RCC2	1,	0			0	0		OK
	1	RCC2	Ο,	8	RCC2	1,	8	•		0	0		OK
	2	RCC2	Ο,	4	RCC2	1,	7			0	0		OK
	3	RCC2	Ο,	б	RCC2	1,	б			0	0		OK

- 17 IRLINKS and ForceESA static data are dynamically downloaded to both RCC2s of the DRCC2. However, the ESA lines, trunks and ESA table control data, components of the ESA static data for both RCC2s must also be downloaded. For this reason, the units of both RCC2s are set to in-service trouble (ISTb) with the reason ESA STATIC DATA MISMATCH.
- 18 ESA static data can be manually downloaded at the PM Level of the MAP display with the RCC2s posted, by entering the LOADPM command with the source of CC. and file of ESADATA. ESA static data can also be updated at

the automatic nightly static data updates as defined in table OFCENG tuples RSC\_XPMESASDUPD\_BOOL and RSC\_XPMESASDUPD\_HOUR.

*Note:* To load ESADATA the RCC2 units must be in service.

If the RCC2 is in a	Do	
single configuration	step 21	
dual configuration	step 19	

**19** Translate the dual RCC2s IRLINKS by typing

>TRNSL

and pressing the Enter key.

Example of a MAP response

См	MS IOI	) Net	1	РМ	CC	s	LNS	Trks	Ext	: Appl
•	• •	•	11	RCC2	•		•	•	•	•
IRLINK		SysB	Mai	nB	0	ffL	CBsy	IS	Tb	InSv
0 Quit	PM	0	0			2	0	2		25
2	RCC2	0	0			0	0	1		1
	J Unit0: Unit1:		t InS	_	S:	CSide	: 1, PS	Side	1	
10	IR	From		То			CAP	STAT	E	MSGCOND
11	0	RCC2				0	MS	0		OPN
12	1	RCC2	0, 8	Rcc2	1,	8	MS	0	К	OPN
13	2	RCC2	0, 12	RCC2	1,	12	S	0	К	
	VIR 3							0	K	
15 16 17 18										

20

Busy IRLINKS in the faulty NTMX87 circuit card by typing

>BSY irlink\_no

and pressing the Enter key.

where

#### irlink\_no

is the number of the irlink that must be busied

*Note 1:* This step must be performed for each provisioned link in the slot position.

*Note 2:* For link-to-slot assignments, reference step 28 for the main shelf.

**21** Busy the inactive PM unit by typing

*>bsy unit* unit\_no

and pressing the Enter key.

where

#### unit\_no

is the number of the inactive RCC2 unit (unit 0 or 1)

When both units are in-service, proceed to next step.

22 Display the C-side links associated with the DS-1 card by typing

```
>TRNSL C
```

and pressing the Enter key.

Example of a MAP response

LINK	0	LTC	0	0;CAP	MS:STATUS	OK	MSGCOND	OPN
LINK	1	LTC	0	1;CAP	S:STATUS	SBsy		
LINK	2	LTC	0	2;CAP	MS:STATUS	OK	MSGCOND	OPN
LINK	3	LTC	0	3;CAP	S:STATUS	OK		
LINK	4	LTC	0	4;CAP	S:STATUS	OK		
LINK	5	LTC	0	5;CAP	S:STATUS	SBsy		
If C	-side	e links	s are		Do			
If C		e links	s are		Do step 24			

23 Display the P-side links associated with the DS-1 card by typing

#### >TRNSL P

and pressing the Enter key.

Example of a MAP response

LINK O	RCC2 0	5 2	7;CAP	MS:	STATUS	OK	MSGCOND	OPN	
LINK 1	RCC2 1	5 2	7;CAP	MS:	STATUS	SBsy	MSGCOND	CLS	
LINK 2	RCC2 0	7 4	7;CAP	MS:	STATUS	OK			
LINK 3	RCC2 1	7 4	7;CAP	MS:	STATUS	OK			
LINK 4	RCC2 0	5 5	0;CAP	MS:	STATUS	OK	MSGCOND	OPN	
LINK 5	RCC2 1	55	0;CAP	MS:	STATUS	SBsy	MSGCOND	CLS	
If P-side I	inks ar	е			Do				
faulty					step	24			
not faulty	7				step	38			
Busy the links associated with the RCC2 by typing									
>BSY LINK 0									
and processing the Enter key									

and pressing the Enter key.

24

Example of a MAP response:

Please confirm ("Yes" or "No")

Confirm by typing

>YES

and pressing the Enter key.

Example of a MAP response:

LTC 0 LINK 0 Bsy Passed

*Note:* To busy the other links associated with the RCC2, execute the procedures in this step for each link until all links are busied.

25 Post the host PM by typing

>POST host\_pm host\_pm\_no

and pressing the Enter key.

where

#### host\_pm

is either a line group controller (LGC), a line group controller with ISDN (LGCI), a line trunk controller (LTC), or a line trunk controller with ISDN (LTCI)

host\_pm\_no

is the number of either an LGC, LGCI, LTC, or LTCI

Example of a MAP display:

			PM 1RCC2				Ext	Appl
LTC		SysB	ManB	OffL	CBsy	ISTb		InSv
0 Quit	PM	0	0	1	0	4		12
2 Post_ 3 ListSet		0	0	2	0	2		9
4 5 Trnsl_ 6 Tst_ 7 Bsy_ 8 RTS_	Unit0:	Act		CSide	0, PSi	de 1		
9 OffL 10 LoadPM_								
11 Disp_ 12 Next								
13 SwAct								
14 QueryPM								
15 16								
17 Perform								

26 Manually busy the links connected to the faulty card by typing

>BSY LINK link\_no

and pressing the Enter key.

where

#### link\_no

is the number of the link associated with the faulty MX81 card, from step 21

*Note:* Each NTMX81 card has two links associated with it. Therefore, each link must be manually busied. Possible link number pairs are as follows: 0,1; 2,3; 4,5; or 6,7.

#### At the RCE frame

27



#### DANGER

Static electricity damage

Before removing any cards, put on a wrist strap and connect it to the wrist strap grounding point on the left side of the modular supervisory panel (MSP) of the RCC2. This protects the equipment against damage caused by static electricity.



#### DANGER

Equipment damage


Take the following precautions when removing or inserting a card:

- 1. Do not apply direct pressure to the components.
- 2. Do not force the cards into the slots.

Put on a wrist strap.

After identifying the faulty link, use the following charts to determine which NTMX81 is to be removed. First identify whether the link is a C-side or P-side link, then by matching the link number with the slot number and packlet number to the left of each respective table.

28



Remove the NTMX81 card as described in the following steps:

- a Locate the packlet to be removed on the appropriate NTMX87 card slot.
- **b** Open the locking lever on the packlet to be replaced and gently pull the card toward you until it clears the shelf.
- c Ensure that the replacement card has the same PEC, including suffix, as the card you just removed.
- **29** Before inserting the replacement card, set the DS-1 switch settings according to the following table.

(Sheet	1	of	2)
--------	---	----	----

Distance to cross connect		Dip switch settings				
Feet Meters		S3/6	S2/5	S1/4		
0—133	0—41	On	Off	Off		
133—266	41—81	Off	On	On		
266—399	81—122	Off	On	Off		
<i>Note:</i> S indicates switch number(s). On S1 dip switch (6 position): S1—S3 belong to even port, and S4—S6 belong to odd port.						

#### (Sheet 2 of 2)

Distance to cross connect		Dip swit				
Feet	Meters	S3/6	S2/5	S1/4		
399—533	122—163	Off	Off	On		
533—655	163—200	Off	Off	Off		
<i>Note:</i> S indicates switch number(s). On S1 dip switch (6 position): S1—S3 belong to even port, and S4—S6 belong to odd port.						

**30** Open the locking lever on the replacement packlet.

- a Align the packlet with the slots in the shelf.
- **b** Gently slide the packlet into the card slot in the NTMX87 card.
- **31** Seat and lock the packlet.
  - **a** Using your fingers or thumbs, push on the upper and lower edges of the faceplate of the packlet to ensure that the packlet is fully seated in the slot.
  - **b** Close the locking lever.
- **32** Use the following information to determine what step to go to next in this procedure.

If you entered this procedure from	Do
alarm clearing procedures	step 39
other	step 33

#### At the MAP terminal

33 Test the busied network links from step 22 by typing

>TST LINK link\_no

and pressing the Enter key

where

link\_no

is the number of the link that was manually busied in step 24. This step must be performed for each link that is manually busied.

*Note:* To test the other links associated with the RCC2, execute this step for each link until all links are tested.

passed	step 34

# NTMX81

# in an RSC-S (DS-1) Model B RCC2 (continued)

If TST		Do				
failed		step 40				
Return to service the P-side links by typing						
>RTS LI	<b>ТК 0</b>					
and press	ing the Enter key.					
	To RTS the other links asson I link until all links are retur	ciated with the RCC2, execute this ste ned to service.				
If RTS		Do				
passed		step 35				
failed		step 40				
Post the i	active RCC2 unit in which	the NTMX81 card is located by typing				
>POST RCC2 UNIT unit_no						
and pressing the Enter key.						
where						
unit_ is f		t associated with the faulty card				
Return the inactive RCC2 unit to service by typing						
>RTS UNIT unit_no						
and pressing the Enter key.						
where						
unit_no is the number of the RCC2 unit posted in step 35						
If RTS		Do				
passes		step 37				
fails		step 40				
Send any	faulty cards for repair acco	rding to local procedure.				
Record th symptom:	e date the card was replaced that prompted replacement	d, the serial number of the card, and th t of the card. Go to step 39.				
this proce next fault	dure. At the point where a fa	or other procedure that directed you t aulty card list was produced, identify th he appropriate card replacement l.				
		this card by contacting the personne				

41 You have successfully completed this procedure. Remove the sign from the active unit and return to the maintenance procedure that directed you to this card replacement procedure and continue as directed.

# NTMX87 in an RSC-S (DS-1) Model B RCC2

# Application

Use this procedure to replace an NTMX87 card in an RSC-S RCC2.

PEC	Suffixes	Name
NTMX87	AA, AB	Quad Frame Carrier
	BA	Penta DS-1 Packlet Carrier


# **Common procedures**

There are no common procedures.

# Action

This procedure contains a summary flowchart and a list of steps. Use the flowchart to review the procedure. Follow the steps to perform the procedure.

Summary of card replacementprocedure for an NTMX87 card in RSC-S RCC2



#### Replacing an NTMX87 card in RSC-S RCC2

#### At the Current Location

- 1 Proceed only if
  - a step in a maintenance procedure directed you to this card replacement procedure
  - you use the procedure to verify or accept cards
  - your maintenance support group directed you to this procedure
- 2



#### WARNING This procedure describes several configurations of the NTMX87 carrier card.

Make sure you use the steps for the configuration of your RCC2. These steps include a single or dual RCC2 (DRCC2), main or extension shelf, or links compared to carrier trunks.



#### WARNING Loss of service

When you replace a card in the RCC2, make sure the unit that contains the card you want to replace is *inactive*. Make sure the mate unit is *active*.

Obtain an NTMX87 replacement card. Make sure the replacement card has the same product equipment code (PEC) and suffix, as the card you want to remove.

#### At the MAP terminal

3 To view the PM level of the MAP display, type

>MAPCI;MTC;PM;POST RCC2 rcc2\_no

and press the Enter key.

where

rcc2\_no

is the number of the RCC2 with the card with faults

Example of a MAP display:

CI	a MS	IOD	Net	РМ	CCS	LNS	Trks Ext	Appl
	• •	•	•	1RCC2	•	•	· ·	•
RCC	22		SysB	ManB	OffL	CBsy	ISTb	InSv
0	Quit	PM	0	0	2	0	2	25
	Post_ ListSet	RCC2	0	0	0	0	1	1
4				_	os: csid	e 1, P	Side 1	
	TRNSL							
	TST	Unitl:	Act I	nSv				
	BSY							
	RTS							
	OffL							
	LoadPM_							
	Disp_							
	Next_							
13								
	QueryPM							
15								
16								
17								
18								/

To display and record the central-side (C-side) link status of the posted RCC2 associated with the NTMX87 carrier card with faults, type

#### >TRNSL C

4

and press the Enter key.

Example of a MAP response

LINK 0 LTC 0 0;CAP MS: STATUS SysB MSGCOND CLS RESTRICT LINK 1 LTC 0 1;CAP S: STATUS SysB LINK 2 LTC 0 2;CAP MS: STATUS OK MSGCOND OPN UNRESTRICT LINK 3 LTC 0 3;CAP S: STATUS OK LINK 4 LTC 0 4;CAP S: STATUS SysB LINK 5 LTC 0 5;CAP S: STATUS SysB

5 To display and record the P-side link status of the posted RCC2 associated with the NTMX87 carrier card that has faults, type

```
>TRNSL P
```

and press the Enter key.

Example of a MAP response

LINK	1	Carrier of Class - Trunk ;Status;OK
LINK	2	Carrier of Class - Trunk ;Status;OK
LINK	3	Carrier of Class - Trunk ;Status;OK
LINK	10	DCH 6; Status :OK
LINK	13	DCH 7; Status :OK
LINK	17	DCH 4; Status :OK
LINK	22	RMM 6 0;CAP MS;Status OK MSGCOND OPN
LINK	24	LCME RSCS 00 0 0;CAP MS;Status OK MSGCOND OPN
LINK	25	LCME RSCS 00 0 1;CAP MS;Status OK MSGCOND OPN
LINK	26	LCME RSCS 00 0 2;CAP S;Status OK

6 Check the MAP display to make sure the card you want to remove is in the inactive unit.

If the card with faults	Do
is in the active unit	step 7
is in the inactive unit	step 9

7 To switch the processing activity (SWACT) to the inactive unit, type

>SWACT

and press the Enter key.

8 To confirm the system prompt, type

>YES

and press the Enter key.

When both units are in-service, proceed to the next step.

#### At the RCE frame

9 Place a sign on the active unit that bears the words *Active unit - Do not touch*. Do not attach this sign by magnets or tape.

If defective card	Do
is C-side of RCC2	step 10
is P-side defective	step 16

#### At the MAP terminal

- **10** To busy the inactive PM unit, type
  - >bsy unit unit\_no

and press the Enter key.

where

unit no

is the number of the inactive RCC2 unit (unit 0 or 1)

11 To post the host PM, type

>POST host\_pm host\_pm\_no

and press the Enter key.

where

#### host\_pm

is a line group controller (LGC) or a line group controller

with ISDN (LGCI), a line trunk controller (LTC), or a line trunk

controller with ISDN (LTCI)

#### host\_pm\_no

is the number of an LGC, LGCI, LTC, or LTCI

Example of a MAP display:

	M MS			PM 1RCC2					Appl
T TT	2		SvaP	ManB	OFFT	CD	<b>a</b> 17	TOTT	InSv
			-	0		CB	-		
	Quit			-	1		0	4	12
	Post_	LTC	0	0	2		0	2	9
	ListSet								
4		LTC 1	l ISTb	Links_00S	CSid	e 0,	PSide	1	
5	Trnsl_	Unit0:	Act	InSv					
6	Tst_	Unit1:	Inac	t InSv					
7	Bsy_								
8	RTS_								
9	OffL								
10	LoadPM_								
11	Disp_								
12	Next								
13	SwAct								
14	QueryPM								
15	_								
16									
17	Perform								
18									
<u></u>									/

12 To display the P-side links of the host peripheral associated with the RCC2, type

>TRNSL P

and press the Enter key.

Example of a MAP response

LS RESTRICT
UNRESTRICT

**13** To manually busy the links connected to the defective NTMX87 card, type

>BSY LINK link\_no

and press the Enter key.

where

link no


is the number of the link associated with the defective NTMX87 card

*Note 1:* You must busy all provisioned links in the slot.

*Note 2:* Refer to the chart in step 14 for the RCC2 C-side link-to-slot assignments.

#### At the RCE frame

14 Use the following charts to determine which NTMX87 card you must remove. Match the provisioned link number with the slot number and the packlet number to the left of each table.



#### At the MAP terminal

15



#### WARNING Static electricity damage

Put on a wrist strap before you remove any cards. Connect the wrist strap to the wrist strap grounding point. This point is on the left side of the modular supervisory panel (MSP) of the RCC2. This action protects the equipment against damage from static electricity.

Use the following steps to remove the NTMX81 packlet:

- **a** Locate the NTMX81 packlet you want to remove on the correct NTMX87 carrier card slot.
- **b** Open the locking lever on the NTMX81 packlet. Carefully pull the packlet toward you until the packlet clears the shelf.
- c Make sure the NTMX81 packlets are stored in an electrostatic discharge (ESD) container. This container protects the circuit card until you reinstall the packlet in the NTMX87 carrier card.
- d Go to step 42.

#### At the MAP terminal

16 To determine if the RCC2 is in a single or dual configuration, type

>POST RCC2 rcc2\_no ;IRLINK

and press the Enter key.

where

#### rcc2 no

is the number of the RCC2 associated with the defective NTMX87 card

*Note:* If the posted RCC2 is in a single RCC2 configuration, the system responds with:

NO IRLINKS DATAFILLED, IRLINK LEVEL CANNOT BE ENTERED.

**17** Before you add, remove, or move interlinks of a posted RCC2 of a DRCC2, enter the following command. Enter this command from the IRLINK MAP level. This command disables interswitching capability.

#### >INTERSW DISABLE

*Note:* If you do not enter the INTERSW DISABLE command before you attempt to busy (BSY) a specified IRLINK, the MAP terminal displays the following response:

interswitched calls should be disabled before an interlink is busied.

**18** To confirm that the system disabled interswitching, enter the QUERYIR command. The QUERYIR command displays the status of interswitching capability for the posted RCC2:

#### >QUERYIR

Example of a MAP display

$\mathcal{C}$									
Inte	erswitc	hing	is DISAN	BLED					
IR	FROM		TO		С	ALRM SLIP	FRME	BER STATE	
0	RCC2	0,0	RCC2	1, 0		0	0	OK	
1	RCC2	0,8	RCC2	1, 8		0	0	OK	
2	RCC2	0,4	RCC2	1, 7		0	0	OK	
3	RCC2	0,9	RCC2	1, 12		0	0	OK	

19 When the system disables interswitching capability, reconfigure the IRLINKS. Enter the BSY command with the IRLINK number(s) to reconfigure. This action enhances the BSY command. The BSY command can display the number of interswitched calls. These calls use available C-side channels to revert to the network. The following example describes this process.

>BSY 3

Example of a MAP response

67 interswitched calls will be reverted to the network. Potential loss of calls on the interlink if there are no available C-side channels.

- 20 The C-side channels of the RCC2 are a limited resource. To prevent the loss of some interswitched calls, reconfigure IRLINKS only during periods of low traffic. The system can lose interswitched calls if not enough C-side channels are available.
- 21 Manually busy (ManB) the IRLINKS. Enter table IRLNKINV and make link changes for the required IRLINK configuration. The system downloads static data to both units of both RCC2s of the DRCC2. This action can only occur if the units are InSv.
- 22 When you reconfigured the DRCC2 IRLINKS, enter the enhanced RTS command to return to service the IRLINKS. The MAP terminal displays the following response to indicate that the system disabled interswitching.

>RTS 3

Example of a MAP response

Be aware that Interswitching is Disabled.

23 To enable interswitching, enter the following command from the IRLINK MAP level:

#### >INTERSW ENABLE

24 To confirm interswitching is enabled for the posted RCC2, enter the QUERYIR command from the IRLINK MAP level:

>QUERYIR

Example of a MAP display

$\mathcal{C}$													
Inte	rswitch	ning	y is	ENABLI	ED								
IR	FROM			TO			С	ALRM	SLIP	FRME	BER	STATE	
0	RCC2	Ο,	0	RCC2	1,	0			0	0		OK	
1	RCC2	Ο,	8	RCC2	1,	8			0	0		OK	
2	RCC2	Ο,	4	RCC2	1,	7			0	0		OK	
3	RCC2	Ο,	6	RCC2	1,	б			0	0		OK	

25 The system downloads RLINKS and ForceESA static data to both RCC2s of the DRCC2. The system must download the components of the ESA static data for both RCC2s. These components include the ESA lines, trunks and ESA table control data. The system sets the units of both RCC2s to in-service trouble (ISTb) with the reason ESA STATIC DATA MISMATCH.

26 You can download ESA static data at the PM Level of the MAP display with the RCC2s posted. To download this data, enter the LOADPM command with the source of CC. and file of ESADATA. You can update ESA static data at the automatic nightly static data updates. The table OFCENG tuples RSC\_XPMESASDUPD\_BOOL and RSC\_XPMESASDUPD\_HOUR define these updates.

*Note:* To load ESADATA the RCC2 units must be in service.

If the RCC2	Do
is in a single configuration	step 27
is in a dual configuration	step 40

27 To determine if P-side ports are links or carrier trunks, refer to the information obtained in step 5.

If P-side port	Do	
is links	step 28	
is trunks	step 30	

**28** To manually busy all provisioned links connected to the defective NTMX87 circuit card, type

>bsy link link\_no

and press the Enter key.

where

link\_no

is the number of the link associated with the defective NTMX87 circuit card

*Note 1:* Each NTMX81 card has two links. The user must busy each link. Possible link pairs are 0 and 1, 2 and 3, 4 and 5, 6 and 7. This pair relationship continues in all 54 P-side links.

*Note 2:* Refer to the charts in steps 36 and 38 for P-side link-to-slot assignments. You must busy all provisioned links in the slot.

**29** Determine if the NTMX87 circuit card that has faults is on the main or extension shelf. P-side ports 0 to 23, and 48 to 54 are on the main shelf. Ports 24 to 47 are on the extension shelf.

If the defective NTMX87	Do
is on the main shelf	step 36
is on the extension shelf	step 38

30 Access the TRKS;TTP MAP display level. Busy the trunks assigned to the P-side carriers associated with the defective NTMX87. To perform these actions, type

>TRKS;TTP;POST D RCC2 rcc2\_no carrier\_no

and press the Enter key.

where

rcc2 no

is the number of the RCC2 associated with the NTMX87 that

has faults

#### carrier\_no

is the number of the P-side carrier assigned

Example of a MAP response

LAST CIRCUIT = 27POST CKT IDLED SHORT CLLI IS: 1125 OK, CLLI POSTED POST 18 DELO BUSY O DIG TTP 6-006 CKT TYPE PM NO. COM LANG STA S R DOT TE R OG RCC2 0 1 WADEOUT796 11 LO

**31** To busy the trunks associated with the NTMX87 circuit card that has faults, type

#### >BSY ALL

and press the Enter key.

*Note 1:* Wait for the busy queue to clear.

*Note 2:* To busy other carriers associated with the NTMX87 circuit card that has faults, refer to the link-to-slot assignment charts. These charts appear in steps 36 and 38.

32 To installation busy all the trunks to prevent carrier alarms, type

>BSY INB ALL

and press the Enter key.

33 To access the CARRIER level and post the P-side carriers associated with the NTMX87 circuit card that has faults, type

>CARRIER;POST RCC2 rcc2\_no carrier\_no

and press the Enter key.

where

rcc2 no

is the number of the RCC2 associated with the NTMX87 that

has faults

#### carrier\_no

is the number of the P-side carrier assigned

*Note:* Perform this step for each carrier span in the defective NTMX87 circuit card.

**34** To busy and offline the P-side carriers associated with the NTMX87 circuit card that has faults, type

>BSY carrier\_no ;OFFL carrier\_no

and press the Enter key.

where

carrier\_no

is the number of the P-side carrier assigned


*Note:* Perform this step for each carrier span in the NTMX87 circuit card that has faults.

**35** Determine if the NTMX87 circuit card that has faults is on the main or extension shelf. P-side ports 0 to 23, and 48 to 54 are on the main shelf. Ports 24 to 47 are on the extension shelf.

If the NTMX87 that has faults	Do
is on the main shelf	step 36
is on the extension shelf	step 38

#### At the RCE frame

**36** Use the following figure to determine slot assignments on the P-side of the main shelf.



37



#### WARNING


**Static electricity damage** Before you remove any cards, put on a wrist strap and connect the wrist strap to the wrist strap grounding point. This point is on the left side of the modular supervisory panel (MSP) of the RCC2. This action protects the equipment against damage from static electricity.

Remove the NTMX81 packlet as described in the following steps:

- a Locate the NTMX81 packlet you want to remove on the correct NTMX87 carrier card slot.
- **b** Open the locking lever on the NTMX81 packlet. Carefully pull the packlet toward you until the packlet clears the shelf.
- **c** Make sure the NTMX81 packlets are stored in an electrostatic discharge (ESD) container. This container protects the circuit card until you reinstall the packlet in the NTMX87 carrier card.
- d Go to step 42.

#### At the RCE frame

**38** Refer to field SIDE of table RCCINV to determine which side of the extension shelf contains the NTMX87 circuit card that has faults



39



### WARNING

Static electricity damage

Before you remove any cards, put on a wrist strap and connect the wrist strap to the wrist strap grounding point. This point is on the left side of the modular supervisory panel (MSP) of the RCC2. This action protects the equipment against damage from static electricity.

Remove the NTMX81 packlet as described in the following steps:

a Locate the NTMX81 packlet you want to remove on the correct NTMX87 carrier card slot.

- **b** Open the locking lever on the NTMX81 packlet. Carefully pull the packlet toward you until the packlet clears the shelf.
- **c** Make sure the NTMX81 packlets are stored in an electrostatic discharge (ESD) container. This container protects the circuit card until you reinstall the packlet in the NTMX87 carrier card.
- d Go to step 42.
- 40 To translate the dual RCC2s IRLINKS, type

>TRNSL

and press the Enter key.

Example of a MAP response

(	~ ~									_			`
(	CM	MS	IOD					CS		т	rks	Ext	Appl
	•	•	•	•		1R(	CC2	•	•		•	•	•
I	RLINK			SysB		Mar	ıВ	01	EfL	CBsy		ISTb	InSv
	0 Quit		PM	0			0		2	0		2	25
	2		RCC2	0			0		0	0		1	1
	3												
	4		RCC2	0 IST	) I	lin	(s_00	3:	CSide	1, P	Side	1	
	5 TRNSI	5	Unit0:	Inac	t I	InSv	7						
	6 TST_		Unit1:	Act	Ins	Sv							
	7 BSY												
	8 RTS_												
	9												
1	0		IR	From	n		То			CAP	ST	ATE	MSGCOND
1	1		0	RCC2	Ο.	0	RCC2	1.	0	MS		OK	OPN
1			1						8	MS		OK	OPN
1	_		2						12			OK	0111
	4 Query	7TR							13	S		OK	
1		, 110	5	11002	0,	10	1002	±,	10	D		010	
1													
1													
\ 1	-												
$\nearrow$	0												/

41 To busy IRLINKS in the NTMX87 circuit card that has faults, type

>BSY irlink\_no

and press the Enter key.

where

#### irlink\_no

is the number of the irlink that must be busied

*Note 1:* You must perform this step for each provisioned link in the slot position.

*Note 2:* For link-to-slot assignments, refer to step 36 for the main shelf, and step 38 for the extension shelf.

#### At the RCE frame

42



#### WARNING Static electricity damage

Before you remove any cards, put on a wrist strap and connect the wrist strap to the wrist strap grounding point. This point is on the left side of the modular supervisory panel (MSP) of the RCC2. This action protects the equipment against damage from static electricity.



DANGER


Equipment damage Take the following precautions when you remove or insert a card:

- 1. Do not apply direct pressure to the components
- 2. Do not force the cards in the slots.

Put on a wrist strap.

43

Use the T9908 wrist grounding strap and a T1324 screwdriver to remove the NTMX87 frame carrier circuit card. Insert the new carrier card and secure the card.



- a Use your fingers or thumbs to push on the upper and lower edges of the faceplate of the packlet. This method makes sure the packlet is fully seated in the slot.
- **b** Close the locking lever.
- **46** Use the following information to determine the next step in this procedure.

lf	Do	
you entered this procedure from alarm clearing procedures	step 63	
you entered this procedure from another point	step 47	

47	Use the following information to determine the next step in this procedure.							
	lf		Do					
	you entered this pr RCC2 with C-side	rocedure from step 15 for a single links affected	step 48					
	you entered this pr RCC2 with P-side	step 56						
	you entered this pr single RCC2 with	step 52						
	you entered this pro with irlinks affecte	step 54						
At the	MAP terminal							
48	To test the busied net	work links from step 13, type						
	>TST LINK link_n	0						
	and press the En	ter key.						
	where							
	link_no is the number of	of the link associated with the new NTN	IX87					
	carrier card							
	Note 1: You must	perform this step for each manually bu	sied link.					
	Note 2: Test the of	ther links associated with the RCC2. P ne system tested all links.						
	If TST	Do						
	passes	step 49						
	fails	step 64						
49	To return to service th	e P-side links, type						
	>RTS LINK link_n	o						
	and press the Enter k	ey.						
	where							
	link_no	of the link manually busied in step 13						
		of the link manually buoloa in otop to						
	Note 1. You must	perform this step for each link that is m	anually busied					
	<i>Note 1:</i> You must	perform this step for each link that is m	anually busied.					

Note 2: RTS the other links associated with the RCC2. To RTS these links, perform the procedures in this step for each link until all links return to service.

		Do					
	passes	step 50					
	fails	step 64					
	To post the inactive RCC2 that contains the NTMX87 card, type						
>POST RCC2 rcc2_no							
	and press the Enter key.						
	where						
	rcc2_no is the number of the RCC2 ass	ociated with the card that has fault					
To return the inactive RCC2 unit to service, type							
>RTS UNIT unit_no							
and press the Enter key.							
	where						
unit_no is the number of the RCC2 unit posted in step 50							
	If RTS	Do					
	passes	step 61					
		step 64					

>TST LINK link\_no

and press the Enter key.

where

link\_no

is the number of the link associated with the new NTMX87

carrier card

*Note 1:* You must perform this step for each manually busied link.

*Note 2:* To test the other links associated with the RCC2, perform this step for each link until you tested all links.

If TST	Do
passes	step 53
fails	step 64

53

To return to service the P-side links, type

>RTS LINK link\_no

and press the Enter key.

where

#### link\_no

is the number of the link manually busied in step 13

Note 1: You must perform this step for each link that is manually busied.

*Note 2:* RTS the other links associated with the RCC2. To RTS these links, perform the procedures in this step for each link until all links return to service.

If RTS	Do
passes	step 61
fails	step 64

#### At the MAP terminal

54 To test the IRLINKS, type

>TST irlink\_no

and press the Enter key.

where

#### irlink\_no

is the number of the link busied in step 41

*Note 1:* You must perform this step for each manually busied link.

*Note 2:* To test the other irlinks associated with the RCC2, perform this step for each irlink until you tested all links.

If TST	Do	
passes	step 55	
fails	step 64	

55 To return to service the IRLINKS, type

>RTS irlink\_no

and press the Enter key.

where

#### irlink no

is the number of the link manually busied in step 41

*Note 1:* You must perform this step for each irlink that is manually busied.

*Note 2:* RTS the other links associated with the RCC2. To RTS these links, perform this step for each link until all links return to service.

If RTS	Do
passes	step 61
fails	step 64

#### At the MAP terminal

56 To busy and return to service P-side carriers offlined in step 34, type

```
>BSY carrier_no; RTS carrier_no
```

and press the Enter key.

where

carrier\_no is the number of the P-side carrier assigned

If carrier RTS	Do
passes	step 57
fails	step 64

57 To access the TTP MAP level to post the P-side links associated with the new NTMX87 circuit card, type

>TTP;POST D RCC2 rcc2\_no carrier\_no

and press the Enter key.

where

#### rcc2\_no

is the number of the RCC2 associated with the new NTMX87

circuit card

#### carrier\_no

is the number of the P-side link trunks assigned

Example of a MAP response

58

59

60

61

62

63

# NTMX87 in an RSC-S (DS-1) Model B RCC2 (continued)

LAST CIRCUIT = 27POST CKT IDLED SHORT CLLI IS: 1125 OK, CLLI POSTED POST 18 BUSY Q DIG DELQ TTP 6-006 CKT TYPE COM LANG STA S R DOT TE R PM NO. RCC2 0 1 WADEOUT796 11 INB OG To busy the trunks associated with the new NTMX87 circuit card, type >BSY ALL and press the Enter key. Note 1: Wait for the busy queue to clear. Note 2: Busy the other carriers associated with the NTMX87 circuit card that has faults. Refer to the link-to-slot assignment charts in steps 36 and 38. To test the trunks associated with the new NTMX87 circuit card, type >TST;NEXT and press the Enter key. Note: Perform this step for each carrier span associated with the new NTMX87 circuit card. If trunks TST Do step 60 passes fails step 64 To return to service trunks assigned to links on the new NTMX87 circuit card, type >RTS ALL and press the Enter key. If RTS Do step 61 passes fails step 64 Send any cards that have faults for repair according to local procedure. Record the date card replaced, the serial number of the card, and the reason you performed card replacement. Go to step 65. Return to *Alarm Clearing Procedures* or the procedure that directed you to this procedure. At the point where a list of card that have faults appeared,

identify the next card on the list. Refer to the correct card replacement procedure for that card in this manual.

- 64 To replace this card, contact the next level of maintenance for help.
- 65 This procedure is complete. Remove the sign from the active unit. Return to the maintenance procedure that directed you to this card replacement procedure. Continue as directed.

# NTRX41 in an RSC-S (DS-1) Model B MSP

# Application

Use this procedure to replace an NTRX41 card in a modular supervisory panel (MSP) located in a

- cabinetized extension module (CEXT)
- cabinetized line concentrating equipment (CLCE)
- cabinetized line module ISDN (CLMI)
- cabinetized power distribution center (CPDC)
- cabinetized remote switching center (CRSC)
- cabinetized miscellaneous equipment (CMIS)
- cabinetized remote miscellaneous equipment (CRME)


PEC	Suffixes	Name
NTRX41	AA, BA, CA	Alarm Module


# **Common procedures**

None

### Action

The following flowchart is only a summary of the procedure. To replace the card, use the instructions in the step-action procedure that follows the flowchart.





### Replacing an NTRX41 card in RSC-S MSP


#### At your Current Location

- 1 Proceed only if you have been directed to this card replacement procedure from a step in a maintenance procedure, are using the procedure for verifying or accepting cards, or have been directed to this procedure by your maintenance support group.
- 2 Obtain a replacement card. Ensure that the replacement card has the same product equipment code (PEC), including suffix, as the card that is to be removed.

#### At the front panel of the cabinet

**3** Open the front cover of the MSP. Release the two cover latches and swing the cover down to the open position.

*Note:* The illustrations in this card replacement procedure are for the MSP shelf in an CRSC or CEXT module. The circuit breaker designation may vary depending on the type of cabinet you are working in.



4



## DANGER

**Risk of injury from high energy levels, static electricity damage** Before removing any cards, put on a wrist strap and connect it to the wrist strap grounding point on the left side of the modular supervisory panel (MSP). This protects the equipment against damage caused by static electricity.



## DANGER


**Risk of injury from high energy levels, equipment damage** Take these precautions when removing or inserting a card:

- 1. Do not apply direct pressure to the components.
- 2. Do not force the cards into the slots.

Put on a wrist strap.


5

- Remove the NTRX41 circuit card as shown in the following figure.
  - **a** Open the front doors of the cabinet and locate the circuit card, it will be in slots 05 and 06.



- **b** At the front of the MSP, disengage the knurled thumbscrew at the top of the circuit card.
- c Pull out the lever on the upper left side of the alarm module.
- d Gently pull the circuit card toward you until it clears the shelf.
- 6 Ensure the replacement circuit card has the same PEC, including suffix, as the circuit card just removed.

# NTRX41 in an RSC-S (DS-1) Model B MSP (end)



- **a** Align the circuit card with the slots in the shelf and gently slide the circuit card into the shelf.
- **b** Gently but firmly seat the circuit card.
- c Push in lever on the upper left side of alarm module.
- d Tighten the knurled thumbscrew at the top of the circuit card.

If alarm lights	Do	
remain off	step 7	
light up	step 9	

- 7 Send any faulty cards for repair according to local procedure.
- 8 Record the date the card was replaced, the serial number of the card, and the symptoms that prompted replacement of the card. Go to step 10.
- **9** Obtain further assistance in replacing this card by contacting the personnel responsible for the next higher level of support.
- **10** You have successfully completed this procedure. Return to the maintenance procedure that directed you to this card replacement procedure and continue as directed.

# NTRX42 in an RSC-S (DS-1) Model B MSP

# Application

Use this procedure to replace an NTRX42 card in a modular supervisory panel (MSP) located in a

- cabinetized extension module (CEXT)
- cabinetized line concentrating equipment (CLCE)
- cabinetized line module ISDN (CLMI)
- cabinetized power distribution center (CPDC)
- cabinetized remote switching center (CRSC)
- cabinetized miscellaneous equipment (CMIS)
- cabinetized remote miscellaneous equipment (CRME)

PEC	Suffixes	Name
NTRX42	AA, CA	Circuit Breaker Module

## **Common procedures**

None

## Action

A connector removal tool is available to facilitate removal of the AMP Faston receptacles from the power input and output connectors of the MSP modules. This tool comes in two lengths: P0746192 152 mm (6 in.), and P0747552 254 mm (10 in.). The shorter tool is used when access to the rear of the MSP is very limited. An example of limited access is, MSP modules located directly behind the cabinet bulkhead.


This tool is approximately 2 mm (.090 in.) thick and 17 mm (.65 in.) wide, with a jaw-like cut-out at each end. The cut-out profile conforms to the shape of the Faston receptacle. The shorter tip of each profile is used to position the receptacle in the tool.

The first meeting point of the tool serves as the pivot point. By rotating the tool around this pivot point, the longer tip of the profile which has a hook on its end, is engaged with the action-arm of the power connector. As the action-arm of the connector is depressed, the receptacle is disengaged from the connector tab. The receptacle is removed by pulling the tool with the receptacle trapped in its jaw, away from the connector. The tool is disengaged

from the receptacle by rotating the tool's hook off the action-arm of the receptacle.


Although the shape of the cut-out is the same on each end of the tool, the orientation of the profile is off by 15 degrees. This difference allows for the use of the tool at different angles, which may be required due to limited access to the connectors.

#### **Connector removal tool**



The following flowchart is a summary of this procedure. Use the instructions in the step-action table that follows the flowchart to perform the procedure. The detailed procedure depends on which circuit cards are served by the breaker module circuit card (NTRX42). You will be directed to the appropriate steps depending on your configuration.

## Summary of replacing an NTRX42 card in an RSC-S MSP



### Replacing an NTRX42 card in RSC-S MSP

#### At your Current Location


- 1 Proceed only if you have been directed to this card replacement procedure from a step in a maintenance procedure, are using the procedure for verifying or accepting cards, or have been directed to this procedure by your maintenance support group.
- 2 Obtain a replacement card. Ensure that the replacement card has the same product equipment code (PEC), including suffix, as the card that is to be removed.

#### At the front panel of the cabinet

**3** Open the front cover of the MSP. Release the two cover latches and swing the cover down to the open position.

*Note:* The illustrations in this card replacement procedure are for the MSP shelf in an CRSC or CEXT module. The circuit breaker designation may vary depending on the type of cabinet you are working in.

## Modular supervisory panel



- 4 Use the breaker designation label to identify which cards are serviced by each circuit breaker (CB). For example, the label CB01-47-01 identifies circuit breaker 01 as controlling circuit card position 01 on shelf 47. Many RX42 modules service two separate devices (or units); both units must be powered down prior to removal of the associated RX42 circuit card.
- **5** Use the following table to determine which step to do next.

If the CB powers the	Do
RMM shelf containing 2X09 or 2X06 cards	step 6

## NTRX42

in an RSC-S (DS-1) Model B MSP (continued)

If the CB powers the	Do
RCC2 shelf containing MX72 card	step 9
LCME shelf containing 6X30, 6X53 or BX72 cards	step 15

## At the MAP terminal

6 Set the MAP display to the PM level and post the RMM by typing

>MAPCI; MTC; PM; POST RMM rmm\_no

and pressing the Enter key.

where

rmm\_no

is the number of the RMM unit from which the card is to be removed Example of a MAP display

	M MS	IO	D	Net	PM	CCS	LNS	Trks	Ext	Appl
.	•	•		•	•	•	•	•	•	•
RMI	M		S	vsB	ManB	Offi		CBsy	ISTb	InSv
	Quit	DM		-	0			-	3	130
	Post_				1	1		0	0	2
	_	RIMM		0	T	T		0	0	2
3			_							
4		RMM	5	INSV						
5	Trnsl									
6	Tst									
7	Bsy									
8	RTS									
9	OffL									
10	LoadPM									
11	Disp_									
12	Next									
13										
14	QueryPM									
15	~ 1									
16										
17										
18										
( 10										

7 Busy the RMM by typing

>BSY and pressing the Enter key.

Example of a MAP display

CI	4 MS ·	IOD	Net	-		LNS	Trks	Ext	Appl
RMN	4		SysB	ManB	Of	fL	CBsy	ISTb	InSv
0	Quit	PM	4	0		10	0	0	130
	Post_	RMM	0	1		0	0	0	0
3 4			MamD						
	Trnsl	RMM 5	ManB						
	Tst								
	Bsy								
	RTS								
9	OffL								
10	LoadPM								
	Disp_								
	Next								
13	0								
14 15	QueryPM								
16									
17									
18									/

#### At the RMM shelf

8 Power down the unit by setting the ON/OFF switch on the power converter faceplate to the OFF position. Both the converter FAIL LED and FRAME FAIL lamp on the MSP will be ON. An audible alarm may sound. If an alarm does sound, silence it by typing

SIL

and pressing the Enter key.

Go to step 28.

9 Access the PM level and post the RCC2 by typing

>MAPCI;MTC;PM;POST rcc2\_no

and pressing the Enter key.

where

rcc2 no

is the number of the RCC2 unit that will be busied.

Example of a MAP display

C1	i MS	IOD	Net	РМ	CCS	LNS	Trks	Ext	Appl
•	•	•	•	1RCC2	•	•	•	•	•
RCC	22		SysB	ManB	Of	fL	CBsy	ISTb	InSv
0	Quit	PM	0	0		2	0	2	25
2	Post_	RCC2	0	0		0	0	1	1
3	ListSet								
4		RCC2	0 ISTb	Links	_00S:	CSide	1, PSic	le 1	
5	TRNSL	Unit0:	Inact	InSv					
6	TST	Unit1:	Act Ir	ıSv					
7	BSY								
8	RTS								
9	OffL								
10	LoadPM_								
11	Disp_								
12	Next_								
13									
14	QueryPM								
15									
16									
17									
18									

**10** The NTRX42 you are replacing should be controlling the INACTIVE side of the RCC2.

If NTRX42 card is on the	Do
active unit	step 11
inactive unit	step 13

11 Switch the processing activity (SWACT) to the INACTIVE unit by typing >SWACT

and pressing the Enter key.

12 Confirm the system prompt by typing

>YES

and pressing the Enter key.

After both units are in-service proceed to the next step.

#### At the RCE frame

**13** Place a sign on the active unit bearing the words: *Active unit. Do not touch.* This sign should not be attached by magnets or tape.

# NTRX42 in an RSC-S (DS-1) Model B MSP (continued)

At the	MAP terminal										
14	Busy the inactive PM unit by typing										
	> <i>bsy unit</i> unit_no										
	where										
	unit_no is the number of the INACTIVE	RCC2 unit that will be busied.									
	Go to step 28.										
15	Use the following information to deter	mine where to proceed.									
	If top circuit breaker of NTRX42 powers	Do									
	NT6X53 or NTBX72	step 17									
	NT6X30	step 21									
16	Use the following information to determine where to proceed.										
	If bottom circuit breaker of NTX42 powers	Do									
	NT6X53 or NTBX72	step 17									
	NT6X30	step 21									
17	Set the MAP display to the PM level an breaker by typing	d post the LCME powered by the circuit									
	>MAPCI;MTC;PM;POST LCME site	e lcme_frame_no lcme_no									
	and pressing the Enter key.										
	where										
	<b>site</b> is the name of the site at which	the LCME is located									
	<pre>lcme_frame_no     is the number of the frame in w</pre>	hich the LCME is located									

lcme\_no

is the number of LCME the circuit breaker supplies power to

Example of a MAP display

/																	
(	CI	M MS	IOD		Net		PM		CC	cs	LN	1S	Trks	3	Ext	Appl	
	•	•	•		•		•		•				•		•	•	
	LCN	ΊE		Sy	sB		Ma	nB		Of	fL		CBsy		ISTb	InSv	
	0	Quit	PM	-	4			0			10		- 3		3	130	
		~ Post_			1			0			5		0		1	9	
	4	Swrg_	LCME Unit-(		emL InS		0 0	IS	Гb	Liı	nks_(	00S	: CSi /RG:	de 1 0	L		
		Trnsl_	Unit-1										/RG:	0			
		Tst_ Bsy_								11			/1001	-	G:Pref:0		
	8	RTS_	Drwr:	01	23	45	67	89	01	23	45				Stby:1	InSv	
	9	OffL_		••	••	••	••	••	••	••	••						
	10	LoadPM_															
	11	Disp_															
	12	Next_															
	13																
	14	QueryPM															
	15																
	16																
	17																
$\left( \right)$	18																Ϊ

**18** Busy the LCME unit powered by the circuit breaker by typing

>BSY UNIT lcme\_unit\_no

and pressing the Enter key.

where

lcme\_unit\_no

is the unit number of LCME to which the circuit breaker supplies power.

Example of a MAP display

.       .
0 Quit PM 4 1 10 3 3 13 2 Post_ LCME 1 1 5 0 1 3 4 SwRg LCME RemL OO 0 ISTB Links_OOS: CSide 1 5 Trnsl Unit-0: InSv Mtce TakeOver /RG: 0 6 Tst Unit-1: ManB Mtce /RG: 0 7 Bsy 11 11 11 RG:Pref:0 InSv 8 RTS Drwr: 01 23 45 67 89 01 23 45 Stby:1 InSv 9 OffL
2       Post_       LCME       1       1       5       0       1         3       4       SwRg       LCME       RemL       OO O ISTb       Links_OOS:       CSide 1         5       Trnsl       Unit-0:       InSv       Mtce       TakeOver       /RG:       0         6       Tst       Unit-1:       ManB       Mtce       /RG:       0         7       Bsy       11       11       RG:Pref:0       InSv         8       RTS       Drwr:       01       23       45       Stby:1       InSv         9       OffL               10       LoadPM               12       Next               14       QueryPM               15                16               17
3         4 SwRg       LCME       RemL       OO O ISTb       Links_OOS:       CSide 1         5 Trnsl       Unit-0:       InSv       Mtce       TakeOver       /RG:       0         6 Tst       Unit-1:       ManB       Mtce       /RG:       0         7 Bsy       11 11 11       RG:Pref:0       InSv         8 RTS       Drwr:       01 23 45 67 89 01 23 45       Stby:1       InSv         9 OffL              10 LoadPM              12 Next              13       QueryPM             15              16              17
4       SwRg       LCME       RemL       OO O ISTb       Links_OOS:       CSide 1         5       Trnsl       Unit-0:       InSv       Mtce       TakeOver       /RG:       0         6       Tst       Unit-1:       ManB       Mtce       /RG:       0         7       Bsy       11       11       II       RG:Pref:0       InSv         8       RTS       Drwr:       01       23       45       Stby:1       InSv         9       OffL               0       LoadPM               2       Next               3                4       QueryPM               5                6
6 Tst Unit-1: ManB Mtce /RG: 0 7 Bsy 11 11 11 RG:Pref:0 InSv 8 RTS Drwr: 01 23 45 67 89 01 23 45 Stby:1 InSv 9 OffL
7 Bsy       11 11 11       RG:Pref:0 InSv         8 RTS       Drwr: 01 23 45 67 89 01 23 45       Stby:1 InSv         9 OffL            10 LoadPM            11 Disp_            12 Next            13       QueryPM           15            16            17
8 RTS Drwr: 01 23 45 67 89 01 23 45 Stby:1 InSv 9 OffL
9 OffL 10 LoadPM 11 Disp_ 12 Next 13 14 QueryPM 15 16 17
10 LoadPM 11 Disp_ 12 Next 13 14 QueryPM 15 16 17
11 Disp_ 12 Next 13 14 QueryPM 15 16 17
12 Next 13 14 QueryPM 15 16 17
L3 L4 QueryPM L5 L6 L7
15 16 17
.6 .7
.7
-8
Use the following information to determine where to proceed
Use the following information to determine where to proceed.
Use the following information to determine where to proceed.  If Do
IfDoCircuits associated with bottom circuit breaker of NTRX42 have not been busied or otherwise addressedstep 16Circuits associated with both circuit breakers of NTRX42 have been busied or otherwisestep 28
If     Do       Circuits associated with bottom step 16       circuit breaker of NTRX42 have not been busied or otherwise addressed       Circuits associated with both step 28       circuit breakers of NTRX42
If       Do         Circuits associated with bottom step 16       step 16         circuit breaker of NTRX42 have not been busied or otherwise addressed       step 28         Circuits associated with both step 28       step 28         circuit breakers of NTRX42 have been busied or otherwise addressed       step 28         Set the MAP display to the PM level and post the LCME in the same for the
If       Do         Circuits associated with bottom step 16       step 16         circuit breaker of NTRX42 have not been busied or otherwise addressed       circuits associated with both step 28         Circuits associated with both step 28       circuit breakers of NTRX42         have been busied or otherwise addressed       Set the MAP display to the PM level and post the LCME in the same fithe circuit breaker by typing

#### site

is the name of the site at which the LCME is located

#### lcme\_frame\_no

is the number of the frame in which the LCME is located

#### lcme\_no

is the number of the LCME in the same frame as the circuit breaker *Example of a MAP display* 

(	CM	MS	IOD		Net		₽M	I	CC	S	LNS	5	Trks	5	Ext	Appl
	•	•	•		•		•				•		•		•	•
L	CME			Sγ	∕sB		Ма	nB		Of	fL		CBsy		ISTb	InSv
	) Quit		PM		4			0			10		3		3	130
	2 Post	_	LCME		1			0			5		0		1	9
	3															
	4 Swrg		LCME	Re	emL	00	0 0	IST	Гb	Liı	nks_00	os:	CSid	de	1	
!	5 Trns	1_	Unit-	0:	Ins	Sv							/RG:	0		
	5 Tst_		Unit-1	1:	Ins	Sv							/RG:	0		
	7 Bsy_								11	11	11			R	G:Pref:0	InSv
;	3 RTS_		Drwr:	01	23	45	67	89	01	23	45				Stby:1	InSv
1	9 OffL	_														
1	) Load	PM_														
1	l Disp															
1	2 Next	_														
1	3															
1	4 Quer	уРМ														
1	5															
1	5															
1	7															
1	3															

22 Busy the LCME unit associated with the ring generator by typing

>BSY UNIT lcme\_unit\_no

and pressing the Enter key.

where

#### lcme\_unit\_no

is zero when the circuit breaker powers ring generator zero

is one when the circuit breaker powers ring generator one *Example of a MAP display* 

	CM	MS	IOD				CS .		Trks	Ext	Appl
L	CME	3		SysB	Ma	nB	OffL	(	CBsy	ISTb	InSv
	0 Ç	Quit	PM	4		1	10		3	3	130
		Post_	LCME	1		1	5		0	1	9
	3										
	4 8	SwRg	LCME	RemL	00 0	ISTb	Link	s_00S	: CSid	e 1	
		rnsl									
	бΊ	st	Unit-1	: Mai	nB Mtce	•		/RG:	0		
		Bsy								f:0 InSv	
	8 F	RTS	Drwr:	01 23	45 67	89 01	23 45		Stb	y:1 InSv	
	9 C	DffL		• • • •	•••••		•••••				
1	0 I	LoadPM									
1	1 I	Disp_									
1	2 N	lext									
1	3										
1	4 Ç	)ueryPM									
1	5										
1	б										
1	7										
( 1	8										/

An alarm may sound. If this occurs, silence the alarm by typingSIL

and pressing the Enter key.

24 If there is a second LCME in the same frame as the circuit breaker, post the other LCME by typing

>MAPCI;MTC;PM;POST LCME site lcme\_frame\_no lcme\_unit\_no
and pressing the Enter key.

where

site

is the name of the site at which the LCME is located

Icme\_frame\_no

is the number of the frame in which the LCME is located

#### lcme\_unit\_no

is the number of the LCME in the same frame as the circuit breaker

**25** Busy the LCME unit associated with the ring generator by typing

>BSY UNIT lcme\_unit\_no

and pressing the Enter key.

#### where

#### Icme\_unit\_no

is zero when the circuit breaker powers ring generator zero.

is one when the circuit breaker powers ring generator one

26 An alarm may sound. If this occurs, silence the alarm by typing >SIL and pressing the Enter key. 27 Use the following information to determine where to proceed. lf Do Circuits associated with bottom step 16 circuit breaker of NTRX42 have not been busied or otherwise addressed Circuits associated with both step 28 circuit breakers of NTRX42 have been busied or otherwise addressed At the front panel of the cabinet 28 Verify and switch off associated power converter. Note: Not applicable to the CPDC and CRME. Determine faulty circuit breaker on MSP and switch both breakers on that circuit card to the OFF position. Safety tag the front of the circuit breaker. 29 30 An alarm may sound. If this occurs, silence the alarm by typing >SIL and pressing the Enter key. 31 Power down and safety tag the ABS fuse in the power room. *Note:* This step applies to the CPDC and CRME. 32 Pull out corresponding line shelf approximately 152 mm (6 in.). The line shelf is located below the MSP. This approach permits easier hand access to the connectors on the rear of the MSP.

*Note:* This step does not apply to the CMIS, CPDC, and CRME.

At the rear panel of the cabinet

33



## DANGER

**Risk of injury from high energy levels, static electricity damage** Before removing any cards, put on a wrist strap and connect it to the wrist strap grounding point on the left side of the modular supervisory panel (MSP). This protects the equipment against damage caused by static electricity.

## DANGER


**Risk of injury from high energy levels, equipment damage** Take these precautions when removing or inserting a card:

- 1 Do not apply direct pressure to the components.
- 2. Do not force the cards into the slots.

3. Do not insert metallic objects into the black connectors. Voltage is present and equipment damage could result.

Put on a wrist strap.

- **34** Open the rear door and locate the NTRX42 circuit card. Verify the card location by checking the slot number stamped into the chassis.
  - a Note wire color and location to facilitate re-connection.




- **b** Safety tag the front of the circuit breaker to indicate maintenance activity.
- **c** Using the connector removal tool, manually disconnect the power connectors to the circuit card. Working from the bottom of the MSP shelf to the top of the MSP shelf, manually disconnect and tag the smaller black power connectors located below the larger blue power connector.

Manually disconnect and tag the large blue power connector. Disconnect and tag the smaller black power connectors located above the large blue power connector. Ensure you disconnect the black connectors *before* removing the circuit card.


- **d** Although the connectors have voltage present on them, they are insulated. Secure the connectors to the power-connector bundle with a line-tie until it is time to reconnect them.
- **35** Disconnect and tag any jumper connectors and cables which may be present and set them aside for use on the replacement unit.

#### At the front panel of the cabinet

- 36 Remove the NTRX42 card.
  - **a** Disengage the spring-loaded captive screw at the top of the circuit card.
  - **b** Grasping the top and bottom of unit, gently pull the circuit card towards you until it clears the shelf.
  - **c** Replace the circuit card. Ensure the replacement circuit card has the same PEC, including suffix, as the circuit card being replaced.
  - **d** Tighten the spring-loaded captive screw at the top of the circuit card.




**37** Replace any jumper connectors and cables removed in step 35. Reinsert the power connectors at the rear of the circuit card.



38

Push in corresponding line shelf. This step does *not* apply to the CMIS, CPDC, and CRME.



- **39** Apply appropriate label from spare parts on replacement NTRX42 circuit card.
- 40 Power up the ABS fuse in the power room, remove safety tag from ABS fuse. *Note:* This step applies to the CPDC and CRME.
- 41 Switch on associated power converter.

*Note:* This step does not apply to the CPDC and CRME.

Reset the circuit breakers to ON (upward). If any card controlled by this breaker includes a reset switch, hold the RESET button downward while setting the circuit breaker to the ON position.					
	Remove safety tag from front of circuit breaker.				
Close the front cover of the MSP. Swing the cover up to the closed position and lock the two cover latches.					
Proceed according to the following table.					
	Do	If circuit breakers power the			
	step 46	LCME shelf containing 6X30, 6X53 or BX72 cards			
	step 51	RCC2 shelf containing MX72 card			
	step 56	RMM shelf containing 2X09 or 2X06 cards			
		Test the LCME unit by typing	46		
		<i>TST UNIT</i> lcme_unit_no			
		and pressing the Enter key.			
		where			
<pre>lcme_unit_no     is the number of the LCME unit busied.</pre>					
	Do	If test			
	step 47	passed			
	step 65	failed			
	ping	Return the LCME unit to service by ty	47		
		RTS UNIT lcme_unit_no			
		and pressing the Enter key.			
		where			
<pre>lcme_unit_no     is the number of the LCME unit tested in step 46</pre>					
	Do	If RTS			
		massad			
	step 48	passed			
	step 48 step 65	failed			
-	t tested in step 46	RTS UNIT lcme_unit_no and pressing the Enter key. where lcme_unit_no is the number of the LCME uni If RTS	47		

# NTRX42 in an RSC-S (DS-1) Model B MSP (continued)

- 49 Record the date the card was replaced, the serial number of the card, and the symptoms that prompted replacement of the card.
- 50 Go to step 66.
- 51 Test the RCC2 unit by typing

>TST UNIT rcc2\_unit\_no

and pressing the Enter key.

where

rcc2\_unit\_no

is the number of the RCC2 unit

	If test	Do				
	passed	step 52				
	failed	step 65				
52	Return the RCC2 unit to service by typing					
	>RTS UNIT RCC2_unit_no					
	and pressing the Enter key.					
	where					
	<pre>rcc2_unit_no     is the number of the RCC2 unit tested in step 51</pre>					
	If RTS	Do				
	If RTS passed	Do step 53				
53	passed	step 53 step 65				
53 54	passed failed Send any faulty cards for repair acco	step 53 step 65 rding to local procedure. d, the serial number of the card, and the				
	passed failed Send any faulty cards for repair acco Record the date the card was replaced	step 53 step 65 rding to local procedure. d, the serial number of the card, and the				

56 Determine the system load version.

lf	Do
System Load Module is Version 1	step 57
System Load Module is Version 2	step 58

57	List the loadfile in the directory by typin	ng			
	> DSKUT;listvol d000 all				
	or				
	> dskut;listvol d010 all				
	and pressing the Enter key.				
	Local operating company policy detern loadfile will be on.	nines which disk, D000 or D010, the			
	Proceed to step 59.				
58	List the loadfile in the directory by typing				
	>DISKUT;LV S00d				
	>LF				
	or				
	> diskut;LV s01d				
	>LF				
	and pressing the Enter key.				
59	Leave the disk utility by typing				
	>QUIT				
	and pressing the Enter key.				
60	Reload the RMM by typing				
	>LOADPM				
	and pressing the Enter key.				
	lf	Do			
	load passes	step 61			
	load fails	step 65			
61	Test the RMM unit by typing				
	>TST UNIT rmm_unit_no				
	and pressing the Enter key.				
	where				
	<pre>rmm_unit_no     is the number of the RCC2 unit</pre>				
	K DTC	Do			
		<u> </u>			
	passed	step 62			

62 Return the RMM shelf to service by typing

>RTS UNIT rmm\_unit\_no

and pressing the Enter key.

where

rmm\_unit\_no
is the number of the RCC2 unit tested in step 61

If RTS	Do
passes	step 63
fails	step 65

63 Send any faulty cards for repair according to local procedure.

- 64 Record the date the card was replaced, the serial number of the card, and the symptoms that prompted replacement of the card. Go to step 66.
- 65 Obtain further assistance in replacing this card by contacting the personnel responsible for the next higher level of support.
- 66 You have successfully completed this procedure. Return to the maintenance procedure that directed you to this card replacement procedure and continue as directed.

# NTRX43 in an RSC-S (DS-1) Model B MSP

# Application

Use this procedure to replace an NTRX43 card in a modular supervisory panel (MSP) located in a

- cabinetized extension module (CEXT)
- cabinetized line concentrating equipment (CLCE)
- cabinetized line module ISDN (CLMI)
- cabinetized power distribution center (CPDC)
- cabinetized remote switching center (CRSC)
- cabinetized miscellaneous equipment (CMIS)
- cabinetized remote miscellaneous equipment (CRME)

PEC	Suffixes	Name
NTRX43	AA	Fuse Module

## **Common procedures**

None

## Action

A connector removal tool is available to facilitate removal of the AMP Faston receptacles from the power input and output connectors of the MSP modules. This tool comes in two lengths: P0746192 152 mm (6 in.), and P0747552 254 mm (10 in.). The shorter tool is used when access to the rear of the MSP is very limited. An example of limited access is, MSP modules located directly behind the cabinet bulkhead.


This tool is approximately 2 mm (.090 in.) thick and 17 mm (.65 in.) wide, with a jaw-like cut-out at each end. The cut-out profile conforms to the shape of the Faston receptacle. The shorter tip of each profile is used to position the receptacle in the tool.

The first meeting point of the tool serves as the pivot point. By rotating the tool around this pivot point, the longer tip of the profile which has a hook on its end, is engaged with the action-arm of the power connector. As the action-arm of the connector is depressed, the receptacle is disengaged from the connector tab. The receptacle is removed by pulling the tool with the receptacle trapped in its jaw, away from the connector. The tool is disengaged


from the receptacle by rotating the tool's hook off the action-arm of the receptacle.


Although the shape of the cut-out is the same on each end of the tool, the orientation of the profile is off by 15 degrees. This difference allows for the use of the tool at different angles, which may be required due to limited access to the connectors.

#### **Connector removal tool**



The following flowchart is a summary of this procedure. Use the instructions in the step-action table that follows the flowchart to perform the procedure.





#### Replacing an NTRX43 card in RSC-S MSP


#### At your Current Location

- 1 Proceed only if you have been directed to this card replacement procedure from a step in a maintenance procedure, are using the procedure for verifying or accepting cards, or have been directed to this procedure by your maintenance support group.
- 2 Obtain a replacement card. Ensure that the replacement card has the same product equipment code (PEC), including suffix, as the card that is to be removed.

#### At the front panel of the cabinet

**3** Open the front cover of the MSP. Release the two cover latches and swing the cover down to the open position.

*Note:* The illustrations in this card replacement procedure are for the MSP shelf in an CRSC or CEXT module. The circuit breaker designation may vary depending on the type of cabinet you are working in.



4 Power down circuit breaker supplying fuse module. Safety tag the front of the circuit breaker. When servicing the fuse module, fans may shut down, alarms may sound, or there may be a loss of alarms.

5



#### DANGER

**Risk of injury from high energy levels, static electricity damage** Before removing any cards, put on a wrist strap and connect it to the wrist strap grounding point on the left side of the modular supervisory panel (MSP). This protects the equipment against damage caused by static electricity.



**DANGER Risk of injury from high energy levels, equipment damage** Take these precautions when removing or inserting a card:

- 1. Do not apply direct pressure to the components.
- 2. Do not force the cards into the slots.

Put on a wrist strap.

6 Remove fuses from fuse module.

*Note:* Observe fuse colors, values, and positions before removing fuses from fuse module.

7 Pull out corresponding line shelf approximately 152 mm (6 in.). The line shelf is located below the MSP. This approach permits easier hand access to the connectors on the rear of the MSP. This step does *not* apply to the CMIS, CPDC, and CRME.

#### At the rear panel of the cabinet

8




## DANGER

**Risk of injury from high energy levels, voltage present** Do not insert metallic objects into the black connectors. Voltage is present and equipment damage could result.

Remove the NTRX43 circuit card as shown in the following figures.


- **a** Open the rear doors of the cabinet and locate the back of the card to be replaced.
- **b** Note wire color and location to facilitate re-connection.



- **c** Using the connector removal tool, manually disconnect the power connectors to the circuit card. Working from the bottom of the MSP shelf to the top of the MSP shelf, manually disconnect the smaller black power connectors located below the larger blue power connector. Manually disconnect the large blue power connector. Disconnect the smaller black power connectors located above the large blue power connector. Ensure you disconnect the black connectors *before* removing the circuit card.
- **d** Although the connectors have voltage present on them, they are insulated. Secure the connectors to the power-connector bundle with a line-tie until it is time to reconnect them.
- e Remove and tag jumper connectors and cables, which may be present on the back of the circuit card and save for use on the replacement circuit card.

#### At the front panel of the cabinet

- 9 Remove the NTRX43 card.
  - **a** Disengage the knurled thumbscrew at the top of the card.
  - **b** Gently pull the card towards you until it clears the shelf.




**10** Ensure the replacement circuit card has the same PEC, including suffix, as the circuit card just removed.

- **a** Align the circuit card with the slots in the shelf and gently slide the circuit card into the shelf.
- **b** Gently but firmly seat the circuit card.
- c Tighten the knurled thumbscrew at the top of the circuit card.

## At the rear panel of the cabinet

11 Locate the replaced circuit card and re-attach the power connectors.



12 Install the jumper connectors and cables removed in step 8 onto the replacement circuit card.

#### At the front of the cabinet

- **13** Push in corresponding line shelf. Please note this step does *not* apply to the CMIS, CPDC, and CRME.
- 14 Replace fuses removed in step 6.
- **15** Power up circuit breaker supplying fusEve module and remove safety tag.

If fuses	Do
do not blow	step 16
blow (protrude)	step 18

- **16** Send any faulty cards for repair according to local procedure.
- 17 Record the date the card was replaced, the serial number of the card, and the symptoms that prompted replacement of the card. Go to step 19.
- **18** Obtain further assistance in replacing this card by contacting the personnel responsible for the next higher level of support.
- **19** You have successfully completed this procedure. Return to the maintenance procedure that directed you to this card replacement procedure and continue as directed.

# NTRX44 in an RSC-S (DS-1) Model B MSP

# Application

Use this procedure to replace an NTRX44 card in a modular supervisory panel (MSP) located in a

- cabinetized extension module (CEXT)
- cabinetized line concentrating equipment (CLCE)
- cabinetized line module ISDN (CLMI)
- cabinetized power distribution center (CPDC)
- cabinetized remote switching center (CRSC)
- cabinetized miscellaneous equipment (CMIS)

PEC	Suffixes	Name
NTRX44	AA	Talk Battery Module

## **Common procedures**

None

## Action

A connector removal tool is available to facilitate removal of the AMP Faston receptacles from the power input and output connectors of the MSP modules. This tool comes in two lengths: P0746192 152 mm (6 in.), and P0747552 254 mm (10 in.). The shorter tool is used when access to the rear of the MSP is very limited. An example of limited access is, MSP modules located directly behind the cabinet bulkhead.


This tool is approximately 2 mm (.090 in.) thick and 17 mm (.65 in.) wide, with a jaw-like cut-out at each end. The cut-out profile conforms to the shape of the Faston receptacle. The shorter tip of each profile is used to position the receptacle in the tool.

The first meeting point of the tool serves as the pivot point. By rotating the tool around this pivot point, the longer tip of the profile which has a hook on its end, is engaged with the action-arm of the power connector. As the action-arm of the connector is depressed, the receptacle is disengaged from the connector tab. The receptacle is removed by pulling the tool with the receptacle trapped in its jaw, away from the connector. The tool is disengaged


from the receptacle by rotating the tool's hook off the action-arm of the receptacle.

Although the shape of the cut-out is the same on each end of the tool, the orientation of the profile is off by 15 degrees. This difference allows for the use of the tool at different angles, which may be required due to limited access to the connectors.

#### **Connector removal tool**



The following flowchart is a summary of this procedure. Use the instructions in the step-action table that follows the flowchart to perform the procedure.



#### Summary of card replacement procedure in an NTRX44 card in RSC-S MSP

#### Replacing an NTRX44 card in RSC-S MSP

At your Current Location

1



## CAUTION

Loss of service

A loss of service *will* occur when this procedure is used as an acceptance procedure or when talk battery is already available on the affected LCM unit. Busying the LCM unit is a precaution only and does not transfer talk battery to the other LCM unit. Talk battery is *not redundant*, and therefore a loss of service occurs on the affected LCM unit. Perform this procedure only during periods of low traffic.

Proceed only if you have been directed to this card replacement procedure from a step in a maintenance procedure, are using the procedure for verifying or accepting cards, or have been directed to this procedure by your maintenance support group.

2 Obtain a replacement card. Ensure that the replacement card has the same product equipment code (PEC), including suffix, as the card that is to be removed.

#### At the MAP terminal

3 Set the MAP display to the PM level and post the LCME powered by the talk battery module by typing

>MAPCI;MTC;PM;POST LCME site lcme\_frame\_no lcme\_no

and pressing the Enter key.

where

site

is the name of the site at which the LCME is located

Icme\_frame\_no

is the number of the frame in which the LCME is located

lcme\_no

is the number of the LCME powered by the talk battery module

Example of a MAP display

	СМ •	MS	IOD		et	PM 1LCMB		CCS •	5 1	Lns •		Trks •	Ex	t A	Pbr
LCI	ЧE			SysE	3	Mar	nВ	(	DffL		CBs	у	ISTb	1	InSv
0	Qui	t	PM	1	-		0		2			0	2		12
2	Pos	st_	LCME	(	)		0		2			0	2		9
3	Lis	stSet													
4	SwF	RG	LCME	RSC-	S	14 1	IST	b I	Links_	_005	:	CSide	0	PSid	e 0
5	Trr	nsl_	Unit0:	Ir	ıSv				,	/RG:	1				
6	Tst	-	Unit1:	Ir	ıSv				,	/RG:	1				
7	Bsy	<u>_</u>							11	11	11		RG:P	ref 1	ISTB
8	RTS	5_	Drwr:	01	23	45	67	89	01	23	4		Stby	0 In	Sv
9	Off	L		••	••	• •	••			••	• •				
10	Loa	adPM_													
11	Dis	sp_													
	Nex	t													
13															
	Que	eryPM													
15															
16															
17															
18															/

Busy the affected in-service PM unit by typing

>BSY UNIT lcme\_unit\_no

and pressing the Enter key.

where

4

#### lcme\_unit\_no


is the number of the LCME unit.

*Note:* The talk battery module in slots 1 and 2 controls unit number 0; the module in slots 3 and 4 controls unit number 1.

#### At the front panel of the cabinet

5 Open the front cover of the MSP. Release the two cover latches and swing the cover down to the open position.

*Note:* The illustrations in this card replacement procedure are for the MSP shelf in an CRSC or CEXT module.



6



#### DANGER

**Risk of injury from high energy levels, static electricity damage** Before removing any cards, put on a wrist strap and connect it to the wrist strap grounding point on the left side of the modular supervisory panel (MSP). This protects the equipment against damage caused by static electricity.



#### DANGER

**Risk of injury from high energy levels, equipment damage** Take these precautions when removing or inserting a card:

- 1. Do not apply direct pressure to the components.
- 2. Do not force the cards into the slots.

Put on a wrist strap.

Turn off the circuit breaker at slot 15 (circuit breaker 12) if replacing the talk battery module in slots 1 and 2. Turn off the circuit breaker at slot 16 (circuit breaker 14) if replacing the talk battery module in slots 3 and 4. These circuit breaker locations correspond to the CRSC and CEXT modules.

*Note:* The circuit breaker designation may vary depending on the type of cabinet where you are replacing the talk battery module. Verify the circuit breaker designation at shelf position 61 before replacing the talk battery.

8 Pull out corresponding line shelf approximately 152 mm (6 in.). The line shelf is located below the MSP. This approach permits easier hand access to the

7

connectors on the rear of the MSP. This step does not apply to the CMIS, CPDC, and CRME.

#### At the rear panel of the cabinet

9




#### DANGER

**Risk of injury from high energy levels, voltage present** Do not insert metallic objects into the black connectors. Voltage is present and equipment damage can result.

Remove the NTRX44 circuit card as shown in the following figures.


- a Open the rear doors of the cabinet and locate the back of the circuit card to be replaced. The circuit card is located in slots 1 and 2 for talk battery "A" or in slots 3 and 4 for talk battery "B".
- **b** Note wire color and location to facilitate re-connection.



- **c** Using the connector removal tool, manually disconnect the power connectors to the circuit card. Working from the bottom of the MSP shelf to the top of the MSP shelf, manually disconnect the smaller black power connectors located below the larger blue power connector. Manually disconnect the large blue power connector. Disconnect the smaller black power connectors located above the large blue power connector. Ensure you disconnect the black connectors before removing the circuit card.
- **d** Although the connectors have voltage present on them, they are insulated. Secure the connectors to the power-connector bundle with a line-tie until it is time to reconnect them.

#### At the front panel of the cabinet


- **10** Remove the NTRX44 card.
  - **a** Disengage the knurled thumbscrew at the top of the card.
  - **b** Gently pull the card towards you until it clears the shelf.



- 11 Ensure the replacement circuit card has the same PEC, including suffix, as the circuit card just removed.
  - **a** Align the circuit card with the slots in the shelf and gently slide the circuit card into the shelf.
  - **b** Gently but firmly seat the circuit card.
  - **c** Tighten the knurled thumbscrew at the top of the circuit card.

#### At the rear panel of the cabinet

12 Locate the replaced circuit card and re-attach the power connectors.



**13** Install the jumper connectors and cables removed in step 9 9 onto the replacement circuit card.

#### At the front of the cabinet

14 If talk battery A, in slots 1 and 2, was replaced, turn on the circuit breaker at slot 15 (circuit breaker 12). If Talk Battery B, in slots 3 and 4, was replaced, turn on the circuit breaker at slot 16 (circuit breaker 14).

*Note:* The circuit breaker designation may vary depending on the type of cabinet where you are replacing the talk battery module. Verify the circuit breaker designation at shelf position 61 before replacing the talk battery.

**15** Push in corresponding line shelf. Note that this step does *not* apply to the CMIS, CPDC, and CRME.

#### At the MAP terminal

**16** Return the LCME to service by typing

>RTS UNIT lcme\_unit\_no

and pressing the Enter key.

where

#### Icme\_unit\_no is the number of the LCME unit.

If RTS	Do
passed	step 17
did not pass	step 19

- 17 Send any faulty cards for repair according to local procedure.
- **18** Record the date the card was replaced, the serial number of the card, and the symptoms that prompted replacement of the card. Go to step 20.
- **19** Obtain further assistance in replacing this card by contacting the personnel responsible for the next higher level of support.

20 You have successfully completed this procedure. Return to the maintenance procedure that directed you to this card replacement procedure and continue as directed.

# NTRX54 in an RSC-S (DS-1) Model B MSP

# Application

Use this procedure to replace an NTRX54 card in a modular supervisorb(MSP) located in a

- cabinetized extension module (CEXT)
- cabinetized line concentrating equipment (CLCE)
- cabinetized line module ISDN (CLMI)
- cabinetized power distribution center (CPDC)
- cabinetized remote switching center (CRSC)
- cabinetized miscellaneous equipment (CMIS)

PEC	Suffixes	Name
NTRX54	BA	Fan Power Control Module

# **Common procedures**

None

# Action

A connector removal tool is available to facilitate removal of the AMP Faston receptacles from the power input and output connectors of the MSP modules. This tool comes in two lengths: P0746192 152 mm (6 in.), and P0747552 254 mm (10 in.). The shorter tool is used when access to the rear of the MSP is very limited. An example of limited access is, MSP modules located directly behind the cabinet bulkhead.


This tool is approximately 2 mm (.090 in.) thick and 17 mm (.65 in.) wide, with a jaw-like cut-out at each end. The cut-out profile conforms to the shape of the Faston receptacle. The shorter tip of each profile is used to position the receptacle in the tool.

The first meeting point of the tool serves as the pivot point. By rotating the tool around this pivot point, the longer tip of the profile which has a hook on its end, is engaged with the action-arm of the power connector. As the action-arm of the connector is depressed, the receptacle is disengaged from the connector tab. The receptacle is removed by pulling the tool with the receptacle trapped in its jaw, away from the connector. The tool is disengaged


from the receptacle by rotating the tool's hook off the action-arm of the receptacle.


Although the shape of the cut-out is the same on each end of the tool, the orientation of the profile is off by 15 degrees. This difference allows for the use of the tool at different angles, which may be required due to limited access to the connectors.

#### **Connector removal tool**



The following flowchart is a summary of this procedure. Use the instructions in the step-action table that follows the flowchart to perform the procedure.





#### Replacing an NTRX54 card in RSC-S MSP


#### At your Current Location

- 1 Proceed only if you have been directed to this card replacement procedure from a step in a maintenance procedure, are using the procedure for verifying or accepting cards, or have been directed to this procedure by your maintenance support group.
- 2 Obtain a replacement card. Ensure that the replacement card has the same product equipment code (PEC), including suffix, as the card that is to be removed.

#### At the front panel of the cabinet

**3** Open the front cover of the MSP. Release the two cover latches and swing the cover down to the open position.

*Note:* The illustrations in this card replacement procedure are for the MSP shelf in an CRSC or CEXT module. The circuit breaker designation may vary depending on the type of cabinet you are working in.



4



#### DANGER

**Risk of injury from high energy levels, static electricity damage** Before removing any cards, put on a wrist strap and connect it to the wrist strap grounding point on the left side of the modular supervisory panel (MSP). This protects the equipment against damage caused by static electricity.



## DANGER

**Risk of injury from high energy levels, equipment damage** Take these precautions when removing or inserting a card:

- 1. Do not apply direct pressure to the components.
- 2. Do not force the cards into the slots.



#### DANGER Heat damage


Avoid leaving this card out of service for more than 30 minutes. Extensive damage to the entire cabinet may occur if cooling is lost for more than 30 minutes.

Put on a wrist strap.

5 Remove the two fuses in the fan power control module.

#### At the rear panel of the cabinet

- 6 Remove the NTRX54 circuit card as shown in the following figures.
  - **a** Open the rear doors of the cabinet and locate the circuit card, it will be in slots 19 and 20.
  - **b** Note the wire color and location to facilitate re-connection.




c Using the connector removal tool, manually disconnect the power connectors to the circuit card. Working from the bottom of the MSP shelf to the top of the MSP shelf, manually disconnect the smaller black power connectors located below the larger blue power connector. Manually disconnect the smaller black

power connectors located above the large blue power connector. Ensure you disconnect the black connectors *before* removing the circuit card.

**d** Although the connectors have voltage present on them, they are insulated. Secure the connectors to the power-connector bundle with a line-tie until it is time to reconnect them.

#### At the front panel of the cabinet


- 7 Remove the NTRX54 card.
  - a Disengage the knurled thumbscrew at the top of the card.
  - **b** Gently pull the card towards you until it clears the shelf.



- 8
- Ensure the replacement circuit card has the same PEC, including suffix, as the circuit card just removed.
  - **a** Align the circuit card with the slots in the shelf and gently slide the circuit card into the shelf.
  - **b** Gently but firmly seat the circuit card.
  - c Tighten the knurled thumbscrew at the top of the circuit card.

#### At the rear panel of the cabinet

**9** Locate the replaced circuit card and re-attach the power connectors, as noted in step 6.



#### 10

Replace the two fuses removed in step 5.

If fuses	Do
do not blow	step 11
blow (protrude)	step 13

- 11 Send any faulty cards for repair according to local procedure.
- 12 Record the date the card was replaced, the serial number of the card, and the symptoms that prompted replacement of the card. Go to step 14.
- **13** Obtain further assistance in replacing this card by contacting the personnel responsible for the next higher level of support.
- 14 You have successfully completed this procedure. Return to the maintenance procedure that directed you to this card replacement procedure and continue as directed.

# 7 Locating and clearing RSC problems

Maintenance engineering and field maintenance personnel use this section on how to locate and clear RSC problems. The personnel must have basic knowledge of the Digital Multiplex System-100 (DMS-100) Family of switches, and of the Remote Switching Center-SONET (RSC-S). Operating company personnel that need exact procedures to perform maintenance tasks do not use this section.

# 8 Trouble isolation and correction

The Remote Switching Center-SONET (RSC-S) consists of the remote cluster controller 2 (RCC2) or the RCC2 with:

- integrated services digital network (ISDN)
- line concentrating devices (LCD)
- trunks
- links that connect the components.

This section describes how to troubleshoot for these components.

## Description of troubleshooting

The RCC2 is the primary component of the RSC-S configuration. The state of the RCC2 can determine the state of the other RSC-S components.

## Locating and clearing faults

This section describes fault location and clearance in terms of trouble condition indicators and trouble conditions.

#### **Trouble condition indicators**

The following indicate the presence of trouble conditions:

- operational measurements (OMs)
- log reports
- alarms.

#### **Operational measurements**

The OMs monitor and count events in the system. The OMs detect both real and potential system troubles. The OM thresholding feature must be used to monitor and report key RSC-S with ISDN activity. These reports must be daily or weekly and must be the primary method of trouble detection.

## Log reports

Logs are an analysis tool, and provide detailed information on call errors, diagnostic results, and system status. Logs indicate trouble conditions when one of the following conditions are present:

- sudden increase in the volume of logs
- message not printed reports
- large number of logs that are the same.

#### Alarms

Audible and visual alarms indicate that corrective action is required. Proper performance of routine system maintenance and use of OMs and logs can minimize the occurrence of alarms.

The level of the alarm indicates alarm severity and corresponding urgency for corrective action. The alarm level can be minor, major, or critical. The following table describes these alarm conditions:

Alarms	MAP display	Description
Minor	(blank)	non-service affecting
Major	(M)	indicates a service-degrading, threatening condition
Critical	(*C*)	indicates a service outage or potential service outage

**Assessing alarms** A MAP display subsystem produces alarms for the RSC-S configuration. The following table lists the alarms and alarm meanings. The following table lists log reports that can accompany the alarm:

Table 8-2 Assessing PM alarms from the MAP display (Sheet 1 of 2)

MTC level	PM level	Possible scenarios	
PM RCC2	ISTb 1	One or both units have minor problems, that do not always involve the peripheral processor (PP).	
		A static data mismatch is present between an RCC2 unit and central control (CC).	
		A non-messaging central-side (C-side) link is out-of-service (OOS).	
		A peripheral-side (P-side) link is OOS.	
PM RCC2 M	ISTb 1	One unit is system busy (SysB), because of a PP card failure. If the unit is the active unit, peripheral module (PM) software executes Switch of Activity (SWACT) on the units. Check for PM128 logs.	
PM RCC2 *C*	SysB 1	Both units are SysB. If noncommunication with the host causes the SysB, the RCC2 enters emergency stand-alone (ESA). Refer to the following sequence of logs when ESA is entered:	
		PM109 The carrier is busy.	
		• PM128 The RCC2 is in-service trouble (ISTb).	
		PM107 The RCC2 is C-side busy (CBsy).	
		<ul> <li>PM107 The line controller modules (LCM) are CBsy.</li> </ul>	
		PM102 The RCC2 is SysB.	
		PM181 The RCC2 tries to restart the message links.	
		Another possible reason is that the two PPs have faults, so the two units are SysB.	
PM RCC2	ISTb 1	One or two units have minor problems, that do not always involve the PP. For RCC2 with ISDN, the following problems can occur:	
		The D-channel handler (DCH) card malfunctions. If a spare DCH is available, the DCH is put in-service (InSv). If a spare DCH is not available, D-channel capability is lost. In each event, the RCC2 is set ISTb.	
		The ISDN signaling preprocessor (ISP) card malfunctions. The RCC2 cannot process ISDN calls,but the system still processes plain old telephone service (POTS) calls.	

MTC level	PM level	Possible scenarios
PM RCC2 M	ISTb 1	One RCC2 unit is OOS. The RCC2 can still process voice and data calls.
PM RCC2 *C*	SysB 1	The two RCC2 units are OOS. Voice and data services are lost. If the RCC2 enters ESA, the ability to process data calls depends on the location of the packet handler (PH).

#### Table 8-2 Assessing PM alarms from the MAP display (Sheet 2 of 2)

**Clearing alarms** Use the following guidelines when you respond to alarms:

- When more than one alarm of the same severity appears on the MAP display, clear the alarms from the left of the screen to the right.
- If at the same time that you fix an alarm, an alarm of greater severity occurs, respond to the new alarm. Do not continue attempts to clear the less severe alarm.

For information on how to clear alarms, refer to Alarm Clearing Procedures.

## **Trouble conditions**

The following are possible RSC-S trouble conditions:

- data mismatch
- lines
- DS30A
- digital signal 1 (DS-1) links
- dual remote cluster controller 2 (DRCC2)
- forced ESA
- RCC2 with ISDN
- ISDN lines.

#### Lines

When a fault is isolated to an LCD, maintenance procedures are like the procedures at the host office. Make sure faults in an LCM are not the result of a fault from another location.

## DS30A

The DS30A links are on:

- the P-side of the RCC2
- the C-side of the enhanced line concentrating module (LCME)

- the LCM
- the remote maintenance module (RMM).

When these links are defective, the associated components are affected.

## **DS-1** links

The links are used on the C-side and P-side of the RCC2. Links on the C-side of the RCC2 are used to send voice and messages to the host. Some of the channels can be used as trunks. Two channels, links zero and two, are used for messaging.

Links on the P-side of the RCC2 connect remote line concentrating modules (RLCM) or other offices. The links function as trunks. These trunks can be static or dynamic.

## **Dual remote cluster controller 2**

Primary sources of trouble for the DRCC2 are:

- the condition of the interlinks
- the possibility that the condition of the messaging links to the host office can cause the RCC2 to enter dual ESA (DESA).

The following table summarizes trouble indicators for faults that can occur on the interlinks. The table summarizes indicators that appear when the problem is corrected:

Table 8-3	Indicators	for interlink ma	aintenance	(Sheet 1 of 3)
-----------	------------	------------------	------------	----------------

Trouble indicator	Meaning	Indicators when cleared	
PM110—MTCE LIMIT SET	Bipolar violation (BpV) at the maintenance limit (ML)	PM110— <i>Carrier BPV Limit</i> Cleared	
>QUERYIR displays ML under the BER heading.	BpV at the ML indicates a decrease of the DS-1 link. Set in table CARRMTC.	>QUERYIR indicates the ML alarm is gone.	
PM110—MTCE LIMIT SET	BpV at the OOS limit BpV problems at the OOS limit are set in table CARRMTC.	PM110—Carrier BPV Limit	
PM222—Interlink is system busied.		Cleared PM106—RCC2 returns to service from ISTb.	
PM128—RCC2 goes ISTb. The system drops calls on that link.		PM223—Interlink returns to service.	
>QUERYIR displays OS under the BER heading and the state as SysB.		>QUERYIR displays the ML alarm is gone, and the link is OK.	

Trouble indicator	Meaning	Indicators when cleared
PM109—Carrier Local Alarm Set	Local alarm is set	PM106—RCC2 returns to service from ISTb.
PM222—Interlink is system busied.		PM223—Interlink returns to service.
PM128—RCC2 goes ISTb. The system drops calls on that link.		>QUERYIR indicates the ML alarm is gone, and the link is OK.
>QUERYIR displays LCGA under the ALRM heading and the state as SysB.		
For the interconnected RCC2, >QUERYIR shows RCGA under ALRM.		
PM109—Carrier Card Removed	DS-1 card is not present	PM106—RCC2 returns to service from ISTb.
PM128—RCC2 goes ISTb.		PM223—Interlink returns to service.
PM222—Interlink is system busied. The system drops calls on that link.		>QUERYIR indicates the ML alarm is gone, and the link is OK.
>QUERYIR displays (-) under the C heading and the state as SysB.		
For the interconnected RCC2, >QUERYIR displays LCGA under ALRM.		
PM110—Carrier Slip Maintenance Limit Set	Slips at the ML	>QUERYIR indicates the ML alarm is gone.
>QUERYIR displays ML under the slip heading.		
For the interconnected RCC2, >QUERYIR displays RCGA under ALRM.		

## Table 8-3 Indicators for interlink maintenance (Sheet 2 of 3)

Trouble indicator	Meaning	Indicators when cleared
PM110—Carrier OSS Limit Set	Slips at the OOS limit	>QUERYIR indicates the OS alarm is gone.
>QUERYIR displays OS under the SLIP heading.		
For the interconnected RCC2, >QUERYIR shows RCGA under ALRM.		
PM110—Carrier LOF Maintenance Limit Set	Frame loss at the ML	>QUERYIR indicates the ML alarm is gone.
>QUERYIR displays ML under the FRME heading.		
For the interconnected RCC2, >QUERYIR displays RCGA under ALRM.		
PM110—Carrier LOF Maintenance Limit Set	Frame loss at the OOS limit	>QUERYIR indicates the OS alarm is gone.
>QUERYIR displays OS under the FRME heading.		
For the interconnected RCC2, >QUERYIR displays RCGA under ALRM.		

Table 8-3	Indicators for	interlink maintenance	e (Sheet 3 of 3)
	manualoro	mitor mit manitoriano,	

## Forced emergency stand-alone

When an RCC2 is forced in ESA, the system sends a PM189 log to the host with a FORCE DOWN message. The PM189 log simulates link faults on messaging links zero and two. If these links are posted at the CARRIER level of the MAP display for example, POST LTC 2, the alarm remote carrier group alarm (RCGA) appears.

To know if the RCGA is a real alarm, you must receive the PM189 log. The links zero and two can break while the RCC2 is in forced ESA. If the links break, the links at the CARRIER level have the local carrier group alarm (LCGA) alarm.

*Note:* Real faults at the RCC2 can be one-way. Because the alarm continues to be RCGA, operating company personnel have the PM189 log. The presence of this log can mislead operating company personnel. Real faults on the messaging links are normally two-way and produce LCGA alarms.

## Remote cluster controller 2 with ISDN

The following list contains procedures used to troubleshoot the RSC-S with ISDN:

- B-channel packet service, ISDN line to Data Packet Network (DPN)
- provisioned B-channel data service, ISDN line to ISDN line
- D-channel packet service
- B-channel voice service
- B-channel circuit-switched data service.

*Note:* The main difference between an RCC2 that does not have an ISDN and an RCC2 with ISDN is the enhanced ISDN signaling preprocessor (EISP). If the EISP is at fault, the RCC2 with ISDN does not work. Enter the QUERY PM FAULT command to check for defective cards before you take other maintenance action.

## Integrated services digital network lines

The following table lists possible states for the:

- ISDN line card
- equipment that is most likely OOS
- suggested maintenance action.

#### Table 8-4 Restoring service to the line (Sheet 1 of 2)

ISLC	Equipment OOS	Suggested maintenance action
CUT	Line	Post the ISDN line by line equipment number (LEN) and enter the DIAG command to determine if the relay is stuck. If the relay is stuck, replace the line card.
LMB	RCC2, LCME, or	Post the ISDN line by LEN. Enter the CKTLOC command to display the status of all PMs and links that associate with the line.
message link between RCC2 and LCME	Access the MAP level that associates with the item that does not have the correct status. Use MAP commands to test components.	
DMB		Use the CKTLOC command in the line test position (LTP) level to identify the location of the fault. Take one of the following actions:
	DCH OOS	Access DCH and ISDN service group (ISG) levels of the MAP display. Post the appropriate DCH. Use MAP commands to locate defective components.

ISLC	Equipment OOS	Suggested maintenance action
DMB (continued)	Speech link OOS	Access the PM level of the MAP display. Identify the defective speech link. Test the speech link and return the link-to-service to restore LENs that associate with that speech link.
	ISG channel	Busy and RTS the ISG channel at the ISG level of the MAP display.
	Path fault in RCC2	Perform a SWACT to check if the fault is still present.
	Path fault in LCME	Busy and return the LCME to service.
	I-flag is set	Use MAP commands to test for a defective connection or a babbling terminal.
LO	Line	Loss of sync between the ISDN line card and the network termination 1 (NT1). This loss is a system-detected fault. The change out of this state occurs when the system detects a sync condition. Use commands available at the LTP level of the MAP display to locate defective hardware.
INB	Line	Line that undergoes office data modifications. An entry is present in table LNINV. If the line cannot go out of the installation busy state, use the CKTLOC command to verify if:
		a DCH channel associates with the ISDN line
		• the path between the DCH and the LEN is complete.
МВ	Line	Indicates line is ready for routine maintenance by input of commands at the LTP level of the MAP display. Indicates the line is removed from service for maintenance as a result of a customer complaint.
MB	Line	Line undergoes that finds tests.
CPD	Line	Line currently processes a circuit-switched call. The line is removed from service for possible maintenance activity when the call terminates. Operating company personnel can access the line from the MAP display for maintenance when the state changes to manually busy.
		To cancel maintenance, post the deload queue at the LTP level of the MAP display.
NEQ	Line	Use the table editor (TE) to enter data in tables LNINV and DCHINV.

Table 8-4 Restoring service to the line (Sheet 2 of 2)

## Posting ISDN lines with the POST DK command

The following POST command parameters can be activated if the customer purchases the SOC NI000050 2B-FIT/NIT feature:

```
POST DK dn_number [<key#>| `all']
```

The POST DK command displays a DN appearance on the specified key on an ISDN terminal, as the following figure indicates:

If the DN appearance is active, the following information can appear:

- the key number of the DN appearance
- the bearer capability of the call
- the far-end information.

```
Figure 8-1 LTP MAP level display with a posted ISDN line with key number and bearer capability
```

	CM ·	MS ·	IOD	Net	PM 4 SysB M	CCS ·	Lns	Trks	Ext	Appl
L7 0	Quit		POST	95			BUSYQ		PRE	FIX
2 3 4	Post	-					DN 02 62159		-	E Result 3 6215982
5	Bsy RTS						33 S	P		
78	Diag	3						Bearer ca	pability	
9 10	Alms) CktI						Ke	y number		
12	l Hold 2 Next									
13 14	ł									
	5 Pref									
	7 LCO_ 3 Leve	el_								
(т)	usei IME ł	rid nh:mm;	>							

The line below the control position displays the key number and bearer capability. This information appears after the ISDN line is posted with the POST DK command. In the previous example, the customer premises

equipment (CPE) has DN 621-5986 assigned to key 33, and has a speech call active. The possible bearer capabilities appear in the following table:

Bearer capability	Display
Speech	SP
3.1 kHz audio	3AU
Circuit mode data, rate adapts to 56 kHz	56C
Circuit mode data 64 kHz	64C
Packet data	PMD

 Table 8-5
 Bearer capability display codes

The DN state is checked one time each second and the display updates.

## **Responses to LTP level commands**

The following table lists responses to commands from the LTP level:

Table 8-6	Responses to I	TP level command	(Sheet 1 of 2)
-----------	----------------	------------------	----------------

POST		
Response	What it means	What to do
Option NI000050 is not enabled	The user attempts to use the POST DK command but does not enable software selection control (SOC) option NI000050.	Use a different POST command to post the DN.
The DN is not an ISDN DN Posted circuits unchanged	The POST DK command issued on a non-ISDN line. This command is valid for ISDN lines.	Enter the command again on an ISDN line, or use a different POST command.
The system responds and displays NO EQUIPMENT in the LEN field and NEQ in the STATUS field.	The posted DN is assigned to an LTID that is not mapped to a LEN in table LTMAP.	Use the SLT ATT command to map the LTID to a LEN before you post the DN.

POST		
Incorrect DN Appearance.	The specified DN does not appear on the specified Key.	Enter the POST DK command again with the correct key, or use the ALL option to list all keys for the DN.
ACO/AFC DN:The key number shown may be different than the actual key in use	The DN Appearance is a member of a group of Appearances for the DN. This association occurs when you post a DN Appearance that has additional functional calls (AFC) or ACO provisioned. The key numbers for these DNs are not always the same as the keys on the ISDN set. This difference is caused by the Q.931 message protocol which first refers to the DN and does not reference the key number in use. The user or the ISDN set determine which key is used for a call. That information is never communicated to the CM or XPM.	Information only.

Table 8-6	Responses to	LTP level	command (	(Sheet 2 of 2)
	11000001000010		oominana j	

# Fault isolation tests

This section describes fault isolation tests for the following components:

- RCC2
- lines
- RCC2 with ISDN.

## Remote cluster controller 2

When you troubleshoot an RCC2, access the RCC2 MAP level and enter the QUERYPM FLT command. The following table lists possible reasons for a

SysB RCC2 alarm and the possible conditions. The log report can mirror the response to the QUERYPM FLT command.

Table 8-7 Assessing SysB alarms for the RCC2 (Sheet 1 of 2)

Message at RCC2 level	Possible scenarios
All C-side Links are Down	The C-side PM cannot talk with the RCC2.
Audit Detected Inconsistent PM Activity	For example, CC determines that unit zero is active, when unit one is active. This error indicates CC does not determine that a SWACT occurs. The CC busies and returns the two units to service. The units come back with the active and inactive unit configuration that CC had.
Audit Detected Inconsistent PM State	The internal state of the active unit is not ready. The state is busy, restart, or synchronizing. This error is normally a software error. The CC busies and returns both the RCC2 and the C-side links to service.
Autonomous Activity Drop	A system-generated SWACT occurs, normally because of a trap or facility audit.
Diagnostics Failed	Unit fails test or RTS.
Inact Unit Lost Data Synch	Unit-to-unit communication fails; the system cannot perform a SWACT.
PM Audit Detect Fault	One of the background hardware audits detects a fault.
PM SWACT	A SWACT occurs.
Require Data Load	An error occurs on a DS-1 link to the unit. The unit waits for a reset by the maintenance system.
Reset While InSv	An error occurs on a DS-1 link to the unit. The unit waits for a reset by the maintenance system.
REx Incomplete (Terminated)	The routine exercise (REX) test cannot complete the series of tests because of a not normal condition.
	A minimum of one unit is ISTb.
	Inactive unit is BSY.
REx Failed	A failure occurs while a test runs. The messages are the result of what the system does to compensate for the failure. Achieves superframe and data sync. Inactive OOS Tests. Inactive RTS. Inactive OOS Tests after SWACT.
Self Test Failed	One of the background hardware audits detects a fault.

Message at RCC2 level	Possible scenarios
Trap Message Received From PM	Unit sends a start complete message to CC after an auto-restart.
Unsolicited Message Limit Exceeded	Unit sends more than 100 unsolicited messages to the CC in 1 min.

#### Table 8-7 Assessing SysB alarms for the RCC2 (Sheet 2 of 2)

The following table lists possible reasons for an ISTb RCC2 alarm and possible conditions. The log report can mirror the QUERYPM FLT response.

Table 8-8 Assessing ISTb alarms for the RCC2 (Sheet 1 of 2	ble 8-8 Assessing ISTb alarms for th	e RCC2 (Sheet 1 of	2)
--	--------------------------------------	--------------------	----

Message at RCC2 level	Alarm	Possible scenarios
One/Both Unit(s) ISTb	minor	One or two units are ISTb.
PM Overloaded	minor	Traffic load exceeds the ability of the PM to process calls.
CSLinks Out of Service	minor	C-side message links fail the periodic InSv C-side links test, one for each minute.
PSLinks Out of Service	minor	A P-side link for example, to the LCME or RMM, goes SysB.
Node Redundancy Lost	major	A unit is OOS. The RCC2 cannot perform a SWACT.
Major CSLink Failure	major	A C-side link failure causes a major alarm.
Critical CSLink Failure	critical	A C-side link failure causes a critical alarm.
Interlinks out of service	minor	One of the interlinks of the DRCC2 configuration is SysB.
Bad MX77 IMC link	minor	An intermodule communication link is bad.
Bad 6X69 IMC link	minor	An intermodule communication link is bad.
PM node table mismatch	minor	The node table data in the RCC2 and CC do not match.
Dynamic data sync	minor	The RCC2 has to achieve dynamic data sync.
ESADATA	minor	The RCC2 does not have an ESA load, or the current load of the RCC2 is corrupted or does not match the CC.

•		<i>\</i> ,
Message at RCC2 level	Alarm	Possible scenarios
Static data mismatch with CC	minor	The RCC2 static data does not match CC static data.
Data mismatch with inventory table	minor	The load in table RCCINV does not match the load name by CC.

Table 8-8 Assessing ISTb alarms for the RCC2 (Sheet 2 of 2)

#### Lines

When the MAP screen displays an LCM alarm, enter the LCM MAP level and post the LCMs that match that state. Post the LCM by site to make sure the LCM with the alarm is part of the RSC-S configuration.

If the LCM is part of the RSC-S configuration, post the C-side RCC2 and enter the QUERYPM FLT command. If a problem is present, perform an InSv test. If the test fails, normal RCC2 maintenance is required. When normal RCC2 maintenance is complete, LCM maintenance is the same as for the host office.

## Remote cluster controller 2 with ISDN

When you troubleshoot an RCC2, access the RCC2 MAP level and enter the QUERYPM FLT command.

## **Diagnostic tests**

The following section describes RSC-S diagnostic tests.

## NTMX76 pack diagnostics

Feature AF4342, NTMX76 Pack Diagnostics, provides message and high-level data link control diagnostics on the Channel Supervisory Messaging NTMX76AA memory and hardware.

Tests are run from the CC or PMDEBUG level and are destructive or nondestructive. Destructive tests are performed on inactive and manually busied units. The test that the system performs, depends on the: message card data entered in the inventory table of the RCC2 shelf and the message card NT6X69AC or NTMX76AA located on the RCC2 shelf. The following tests are available:

- message tests—current tests for the NT6X69AC card used for the NTMX76AA card.
  - tone diagnostic
  - message
- high-level data link control tests—new hardware tests for NTMX76AA. These tests diagnose the Q.703 part of NTMX76AA.
  - NTMX76 card presence
  - memory
  - receive connection memory
  - data routing
  - high-level data link control messaging system
  - intermodule communication

#### Tone diagnostic test

Tone generation, interpretation test, tone checksum follow the current XMS-based peripheral module (XPM) message test design. This test is destructive.

#### Message tests

The same tests are used for the NT6X69AC circuit card and the NTMX76AA circuit card.

#### NTMX76AA card existence test

This test verifies that the NTMX76AA circuit card and not the NT6X69AC circuit card is used. This test is nondestructive.

#### Memory test

This test verifies the access and functionality of the receive and transmit data memory and the receive and transmit connection memory. This test is destructive.

#### **Receive connection memory test**

This test verifies the ability to route data from the receive data memory to the correct channel according to the receive connection memory. This test is destructive.

#### Data routing test

This test verifies the ability to route data from the transmit and receive data memories to the correct channels. The receive and transmit connection memories determine these abilities. This test verifies data is received by the

transmit and receive data memories from the associated channels. This test is destructive.

#### High-level data link control messaging system test

This test verifies the functionality of the high-level data link control messaging system. This test sends a high-level data link control message and loops the message back. This test is nondestructive.

#### Intermodule communication test

This test verifies the presence of bidirectional intermodule communication connection with the mate unit. This test uses two channels in each direction. These channels cannot be used for other purposes. This test is nondestructive.

#### Enhanced line testing 1

Feature AF4838, RSC-S Enhanced Line Testing 1, verifies the provisioning of functionality in phases 1 and 2 of the DMS-100 switch translation language 1 project. Functionality is provided for ISDN 2B1Q loops subtending LCMEs that attach to an ISDN RCC2.

An operating system is an operating company system that supports operations, administration, and maintenance (OAM) of:

- subscriber loops
- trunks
- POTS
- special services
- other services that the DMS-100 switch provides.

An operating system communicates with a DMS-100 switch through an X.25 data link. The interface between an operating system and DMS-100 switch is the translation language 1 command and response set.

The ISDN translation language 1 project provides the following capabilities:

- to support X.25 data links between operating systems and the DMS-100 switch
- to decode and encode translation language 1 commands and responses
- to execute maintenance that translation language 1 commands specify, and generation of responses that contain the results of maintenance
- to support test equipment required to execute maintenance
- to support commands at the LTPISDN and LTPLTA levels of the MAP display to allow support of ISDN 2B1Q loop and line activities.

The TEST command is a menu command available at the LTPISDN MAP level. The test command requires an ISDN 2B1Q loop to be posted in order to function. The TEST command consists of many options. These options are called as *unlisted menu* commands. Each option or *unlisted menu* of the TEST command is a test provided in support of a corresponding translation language 1 command. These tests implement ISDN loop and line maintenance activities.

All tests occur at the LTPISDN MAP level except for one. The *ac* resistance test that is run at the LTPLTA MAP display level, does not occur at the LTPISDN MAP level. Each test at the LTPISDN MAP display level is run with the TEST command with a specific option. The ac resistance test is run with the RES command with *ac* as an option. The RES command is a menu command that requires a line to be posted in order to function.

The following table provides a description of the correct commands and activities:

Command	Option and activity
CONN-DTAC-ISDN	Indicates the beginning of a test session. Tests and measurements that require digital test access can be performed. The system seizes the tested line. The system keeps the line OOS for the duration of the test session.
CONN-MTAC-ISDN	Indicates the beginning of a test session. Tests and measurements that require metallic test access (MTA) can be performed. The system seizes the tested line. The system keeps the line OOS for the duration of the test session.
DGN-DET-TOTS	Requests a complete set of tests on the ISDN 2B1Q line card, digital subscriber loop, and the 2B1Q NT1. This command determines if a fault is present in a 2B1Q loop component. The system terminates this test when the system encounters a fault.
DISC-TACC	Indicates the end of a test session. Connections set up through the connect commands are released and the line returns to previous state.
MEAS IMPNSE	Measures the impulse noise on the loop for a specified time.
MEAS-LOOP-LOSS	This command measures the 2B1Q signal level that the NT1 generates. This command measures the signal to identify the presence of load coils on the loop. This command measures the signal to verify if the amount of loss is acceptable.
MEAS-NSE	Measures wideband noise interference on the digital subscriber loop.

Table 8-9 MAP commands, options, and activities (Sheet 1 of 4)

Command	Option and activity
MEAS-SCUR-DSL	Measures the sealing current that the ISDN 2B1Q line card generates on the digital subscriber loop.
REPT-ALM	The DMS-100 switch generates this command when the system encounters a failure on one or more test sessions.
REPT-INITZN	An autonomous command that the operating system or the DMS-100 switch sends. The operating system uses this command to verify the DMS-100 switch is online and reinitialization is complete. The DMS-100 switch uses this command to report that the switch undergoes a reinitialization.
REPT-STAT	Checks the X.25 data link operation. The operating system sends this command to the DMS-100 switch if additional messages are not sent in the last 60 s.
RES AC	Implements the measurement of two-terminal <i>ac</i> resistance. Two-terminal <i>ac</i> resistance is used to calculate three-terminal resistance to identify terminations and high resistance open circuits.
RMV-TOTS	Removes services from an ISDN 2B1Q line and places the line in a <i>manual</i> OOS state.
RST-TOTS	Restores service to an ISDN 2B1Q line and places the line in an <i>idle</i> InSv state.
RTRV-COND-ISDNL2	Instructs the DMS-100 switch to retrieve the current line state and standing condition alarm or status for one or more lines.
RTRV-DNCT	Retrieves the equipment for the directory number (DN) and call type of the line.
RTVR-PM-TOTS	Retrieves the current set of performance monitoring data for an ISDN 2B1Q line. The data retrieved are block errors, errored seconds, and severely errored seconds in the two directions of the transmission path.
RTRV-TRNSL	Retrieves the translation information for an ISDN line. This information helps to determine if an ISDN 2B1Q line is not operational because of data entry problems.
TEST ALM	Verifies the ability of the DMS-100 switch to detect and report loss of signal and not use an NT1 <i>Dying Gasp</i> .

#### Table 8-9 MAP commands, options, and activities (Sheet 2 of 4)

#### 8-20 Trouble isolation and correction

Command	Option and activity	
TEST COLDST	Implements the cold start test. The cold start test checks the ability of the ISDN 2B1Q line card to train:	
	echo cancellors	
	equalizers	
TEST DCSIG	Implements the NT1 signature test. This command measures the direct current metal termination characteristic of the NT1.	
TEST DET	Implements the performance monitoring test. This command checks the ability of the ISDN 2B1Q line card to detect:	
	bit block errors	
	errored seconds	
	severely errored seconds.	
TEST ILOSS	Implements the measurement of insertion loss test. This command is used to implement the measurement of insertion loss on an ISDN 2B1Q digital subscriber loop.	
TEST IMP	Implements the impulse noise measurement test. This command is used to implement the measurement of impulse noise on an ISDN 2B1Q digital subscriber loop.	
TEST NSE	Implements the measurement of wideband noise interference test. This command is used to implement the measurement of wideband noise interference on an ISDN 2B1Q digital loop subscriber.	
TEST SCUR	Implements the sealing current measurement test on an ISDN 2B1Q line card. While this test runs, sealing current is applied continuously while the test equipment verifies the current is in the acceptable range.	
TEST THR	Implements the performance monitoring threshold test. This command checks the ability of the ISDN 2B1Q line card to report threshold crossings for:	
	bit block errors	
	• ES	
	severely ES	
TST-LPBK-ISDN	Performs bit error tests on an ISDN line card, and on the digital subscriber loop to the NT1.	

#### Table 8-9 MAP commands, options, and activities (Sheet 3 of 4)

Command	Option and activity
TST-PM	Checks the ability of the ISDN 2B1Q line card to detect:
	bit block error
	errored seconds
	severely errored seconds
TST-QISDN	Performs loop measurements on the ISDN 2B1Q digital subscriber loop.
TST-THRS	Checks the ability of the ISDN 2B1Q line card to report threshold crossings for:
	bit block errors
	errored seconds
	severely errored seconds

#### Table 8-9 MAP commands, options, and activities (Sheet 4 of 4)

# **Digital test access**

Feature AF4839, RSC-S Digital Test Access, is a digital monitoring method for ISDN basic rate interface (BRI) loops and Bd connections.

Feature AF4839 provides the following services for the RSC-S product:

- user-assigned terminal endpoint identifier (TEI)
- unsolicited message and link access procedure on the D-channel (LAPD) cleanup
- a digital monitoring method for ISDN BRI and Bd connections.

# **User-assigned TEI**

User-assigned TEI allows customers to specify an ISDN TEI. The range of TEIs is zero to 63.

# Link access procedure on the D-channel cleanup

The layer 2 state machine software in the DCH, and the EISP changes. These components change to comply with specifications in *Bellcore Technical Reference*, ISDN D-Channel Exchange Access Signaling and Switching Requirements (Layer 2).

The LAPD cleanup creates an audit of the resources that are important for correct messaging in the DCH and EISP.

# **Digital test access**

Digital test access provides the ability to monitor:

- circuit-switched B-channels
- packet-switched B-channels
- D-channels
- Bd-channel traffic from an ISDN BRI loop.

The MTA allows test equipment to connect to subscriber lines through the use of a test access bus in the LCM. Test equipment connects to line cards in the drawer. Digital test access (DTA) is established through the broadcast of the digital data streams to and from subscriber lines to a protocol analyzer. Normally, a metal path between the subscriber line and the test equipment establishes DTA. This test equipment is used in the MTA process. The DTA monitors in the LCME for loop monitors, and in the XPM that hosts the LCME for Bd connections. Digital test access does not affect service on the loop to which DTA is applied.

When the DTA monitors loop channels or Bd connections, the DTA obtains two streams of digital data. The first type is upstream data, the data that flows *toward* the DMS switch and *away* from the subscriber. The second type is downstream data, the data that flows *toward* the subscriber and *away* from the DMS switch.

The upstream and downstream data of the loop or channel that the DTA monitors are 64-kb/s serial digital data streams to:

- two DS-0 channels of a DS-1 interface, entered for 64-kb/s transmission
- the B1 and B2 channels of an ISDN line card.

The monitoring point for the upstream and downstream data of the loop channels B or D is the LCME time switch. The monitoring point is the LCME time switch at the point the LCME connects to the line card. The monitoring point for the upstream data of Bd channels is the RCC2 time switch. The monitoring point is at the point the time switch connects to the DCH. The monitoring point of the downstream data of Bd channels is the time switch at the digital trunk that interfaces to the DPN PH.

# Channels available for the DTA to monitor

Digital test access monitors the following:

- provisioned B-channels
- TDM D-channels

- circuit switched B-channels
- Bd channels that the system routes to a DS-1 interface that connects to a DPN switch.

Each loop can have one digital test access Bd connection at a time. Multiple taps can be present on one Bd connection. Multiple taps allow different loops that use the same Bd connection to have concurrent digital test access connections.

When DTA monitors a D-channel, all four TDM channels go to the protocol analyzer. The TDM group member number for a particular line is available from the LTP level of the MAP display with the CKTLOC command. The TDM number is available at the LTPDATA level of the MAP display with the EQUIP DTA QUERY command.

Equipment that the DTA monitors is reserved for digital test access use. Two commands at the MAP display are used to connect this equipment to the monitored BRI channel or Bd connection. The connection between the monitoring equipment and the monitored channel is established through a nailed-up connection. This connection remains in place until operating company personnel use a MAP command to remove the connection.

Digital test access connections remain in place over CC restarts and XPM SWACTs. A user or a REX test can initiate the connections. Digital test access connections remain in place when DCH takeovers occur and when LCME takeovers and takebacks occur.

# Protocol analyzer requirements

The protocol analyzer must be able to interconnect with a DS-1 digital interface or an ISDN S/T loop interface. The protocol analyzer must be able to resolve separate D-channel members from the TDM group.

#### Preparation for digital test access monitoring

Several steps must be taken before digital test access monitoring can start. The DMS switch network must be provisioned for data transmission to preserve the data streams. Failure to provision the DMS switch network can result in damage of digital data streams to the protocol analyzer.

The following list contains the requirements to prepare for digital test access monitoring:

- provision DS-1 monitoring equipment or provision ISDN line card monitoring equipment
- reserve equipment for use in digital test access monitoring

- establish digital test access connection
- monitor with digital trunk facilities or an ISDN line card.

**Provision DS-1 monitoring equipment** If a DS-1 facility is used for digital test access monitoring, the facility must be provisioned to support 64 kbps clear data transmission.

This requirement has implications in the following areas of the DMS switch:

- hardware that supports the DS-1 interface
- carrier data entries.

The RCC2 DS-1 circuit card must be NTMX81AA or NTMX81BA.

**Provision ISDN line card monitoring equipment** An ISDN line card can be used to monitor the digital data from the digital test access on an ISDN line. Enter the line card in table LNINV as *hardware assigned software unassigned (HASU)*. Entry of the line card as HASU prevents assignment of DCH resources when assignment is not necessary. The B-channels of an ISDN line card cannot be nailed-up for provisioned B-channel service. The loop state must be installation busy.

**Reserve equipment for digital test access monitoring** The equipment used to monitor the upstream and downstream data are two channels of a DS-1 digital trunk, or an ISDN line card. The data are from the monitoring points that result from each digital test access application.

The operating company personnel can monitor the upstream and downstream data from a distance. The digital trunk must be entered in an appropriate way for RCC2 DS-1 digital test access. The operating company personnel use two channels of a digital trunk to monitor the data.

When digital test access uses a digital trunk for monitoring, the channels must be unequipped from digital test access use. These connections cannot be nailed-up to the two DS-0 channels. The channels cannot be entered in table TRKMEM until the channels are unequipped. The EQUIP DTA RESET command at the LTPDATA level of the MAP display makes the channels unequipped.

A line card is equipped for digital test access use with the EQUIP command at the LTPDATA level of the MAP display. An LEN specifies the ISDN line card. The B1 channel receives the upstream data from the monitored line, and the B2 channel receives the downstream data.

Establish digital test access connection

With the monitoring equipment provisioned, operating company personnel can establish and verify the digital test access connections from the LTPDATA MAP level. The CONNECT command makes the connection between the monitoring equipment and the BRI loop or Bd connection that the DTA must monitor.

If the monitoring equipment and monitored loop or Bd connection are supported on different peripherals, a network connection occurs between the two end-points. A network connection is required if the Bd-channel that the DTA monitors is nailed-up to a digital trunk. The digital trunk is supported from a different peripheral. Connections in the network are nailed-up connections and are retained over CC restarts.

# Details of monitoring in the enhanced line concentrating module

The LCME time switch where the line card resides provides upstream and downstream data for loop channels B or D. A broadcast connection is used at the time switch to monitor the digital data for the upstream and downstream directions. A broadcast connection allows present connections to remain in the present state. For each data stream, connections are made to the RCC2 that hosts the LCME, and to the monitoring equipment. If the monitoring equipment resides in an XPM other than the RCC2, the system allocates bidirectional network connections. The following table contains a summary of this information:

Monitored channel	Channel connects to	Upstream monitor point	Downstream monitor point
Circuit switched (B1 or B2)	End-point supporting circuit switching	LCME hosting line card	LCME hosting line card
Provisioned B-channel, B1, and B2	Digital trunk or ISDN line card	LCME hosting line card	LCME hosting line card
D-channel	ISG or DCH	LCME hosting line card	LCME hosting line card

#### Table 8-10 Time switch end-points (B or D channels)

# Details of monitoring in XPMs (Bd-channel)

Upstream and downstream data for the Bd-channel that the DTA monitors come from different points in the DMS switch. The upstream monitor point resides at the XPM that supports the LCME that serves the ISDN loop. The downstream monitor points for a Bd-channel are in the XPM that hosts the digital trunk to the PH. A broadcast connection is used at the time switch to monitor the digital data for the upstream and downstream directions. If the monitoring equipment resides on another XPM, bidirectional network connections are established. If monitoring equipment resides on the same XPM, connections remain in the XPM. The following table summarizes end-points for Bd-channels:

Monitored channel	Channel connects to	Upstream time switch end-point	Downstream time switch end-point
Bd-channel	Digital trunk	XPM hosting loop	XPM hosting digital trunk

Table 8-11 Timeswitch end-points for Bd-channels

# Verification of digital trunk access connections

When a digital test access connection is established, use the CONNECT command at the LTPDATA MAP level to verify connection integrity. This command makes sure connection information is delivered to XPMs that support the monitoring connection. This verification replaces the channel supervision message (CSM) for circuit-switched connections. If the system encounters a bad connection segment, the system updates the status information that appears at the MAP display.

Use the following procedure to use the digital test access feature in the correct way:

# Procedure 8-1 Steps for digital test access use

1 Identify a loop to monitor.

*Note:* Only ISDN BRI loops are valid.

2 Identify the monitor equipment.

*Note:* The monitor equipment can be a digital trunk or an ISDN line card.

- 3 Make sure the monitor equipment is provisioned in the correct way.
  - Note: Check carrier or line entries.
- 4 Connect protocol analyzer to the selected access point.
- 5 Enter the LTPDATA level of the MAP display.

Note: The digital test access commands are at this level.

- 6 Post the loop that the DTA must monitor.
- 7 Reserve the monitoring equipment.

*Note:* Use the EQUIP command, note the equipment number that returns.

8 Connect the monitoring equipment.

*Note:* Use the following command syntax of the CONNECT command:

>CONNECT equip# chnl

- **9** Query all digital test access connections. This step is optional.
  - Note: Command syntax:
  - >EQUIP DTA QUERY ALL
- **10** Verify connection integrity. This step is optional.

Note: Command syntax:

>CONNECT equip# VERIFY

11 Release the digital test access connection.

Note: Command syntax:

>CONNECT equip# RLS

**12** Release monitoring equipment.

*Note:* Command syntax:

>EQUIP DTA RESET equip#

# Limits and feature interactions

The following is a list of digital test access limits and feature interactions:

- The DTA does not monitor Bd connections that terminate to the DMS PH.
- The number of digital test access connections active in the office that office parameter MAX\_DTA\_ON\_SWITCH in table OFCENG limits.
- A maximum of six digital test access connections are allowed in an XPM at the same time.
- Channels are allocated on links between the loop monitoring point and the monitoring equipment. Connections are made across peripheral and network modules between these channels. These channels are not available for call processing while the digital test access connection is active.
- Be careful when you add or remove digital test access connections if a unit of the RCC2 is OOS. Digital test access connections are downloaded as part of the XPM static data. Changes to static data impact the RCC2 as follows:
  - If the RCC2 is OOS, static data for the RCC2 is downloaded as part of the RTS sequence. This process can increase recovery time.
  - If the RCC2 is RTS and static data is downloaded, the change results in a static data mismatch between CC and the RCC2. This static data mismatch does not allow ESA static data to download to the RCC2.
- Link rearrangement of an LCME off an RCC2 is not allowed when DTA connections are active on lines on that LCME.
- Removal a digital test access connection while an XPM is OOS can increase the time required to return that XPM to service. Digital test access connection information is downloaded as static data. Removal of a digital test access connection while the XPM is OOS requires static data to

download to the XPM. The static data must download to the XPM when the XPM RTS.

*Note:* The impact of the addition and removal of digital test access connections of host XPMs is identical to the RCC2. The addition and removal of these connections does not affect ESA-related items in the same way.

# Layer 1 performance monitoring

Feature AF4842, RSC-S Layer 1 Performance Monitoring, provides the following layer 1 performance monitoring capabilities to the RCC2:

- Bd-channel logical loopback
- DCH performance OM (Refer to *Operational Measurements Reference Manual*)
- layer 1 performance monitoring
- multi-point embedded operations channel (EOC).

# **Bd-channel logical loopback**

The Bd-channel logical loopback provides logical loopback between a DCH and the PH in the DPN. This loopback allows operating company personnel to place a P-side link of a logical terminal in loopback mode. This loopback helps to determine if a fault is present:

- outside the DCH
- inside the DCH.

This loopback is asserted at the DCH end of the connection, and not at the PH end. When the logical loopback is implemented for a logical terminal, the DCH loops back the test frame or test packet. The DCH receives the test frame or test packet from the PH. This loop back occurs through the use of the logical terminal identifier (LTID) for that logical terminal.

A command at the LTPISDN level of the MAP display places a logical terminal P-side link in logical loopback mode. The DCH makes sure the logical terminal cannot use that P-side link to establish new packet-switched virtual circuits (SVC). The DPN PH drops active SVCs on the P-side link before the P-side link goes to loopback mode. The DPN PH drops current permanent virtual circuits (PVC) on the P-side link while the P-side link is in loopback mode.

The logical terminal can send LAPD frames when a corresponding P-side link is not in logical loopback mode. The logical terminal can send frames when the DPN PH logically enables the P-side link. Operating company personnel bring the P-side link out of loopback mode when the loopback timer that associates with the logical timer expires. Operating company personnel can bring the P-side link out of loopback mode when the LTLOOPBK command is in use. The LTLOOPBK is at the LTPISDN level of the MAP display. If the PH sends LAPD frames on this LTID, the DCH loops the frames back to the PH.

*Note 1:* The loopback timer is one of the parameters entered when the logical terminal P-side link is in the logical loopback mode.

*Note 2:* This feature does not support attempts to logically loop back a logical terminal P-side link that terminates on a DMS PH.

# **Emergency stand-alone effects**

In ESA, SWACT, and restart conditions, the result of loopback maintenance is not known. Remove Bd-channel loopbacks before or after these maintenance activities.

#### Layer 1 performance monitoring

Layer 1 performance monitoring provides layer 1 monitoring capabilities for a 2B1Q loop. Layer 1 monitoring comprises performance monitoring of cyclic redundancy checks (CRC), block error events and the monitoring of loop conditions like:

- synchronization
- signal presence
- NT1 power status.

#### Monitoring capabilities

These capabilities include the ability to enable or disable loop reports of performance monitoring alerts and status alarms. Logs for each loop and each office are used to enable or disable the reports.

Loop status monitoring permits loops to report the following layer 1 conditions that are not normal:

- loss of synchronization word (LOSW)
- loss of signal with *no dying gasp* (LOS)
- loss of signal with *dying gasp* (LOSDG)
- change of NT1 test mode (NTM)
- S/T interface synchronization lost (TSYNC)
- performance monitor reporting (PERF).

The following capabilities handle line performance monitoring data:

- Define a maximum of 16 performance monitoring threshold sets for the generation of alerts by subscriber loops. Each set contains a maximum of four thresholds:
  - errored seconds (ES)-each hour one to 4095
  - ES—each day one to 16383
  - severely ES—each hour one to 4095
  - severely ES—each day one to 16383.

*Note:* An ES is one or more CRC problems in a single direction of transmission in a 1 s interval. A severely ES is three or more CRC problems in a single direction of transmission in a 1 s interval.

• Set one of 16 predefines threshold sets to a 2B1Q loop. Presthreshold set values provide the performance monitoring threshold process for each loop. The performance monitoring threshold process is not limited to prethreshold set values. The system delivers threshold data to line card hardware. The system preserves threshold information of each loop over a batch change supplement (BCS) application.

*Note:* A threshold parameter for far-end block error and near-end block error can meet or exceed the threshold level on an ISDN line card. If a parameter meets or exceeds the threshold level, the system generates a log. *Near end* refers to the parameters collected for NT1 to ISDN line card of data transmission on a U-loop. *Far end* refers to the parameters collected from the opposite direction of transmission.

- The time-of-day (TOD) reference clock of each 2B1Q loop synchronizes with the master clock of the DMS-100 switch.
- Detect and correct threshold and TOD values on line cards through periodic audits of each line.
- The 2B1Q diagnostic functionality, from the MAP display, which verifies threshold levels in the ISDN line card.

# Tables added or modified for layer 1 performance monitoring

Tables BLMTHRSH and LNTHRSH are added to support 2B1Q lines off an RCC2.

Table BLMTHRSH helps to define threshold groups for 2B1Q loops. Table LNTHRSH supports the preservation of threshold and alarm reporting data over a BCS application for 2B1Q and S/T loops. An entry is present for each 2B1Q loop with a nondefault threshold group or nondefault alarm reporting capability.

Table Office Variable (OFCVAR) controls the default alarm reporting status of loops entered in a table. The following table OFCVAR parameters support 2B1Q lines off an RCC2:

- ISDN\_PERFORMANCE\_MON\_ALARM
  - controls reports of performance monitoring log LINE131 for each office
- ISDN\_LOSS\_OF\_SYNC\_WORD\_ALARM
  - controls reports of layer 1 loss of sync
- ISDN\_LOSS\_OF\_SIG\_NO\_DGASP\_ALARM
  - controls reports of layer 1 loss of signal that does not have *dying gasp* by 2B1Q loops for each office
- ISDN\_LOSS\_OF\_SIG\_DGASP\_ALARM
  - controls reports of layer 1 loss of signal with *dying gasp* by 2B1Q loops for each office
- ISDN\_NT1\_TEST\_MODE\_ALARM
  - controls reports of NT1 test mode by 2B1Q loops for each office
- ISDN\_T\_SYNC\_LOST\_ALARM
  - controls reports of T-SYNC by 2B1Q and S/T loops for each office

#### **Emergency stand-alone effects**

Data changes can occur while the RSC-S is in ESA. These changes are not guaranteed in the subtending nodes of the remote after a warm ESA exit. When communication with the host office is restored, the following condition occurs: the state of the RSC-S is guaranteed to be equal to the state before entry to the ESA.

Table BLMTHRSH contains 16 PM threshold sets. There is a high possibility that these values do not change often. There is a higher possibility that these values do not change while the RSC-S is in ESA. If the system does not update the LCME data with changed data, the lines on the LCME use old threshold values.

Table LNTHRSH contains lines that do not use default values. Changes can occur on a line while the RSC-S is in ESA. If changes do occur the line continues to use the old value or default value. An audit corrects mismatches between ISDN line cards and CC. Office parameters LCDI\_SYNC\_BURST and LCDI\_SYNC\_DELAY in table OFCENG determine the frequency of this audit. To disable this audit, set office parameter LCDI\_SYNC\_BURST to zero. Do not disable this audit under normal conditions. The system generates log LINE148 if the audit detects and corrects mismatches.

The following steps describe the procedure to restore the data in the RSC-S and RSC-S subtending nodes. The data that changes during ESA determine if the data requires an update in the LCME after warm exit ESA. Use this procedure to update the data. Operating company personnel can determine if the data requires an update in the LCME.

#### Procedure 8-2 Updating LCME data after ESA warm exit

- 1 Wait for the inactive unit of the RSC-S to RTS. The active RSC-S unit does not receive a duplicate of the current static data of the CC. The inactive RSC-S unit undergoes a full RTS, which updates static data.
- 2 Perform a SWACT on the RSC-S. This SWACT occurs between the active and inactive units. The previously active unit becomes inactive and undergoes a complete initialization. Static data is downloaded.
- 3 For each LCME that attaches to the RSC-S, busy and RTS each unit in in sequence. This process allows the other unit to takeover call processing during the busy and RTS procedure. This process makes sure that new data downloads to the two units of the PM.
- 4 The procedure is complete.

# Multi-point embedded operations channel

Multi-point EOC permits operating company personnel to determine the multi-point EOC configuration of a 2B1Q loop. Multi-point EOC allows operating company personnel to perform diagnostics on 2B1Q lines that have multi-point EOC. Multi-point EOC permits operating company personnel to set and release a B1, B2, or 2B+D loopback at the multi-point EOC nodes.

The original EOC plan was for the digital subscriber line, to give access to necessary operations functionality in the NT1. Two EOC configurations are possible:

- standard EOC
- multi-point EOC.

The standard EOC defines the operations interface that sends operation messages across the customer to network interface. Standard EOC is another name for point-to-point EOC. Point-to-point EOC occurs when two end nodes access the EOC. When the NT1 uses point-to-point capability, the NT1 connects to the ISDN line card. The channel between the ISDN line card and the NT1 used for OAM purposes is the point-to-point EOC channel. The EOC channel is used to conduct exercises like the logical loopback on separate B-channels or the whole 2B+D loop.

Multi-point EOC occurs when additional nodes are placed on the 2B1Q loop between the ISDN line card and NT1. These additional nodes access the same EOC and allow the transport of basic rate 2B+D information over a T1 span line. Additional nodes pass the EOC signals from a digital subscriber line to a digital carrier facility. Signals are passed from a digital carrier facility to a digital subscriber line.

The additional nodes can monitor information on an ISDN line card, and store errors of different types. Through the use of enhanced EOC messaging, data transfer takes place between these nodes and the ISDN line card. This messaging allows the DMS-100 switch to monitor the performance of an ISDN loop at an exact node. This messaging allows the switch instruct a node to set a loopback on a specified channel. The EOC specification for multi-point EOC builds on the point-to-point EOC specification. Between one and six multi-point EOCs can be present on a 2B1Q line.

*Note:* The point-to-point EOC differs from the multi-point EOC in that multipoint EOC loopback can occur at different points in the loop.

Multi-point EOC provides the following capabilities:

- a table that provides operating company personnel with the ability to list all 2B1Q loops with multi-point EOC nodes. The term node refers to line unit.
- the ability to determine the multi-point EOC configuration of the loop
- enhanced SUSTATE and QLEN commands to display multi-point EOC configurations and status information
- the ability to perform diagnostics on 2B1Q lines equipped with multi-point EOC line units
- the ability to set and release a B1, B2, or 2B+D loopback at multi-point EOC node.

A 2B1Q loop has multipoint capability when the associated LEN and the number of nodes in the loop are in table LNMPEOC. Table LNMPEOC supports 2B1Q lines off an RCC2. Multipoint EOC messages from the LCME enter data in table LNMPEOC. The user can read Table LNMPEOC. The LENs that support multi-point EOC are in sequential order. All 480 lines on an LCME can support multi-point EOC capability. The system maintains multi-point EOC data in table LNMPEOC over restarts and BCS applications.

When multi-point hardware is placed on a loop, the LCME detects this change and reports the change to the computing module (CM). An audit in the LCME reports this detection of hardware. The audit cycles through the 2B1Q loops on an LCME and checks for the presence of multi-point EOC nodes. When the CM receives this message, the system validates the data and adds a tuple to table LNMPEOC. The system generates log LINE148. This log states that the loop contains multi-point EOC nodes. When a change to the multi-point EOC configuration of a loop occurs, the LCME informs the CM. The change occurs in table LNMPEOC. The system generates a LINE149 log. The LCME performs a second audit to make sure that multi-point EOC accuracy is present between the LCME and the CM.

The time required to poll a multipoint EOC loop depends on the location of the loop in the LCME. With a logical drawer complete with 2B1Q loops, the audit can detect changes in the multi-point EOC configuration. The audit can take a maximum of 8 min to detect a change. Spread the 2B1Q loops across the logical drawers so that an audit can report the 2B1Q loops in the same time period.

*Note:* The system releases multi-point EOC loopbacks. The system returns the loop to the idle state with restarts.

# **Emergency stand-alone effects**

A loopback set before the ESA entry, is maintained on ESA exit. The loopback remains manually busy (ManB). The following are affected when multipoint EOC line units, are added to or deleted from an LEN while RSC-S is in ESA. The CC provides the QLEN command with information and is not affected:

- line diagnostics
- output that appears from the SUSTATE command

The following four figures contain examples of what appears at the MAP display when the system sets and releases loopbacks. The system sets and releases these loopbacks at a multipoint EOC line unit.

The following figure is an example of the LTPdata MAP display of an ISDN loop. For this loop, a B1 loopback is set at multipoint EOC line unit 3. The following command sets the loopback:

>LOOPBK mplu 3 b1

LNS Trks Ext APPL IOD NET PM СМ MS CCS . . . . . . 10 GC . . . \*C\* LTPDATA 1 Quit\_ POST DELQ BSYQ PREFIX 2 Post\_ LCC PTY RNG .....LEN..... DN STA F S LTA TE RESULT ISDN LOOP HOST 67 0 08 15 7226345 MB . 3 4 Equip\_ 5 Connect\_ 6 Sustate 7 LoopBk\_ 8 BERT 9 10 BPVO\_ 11 Hold Bl Loopback activated at MPLU 3 12 Next\_ 13 14 15 16 17 18 MYMAP Time 10:25>

Figure 8-2 Example of LOOPBK mplu 3 b1 MAP display

The following figure is an example LTPdata MAP display of an ISDN loop. For this loop, a B1 loopback is set at multipoint EOC line unit 3 and a loopback query is issued. The following command queried this loopback:

>LOOPBK query

CM	MS	IOD	NET	PM	CCS	LNS		Ext	APPL
•		•	•		·	•	10 GC *C*		•
LTPDA	TA								
1 Qu	it_	POST	ſ	DELQ	BSYÇ	2	PREFIX		
2 Po	st_								
3							STA F S		E RESULT
4 Eg	uip_	ISDN	1 LOOF	HOST	67 0 08	3 15 7	226345 MB	•	
5 Co	nnect_								
6 Su	istate								
7 Lo	opBk_								
8 BE	RT								
9									
10 BP	_								
11 Ho	ld	Bl	Loc	pback	on HOST	67 0	08 15 722	2 6345	at MPLU
12 Ne	xt_								
13									
14									
15									
16									
17									
18									
MYM	IAP								
Time	10:25>								

Figure 8-3 Example of LOOPBK query MAP display

The following figure is an example LTPdata MAP display of an ISDN loop. For this loop, a B1 loopback is released from multipoint EOC line unit 3. The following command released this loopback:

>LOOPBK rls

Figure 8-4 Example of LOOPBK rls MAP display

CM ·	MS ·	IOD	NET	PM ·	CCS ·	LNS ·	Trks 10 GC *C*		APPL
LTPDA'	TA								
1 Qu	it_	POS	Т	DELQ	BSY	2	PREFIX		
2 Po	st_								
3		LCC	PTY RN	IG	.LEN	DN	STA F S	LTA TE	RESULT
4 Eq	uip_	ISD	N LOOF	HOST	67 0 0	3 15 72	26345 ID	<u>.</u>	
5 Co	nnect_								
6 Su	state								
7 Lo	opBk_								
8 BEI	RT								
9									
10 BP	vo_								
11 Ho	ld	Bl	Loc	pback	at MPLU	3 rele	eased		
12 Ne:	xt_								
13									
14									
15									
16									
17									
18									
MYM	AP								
Time	10:25>								

The following figure is an example LTPdata MAP display of an ISDN loop. For this loop, a 2B+D loopback is set at multipoint EOC line unit 6. The following command set this loopback:

>LOOPBK mplu 6 bbd

CM	MS	IOD	NET	PM	CCS	LNS		Ext	APPL
•	•		•		·		10 GC *C*	•	
LTPDATA	A								
1 Quit		POS	Т	DELQ	BSY	2	PREFIX		
2 Post	-								
3							STA F S		E RESULT
_	-		N LOOF	HOST	67 0 08	3 15 72	226345 MB	•	
5 Conr	_								
6 Sust	tate								
7 Loop	. –								
8 BERT	Г								
9									
10 BPVC	_								
11 Hold		2B+	D L	oopbac	k activa	ated at	: MPLU 6		
12 Next	-								
13									
14									
15									
16									
17									
18									
MYMAI	2								
Time 10	):25>								

Figure 8-5 Example of LOOPBK mplu 6 bbd MAP display

# Extended peripheral modules diagnostics history

Feature AF5006, Extended Peripheral Modules Diagnostics History, provides a resident database to record selected diagnostic results of XPMs. This feature captures diagnostic results that indicate the sanity of the XPM. The data in this database can affect DMS switch maintenance. This database provides operating company personnel with MAP command access to data on the accumulated results of diagnostics. The system retains data in the history database over warm, cold, and reload restarts. This feature is not optional and is part of software package New Peripheral Maintenance NTX270AA.

An XPM can execute diagnostics to test hardware functionality. Diagnostics can run as a result of CC or XPM requests. Diagnostics that the XPM performs are normally part of XPM audits. Feature AF5006 provides diagnostic results that operating company personnel use for system analysis.

# **Operating company personnel analysis**

Feature AF5006 provides data on the failure history of diagnostics. This data is in the form of the number of failures that occur and cards that are at fault. The MAP commands display data for a given XPM or the XPMs that this feature supports. Two sets of data are available through MAP commands: short-term failure counts and long-term failure counts.

Short-term failure counts

Short-term failure counts accumulate from the last time a unit gains activity. This data can help operating company personnel to guide maintenance activities and support organizations for outage analysis. If an outage occurs, the XPM diagnostic history data for that peripheral must accompany other important data.

# Long-term failure counts

Long-term failure counts accumulate from the last time long-term failure counts are reset. The user or a BCS application can reset the counts. Long-term failure counts must last for the life of the BCS. The system channels this data back to the design groups to provide data for additional diagnostic system improvements.

Functionality that this feature describes is implemented on SuperNode and Bell-Northern Research (BNR) Reduced Instruction Set Computing platforms. For the NT-40 platform, the diagnostic results and suspect cards captured are smaller than the SuperNode or BNR Reduced Instruction Set Computing platforms. This NT-40 data store requirements cause this restriction.

#### **Description of diagnostics**

Because different PMs contain different hardware, different diagnostics run on each type of PM. There are approximately 75 diagnostics for XPMs. A part of the 75 diagnostics is run on a PM. This feature captures failures for the following diagnostics:

- InSv
- 00S
- single diagnostic
- facility audit
- other audits.

Each diagnostic implicates zero or more cards. The XPM determines the number of cards to implicate. The CC can generate card lists for display at the MAP terminal or in logs. A list of card failures contains cards that an XPM implicates for diagnostic or audit, and reports to the CC.

*Note:* Feature AF5006 records cards that an XPM implicates. The feature does not record cards that the CC generates.

The system can group diagnostics and run the diagnostics as a set of tests or a single test. Sets that are often defined are:

- InSv tests
- OOS tests
- facility audit tests
- mate diagnostics
- read-only memory (ROM) diagnostics.

# In-service and out-of-service tests

The InSv and OOS tests are solicited tests. These tests run as a result of CC requests. When the CC requests to test an XPM unit, the XPM runs a set of diagnostics. The CC uses the manual TST command, manual or system RTS, SWACT, BSY, or REX commands to request a test. Diagnostics in the set differ according to the:

- PM type of the XPM
- state of the XPM unit
- activity of the XPM unit.

The system returns the results of each diagnostic test to the CC with a final result for the whole set. If a card is defective, the system generates a card list. The system transfers the list to the CC at the termination of the set of tests.

#### **Facility audit**

The facility audit is a set of diagnostics the XPM runs to self test. If the system encounters problems, the system sends a message to the CC. The message indicates the problem and provides a list of defective cards.

#### Mate diagnostics

If one unit loses communications, the mate unit can diagnose that unit. The mate unit sends the results to the CC.

#### **Read-only memory diagnostics**

If the XPM is at ROM level, a set of read-only memory (ROM) diagnostics can be implemented.

This feature does not capture failures. This feature does not capture cards that mate and ROM diagnostics implicate. For each diagnostic, the system generates a card list or log at the MAP terminal. The system does not record a card list or diagnostic failure in the diagnostic history.

The following table describes diagnostics that this feature supports. The classes of diagnostics are solicited or audit, or solicited and audit.

Diagnostic name	Description	Type (solicited, audit, or both)
AB DIAG	A/B Bits	solicited
AMUDIAG	NT6X50 External Loop	solicited
CSD1 DG	C-Side DS-1	solicited
CMRDIAG	CLASS modem resource (CMR) card	both
CONT DG	Continuity Diag	solicited
CSMDIAG	CSM Diag	solicited
CS SPCH	Network Links	solicited
DCHIALB	DCH Inactive Loopback	solicited
DS1DIAG	P-Side DS-1	solicited
DS30A	NT6X48/NTMX74 Audit	audit
FAC AUD	Facility Audit	audit
FORMATR	Local Formatter	solicited
ISPHDLC	ISP HDLC Diag	solicited
ISPSPHI	ISP Speech Bus Internal	solicited
ISPSPHF	ISP Speech Bus Full	solicited
MSGDIAG	NT6X69 Messaging Card	solicited
MSG IMC	IMC Link	solicited and audit
MX76 MSG	NTMX76 Messaging Card	solicited
PADRING	NT6X80 Pad and Ring	solicited
PARITY	Parity Audit	audit
PS LOOP	P-Side Loops	solicited
PS SPCH	P-Side Speech Links	solicited
RCC FMT	Remote Formatter	solicited

 Table 8-12 Diagnostic supported (Sheet 1 of 2)

DMS-100 Family Switching Center-SONET Model B Maintenance Manual

Diagnostic name	Description	Type (solicited, audit, or both)
SCM AB	NT6X81 A/B Bits	solicited
SCM MSG	Subscriber carrier module (SCM) A/B DDL Message	solicited
SPCH DG	Speech Path	solicited
STRDIAG	Special Tone Receiver	solicited
SYNC DG	Sync Diag	solicited and audit
TONES DG	Tone Diag	solicited and audit
TS DIAG	Time Switch Diag	solicited
UTRDIAG	UTR Card	solicited

# Table 8-12 Diagnostic supported (Sheet 2 of 2)

The following table lists the cards that this feature supports:

Table 8-13 Supported cards (Sheet 1 of 2)

Card name	Description
NT6X40	Net Interface Link
NT6X41	Speech Bus Formatter and Clock
NT6X42	CSM
NT6X44	Time switch and A/B Bit Logic
NT6X45	Master Signaling File Processor
NT6X46	Signaling Processor (SP) Memory
NT6X47	Master Processor (MP) Memory
NT6X48	DS30A Interface
NT6X50	DS-1 Interface
NT6X55	DS-0 Interface
NT6X62	STR Card
NT6X69	Messaging Card
NT6X70	Continuity Card

Card name	Description
NT6X72	Remote Cluster Controller (RCC) Host Link Formatter
NT6X78	CMR
NT6X79	Tone Generator
NT6X80	SCM Pad and Padring
NT6X81	SCM A-B Bit
NT6X85	SCM DS-1
NT6X86	SCM message
NT6X92	UTR
NT8X18	Subscriber Carrier Module-100S Remote (SMS-R) C-side DS30A Interface
NTBX01	ISP
NTBX02	DCH
NTMX76	CSM and MSG Card
NTMX77	68020 Processor (Unified Processor [UP])

#### Table 8-13 Supported cards (Sheet 2 of 2)

# How diagnostics are stored

This feature stores diagnostic results in the form of counters. Each unit of each peripheral that this feature supports has a set of counters. This feature keeps counters for diagnostic failures and defective cards. This feature keeps three types of counters:

• diag

the number of times a diagnostic fails

• card

the number of times a card is reported as defective

• diag and card combination

the number of times a diagnostic and card combination occurs

This feature keeps two subcounters for each of the three counters: a short-term failure counter and a long-term failure counter. Short-term failure counters are reset often in the BCS cycle. Long-term failure counters record the diagnostic history of a peripheral or office over an extended period of time. Long-term

failure counters are reset through the QUERYPM DIAGHIST RESET command or a BCS application.

A single test failure can report one or more diagnostic failures and zero or more defective cards. A diagnostic that runs in one unit to report cards in that unit and the mate unit. Some diagnostics report failures on the mate unit. When a diagnostic fails, that exact diagnostic sends the failure information to the history database.

# **Resets and time stamps**

The history database stores the following five time stamps for each peripheral:

- for the node
  - the time when long-term failure counters are last reset
- for unit zero
  - the time when short-term failure counters for unit zero are last reset
  - the time when the last diagnostic failure occurs on unit zero
- for unit one
  - the time when short-term failure counters for unit one are last reset
  - the time when the last diagnostic failure occurs on unit one

Short-term counters are internally reset to zero on a unit basis when a unit gains activity. This gain of activity can occur as a result of an RTS or SWACT command. Long-term counters are reset for each node from an XPM posted at the MAP terminal. When long-term counters are reset, the system generates a log. The log includes a summary of the data collected for that node before the reset.

A BCS application resets the diagnostic history data, like short- and long-term failure counts. The system does not generate a log with long-term failure counts.

The user performs diagnostic tests for the RSC-S and RSC-S with ISDN on the following components:

- RCC2
- lines
- DRCC2
- RCC2 with ISDN
- ISDN lines.

# Remote cluster controller 2

The user performs diagnostic tests for the RCC2 when the user issues the TST command.

# Lines

When you perform a test on a subscriber line, you must perform the command several times. Perform the command several times to make sure DS-1 links do not affect the results.

# Dual remote cluster controller 2

The user performs diagnostic tests for DRCC22 when the user issues the TST command at the IRLINK level.

# **Remote cluster controller 2 with ISDN**

The user performs diagnostic tests for the RCC2 when the user issues the TST command.

# **ISDN** lines

When you perform a test on a subscriber line, you must perform the command several times, as with non-ISDN lines. Perform the command several times to make sure the DS-1 links do not affect results.

# Ring pretrip on LCM lines

A ring pretrip is a premature ring trip. It is a false indication that the ringing phone was answered.

In NA009, the PRETRIP nonmenu command is added to the LCM level. The PRETRIP command provides operating company personnel the

- option to enable or disable pretrip log reports on the posted LCM or all LCMs in the posted set
- option to enable or disable extension of the ring trip filter timing on all 4FR lines on the posted LCM or all LCMs in the posted set
- ability to query the status of the two previous pretrip options

*Note:* When a new LCM tuple is entered in table LCMINV, the value for LOGS and 4FR are set to DISABLE by default.

In response to the command string HELP PRETRIP, the command syntax is displayed at the MAP terminal as follows.

```
>help pretrip
PRETRIP : AVAILABLE RINGING PRETRIP OPTIONS
LOGS: Enable/Disable Pretrip LOG Reporting for
the posted PM or posted set of PMs.
4FR: Used to reduce Ring Pretrip occurrences on
long loop length 4FR lines. Enabling this
command results in extension of the Ring
Trip filter timing for ALL lines serviced
by the posted PM or posted set of PMs.
Query: Displays the status of Pretrip options
Parms: <OPTION> {LOGS <ACTION> {ENABLE [<OPTION> {ALL}],
DISABLE [<OPTION> {ALL}]} [<NOWAIT>{NOWAIT}],
4FR <ACTION> {ENABLE [<OPTION> {ALL}]} [<NOWAIT> {NOWAIT}]
QUERY}
```

# **Pretrip log reports**

Pretrip log reports are enabled or disabled for a posted LCM or all LCMs in the posted set. If the LCM is in service, the effect is immediate. Otherwise, the LCM is updated during the next RTS. You must enter one of the following actions with the command string PRETRIP LOGS.

- ENABLE This enables recording of LINE113 log reports for the posted LCM when the system detects a pretrip.
- DISABLE This prevents any LINE113 log reports from being generated when the system detects a pretrip on a posted LCM.

You can enter the following optional parameters with either of the previous actions.

- ALL This results in the selected action being applied to all LCMs in the posted set.
- NOWAIT This option prevents waiting for confirmation that the command has been completed.

For example, to record LINE113 logs for all pretrips detected on all LCMs in the posted set, activate the logs feature by typing

#### >PRETRIP LOGS ENABLE ALL

and pressing the Enter key.

When a pretrip occurs and the pretrip logs are enabled, a LINE113 log is output. An example of a LINE113 log follows.

```
LINE113 JAN27 09:14:14 6220 TBL

KRCM 03 0 19 04 DN 6195441578

TROUBLE CODE = RINGING_FAILED

RINGING TROUBLE = PRETRIP

CALLID = 98776
```

When a pretrip occurs on a line that connects to an LCM, a LINE138 log is output. A LINE138 log identifies the call that was routed to a treatment. An example of a LINE138 log follows.

```
LINE138 JAN27 09:14:14 6321 INFO TRMT

KRCM 03 0 00 08 DN 6195441579

TREATMENT SET = SYFL CALLED NO = 5441578

CALLID= 01D8 0003
```

After two pretrips occur, the line is scheduled for a diagnostic. If the diagnostic fails, a LINE101 log is generated. An example of a LINE101 log follows.

LINE101 JAN27 09:16:05 3782 FAIL LN\_DIAG KRCM 03 0 01 06 DN 6195441586 DIAGNOSTIC RESULT Ringing Failed Pre Trip ACTION REQUIRED Chk Ringing CARD TYPE 6X17AC

# **Pretrip on 4FR lines**

The command string PRETRIP 4FR ENABLE is used to reduce ring pretrip occurrences on long loop length 4FR lines served from the posted LCM or all LCMs in the posted set. The effect of this command is not immediate and will not be realized until the next RTS of the LCM. You must enter one of the following actions with the command string PRETRIP 4FR.

- ENABLE This extends 4FR line ring filter timing.
- DISABLE This returns to non-extended 4FR line ring filter timing.

The following optional parameters can be entered with either of the previous actions.

- ALL This results in the selected action being applied to all LCMs in the posted set.
- NOWAIT This option prevents waiting for confirmation that a command has been completed.

For example, entend 4FR line ring filter timing for all LCMs in the posted set by typing

>PRETRIP 4FR ENABLE ALL

and pressing the Enter key.

# Display status of pretrip options logs and 4FR

Display the status of options LOGS and 4FR by typing

>PRETRIP QUERY

and pressing the Enter key.

An example of a system response to the PRETRIP QUERY command string follows.

CI	4 MS	IOD	Net	PM 1LCM *C*	ccs		Lns	Trk	s	Ext	APPL
	4 Quit Post_	PM LCM	0	ManB 0 0		EL 2 0	CBs 0 0	-	ISTb 2 2		InSv 42 9
3 4 5	ListSet SwRG Trnsl_	LCM HO Unit0:	ST 00 0 InsV	InSv	Lin	/RG	: 1	Side	0 1	Side	0
7 8	Tst_ Bsy_ RTS_ OffL			45 67	_	/RG 1 11 1 23 	11		.1 RG 9		l InsV 0 Insv
11	LoadPM_ Disp_ Next			- PRETRI PRETRI							
14 15 16	QueryPM										
17 18											

# **Product-specific test tools**

Test tools for XPMs, apply to RSC-S components.

# Real-time performance monitoring for NTMX73AA and NTMX76AA

Feature AF4903, Real-Time Time Performance Monitoring for NTMX73AA and NTMX76AA, supplies information about two components. Feature AF4903 provides real-time performance information about the:

- Pulse Code Modulation (PCM) Signaling circuit card NTMX73AA
- optional Message Processor
- Tone Generator circuit card NTMX76AA.

The performance tool provides operating company personnel with performance and activity information for posted peripherals. The data appears at the performance level of the MAP display, sublevel PMACT. The PMACT sublevel provides information that indicates processor activity in the posted peripheral. The PMACT sublevel divides the real time used, into two categories: call processing occupancy and low priority background. These two categories apply to the UP and EISP. Information for the NTMX73AA circuit card appears at the PMACT sublevel. The information appears as the percentage of time required at the interrupt level call processing occupancy, in the last minute. Information for the NTMX76AA circuit card appears as the time required to communicate with the HDLC protocol in the last minute. The time appears as a percentage.

The real time used for the NTMX73AA and NTMX76AA processors is not classified into categories. The information that appears for the UP and EISP is classified in categories. For both circuit cards, the average time that appears, represents the time elapsed from the start of the recording. If the elapsed time is greater than 15 min, the average time is available for the last 15 min.

The following is an example of the command used to monitor the performance in RCC2 unit one.

#### >MAPCI;MTC;PM;POST RCC2 1;PERFORM;PMACT;START

The following figure is an example of the display for the previous command.

# Figure 8-6 Example of an RCC2 MAP display

CM MS	IOD	NET	PM	CCS	Lns	Tr	ks	Ext	APPL
• •	•	•	•				•	•	•
PMAct			Sysb	Manb	Offl	Cbsy	ISTb	INSV	v
1 Quit	PM		0	0	0	0	0	Ę	5
2 Strt	RCC2		0	0	0	0	0	1	1
3 Strtlog 4 Stoplog		1 I	nSv Li	nks_008	S: CSid	de O P	Side	0	
5 Stop	Unit	0: Ac	t I	nSv					
б	Unit	1: In	act I	nSv					
7	LOAD	NAME :							
8	STAT	US:	REA	SON:	LO	GS:	TI	ME:xx	:xx:xx
9			UP	AVG IS	SP AVG	SIGE	AVG	MX76	AVG
10									
11	CALL	PROCE	SSING	XXX XX	x xx	x xxx	XXX :	XXX 2	xxx xxx
12	LOW	PRIO B	GND	XXX XX	x xx	x xxx			
13				ORIG	OR	IGAVG	TERM	1	FERMAVG
14				xxx		xxx	xxx		xxx
15				AVAIL	IN	USE	HIGH		
16	PS_C	HNL		XXX	:	xxx	xxx		
17	UTR			xxx	2	xxx	xxx		
18									
OPERATOR									
Time 09:34									

The following is an example of the command used to monitor performance in line trunk controller (LTC) unit one.

#### >MAPCI;MTC;PM;POST LTC 1;PERFORM;PMACT;START

The following figure is an example of the display for the previous command:

Figure 8-7	Example	of an	LTC MAP	<sup>o</sup> display
------------	---------	-------	---------	----------------------

CM	MS	IOD	NET	PM	CCS	Lns	Tr	ks	Ext	APPL
•	•	•	•		•	•			•	•
PMAct				Sysb	Manb	Offl	Cbsy	ISTb	INS	v
1 Qui	t	PM		- 0	0	0	0	0		5
2 Str		LTC		0	0	0	0	0	-	1
3 Str	tloq									
	plog	LTC	1 I	nSv Li	nks_00	s: CSid	de 0 P	Side (	)	
5 Sto			: 0: Ac		nSv					
6	-	Unit	: 1: In	act I	nSv					
7		LOAI	NAME:							
8		STAT	rus:	REA	SON:	LO	GS:	TIN	/E:xx	:xx:xx
9				UP	AVG	ISP A	VG	MX76 2	AVG	
10										
11		CALI	D PROCE	SSING	XXX X	xx xx	x xxx	xxx >	xx x	xxx xxx
12		LOW	PRIO E	GND	XXX X	xx xx	x xxx			
13					ORIG	OR	IGAVG	TERM	5	TERMAVG
14					xxx		xxx	xxx		xxx
15					AVAIL	IN	USE	HIGH		
16		PS_C	CHNL		XXX	:	xxx	xxx		
17		UTR			XXX	:	xxx	xxx		
18										
OPERAT	OR									
Time 0	9:34									

# 9 Troubleshooting chart

This chapter contains tables to help troubleshoot conditions that cause alarms in the Remote Switching Center-SONET (RSC-S). This chapter contains separate tables for each RSC-S component. These tables include the remote cluster controller 2 (RCC2) or RCC2 with integrated services digital network (ISDN). These tables also include line concentrating modules (LCM) or enhanced line concentrating modules (LCME), and the remote maintenance module (RMM).

The following table lists possible causes and actions to take to clear LCM or LCME alarms.

Alarm condition	Possible cause	Action			
Critical	Indicates the number of	Proceed as follows:			
	system busy (SysB) or central-side busy (CBsy) LCM (or LCME) units.	<ol> <li>Refer to Alarm Clearing Procedures. Follow the procedure to clear an LCM or LCME critical alarm.</li> </ol>			
		<ol> <li>Check for peripheral module (PM), ISDN, or LINE logs that indicate problems in the LCM or LCME.</li> </ol>			
	Both LCM or LCME ringing generators (RG) are in-service trouble (ISTb).	3. Check operational measurements (OM) that indicate problems in the LCM or LCME.			
			Proceed as follows:		
		<ol> <li>Refer to Alarm Clearing Procedures. Follow the procedure to clear an LCM or LCME critical alarm.</li> </ol>			
		<ol><li>Check for PM, ISDN, or LINE logs that indicate problems in the LCM or LCME.</li></ol>			
		3. Check for OMs that indicate problems in the LCM or LCME.			

Table 9-1 Clearing a RSC-S alarm for an LCM or an LCME (Sheet 1 of 2)

# **9-2** Troubleshooting chart

Alarm condition	Possible cause	Action			
Major	Indicates of the number of LCM (or LCME) units that are ISTb or SysB.	Proceed as follows:			
		<ol> <li>Refer to Alarm Clearing Procedures. Follow the procedure to clear an LCM or LCME major alarm.</li> </ol>			
		<ol><li>Check for PM, ISDN, or LINE logs that indicate problems in the LCM or LCME.</li></ol>			
		3. Check for OMs that indicate problems in the LCM or LCME.			
Major (continued)	One of the two RGs in an LCM (or LCME) is ISTb.	Proceed as follows:			
		<ol> <li>Refer to Alarm Clearing Procedures. Follow the procedure to clear an LCM or LCME RG major alarm.</li> </ol>			
		<ol><li>Check for PM, ISDN, or LINE logs that indicate problems in the LCM or LCME.</li></ol>			
		<ol><li>Check for OMs that indicate problems in the LCM or LCME.</li></ol>			
Minor	Indicates the number of	Proceed as follows:			
	LCM or LCME units that are ISTb.	<ol> <li>Refer to Alarm Clearing Procedures. Follow the procedure to clear an LCM or LCME minor alarm.</li> </ol>			
		2. Check for PM, ISDN, or LINE logs that indicate problems in the LCM or LCME.			
		<ol> <li>Check for OMs that indicate problems in the LCM or LCME.</li> </ol>			

Table 9-1 Clearing a RSC-S alarm for an LCM or an LCME (Sheet 2 of 2)

٦

The following table lists possible causes and actions to take to clear RCC2 or RCC2 with ISDN alarms.

Alarm condition	Possible cause	Action			
Critical	RCC2 (or RCC2 with	Proceed as follows:			
	ISDN) units that are SysB or CBsy. Loss in subscriber service.	<ol> <li>Refer to Alarm Clearing Procedures. Follow the procedure to clear an RCC2 critical alarm. When necessary, go to step 1.</li> </ol>			
		2. Refer to <i>Recovery Procedures</i> . Follow the procedures to recover an RCC2.			
		<ol> <li>Check for emergency stand-alone (ESA) and PM logs, or both, that indicate problems in the RCC2. The ESA and PM logs include ESA101-ESA109, PM181 and PM171.</li> </ol>			
		For dual RCC2 (DRCC2), check for PM logs that associate with dual ESA (DESA). Logs: PM221-PM223, and PM189			
		<ol> <li>When ISDN is present, check for ISDN or LINE logs that indicate problems in the RCC2. Logs: ISDN100-ISDN109 and LINE131.</li> </ol>			
		5. Check for OMs that indicate problems in the RCC2.			
	The RCC2 is in ESA.	Proceed as follows:			
	Communication to the CC in the host switch is not available.	<ol> <li>Refer to <i>Recovery Procedures</i>. Follow the procedures to recover an RCC2 in ESA.</li> </ol>			
		<ol> <li>Check for ESA or PM logs, or both, that indicate problems in the RCC2. Logs: ESA101-ESA109, PM181, and PM171.</li> </ol>			
		For DRCC2, check for PM logs that associate with DESA. Logs: PM221-PM223, and PM189.			
		<ol> <li>Check for OMs that indicate problems in the RCC2.</li> </ol>			

Table 9-2 Clearing a RSC-S alarm for an RCC2 or an RCC2 with ISDN (Sheet 1 of 2)

#### **9-4** Troubleshooting chart

Alarm condition	Possible cause	Action			
Major	Indicates the number of	Proceed as follows:			
	RCC2 units that are CBsy or SysB. Subscriber service does not change. Loss in subscriber service occurs when both RCC2s or units fail.	<ol> <li>Refer to Alarm Clearing Procedures. Follow the procedure to clear an RCC2 major alarm.</li> </ol>			
		<ol> <li>Check for PM logs that indicate problems in the RCC2.</li> </ol>			
		<ol> <li>Check for OMs that indicate problems in the RCC2.</li> </ol>			
Minor	Indicates the number of	Proceed as follows:			
	RCC2 units that are ISTb. Does not affect subscriber service.	<ol> <li>Refer to Alarm Clearing Procedures. Follow the procedure to clear an RCC2 minor alarm.</li> </ol>			
		<ol><li>Check for PM181 and PM128 logs that indicate problems in the RCC2.</li></ol>			
		<ol> <li>Check for OMs that indicate problems in the RCC2.</li> </ol>			

Table 9-2 Clearing a RSC-S alarm for an RCC2 or an RCC2 with ISDN (Sheet 2 of 2)

The following table lists possible causes and actions to take to clear RMM alarms.

Table 9-3 Clearing a RSC-S alarm for an RMM

Alarm condition	Possible cause	Action
Major	Indicates the number of RMM units that are SysB.	Refer to <i>Alarm Clearing Procedures</i> . Follow the procedure to clear an RMM major alarm.
Minor	Indicates the number of RMM units that are CBsy.	Refer to <i>Alarm Clearing Procedures</i> . Follow the procedure to clear an RMM minor alarm.

# 10 Advanced troubleshooting procedures

This chapter describes advanced troubleshooting procedures for the RSC-S.

# Advanced trouble locating procedures

Use advanced troubleshooting procedures when normal troubleshooting procedures do not clear a problem. Maintenance personnel can attempt the PMRESET procedure more than one time on the remote cluster controller 2 (RCC2). If an error message occurs after each PMRESET attempt, you must perform advanced troubleshooting procedures. Use the advanced troubleshooting tool PMDEBUG. Refer to the *PMDEBUG User Guide*, TAM-1001-004, for additional information.

# **Bigfoot utility**

The Bigfoot utility stores information on diagnostics that passed and failed. The system implements feature AF5008, XMS-based Peripheral Module (XPM) Routine Exercise (REX) Control and Trouble Notification Improvements. The Bigfoot utility maintains error log information that occurs as a result of failed diagnostics. This utility improves debugging results. The diagnostics code maintains results graphs for each set of diagnostics that runs. The results graph contains data on each diagnostic test in the diagnostics run. The results graph identifies a diagnostic as passed, failed, not run, or test not defined.

# **Diagnostics results graph output**

An example of the diagnostics results graph display output follows:

# Powering up the RSC-S

Use this procedure when you take RSC-S components out-of-service (OOS) and cut power to these components. The following steps are the reverse of a power-down procedure. In this procedure, start with the central side (C-side) and work toward the peripheral side (P-side) of the RCC2.

To power up the RSC-S, perform the following steps:

- Return the RCC2 to service (RTS).
- RTS the enhanced line concentrating module (LCME) or line concentrating module (LCM) off the RCC2.
- RTS the remote maintenance module (RMM).
- Post the RCC2. RTS all P-side DS-1 links.

Use the following procedure to power up an RSC-S.

# **Power-up procedure**

#### At the RSC-S:

- 1 To begin the first part of the RSC-S power-up procedure, post the C-side peripheral of the RCC2. Return the message links to service with the RCC2. Busy these links when the RSC-S powers down.
- 2 Set the power switch to ON for one of the RCC2 units.
- 3 Set the reset button of this RCC2 unit, and at the same time, flip the associated circuit breaker (CB) up and release the CB. The CB must stay in the up position. If the CB does not stay in the up position, a problem is present in the power circuitry.
- 4 Repeat steps 2 and 3 for the other RCC2 unit.
- 5 Post the correct RCC2. The RCC2 must be offline (OFFL).
- 6 Busy both units of the RCC2.
- 7 Load one of the RCC2 units. Make sure you list the correct device like S01DPMLOADS. For example:

>LOADPM UNIT unit\_no LOADFILE IMAGE

- 8 Return the unit to service. Do not use parameters. Make sure the RTS sequence includes diagnostics.
- **9** Repeat steps 7 and 8 for the other unit.
- **10** Perform a switch of activity (SWACT). This action completes the first part of the RSC-S power-up procedure.
- 11 Begin the second part of the RSC-S power-up procedure. To begin the procedure, set the power switch of one of the LCME or LCM units to ON
- 12 Set the associated CB up and release the CB. The CB must stay in the up position. If the CB does not stay in the up position, a problem is present in the power circuitry.
- 13 Repeat steps 11 and 12 for the other LCME or LCM unit.
- **14** Post the first LCME or LCM.

**15** Load one of the LCME or LCM units. Make sure you list the correct device like S01DPMLOADS. For example:

>LOADPM UNIT unit\_no CC

- **16** Return the unit to service. Do not use parameters. Make sure the RTS sequence includes diagnostics.
- 17 Repeat steps 15 and 16 for the other LCME or LCM unit.
- **18** Repeat steps 11 through 17 until the system returns all LCME and LCM units to service. This action completes the second part of the RSC-S power-up procedure.
- **19** To begin the third part of the RSC-S power-up procedure, set the power switch of the RMM to ON.
- **20** Press the reset button on the NT2X09 power converter of this RMM. At the same time, flip the CB that connects to the RMM to the up position. Release the CB. The CB must stay in the up position. If the CB does not stay in the up position, a problem is present in the power circuitry.
- **21** Load the RMM. Make sure you list the correct device like S01DPMLOADS. For example:

>LOADPM

- **22** Return the unit to service. Do not use parameters. Make sure the RTS sequence includes diagnostics.
- 23 Repeat steps 19 through 22 if the RSC-S uses two RMMs.
- 24 Post the RCC2 and RTS all P-side DS-1 links. Busy the P-side DS-1 links when the RSC-S powers down.
- **25** This procedure is complete.

#### Powering down the RSC-S

An RSC-S is a separate switching system. Normally, you must not power the RSC-S down. If you power down the RCC2, loss of communication with other offices occurs. When a power-down procedure is necessary, use the following procedure.

#### Power-down procedure

#### At the RSC-S:

- 1 Inform all appropriate personnel that you plan to perform a power-down procedure. Notify personnel at the host office and at offices that connect to the RCC2 over P-side trunks.
- **2** Busy all P-side peripheral module (PM) off of the RCC2. Busy all RMMs and line concentrating devices (LCD).
- **3** Offline all P-side PMs off the RCC2. PMs to busy include RMMs and the LCD.
- **4** Busy all P-side links off the RCC2. Links to busy include DS-1 links to other offices and the packet handler (PH).
- **5** Power down P-side PMs. Set the switch to the associated power converter units to OFF.
- **6** Busy the inactive unit of the RCC2.

- **7** Post the associated line trunk controller (LTC). Busy the message link that connects to the busied RCC2 unit.
- 8 Power down the inactive unit of the RCC2. Set the power converter of the unit to OFF.
- **9** Busy the active unit of the RCC2. Override any warning.
- **10** Post the associated LTC. Busy the message link that connects to the busied RCC2 unit.
- 11 Power down the previously active unit of the RCC2. Set the power converter of the unit to OFF.
- 12 Post the RCC2 and OFFL the PM.
- **13** This procedure is complete.

# 11 RSC-S routine maintenance procedures

This chapter contains routine maintenance procedures for the remote switching center-synchronous optical network (SONET) (RSC-S). These procedures describe preventive maintenance tasks. These procedures are for maintenance engineering and field maintenance personnel. Maintenance engineering and field maintenance personnel perform these maintenance tasks at scheduled intervals.

## Inspecting cooling unit filters

## Application

Use this procedure to inspect cooling unit filters in the following cabinetized frames:

- NTMX89FA, Cabinetized Remote Switching Center/Line Concentrating Module (CRSC/LCM)
- NTMX89FB, Cabinetized Remote Switching Center/Integrated Services Digital Network (CRSC/ISDN)
- NTMX89FC, Cabinetized Extension Module (CEXT)
- NTRX30CA, Cabinetized Line Concentrating Equipment (CLCE)
- NTRX30DA, Cabinetized Line Module ISDN (CLMI)
- NTRX34BA, Cabinetized Miscellaneous Equipment (CMIS)
- NTRX31AA, Cabinetized Power Distribution Cabinet (CPDC)

## Interval

Perform this procedure every two weeks.

## **Common procedures**


There are no common procedures.

## Action

This procedure contains a summary flowchart and a list of steps. Use the flowchart to review the procedure. Follow the steps to perform the procedure.

# Inspecting cooling unit filters (continued)

#### Summary of Inspecting cooling unit filters



# Inspecting cooling unit filters (continued)

#### Inspecting cooling unit filters

#### At your Current Location


1



**DANGER To prevent overheating** Do not leave the cooling unit fans off for longer than 30 min.


Remove the two fuses in slot position19 on the faceplate of the modular supervisory panel (MSP). This action makes sure the cooling unit fans are off.

**2** Use the two filter access tabs to grip the filter.



- 3
- Slide the filter out of the cabinet.

# Inspecting cooling unit filters (end)



appear dirty	step 4
appear clean	step 5

- 4 Replace the filter with the same part number as the number of the old unit. Go to step 6.
- **5** Install the filter in the cabinet again.
- 6 Replace the two fuses that you removed in step 1.
- 7 The procedure is complete.

## Testing wrist strap grounding cords

#### Application

Use this procedure to verify that the level of resistance of wrist strap grounding cords is correct. The level must be low enough to allow static electricity to discharge from the body of the user. The level must be high enough to prevent electrocution. Electrocution occurs if the equipment develops a short-circuit while the user wears the wrist strap.

#### Interval

Perform this procedure in one month intervals.

## **Common procedures**


There are no common procedures.

## Action

This procedure contains a summary flowchart and a list of steps. Use the flowchart to review the procedure. Follow the steps to perform this procedure.

## Testing wrist strap grounding cords (continued)

#### Summary of Testing wrist strap grounding cords



# Testing wrist strap grounding cords (continued)

#### Testing wrist strap grounding cords

#### At your Current Location

- 1 Obtain an ohmmeter.
- 2 Take the grounding cord off the wrist strap.
- 3 Measure the resistance between opposite ends of the grounding cord with the ohmmeter.

If resistance	Do
is between 800 k $\Omega \alpha v \delta 1200 \kappa \Omega$	step 4
is not between 800 k $\Omega$ av $\delta$ 1200 k $\Omega$	step 5

- 4 You can use the grounding cord and wrist strap assembly. Assemble the wrist strap to the grounding cord. Go to step 6.
- 5



#### DANGER

**Risk of electrocution** 

A grounding cord is only safe to use if resistance of the grounding cord is higher than 800 k $\Omega$ . Lower resistance exposes the user to the risk of electrocution. Electrocution can occur if equipment short-circuits while the user wears the wrist strap.



#### DANGER

#### **Risk of electrocution**

A grounding cord is only safe to use if resistance of the grounding cord is higher than 800 k $\Omega$ . Lower resistance exposes the user to the risk of electrocution. Electrocution can occur if equipment short-circuits while the user wears the wrist strap.



#### WARNING

#### Damage to electronic equipment

A grounding cord that has a resistance higher than  $1200 \text{ k}\Omega$  cannot conduct enough static charges to ground correctly. The grounding cord will not protect sensitive electronic equipment against build-ups of static charges that can cause damage.

# Testing wrist strap grounding cords (end)



#### WARNING Damage to electronic equipment

A grounding cord that has a resistance higher than  $1200 \text{ k}\Omega$  cannot conduct enough static charges to ground correctly. The grounding cord will not protect sensitive electronic equipment against build-ups of static charges that can cause damage.

Discard the complete assembly. Do not attempt to use it.

The procedure is complete.

6

## Fuse replacement in the LCME

## Application

Use this procedure to replace fuses in the enhanced line concentrating module (LCME) fuse panel. This panel is the LCME fuse panel of the CRSC and CEXT cabinets on a remote switching center-SONET (RSC-S) site.

#### Interval

Perform this action as required.

## **Common procedures**


There are no common procedures.

## Action

This procedure contains a summary flowchart and a list of steps. Use the flowchart to review the procedure. Follow the steps to perform the procedure.

## Fuse replacement in the LCME (continued)

#### Summary of fuse replacement in the LCME



#### Fuse replacement in the LCME (continued)

#### Fuse replacement in the LCME

#### At the MAP terminal

To access the EXT level of the MAP terminal, type

>MAPCI;MTC;EXT

and press the Enter key.

To list the MSP alarm, type

>LIST FSP

and press the Enter key.

3 Note the location of the MSP alarm.

#### At the RSC-S site

- 4 Observe the frame LED. The LED must be on.
- 5 Check both ISDN line concentrating array (LCAI) fuse panels for fuse indicators that protrude.
- 6 To post the LCME, type

>POST LCME site cabinet module

and press the Enter key.

where

site is the name of the RSC-S site

cabinet

is the CRSC or CEXT cabinet number

module

is the LCME module number

Example of a MAP display:

LCME RemL 00 0 ISTb Links\_OOS: CSide 1 Unit0: InSv /RG: 0 Unit1: InSv /RG: 0 11 11 11 RG:Pref 0 InSv Drwr: 01 23 45 67 89 01 23 45 Stby:1 InSv II .....

7 To busy (BSY) the drawers that have an I (in-service trouble[ISTb]) condition, type

```
>BSY DRWR number
```

and press the Enter key.

#### where

number

is the line subgroup number

# Fuse replacement in the LCME (continued)

8 Replace the blown fuse with a new fuse of the same rating. Refer to figure LCME fuse panel.

If the fuse	Do
blows again, suspect defective NTBX36 card	Card Replacement Procedures for card replacement.
does not blow and alarm clears	step 9
To test the drawer with the new fuse i	nstalled, type
>TST DRWR number	
and press the Enter key.	
where	
WIICIE	
number is the line subgroup number	
number	with the new fuse installed, type
number is the line subgroup number	with the new fuse installed, type
<b>number</b> is the line subgroup number To return to service (RTS) the drawer	with the new fuse installed, type
number is the line subgroup number To return to service (RTS) the drawer >RTS DRWR number	with the new fuse installed, type


9

10

The following figure shows an example of an LCME fuse panel and fuse assignments.

## Fuse replacement in the LCME (end)

#### LCME fuse panel



# **Replacing cooling unit filters**

## Application

Use this procedure to replace cooling unit filters in the following cabinetized frames:

- NTMX89FA, Cabinetized Remote Switching Center/Line Concentrating Module (CRSC/LCM)
- NTMX89FB, Cabinetized Remote Switching Center/Integrated Services Digital Network (CRSC/ISDN)
- NTMX89FC, Cabinetized Extension Module (CEXT)
- NTRX30CA, Cabinetized Line Concentrating Equipment (CLCE)
- NTRX30DA, Cabinetized Line Module ISDN (CLMI)
- NTRX34BA, Cabinetized Miscellaneous Equipment (CMIS)
- NTRX31AA, Cabinetized Power Distribution Cabinet (CPDC)

## Interval

Perform this procedure in three month intervals.


## **Common procedures**

There are no common procedures.

## Action

This procedure contains flowchart and a list of steps. Use the flowchart to review the procedure. Follow the steps to perform the procedure.

# Replacing cooling unit filters (continued)



#### Summary of replacing cooling unit filters

# Replacing cooling unit filters (continued)

#### **Replacing cooling unit filters**

#### At your Current Location

1




**DANGER To prevent overheating** Do not leave the cooling unit fans off longer than 30 min.



**DANGER To prevent overheating** Do not leave the cooling unit fans off longer than 30 min.


To make sure the cooling unit fans are turned off, remove the two fuses in slot position 19 on the faceplate of the MSP.

2 Use the two filter access tabs to grip the filter.



**3** Slide the filter out of the cabinet.

# Replacing cooling unit filters (end)



If filter surfaces appear	Do	
dirty	step 4	_
clean	step 5	

- 4 Replace the filter with the same part number as that of the old unit.
- 5 Replace the fuses removed in step 1.
- 6 The procedure is complete.

## Testing power converter voltages

# Application

Use this procedure to test power converter voltages.

## Interval

Perform this procedure in six month intervals.

## **Common procedures**


Does not apply

## Action

This procedure contains a summary flowchart and a list of steps. Use the flowchart to review the procedure. Use the steps to perform the procedure.

# Testing power converter voltages (continued)

#### Summary of Testing power converter voltages



## Testing power converter voltages (continued)

#### Testing power converter voltages


#### At your Current Location

- 1 Obtain a DC voltmeter.
- 2 Determine the version of the NTMX72 converter card.

If the NTMX72 card version	Do
is AA	step 4
is AB	step 3

- 3 The NTMX72AB card does not require tests. Voltage test access points are not available on the face plate of the NTMX72AB power converter card. For additional information about the NTMX72AB card, refer to the power converter paragraph in the cards section of the *Maintenance overview chapter*. Go to step 7.
- 4 Measure the voltage at the test points on the face plates of NTMX72AA power converters in the equipment cabinet.

# Testing power converter voltages (continued)



#### Circuit cards with status indicators

5 The voltages must be within 2% of the nominal values that appear on the faceplate. Compare the voltages measured in step 4 with the acceptable voltage ranges that appear in the following table:

#### (Sheet 1 of 2)

Test point voltage	Acceptable range
+12 V	+11.76 V to + 12.24 V
-12 V	-12.24 V to -11.76 V

# Testing power converter voltages (end)

#### (Sheet 2 of 2)

Test point voltage	Acceptable range	
+ 5 V	+4.9 V to +5.1 V	
-5 V	-5.1 V through -4.9 V	
If test point voltages	Do	
are in acceptable range	step 7	
are not in acceptable range	step 6	

6 Replace the power converter according to *Card Replacement Procedures*.

7 The procedure is complete.

# Returning a card for repair or replacement

## Application

Use this procedure to return a circuit card, like a power converter, to Northern Telecom (Nortel) for repair or replacement. Your location, Canada or the United States, determines the documents you must complete. Your location determines to which address you must return the card.

#### Interval

Perform this procedure as required.

## **Common procedures**


There are no common procedures.

## Action

This procedure contains a summary flowchart and a list of steps. Use the flowchart to review the procedure. Follow the steps to perform the procedure.

## Returning a card for repair or replacement (continued)

#### Summary of returning a card for repair or replacement



#### Returning a card for repair or replacement

#### At your current location

1 Place the card in an electrostatic-discharge protective bag.

If your location	Do
is in Canada	step 6
is in the United States	step 2

- 2 Fill in the return label for each card that you return. If return labels are not available, use a blank label. For help to complete these labels, call the Nortel Customer Service Center at 1-800-347-4850.
- **3** Pack the card or assembly in a Nortel card shipping carton and seal the carton.

#### Returning a card for repair or replacement (continued)

If a Nortel shipping carton is not available, use another available carton. Make sure that you perform the following actions:

- enclose each card or assembly in packing paper
- surround each card or assembly in bubble pack or foam
- secure each card or assembly in the carton so that no card or assembly can shift
- 4 Address the carton and send it to Nortel as follows:

Nortel Customer Service Center

4600 Emperor Blvd.

Morrisville, North Carolina 27560

- **5** Go to step 11.
- 6 Fill in one return label (form 24-115) for each card or assembly that you return.

Make sure to include the following information:

- return authorization number from customer service
- Nortel product engineering code (PEC)
- serial number
- release number
- batch change supplement (BCS) release software in use at the time of replacement
- peripheral module load name
- description of the failure and action taken to repair
- fault code that describes the fault best (see the bottom of the label)
- name of your company
- office identifier code
- your name
- site name

For help to fill out the label, call 905-454-2808. In the event of an emergency, call 905-457-9555.

- 7 Attach one copy of the card label to a card latch.
- 8 Keep the other copies of the label for your records.
- 9 Pack the card or assembly in a Nortel shipping carton and seal the carton.

If a Nortel shipping carton is not available, use another available carton. Make sure that you

- enclose each card or assembly in packing paper
- surround each card or assembly in bubble pack or foam
- secure each card or assembly in the carton so that no card or assembly can shift

# Returning a card for repair or replacement (end)

 Address the carton to the following address: Nortel Customer Operations
 c/o Wesbell Transport
 1630 Trinity Road
 Unit #3, Door #4
 Mississauga, Ontario
 L5T 1L6
 This procedure is complete.

## Inspecting spare fuse holders

## Application

Use this procedure to inspect spare fuse holders. Fill the fuse holders again as needed.

#### Interval

Perform this procedure in one week intervals.


#### **Common procedures**

There are no common procedures.

## Action

This procedure contains a summary flowchart and a list of steps. Use the flowchart to review the procedure. Follow the steps to perform the procedure.

#### Summary of Inspecting spare fuse holders



## Inspecting spare fuse holders (end)

#### Inspecting spare fuse holders

#### At your current location

1 Locate the spare fuse holder in the MSP.

If spare fuse holder	Do
is empty	step 2
is not empty	step 3

- 2 Fill the spare fuse holder again with the following fuses and circuit breakers:
  - 15-A circuit breakers (for the -48 V shelf feeds)
  - 1.3-A fuses (for the alarm battery supply [ABS] feeds) Go to step 4.
- 3 Make sure that enough of the following fuses and circuit breakers are provided:
  - 15-A circuit breakers (for the -48 V shelf feeds)
  - 1.3-A fuses (for the ABS feeds)
- 4 The procedure is complete.

# Checking torque on grounding bolts

## Application

Use this procedure to check the correct torque of grounding bolts.

#### Interval

Perform this procedure every month.


## **Common procedures**

Does not apply

## Action

This procedure contains a summary flowchart as an overview of the procedure. Follow the steps to perform this procedure.

#### Summary of checking torque on grounding bolts



## Checking torque on grounding bolts (end)

#### Checking torque on grounding bolts

#### At your Current Location

4

- 1 Locate the T9958 click-type preset torque wrench.
- 2 Align the small fractions on the edge of the handle with the center of the main torque scale.
- **3** To set the correct inspection torque value, turn clockwise to increase value or turn counter-clockwise to decrease value.

If grounding bolts are type	Do
1/4-20 backplane, -48 V ground first nut	step 4
1/4-20 backplane, -48 V ground second nut	step 5

- 5 Set inspection torque to 25 in./lb.
- **6** Position the wrench on the grounding bolts and tighten to the inspection torque specifications.
- 7 Return the T9958 torque wrench to the appropriate location.
- 8 The procedure is complete.

# Inspecting and changing bulbs

# Application

Use this procedure to inspect and replace defective fan fail, aisle end, and modular supervisory panel (MSP) bulbs.

## Interval

Perform this procedure one time each month.


## **Common procedures**

There are no common procedures.

## Action

This procedure contains a summary flowchart and a list of steps. Use the flowchart to review the procedure. Follow the steps to perform the procedure.

# Inspecting and changing bulbs (continued)



# Inspecting and changing bulbs (end)

#### Inspecting and changing bulbs

#### At your current location

1 Use the following procedures to inspect the fan fail, aisle end, and MSP bulbs.

If bulbs		Do
are fan	fail bulbs	step 2
are aisle	end bulbs	step 3
are MSP	bulbs	step 4
Flip the alarm (ALM) override switch, located on the MSP, to ON.		
If fan fai	l bulb	Do
does not	light	step 5
lights		step 9
Press a fu	se on the fuse pad located o	on the MSP.
If aisle e	nd bulb	Do
does not	light	step 6
lights		step 9
Press a fuse on the fuse pad located on the MSP.		
If MSP b	ulb	Do
does not	light	step 6
lights		step 9
	ulb cover. Grasp the bulb tig bulb. Go to step 5.	ght with two fingers, squeeze, and pull
Remove the bulb frame casing. Grasp the aisle end or MSP bulb tight with two fingers, squeeze, and pull to remove end or bulb. Go to step 5.		

- 7 Replace with new bulb.
- 8 Attach bulb cover or bulb frame casing again.
- 9 This procedure is complete.

#### **Cooling unit replacement**

### Application

Use this procedure to replace a defective cooling unit (NTRX91AA) in the following cabinetized frames:

- NTMX89FA, Cabinetized Remote Switching Center/Line Concentrating Module (CRSC/LCM)
- NTMX89FB, Cabinetized Remote Switching Center/Integrated Services Digital Network (CRSC/ISDN)
- NTMX89FC, Cabinetized Extension Module (CEXT)
- NTRX30CA, Cabinetized Line Concentrating Equipment (CLCE)
- NTRX30DA, Cabinetized Line Module ISDN (CLMI)
- NTRX34BA, Cabinetized Miscellaneous Equipment (CMIS)
- NTRX31AA, Cabinetized Power Distribution Cabinet (CPDC)

#### Interval

Perform this procedure when a cooling unit cannot operate. An illuminated fan fail indicator on the front of the MSP indicates a defective cooling unit.

#### **Common procedures**


There are no common procedures.

#### Action

This procedure contains a summary flowchart and a list of steps. Use the flowchart to review the procedure. Follow the steps to perform the procedure.

#### Cooling unit replacement (continued)

#### Summary of cooling unit replacement



#### Cooling unit replacement (end)

#### **Cooling unit replacement**

#### At your current location


1



**DANGER To prevent overheating** Do not leave the cooling unit fans off for longer than 30 min.

To make sure the cooling unit fans are off, remove the two fuses in slot position 19 on the faceplate of the MSP.

2 Turn the two knobs on the front panel of the cooling unit counterclockwise and slide the cooling unit out.



- **3** Replace with the same part number as the part number of the old unit. Slide in the new cooling unit until both sides lock in place.
- 4 Replace the two fuses removed in step 1.
- 5 This procedure is complete.

# Index

1-Meg Modem protocol 3-20
1-Meg Modem Service applications for use 1-57 compatibility 1-57 description 1-55 protocols 3-18

### Α

alarm clearing Ext MSP CLCE cabinet Major 5-2 CPDC cabinet Major 5-35 CRME cabinet major 5-43 CRSC and CEXT cabinets Major 5-20, 5-53 PM LCME critical 5-70 major 5-83 minor 5-102 PM LCME(RG) major 5-93 minor 5-112 PM RCC2 major 5-132 minor 5-143 PM RCC(I) Critical 5-120 PM RMM Major 5-154 Minor 5-163 alarm module (NTRX41AA) description 1-8 diagram 1-10 pin-outs 1-10 automatic maintenance 1-82 audits pre- and post-SWACT 1-89

babbling links EDC protection 1-85 channel management 1-85 loop detection 1-86 overload 1-85 components ESA REX test 1-102 fault indicators 1-103 LCM diagnostics, extended 1-105 LCM REX tests, extended 1-99 LCM REx tests, extended 1-108 line concentrating module REX 1-103 manual commands REX 1-102 remote cluster controller 2 (RCC2) 1-110 REX maintenance records 1-104 diagnostics 1-105 escalation to manual maintenance 1-132 exception processing system 1-82 memory management error recovery 1-84 ROM-level 1-83 task level 1-83 trap recovery 1-83 post-SWACT audit 1-90 pre-SWACT audit 1-90 remote cluster controller 2 parity errors 1-126 remote cluster controller 2 (RCC2) dual 1-132 with ISDN 1-132 routine exercise test (REx) 1-93 illustration 1-95 pre- and post-SWACT 1-97 XPM maintenance 1-97 **SWACT** manual 1-91 uncontrolled 1-91 SWACT controller 1-90 SWACT-back 1-90

A-2 Index

### R

Р	NT6V97 ( 200
В	NT6X87 6-200
Bigfoot utility 10-1	NT6X92 6-208
breaker module (NTRX42AA)	NT6X99 6-216
description 1-14	NT7X05 6-224
diagram 1-15	NTAX74 6-233
pin-outs 1-16	NTBX01 6-244
breaker module (NTRX42CA)	NTBX02 6-253
description 1-17	NTBX26 6-266
diagram 1-18	NTBX27 6-274
pin-out 1-19	NTBX34 6-282
bulbs	NTBX35 6-292
changing 11-32	NTBX36 6-302
Inspecting 11-32	NTBX72 6-312
hispeeting 11.52	NTEX17 6-321
С	NTEX54 6-331
-	NTMX72 6-348
cabinets, specific	NTMX73 6-357
CLMI 2-20	NTMX74 6-367
CMIS 2-20	NTMX75 6-376
CMSS 2-20	NTMX76 6-384
card	NTMX77 6-391
Returning for repair or replacement 11-24	NTMX79 6-404
card replacement procedures	NTMX81 6-415
NT0X10 6-2	NTMX87 6-429
NT2X06 6-8	NTRX41 6-452
NT2X09 6-17	NTRX42 6-457
NT2X10 6-26	NTRX43 6-477
NT2X11 6-33	NTRX44 6-485
NT2X57 6-42	NTRX54 6-495
NT2X59 6-49	components, basic
NT2X90 6-56	LCME 2-13
NT3X09 6-63	RMM 2-12, 2-20
NT6X17 6-73	components, ISDN
NT6X18 6-81	DCH 2-18, 2-20
NT6X19 6-89	EISP 2-20
NT6X20 6-97	OAM 2-20
NT6X21 6-105	
NT6X30 6-114	components, other
NT6X51 6-128	LCM 2-20
NT6X52 6-135	MSP 2-20
NT6X53 6-144	cooling unit
NT6X54 6-153	Replacing 11-35
NT6X69 6-160	cooling unit filters
NT6X71 6-168	Inspecting 11-2
NT6X74 6-176	
NT6X76 6-185	
NT6X78 6-193	
INIUA/0 0-193	

### D

data, static (non-ESA) updating 1-45 Data-enhanced bus interface card protocol 3-18 diagnostic tests 8-15 dual remote cluster controller 2 (DRCC2) 8-45 extended peripheral modules diagnostics history 8-38 cards supported 8-42 description 8-39 facility audits 8-40 in-service and out-of-service tests 8-40 mate diagnostics 8-40 operating company personnel analysis 8-38 resets and time stamps 8-44 ROM diagnostics 8-40 storing diagnostics 8-43 ISDN lines 8-45 lines 8-45 NTMX76 card 8-15 card existence test 8-16 data routing test 8-16 high-level data link control messaging system test 8-17 intermodule communication test 8-17 memory test 8-16 message tests 8-16 receive connection memory test 8-16 tone diagnostic test 8-16 remote cluster controller 2 (RCC2) 8-45 remote cluster controller 2 (RCC2) with **ISDN** 8-45 **RSC-S** digital test access channels monitored 8-22 connection verification 8-26 D-channel cleanup link access procedure 8-21 monitoring enhanced LCM (LCME) 8-25 monitoring XPMs 8-25 preparation 8-23 protocol analyzer 8-23 restrictions, limitations, and interactions 8-27 user-assigned TEI 8-21 RSC-S enhanced line testing 1 8-17 digital test access 8-21

MAP commands, options, and activities 8-18 RSC-S layer 1 performance monitoring 8-28 Bd-channel logical loopback 8-28 LOOPBACK mplu 3b1 MAP display 8-35 LOOPBACK mplu 6 bbd MAP display 8-38 LOOPBACK query MAP display 8-36 LOOPBACK rts MAP display 8-37 multipoint embedded oprations channel 8-32 dual remote cluster controller 2 RSC ESA firewall 1-61 BSY command 1-62 Enhanced log reports 1-71 LOADPM command 1-67 PMRESET command 1-68 QUERYPM command 1-68 RECOVER command 1-70 RSC ESA exit simplification 1-71 RTS command 1-63 TST command 1-63 XPMRESET command 1-69

#### Ε

emergency stand-alone (ESA) operation warm exit 1-54 Ext MSP CLCE cabinet Major clearing 5-2 CPDC cabinet Major clearing 5-35 CRME cabinet major clearing 5-43 CRSC and CEXT cabinets Major clearing 5-20, 5-53

### F

fan power control module (NTRX54BA) description 1-20 diagram 1-20 dimensions 1-22 environmental conditions 1-22 pin-outs 1-21 power requirements 1-22 signaling 1-20 fault conditions dual remote cluster controller 2 (DRCC2) 1-82 not processor card specific 1-79 processor card specific 1-77 remote cluster controller 2 (DRCC2) with **ISDN** 1-82 remote cluster controller 2 (RCC2) 1-77 Remote Switching Center-SONET (RSC-S) 1-76 XPM errors 1-78 fault isolation tests 8-12 ISDN 8-15 ISTb alarms 8-14 lines 8-15 RCC2 8-12 SysB alarms 8-13 fault locating and clearing 8-1 interlink maintenance indicators 8-5 **ISDN** lines POST DK command 8-10 PM alarms 8-3 trouble conditions 8-4 DS-1 links 8-5 DS30A links 8-4 forced ESA 8-7 ISDN 8-8 ISDN lines 8-8 line service restoration 8-8 lines 8-4 trouble indicators 8-1 alarms 8-2 log reports 8-2 operational measurements (OMs) 8-1 Functional description Remote Cluster Controller 2 RSC XPMESAEXIT parameter 1-46 fuse module (NTRX43AA) description 1-12 pin-outs 1-12 fuses in the LCME Replacing 11-10

### G

global tone receiver (GTR) 3-15 grounding bolts Checking torque 11-30

#### 

Interactions Other data services 1-57 voice services 1-57

### L

LAPD 3-1 LCM 1-55 LCM line drawer 1-55 line concentrating module (LCM) 1-75 enhanced 1-75 link access procedure on the D-channel 3-1 links DS30A 2-9, 2-13 DS60 2-18

### Μ

maintenance automatic overload resources 1-110 display 1-110 MTA 2-13 MTM 2-12 Media access control address DBIC provisioning 6-333, 6-345 Ethernet support 3-18 modular supervisory panel (MSP) description 1-5

## Ν

**NT0X10** card replacement procedures 6-2 NT2X06 card replacement procedures 6-8 NT2X09 card replacement procedures 6-17 NT2X10 card replacement procedures 6-26 NT2X11 card replacement procedures 6-33 NT2X57 card replacement procedures 6-42 NT2X59 card replacement procedures 6-49 NT2X90 card replacement procedures 6-56 NT3X09 card replacement procedures 6-63 NT6X17 card replacement procedures 6-73 NT6X18 card replacement procedures 6-81 NT6X19 card replacement procedures 6-89 NT6X20 card replacement procedures 6-97 NT6X21 card replacement procedures 6-105 NT6X30 card replacement procedures 6-114 NT6X51 card replacement procedures 6-128 NT6X52 card replacement procedures 6-135 NT6X53 card replacement procedures 6-144 NT6X54 card replacement procedures 6-153 NT6X69 card replacement procedures 6-160 NT6X71 card replacement procedures 6-168 NT6X74 card replacement procedures 6-176 NT6X76 card replacement procedures 6-185 NT6X78 card replacement procedures 6-193 NT6X87 card replacement procedures 6-200 NT6X92 card replacement procedures 6-208 NT6X99 card replacement procedures 6-216 NT7X05 card replacement procedures 6-224 NTAX74 card replacement procedures 6-233 NTBX01 card replacement procedures 6-244 NTBX02 card replacement procedures 6-253

NTBX26 card replacement procedures 6-266 NTBX27 card replacement procedures 6-274 NTBX34 card replacement procedures 6-282 NTBX35 card replacement procedures 6-292 NTBX36 card replacement procedures 6-302 NTBX72 card replacement procedures 6-312 NTEX17 card replacement procedures 6-321 NTEX54 card replacement procedures 6-331 NTMX72 card replacement procedures 6-348 NTMX73 card replacement procedures 6-357 NTMX74 card replacement procedures 6-367 NTMX75 card replacement procedures 6-376 NTMX76 card replacement procedures 6-384 NTMX77 card replacement procedures 6-391 NTMX79 card replacement procedures 6-404 NTMX81 card replacement procedures 6-415 NTMX87 card replacement procedures 6-429 NTRX41 card replacement procedures 6-452 NTRX42 card replacement procedures 6-457 NTRX43 card replacement procedures 6-477 NTRX44 card replacement procedures 6-485 NTRX54 card replacement procedures 6-495

# 

OPM 2-9

# Ρ

Parity error fault handling 1-129 Parity error faults types 1-129 PM LCME critical clearing 5-70 major clearing 5-83 minor clearing 5-102 PM LCME(RG) major clearing 5-93 minor clearing 5-112 PM RCC2 major clearing 5-132 minor clearing 5-143 PM RCC(I) Critical clearing 5-120 PM RMM Major clearing 5-154 Minor clearing 5-163 PM185 log report example 1-128 PMRCC2 critical recovering service 4-2 power converter voltages Testing 11-19

## R

```
recovery procedures
PMRCC2 critical 4-2
remote cluster controller 2 (RCC2)
cards 1-23
diagram 1-37
dual 1-50
```

maintenance messaging 1-54 speech and message paths 1-50 paths speech and message 1-36 returning to service 1-49 routine excercise (REX) test 1-37 SWACT (switch of activity) 1-38 with ISDN 1-73 cards 1-74 diagram 1-76 host peripherals 1-74 speech and message paths 1-74 Remote Cluster Controller (RCC) testing 1-47 testing specific cards 1-49 Remote Switching Center-SONET (RSC-S) description 1-2 remote cluster controller 2 (RCC2) 1-23 remote switching center-SONET (RSC-S) troubleshooting chart 9-1 Routine maintenance power converter voltages testing 11-19

## S

services DRCC2 2-20 **ISDN 2-20** signaling description 3-1 DMS-X messaging format diagram 3-11 DMS-X protocol diagram 3-10 HDLC protocol 3-11 ISDN BRI 3-13 Q.931 Digital Network Access protocol 3-14 MBS 3-14 spare fuse holders Inspecting 11-28 Subscriber loop protocol 3-19 SWACT (switch of activity) 1-86 diagram 1-89

# Т

```
talk battery module (NTRX44AA)
description 1-5
illustration 1-6
pin-outs 1-7
test tools
product-specific 8-48
LTC MAP display 8-50
RCC2 MAP display 8-49
real-time performance monitoring 8-48
trouble locating
advanced procedures 10-1
Bigfoot utility 10-1
powering down 10-3
powering up 10-2
troubleshooting procedures 8-1
```

### U

universal tone receiver (UTR) 3-15

# V

Voice network interaction 1-57

### W

wrist strap grounding cords Testing 11-6

### Χ

xDSL line card protocol 3-19

#### DMS-100 Family Remote Switching Center

Remote Switching Center-SONET Model B Maintenance

Manual

Product Documentation-Dept. 3423 Nortel Networks PO Box 13010 RTP, NC 27709-3010 Telephone: 1-877-662-5669 Electronic mail: cits@nortelnetworks.com

Copyright © 1994-2000 Nortel Networks, All Rights Reserved

**NORTEL NETWORKS CONFIDENTIAL:** The information contained herein is the property of Nortel Networks and is strictly confidential. Except as expressly authorized in writing by Nortel Networks, the holder shall keep all information contained herein confidential, shall disclose the information only to its employees with a need to know, and shall protect the information, in whole or in part, from disclosure and dissemination to third parties with the same degree of care it uses to protect its own confidential information, but with no less than reasonable care. Except as expressly authorized in writing by Nortel Networks, the holder is granted no rights to use the information contained herein.

Information is subject to change without notice. Nortel Networks reserves the right to make changes in design or components as progress in engineering and manufacturing may warrant. Changes or modification to the DMS-100 without the express consent of Nortel Networks may void its warranty and void the users authority to operate the equipment.

Nortel Networks, the Nortel Networks logo, the Globemark, How the World Shares Ideas, Unified Networks, DMS, DMS-100, Helmsman, MAP, Meridian, Nortel, Northern Telecom, NT, SuperNode, and TOPS are trademarks of Nortel Networks.

Publication number: 297-8281-550 Product release: XPM11 and up Document release: Standard 10.05 Date: November 2000 Printed in the United States of America

